



Fan and Power Control Module User's Guide



Note

Before using this information and the product it supports, be sure to read and understand the safety information and the safety instructions, which are available at:

https://pubs.lenovo.com/safety_documentation/

http://systemx.lenovofiles.com/help/topic/com.lenovo.sysx.safety.doc/safety_pdf.pdf

The server is intended for use in a system/rack always installed on the load side of Power Distribution Unit (PDU) or Uninterruptible Power Supply (UPS) supplying a maximum 20 A branch circuit protection. The overall system/rack connection to mains power is to be a Pluggable Type B connector.

In addition, be sure that you are familiar with the terms and conditions of the Lenovo warranty for your solution, which can be found at:

<http://datacentersupport.lenovo.com/warrantylookup>

First Edition (March 2018)

© Copyright Lenovo 2018.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration (GSA) contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Contents

Contents	i	System Information	18
Chapter 1. Introduction	1	Chassis VPD	18
Chapter 2. Web interface access	3	Midplane VPD.	19
Chapter 3. Overview.	5	FPC VPD	19
Summary	6	PSU VPD	20
Chassis Front Overview	7	Event Log	20
Chassis Rear Overview	7	USB Recovery	21
Power	9	Configuration.	23
Power Overview	10	Firmware Update	24
PSU Configuration	11	SMTP/SNMP/PEF	25
Power Capping	13	Network Configuration	27
Voltage Overview	14	Time Setting	29
Power Restore Policy.	14	User Account	30
Cooling	15	Web Service	31
Cooling Overview	15	Web Certificate	32
PSU Fan Speed	17	Chapter 4. IPMI Command	35
Acoustic Mode	17	Index	51

Chapter 1. Introduction

Use Fan and power control module (FPC) web interface to perform chassis management functions within a web browser.

It performs the following tasks:

1. Node status report
2. Chassis power and fan status report
3. Chassis power and fan configuration management
4. Chassis VPD information report
5. Chassis event log display, backup, and restore
6. FPC management and settings backup/restore

Notes: The FPC web interface supports the following browsers:

- Internet Explorer 8 (Windows 7/64-bit Windows Server 2008 R2 Standard/64-bit Windows Server 2008 R2 Enterprise only) or later
- Firefox 27.0 or later
- Google Chrome 30.0 or later

Chapter 2. Web interface access

FPC web interface can be accessed through Ethernet connection (10/100Mbit) by establishing a session with FPC.

Connecting to the FPC for the first time might require a change of the Internet protocol properties on the client computer. See [“Network Configuration” on page 27](#) section for more information.

Note: For enhanced security FPC firmware that complies with NIST800-131A, please enable at least TLS1.2 on web browser to use FPC Web interface.

To log in to the FPC web interface, complete the following steps :

1. Point your browser to the FPC web interface URL that your system administrator defined during initial configuration.
2. Following out-of-factory default network settings is applied at first use of FPC:
 - IPv4 enabled with static IP = 192.168.0.100)
 - IPv6 enabled with local link address (LLA) IP.

Notes: To calculate LLA IP, follow procedures below:

- a. Split the MAC address of FPC (39-A7-94-07-CB-D0) into two parts and insert FF-FE in the middle.
For example, 39-A7-94-FF-FE-07-CB-D0
 - b. Convert the two hexadecimal digits at the left end of the string to binary. For example, 00111001-A7-94-FF-FE-07-CB-D0
 - c. Invert the value for bit 7 of the binary string. For example, 00111011-A7-94-FF-FE-07-CB-D0
 - d. Convert the binary digits at the left end of the string back to hexadecimal.
 - e. Combine the hexadecimal digit pairs into 4-digit groups. For example, 3BA7-94FF-FE07-CBD0
 - f. Replace dash (-) separators with colon (:) separators. For example, 3BA7:94FF:FE07:CB D0
 - g. Add Fe80:: to the left of the string. For example, FE80::3BA7:94FF:FE07:CB D0
3. Type your user ID and password assigned by a system administrator.
 - Default ID: USERID
 - Password: PASSWORD

Note: The sixth character of PASSWORD is number zero.

4. Click **Log in**.

Chapter 3. Overview

The section introduces detailed functions for FPC web interface.

There are overall six function tabs:

- **Summary**
- **Power**
- **Cooling**
- **System Information**
- **Event Log**
- **Configuration**

Mouse cursor over the function tab buttons reveals the subcategories of the function. Click on the tab or subcategories taking user directly to the function.



Summary



Power and
Cooling



System
Information



Event Log



Configuration

Figure 1. Overview

Note: Pages with **Refresh** button does not refresh periodically, except voltage overview and cooling overview. Auto-refresh interval is every 1 or 5 minutes on these two pages. For the other pages, click **Refresh** button to get the latest readings and status.

Summary

Summary page displays overall chassis status and information.



Figure 2. Chassis

Chassis Front Overview

Individual tab is used introduce status of chassis front view and rear view components. Under **Chassis Front Overview** section, the following illustration indicates the node status:

Node	Width	Height	Status	Reset / Reseat	Node	Width	Height	Status	Reset / Reseat
11	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reseat"/>	12	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reseat"/>
09	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reseat"/>	10	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reseat"/>
07	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reseat"/>	08	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reseat"/>
05	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reseat"/>	06	Half	1 U	Power On	<input type="button" value="Reset"/> <input type="button" value="Reseat"/>
03	Half	1 U	Power Off	<input type="button" value="Reset"/> <input type="button" value="Reseat"/>	04	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reseat"/>
01	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reseat"/>	02	Half	1 U	Power Off	<input type="button" value="Reset"/> <input type="button" value="Reseat"/>

Figure 3. Chassis Front Overview

- **Node:** Indicates node numbering.
- **Width:** Half/full is used to represent half-wide or full-wide node.
- **Height:** Node height can be 1 to 6U.
- **Status:**
 - **Not Present:** No node is installed.
 - **No Permission:** The node has not granted power permission and cannot be powered on.
 - **Fault:** The node has power fault and cannot be powered on.
 - **Power On:** The node is powered on.
 - **Power Off:** The node is powered off.
- **Reset/Reseat:** Used to perform virtual reset/virtual reseal.
 - **Reset:** Remotely reset node XCC through FPC.
 - **Reseat:** Remotely power cycle the entire node.
 - After virtual **Reset/Reseat**, the node XCC takes at least two minutes to be ready.

Note: **Chassis Front Overview** needs to be manually updated 5 minutes after FPC or node XCC is reset to maintain latest node status.

Chassis Rear Overview

Under **Chassis Rear Overview** section, there are three major sections to show the rear chassis status:

- **Management Module**
- **Current PSU**

- Fan

Management Module

Management Module: Indicates the status of FPC

Node	Width	Height	Status	Reset / Reset	Node	Width	Height	Status	Reset / Reset
11	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>	12	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>
09	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>	10	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>
07	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>	08	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>
05	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>	06	Half	1 U	Power On	<input type="button" value="Reset"/> <input type="button" value="Reset"/>
03	Half	1 U	Power Off	<input type="button" value="Reset"/> <input type="button" value="Reset"/>	04	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>
01	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>	02	Half	1 U	Power Off	<input type="button" value="Reset"/> <input type="button" value="Reset"/>

Figure 4. Management Module

- **Status:** Indicates the FPC operating status.
 - **FPC Reboot:** Warm reboot the FPC
 - **Reset to Default:** Restored the FPC settings to out-of-factory default
- **Firmware version:** The current firmware version
- **PSoC version:** When user performs FPC firmware update, PSoC firmware is automatically updated to the latest version.
- **Boot-up Flash:** Indicates FPC current boot up bank. In normal operation, **Boot-up flash** should always be **First**. Only when the first flash has a hardware or firmware failure, FPC will switch to 2nd flash.
- **Identify LED:** Identify LED (ID LED) is a blue LED to assist user in locating chassis in rack. User can choose to turn the blue LED solid on or make the LED blink once every second. Click **Apply** to activate the option.
- **Error LED:** Error LED is on when critical event occurs. User can choose to turn it off and allow the LED to be turned on when the next event comes.

PSU

PSU: Indicates the status of power supplies

Node	Width	Height	Status	Reset / Reset	Node	Width	Height	Status	Reset / Reset
11	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>	12	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>
09	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>	10	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>
07	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>	08	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>
05	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>	06	Half	1 U	Power On	<input type="button" value="Reset"/> <input type="button" value="Reset"/>
03	Half	1 U	Power Off	<input type="button" value="Reset"/> <input type="button" value="Reset"/>	04	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>
01	N/A	0 U	No Present	<input type="button" value="Reset"/> <input type="button" value="Reset"/>	02	Half	1 U	Power Off	<input type="button" value="Reset"/> <input type="button" value="Reset"/>

Figure 5. PSU

- **Status**
 - **Present:** The power supply is installed.
 - **Not Present:** No power supply is installed.
 - **Fault:** The power supply is in faulty condition.

- **Ratings:** Displays the power rating such as 900 W, 1300 W and 2000 W power supplies.
- **AC-IN:** AC input power
- **EPOW (Early power off warning)**
 - **Assert:** The power supply is in AC lost condition.
 - **Normal:** The power supply AC is in normal operating condition.
- **DC-PG (Direct current - power good):** The DC power status of the power supply.
 - **No:** The power supply is not providing the required DC power.
 - **Yes:** The power supply is providing required DC power.

Fan

Fan: Indicates the status of fans.

Fan

Bay	Status	Type	Bay	Status	Type
1	Present	Standard	6	Present	Standard
2	Present	Standard	7	Present	Standard
3	Present	Standard	8	Present	Standard
4	Present	Standard	9	Present	Standard
5	Present	Standard	10	Present	Standard

Figure 6. Fan

- **Status**
 - **Present:** The fan is in normal operating condition.
 - **Not present:** No fan installed.
 - **Fault:** The fan is in faulty condition.
- **Type:** Supports only one type of fan (Standard).

Power

There are five major sections under **Power** tab.



Figure 7. Power tab

- **Power Overview:** Displays the chassis level power consumption, the node level power consumption, and power consumption of subsystems, which includes power subsystem (PSUs), and thermal subsystem (System fans).
- **PSU Configuration:** Allows users to set the redundancy mode for power supplies.
- **Power Cap:** Allows users to set power capping/saving.
- **Voltage Overview:** Monitors the voltage rail on FPC.
- **Power Restore Policy:** Allows user to enable power restore policy.

Power Overview

Power Overview displays the chassis level power consumption, the node level power consumption, and power consumption of subsystems, which includes power subsystem (PSUs), and thermal subsystem (System fans).

Chassis and node level power consumption reports minimum, average, and maximum value

Power Overview

Total Chassis Power Consumption

Min. (W)	Avg. (W)	Max. (W)
337	337	338

Total Fans Power Consumption

53.45 W

Node Power Consumption

Node	Min. (W)	Avg. (W)	Max. (W)	Node	Min. (W)	Avg. (W)	Max. (W)
11	0	0	0	12	41	44	59
09	0	0	0	10	0	0	0
07	0	0	0	08	0	0	0
05	0	0	0	06	110	111	111
03	0	0	0	04	0	0	0
01	0	0	0	02	0	0	0

Figure 8. Power Overview

The chassis and PSU power consumption sampled every 1 second over 30 seconds period.

PSU Configuration

PSU Configuration allows users to set the redundancy mode for power supplies.

PSU Configuration

Redundancy Mode

Redundancy Mode	N + N
Oversubscription Mode	OVS OFF

Apply

Smart Redundancy

Smart Redundancy	Disable
------------------	---------

Apply

Figure 9. PSU Configuration

1. **Redundancy Mode:** Offer two modes for user to choose.

- **Redundancy Mode**

- **No Redundancy:** System could be throttled or shut down if one or more power supplies are in faulty condition.
- **N+1:** There is one properly installed PSU as redundant power supply, so there is no impact to system operation or performance if any one of the PSUs is in faulty condition, given that Oversubscription mode is not enabled.
- **N+N:** Have half of the properly installed PSUs as redundant power supplies, therefore, there is no impact to system operation or performance if any half number of the PSUs has failed, given that Over-subscription mode is not enabled. For example, 6 PSUs properly installed, 3 PSUs could fail without any impact when N+N and no Over-subscription is applied.

- **Over-subscription Mode:** **Oversubscription Mode** allows user to take advantage of the extra power from the redundant power supply when the power supplies are in healthy condition. When the redundancy fails, PSU will shut down within 1 second if system power loading is not corrected after the time limit. FPC takes the action of node throttling at such power emergency. Chassis performance could be impacted even in redundancy mode if oversubscription is also enabled.

- Oversubscription is applied only with N+1 or N+N redundancy modes.
- When enabled with N+1, the total power available is equivalent to **No Redundancy** mode.

- Click on **Apply** after choosing the redundancy and oversubscription mode from drop-down menu to activate.

2. **Smart Redundancy:** Three scanning period are offered: 10/30/60 minutes. The shorter the scanning period, the faster FPC adjusts number of hibernate PSUs to optimize PSU efficiency when system load changes. With shorter scanning period, PSU are also turned on and off more frequently when system loading fluctuates, which could reduce PSU life. Disable smart Redundancy will keep all PSU always active. Click on **Apply** after choosing the scanning period from drop-down menu to apply selections.

Note: CFFv1 PSU (900w) does not support this feature. **Smart Redundancy** will always be in **Disable** state and the **Apply** button will be greyed out when 900w PSU is installed

Power Capping

You can choose the following two cap types through power cap configuration.

1. **Chassis Capping**
2. **Nodes Capping**

Power cap allows user to set a wattage limit on power consumption. When applied on individual node, the node power consumption is capped at assigned level and when applied on chassis, the whole chassis power consumption is capped. When power saving is enabled, individual node or all nodes (chassis level) runs in modes of different throttling level, depending on the modes chosen.

Power Capping Policy

Chassis Capping ▾

Chassis Capping

Nodes Capping

Chassis Power Capping/Saving

Node		Capping	Saving
Chassis	<input type="checkbox"/>	<input type="text"/> W (Range: 219 W ~ 288 W)	<div><input checked="" type="radio"/> Disable</div> <div><input type="radio"/> Mode 1</div> <div><input type="radio"/> Mode 2</div> <div><input type="radio"/> Mode 3</div>

Apply

Figure 10. Chassis Capping

1. Select **Chassis Capping** or **Nodes Capping** from the drop-down menu.
2. Enter a power cap value, check the box, and click on **Apply** to enable power capping.
3. Capping enabled (checked) or disabled (unchecked) can be applied independent of capping value. However, if capping is enabled without any input value, FPC display **0w** as default value to represents that no user capping value is specified and no capping is enforced. If a value is entered and applied without enable ticked, the value will be saved but not enforced.
4. Capping range is suggested to user based on the minimum and maximum possible power consumption of the node/chassis. Any value between 1 ~ 32767W is still allowed even if the value is not set within the suggested range. A capping value of '0w' is not accepted as user input value since it represents no user value specified.
5. User entered capping value might not be met if capping value entered is lower than the lower bound of suggested range.
6. Select enable in the **Power Save** section and click on **Apply** to activate power save.
7. Power save can be applied with power cap simultaneously.
8. The system runs in a throttled state (defined by the implementation) regardless of the workload.

There are three types of power saving modes and the following table provides details about saving modes.

Table 1. Saving Mode

Mode	Title	Description	Supportability
Disable	Static maximum performance	The system runs at full speed (no throttling) regardless of the workload	Support
Mode 1	Static minimum power	The system runs in a throttled state (defined by the implementation) regardless of the workload	Support
Mode 2	Dynamic favor performance	The system adjusts throttling levels based on workload, attempting to favor performance over power savings	Not Supported
Mode 3	Dynamic favor power	The system adjusts throttling levels based on workload, attempting to favor power savings over performance	Not Supported

Voltage Overview

Voltage Overview table provides the status of FPC board (12V, 5V, 3.3V) and battery voltage. Error log is asserted if critical threshold is reached.

Probe List

Status	Probe Name	Reading	Lower Non-Critical	Upper Non-Critical	Lower Critical	Upper Critical	Lower Non-Recoverable	Upper Non-Recoverable
✓	12V_SENSE	11.904 V	N/A	N/A	10.816 V	13.248 V	N/A	N/A
✓	3V3_SENSE	3.2900 V	N/A	N/A	2.9750 V	3.6225 V	N/A	N/A
✓	5V_SENSE	4.995 V	N/A	N/A	4.563 V	5.589 V	N/A	N/A
✓	VBAT_SENSE	2.9040 V	N/A	N/A	1.7952 V	N/A	N/A	N/A
✓	HW_RESET_DEFAULT	2.4735 V	N/A	N/A	0.8051 V	N/A	N/A	N/A

Figure 11. Voltage Overview

Power Restore Policy

When **Power Restore Policy** is enabled as **Restore**, FPC remembers the latest node power status and recovery the node to the power status it was before AC is abruptly lost.

Power Restore Policy

<input type="checkbox"/>	Node	Status	<input type="checkbox"/>	Node	Status
<input type="checkbox"/>	11	Always OFF	<input type="checkbox"/>	12	Always OFF
<input type="checkbox"/>	09	Always OFF	<input type="checkbox"/>	10	Always OFF
<input type="checkbox"/>	07	Always OFF	<input type="checkbox"/>	08	Always OFF
<input type="checkbox"/>	05	Always OFF	<input type="checkbox"/>	06	Always OFF
<input type="checkbox"/>	03	Always OFF	<input type="checkbox"/>	04	Always OFF
<input type="checkbox"/>	01	Always OFF	<input type="checkbox"/>	02	Always OFF

Apply

Power Restore Policy: Determines the mode of operation after loss of power
Always off: Node remains off upon power restore
Restore: Node restores to the state it was before power failed

Figure 12. Power Restore Policy

Power Restore Policy: Determines the mode of operation after loss of power.

- **Always off:** Node remains off upon power restore.
 - **Restore;** Node restores to the previous state that was before power failed.
1. Check the boxes of the nodes that needed to enable power restore policy or uncheck the boxes to set policy to always off after power recovery.
 2. Click **Apply** to activate the setting.

Notes:

- Power restore policy changed within 1 minute before AC lost might not be recovered due to design limitation.
- Nodes ON/OFF state change within 1 minute before AC lost might not be recovered due to design limitation.

Cooling

There are three major sections under **Cooling** tab.

- **Cooling Overview:** System fan speed
- **PSU Fan Speed:** Power supply fan speed
- **Acoustic Mode:** Allow users to choose acoustic mode

Cooling Overview

Fan speed is displayed in RPM. Error log is asserted when fan speed is below lower critical threshold.

Note: This page will automatically refresh every 30 seconds.

Cooling Overview


Probe List

[Refresh](#)

Status	Probe Name	Reading	LowerNon-Critical	UpperNon-Critical	LowerCritical	UpperCritical	LowerNon-Recoverable	UpperNon-Recoverable
✓	FAN_Tach_1A	2752 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_1B	2112 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_2A	2816 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_2B	2176 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_3A	2816 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_3B	2176 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_4A	2752 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_4B	2176 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_5A	2816 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_5B	2112 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_6A	2688 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_6B	2240 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_7A	2752 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_7B	2176 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_8A	2816 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_8B	2112 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_9A	2752 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A
✓	FAN_Tach_9B	2176 RPM	N/A	N/A	1472 RPM	N/A	N/A	N/A

Figure 13. Cooling Overview

- **Status** (two status):

- Healthy condition: 

- Fault condition: 

- **Fan_Tach_#A(B)**: System fan speed normally operates at 2000~13000 rpm.

DW612 Enclosure system fan is equipped with dual motor. Tach A displays the primary fan motor speed and tach B displays the redundant fan motor speed.

- **Lower Critical**: 1472 rpm is set to be the lower critical fan speed threshold.

PSU Fan Speed

PSU Fan Speed

Fan	Speed (RPM)	Speed (% of Max.)	Status
Fan1	0	0%	No Present
Fan2	0	0%	No Present
Fan3	0	0%	No Present
Fan4	5528	10%	Normal
Fan5	0	0%	No Present
Fan6	0	0%	No Present

Figure 14. PSU Fan Speed

- **Speed:** PSU fan speed normally operates at 5500~23000 rpm. PSU fan speed is displayed in RPM.
- **Duty (% of Max.) :** Out of 25000 rpm.
- **Status:**
 - **Normal:** PSU fan is running in healthy condition
 - **Not Present:** No power supply is installed
 - **Fault:** Fan speed is lower than the threshold (3000 rpm)

Acoustic Mode

To reduce the noise level of the chassis during run-time, you can configure the chassis to five different acoustic modes.

Acoustic Mode Selection

Select an Acoustic Mode :

By using acoustic mode, the user has some control over the fan speeds and airflow (and noise) that is produced by the system fans. This mode can be used for noise or airflow concerns in the user environment. As a result, Mode1,2,3 increase the possibility that the node might have to be throttled to maintain cooling within the fan speed limitation.

None: Fan speeds change as required for optimal cooling.
Mode1: Highest acoustics attenuation (lowest cooling).
Mode2: Intermediate acoustics attenuation.
Mode3: Low acoustics attenuation (higher cooling).

NOTE: If there is power or thermal demanding PCI card installed in the chassis, acoustic mode is automatically disabled.

Figure 15. Acoustic Mode Selection

1. Select the mode from the drop-down menu according to your preference.
 - **None:** Fan speeds change as required for optimal cooling
 - **Mode 1:** Highest acoustics attenuation (lowest cooling). System fan speed is capped at 28% duty (7.5 bels)

- **Mode 2:** Higher acoustics attenuation. System fan speed is capped at 34% duty (7.8 bels)
 - **Mode 3:** Low acoustics attenuation (higher cooling). System fan speed is capped at 40% duty (8.1 bels)
2. Click on **Apply** after choosing the acoustic mode from the drop-down menu to activate the setting.

Notes:

- Acoustic modes can only apply to the entire chassis as a whole
- When acoustic modes are applied, nodes workload is also capped to avoid over-heating
- If there is power or thermal demanding configuration in the chassis, acoustic mode is automatically disabled

System Information

There are four sections under **System information** tab and provide the fixed VPD data.

- **Chassis VPD**
- **Midplane VPD**
- **FPC VPD**
- **PSU VPD**

Note: Information displayed with IPMI standard FRU command is limited to FPC Board VPD data only.

Chassis VPD

Chassis VPD

Name	Value
Chassis Name	Vincent Chao
Machine Type/Model	5456HC1
UUID	2E2A8AC8C6B311E282BE6EAE8B16A49E
Chassis Hardware Version	Pass4

Backup Restore

Edit

Figure 16. Chassis VPD

- **Backup:** Save current chassis name onto USB storage device for future migration
- **Restore:** Load the chassis name from previously saved data on the USB storage device
- **Edit:** Modify the chassis name based on following rule
 - Chassis Name can be up to 64 characters using alphanumeric characters a-z, A-Z and 0-9, - (hyphen), _ (underscore), and space
- **Default Chassis Name:** For example, "DW612 Enclosure" (offset 0x02FF of VPD).
- **Machine Type:** For example, "545611Z" (offset 0x01FA of VPD).
- **UUID:** Randomly generated ID number of the chassis (offset 0x0219 of VPD).
- **Chassis Hardware Version:** Hardware version (offset 0x0206 of VPD).

Midplane VPD

Midplane VPD

Name	Value
Card Serial Number	Y031UN41901N
Card UUID	49EB643C7A4D11E384CBE65D41AC854E
Card Hardware Version	Pass5
Card FRU Part Number	46W2907

Backup Restore

Edit

Figure 17. Midplane VPD

- **Backup:** Save the current card serial number, card UUID, hardware version, and FRU part number onto the USB storage device for future migration.
- **Restore:** Load the previously saved card serial number, card UUID, hardware version, and FRU part number data from the USB storage device.
- **Edit:** Modify the card serial number, UUID and FRU part number as user preference based on following rule:
 - Card Serial Number: Card serial number must be filled in with all 12 alphanumeric characters (A-Z, 0-9). No space and no other characters allowed.
 - UUID: Card UUID must be filled in with all 32 alphanumeric characters (A-Z, 0-9). No space and no other characters allowed.
 - FRU Part Number: FRU part number must be filled in with all 7 alphanumeric characters (A-Z, 0-9). No space and no other characters allowed.
- **Card Serial Number:** Should be the last 12 characters of 11S bar code label on midplane (offset 0x00FC, 0x0106 of VPD). For example, 11S00J6184Y03UN28W02X
- **Card UUID:** Randomly generated ID number of the chassis.
- **Card Hardware Version:** Hardware version.
- **Card FRU Part Number:** “46W2907” (offset 0x0126 of VPD).

FPC VPD

FPC VPD

Name	Value
Card Serial Number	Y031UN41901N
Card UUID	49EB643C7A4D11E384CBE65D41AC854E
Card Hardware Version	Pass6
Card FRU Serial Number	00Y8605

Figure 18. FPC VPD

- **Card Serial Number:** Should be the last 12 characters of 11S bar code label on FPC (offset 0x0053, 0x005D of VPD). For example, 11S00J6184Y03UN28W02X
- **Card UUID:** Randomly generated at manufacturing site (offset 0x0083 of VPD).
- **Card Hardware Version:** hardware version (offset 0x0037 of VPD).

- **Card FRU Serial Number:** “00Y8605” (offset 0x0076 of VPD).

PSU VPD

PSU VPD			
PSU #	FRU Part Number	PSU #	FRU Part Number
6	N/A	5	N/A
4	69Y5925	3	N/A
2	69Y5925	1	N/A

Figure 19. PSU VPD

- **FRU Part Number:** It indicates the fan needs to be replaced.

Event Log

Event log tab allow users to view SEL (System Event Log) and perform backup/restore/restore to default operations.

There are three major sections under **Event Log** tab:

- **Event Log:** A record of chassis level events
- **USB Recovery:** Users can perform data migration of event logs and chassis settings between FPC modules. Settings can also be restored to default in this page.

SEL logs chassis level info/warning/critical events so that user can get some clues of what is going on in the chassis. A maximum number of 511 event entries can be logged.

By default, the latest entry is at the last page as events are sorted by occurring order from earliest in time to the latest. Click on **Date/Time** can reorder the sorting from latest to earliest event.

Note: Currently, new event cannot be written into the log when it is full. User needs to manually clear log before latest event can be logged.

Event Log




[Refresh](#) [Save Log](#) [Clear Log](#)

Event Log
 ⓘ To sort system event logs, click the 'Date/Time'.

System Event Count (Current / Maximum) 160 / 511

Severity	Date/Time	Description
✓	2014-01-10 17:02:46	Node_No_Present: Slot sensor, Device (Board No. 1) was asserted
✓	2014-01-10 17:02:46	Node_No_Present: Slot sensor, Device (Board No. 3) was asserted
✓	2014-01-10 18:02:00	Node_Reseat_User: Slot sensor, Device (Board No. 12) was asserted
✓	2014-01-10 18:02:00	Node_DC_OFF: Slot sensor, Device (Board No. 12) was asserted
✓	2014-01-10 18:02:14	Node_Reseat_User: Slot sensor, Device (Board No. 10) was asserted
✓	2014-01-10 18:02:14	Node_DC_OFF: Slot sensor, Device (Board No. 10) was asserted
✗	2014-01-10 18:06:49	PS6_EPOW_Assert: Power Supply sensor, transition to Non-recoverable was asserted
✓	2014-01-10 18:06:56	PS6_EPOW_Assert: Power Supply sensor, transition to Non-recoverable was deasserted
✓	2014-01-10 18:46:56	Node_No_Present: Slot sensor, Device (Board No. 1) was asserted
✓	2014-01-10 18:46:56	Node_No_Present: Slot sensor, Device (Board No. 3) was asserted
✗	2014-01-20 13:53:25	PS6_EPOW_Assert: Power Supply sensor, transition to Non-recoverable was asserted
✓	2014-01-20 13:53:32	PS6_EPOW_Assert: Power Supply sensor, transition to Non-recoverable was deasserted
✗	2014-01-20 13:56:37	PS2_EPOW_Assert: Power Supply sensor, transition to Non-recoverable was asserted
✗	2014-01-20 13:56:37	PS4_EPOW_Assert: Power Supply sensor, transition to Non-recoverable was asserted
✗	2014-01-20 13:56:44	PS1_EPOW_Assert: Power Supply sensor, transition to Non-recoverable was asserted
✗	2014-01-20 13:56:44	PS3_EPOW_Assert: Power Supply sensor, transition to Non-recoverable was asserted
✗	2014-01-20 13:56:44	EPOW_OUT: Power Supply sensor, State Asserted was asserted
✓	2014-01-20 13:58:39	Node_No_Present: Slot sensor, Device (Board No. 1) was asserted

Figure 20. Event Log

- **Refresh:** SEL does not automatic refresh. User needs to manually click **Refresh** to get the latest entries.
- **Save Log:** Exports SEL data and save as .csv file
- **Clear Log:** Clears SEL data
- **Severity:** From low severity to high severity
 -  : Indicates **Information** type of events
 -  : Indicates **Warning** type of event
 -  : Indicates **Critical** type of events. Critical event lits 'Error' LED.

For detailed event log messages, please see *Messages and Codes Reference* at <http://thinksystem.lenovofiles.com/help/index.jsp>.

USB Recovery

USB Recovery page allows you to backup and restore your data.

USB Recovery

Backup Current Configuration to USB

[Apply](#)

Restore from USB Backup Configuration

[Apply](#)

Restore to Default Configuration

[Apply](#)

Figure 21. FPC Recovery

One USB storage device is used for FPC to preserve or to migrate SEL and user configurations. This USB key must be mounted on FPC board for FPC to function correctly. When there is no data stored in the USB key, factory default settings are applied for all configurations. User configurations are automatically backed up to USB key when they are set or modified. There are three functions on the USB recovery page.

Note: The size of the USB storage device should be larger than 1GB. The support file system is VFAT16/32 , ext2 ,ext3...etc (Linux accessible file system).

- **Backup:** Backup SEL and below chassis configurations to local device or USB storage device.
 - Power supply redundancy policy
 - Oversubscription mode
 - Smart Redundancy
 - Chassis capping/saving or node capping/saving
 - Acoustic Mode setting
 - Power restore policy

Restore from USB Backup Configuration

Items	Current	USB Backup		Status
1. Power Supply Policy	N + N	N + N	N/A
2. OVS State	OVS Off	OVS Off	N/A
3. Smart Redundancy	Disable	Disable	N/A
4. Chassis Capping	Disable (1800 W)	Disable (1800 W)	N/A
5. Chassis Saving	Disable	Disable	N/A
6. Acoustic Mode	Mode 2	Mode 2	N/A
7. Power Restore Policy	1, 3, 5, 7, 9, 11	1, 3, 5, 7, 9, 11	N/A
8. Node Capping	None	None	N/A
9. Node Saving	None	None	N/A

Figure 22. FPC Restore

- **Restore:** Restore and apply the configurations stored in USB storage device to FPC.
- **Restore to Default:** Restore the following settings to out-of-factory values.
 - Power supply redundancy policy default = No redundancy
 - Oversubscription mode default = No oversubscription
 - Smart Redundancy = 30 minutes
 - Chassis capping/saving or node capping/saving default = No chassis/node capping/saving
 - Acoustic Mode setting default = Acoustic mode disabled
 - Power restore policy default = All disabled

Restore to Default Configuration					
Items	Current	Default		Status	
1. Power Supply Policy	N + N	No Redundancy	N/A	
2. OVS State	OVS Off	OVS Off	N/A	
3. Smart Redundancy	Disable	30 minutes (default)	N/A	
4. Chassis Capping	Disable (1800 W)	Disable (0 W)	N/A	
5. Chassis Saving	Disable	Disable	N/A	
6. Acoustic Mode	Mode 2	None	N/A	
7. Power Restore Policy	1, 3, 5, 7, 9, 11	None	N/A	
8. Node Capping	None	None	N/A	
9. Node Saving	None	None	N/A	
					Confirm

Figure 23. FPC Restore to Default Configuration

Configuration

Configuration tabs settings are used to manage FPC module.



Figure 24. Configuration

There are eight sections:

- **Firmware Update**
- **SMTP**
- **SNMP**

- **PEF**
- **Network Configuration**
- **Time Setting**
- **User Account**
- **Account Security**
- **Web Certificate**

Note: By pressing hardware reset button for more than 4 seconds, all settings (except **Time Setting**) can be restored to out-of-factory default settings.

All settings, except time setting, in the configuration tab can be restored to out-of-factory default settings through coin battery removal or by pressing hardware reset button for more than 4s.

Complete the following steps to remove the coin battery:

1. Pull FPC module out of the chassis.
2. Remove coin battery from FPC module.
3. Insert FPC module without battery back to chassis, boot up, and wait for FPC to reboot.
4. The following signs can be observed during FPC boot up and reboot.
 - a. Power LED lit on.
 - b. Heartbeat LED blinks for 0.3 seconds on and 3.8 seconds off.
 - c. Checklog LED lit on due to lack of battery
 - d. FPC then reboot and have fan spin up, Power LED lit, Heartbeat LED blinks and Checklog LED on again.
5. After observing Checklog LED lit up again after FPC reboot, pull FPC module out of the chassis.
6. Install the battery back to FPC module.
7. Insert FPC module with battery back to chassis.

Firmware Update

There are two phases to the firmware update process. During firmware upload stage, you can choose path to fetch the firmware image. FPC checks the image header information for validation.

Firmware Update

Upload

Select an image file and click upload. The upload process will terminate all other sessions. After the upload process is started, any attempt to refresh, logout or navigate away from the update page will restart the System.

Firmware File Path	Choose File ibm_fw_fpc_..._noarch.txt	Upload
--------------------	---	--------

Selected file is not valid for FPC Firmware update.
Select valid file and click upload.

Figure 25. Firmware Update

Upload

Select an image file and click upload. The upload process will terminate all other sessions. After the upload process is started, any attempt to refresh, logout or navigate away from the update page will restart the system.

Once a valid firmware image is uploaded, a firmware image confirmation table appears with **Preserve Settings** check box. If **Preserve Settings** is checked, FPC configurations are kept and applied after the firmware update. The preserved settings include:

- SMTP
- SNMP
- PEF
- Network Configuration
- Time Setting (Time is always kept no matter **Preserve Settings** is checked or not)
- User Account
- Account Security
- Web Services

Notes:

1. A **Recover Primary Bank Firmware** check box is present in the firmware update page, but non-functional when FPC is boot up from the primary bank. If FPC starts on secondary bank, which indicates that the primary bank image might be corrupted and need recovery, this check box is open for selection. Check it to perform the recovery measure and update image onto the primary bank, and uncheck to upgrade firmware onto the secondary bank.
2. Secondary bank needs to be pre-installed with firmware up to a certain level for 'Recover Primary Bank Firmware' to be available.
3. FPC will automatically restart if you choose to cancel firmware update process after uploading the firmware image.

During updating, the system will direct you to a loading page where all FPC functions are locked.

Once the progress reaches 100%, FPC automatically restarts and you need to log in again to access FPC Web interface.

SMTP/SNMP/PEF

Configured SMTP and SNMP traps allow user to monitor the chassis for selected events. SMTP/SNMP trap event types can be set in the PEF (Platform Event Filter) page.

SMTP

Before sending alert, please make sure changes to Sender Information, target Destination Email Address, SMTP (email) Server Settings, and SMTP Authentication have been saved by clicking Apply Changes.

Sender Information

From:

Destination Email Addresses

	Enable	Destination Email Address	Email Description	Test
Email Alert 1	<input type="checkbox"/>	<input type="text"/>	FPC email alert	<input type="button" value="Send Alert 1"/>
Email Alert 2	<input type="checkbox"/>	<input type="text"/>	FPC email alert	<input type="button" value="Send Alert 2"/>
Email Alert 3	<input type="checkbox"/>	<input type="text"/>	FPC email alert	<input type="button" value="Send Alert 3"/>
Email Alert 4	<input type="checkbox"/>	<input type="text"/>	FPC email alert	<input type="button" value="Send Alert 4"/>

SMTP (email) Server Settings

SMTP IP Address:
SMTP Port Number:

SMTP Authentication

Enable: ☐ Anonymous account will be used when authentication is disabled.
Username:
Password:
STARTTLS Mode:
SASL Mode:

Figure 26. SMTP

- **SMTP:** You can enable, configure and test SMTP email alert at this page.
 - Click **Send Alert #** to test the email alert
 - Please check **Global Alerting Enable** in PEF page to enable email alerts
 - The following information provides the default values:
 - All email alert disabled
 - Email server address = 0.0.0.0
 - Authentication disabled

Notes:

1. Before sending alert, make sure changes to **Sender Information**, **Destination Email Address**, **SMTP (email) Server Setting**, and **SMTP Authentication** have been saved by clicking **Apply**.
2. When FPC SEL is full, no new event entry can be added to SEL. SMTP event email will not be generated until the log is cleared.

SNMP

Before sending test trap, please make sure changes to the target Destination and Community String have been saved by clicking Apply Changes.

IPv4 Destination List

	Enable	IPv4 Address	Test
IPv4 Destination 1	<input type="checkbox"/>	0.0.0.0	Send Test Trap
IPv4 Destination 2	<input type="checkbox"/>	0.0.0.0	Send Test Trap
IPv4 Destination 3	<input type="checkbox"/>	0.0.0.0	Send Test Trap
IPv4 Destination 4	<input type="checkbox"/>	0.0.0.0	Send Test Trap

IPv6 Destination List

	Enable	IPv6 Address	Test
IPv6 Destination 1	<input type="checkbox"/>	:	Send Test Trap
IPv6 Destination 2	<input type="checkbox"/>	:	Send Test Trap
IPv6 Destination 3	<input type="checkbox"/>	:	Send Test Trap
IPv6 Destination 4	<input type="checkbox"/>	:	Send Test Trap

Community String

Community Name	public
----------------	--------

Figure 27. SNMP

- **SNMP:** You can enable, configure and test SNMP trap at this page.
 - Click **Send Test Trap** to test the event trap
 - **Community Name** displays/configures the SNMP community name using only alphabet and numerical values. The value must not be empty.
 - All the events would be sent to destination IP address when **Global Alerting Enable** in PEF page is checked.
 - For SNMP trap type, check the **Generate PEF** box for targeted type of events.

Notes:

1. Before sending test trap, make sure changes to the target **Destination** and **Community String** have been saved by clicking **Apply**.
 2. When FPC SEL is full, some PEF alerts might be missing or be sent repeatedly.
- The following information provides the default values:
 - All traps disabled
 - Community Name = public

PEF

Platform Event Filters (PEF) List

☐ Global Alerting Enable Note: (This enables/disables both PEF and email alerts).

Filter Name	Generate PET
All Type, Fan Critical Filter	<input type="checkbox"/>
All Type, Power Supply Critical Filter	<input type="checkbox"/>
All Type, Slot Critical Filter	<input type="checkbox"/>
All Type, Voltage Critical Filter	<input type="checkbox"/>

Apply

Figure 28. PEF

- **PEF:** You can set SMTP/SNMP trap event types at this page.
 - The following information provides the default values:
 - None of the filter selected
 - Global Alerting unchecked

Network Configuration

You can modify networking parameters in **Network configuration**.

You can modify following networking parameters in **Network configuration** section:

- Host Name
- DNS Domain Name
- Auto Negotiation Mode
- Network Speed
- Duplex Mode
- IP Version (IPv4, IPv6) Enable/Disable
- IP Address
- IP Source (Static and DHCP)
- Gateway
- Subnet Mask
- DNS Server
- VLAN

Figure 29. Network Configuration

Network Configuration

Refresh

General Settings

To change the Network settings may change IP address settings.
Each change to settings may cause a loss in connectivity and the termination of all sessions.
Changes may not take effect immediately.

Host Name	lenovo-FPC
DNS Domain Name	lenovo.com

Advance Settings

Please click on eth0 below to further configure FPC network settings.

Name	IPv4 Enabled	IPv4 Address	IPv6 Enabled	IPv6 Address
eth0	Enabled	192.168.0.100	Enabled	:::0

Apply

General Settings

To change the Network settings may change IP address settings. Each change to settings may cause a loss in connectivity and the termination of all sessions. Changes may not take effect immediately.

Default settings for **Network configuration**:

- Host Name: lenovo-FPC
- DNS Domain Name: lenovo.com

The screenshot shows the 'Network Interface Configuration' page. At the top, there's a title 'Network Interface Configuration' and two buttons: 'Refresh' and 'Back'. Below the title is a section 'Network Interface Settings' with a warning icon and text: 'To change the Network Interface Configuration will require IP address settings. Each change to settings may cause a loss in connectivity and the termination of all sessions. Changes may not take effect immediately.' The main configuration area is divided into two sections: 'Device Type' and 'General Settings'. The 'Device Type' section includes fields for 'Device Type' (Dedicated), 'MAC Address' (6c ae 8b 08 c3 ef), 'Auto Negotiation' (radio buttons for On and Off, with On selected), 'Network Speed' (a dropdown menu showing 100 Mb), and 'Duplex Mode' (radio buttons for Full and Half, with Full selected). The 'General Settings' section includes three checkboxes: 'Enable Dynamic DNS' (checked), 'Use DHCP for DNS Domain Name' (checked), and 'Respond to ARP' (checked).

Network Interface Settings	
Device Type	Dedicated
MAC Address	6c ae 8b 08 c3 ef
Auto Negotiation	<input checked="" type="radio"/> On <input type="radio"/> Off
Network Speed	100 Mb
Duplex Mode	<input checked="" type="radio"/> Full <input type="radio"/> Half

General Settings	
Enable Dynamic DNS	<input checked="" type="checkbox"/>
Use DHCP for DNS Domain Name	<input checked="" type="checkbox"/>
Respond to ARP	<input checked="" type="checkbox"/>

Figure 30. Network Interface configuration

Click on the item of **Network Interface Configuration** leads to the detail network settings.

Default settings for **Network Interface Configuration**:

- Auto Negotiation: On
- Dynamic DNS: Unchecked
- Use DHCP for DNS Domain Name: Unchecked
- Respond to ARP: Checked

The screenshot shows the 'IPv4 Settings' page. It contains a table with the following settings: 'Enabled' (checked), 'Use DHCP' (unchecked), 'IP Address' (192.168.0.100), 'Subnet Mask' (255.255.255.0), 'Gateway' (192.168.0.1), 'Use DHCP to obtain DNS server addresses' (unchecked), 'Preferred DNS Server' (empty), and 'Alternate DNS Server' (empty).

Enabled	<input checked="" type="checkbox"/>
Use DHCP	<input type="checkbox"/>
IP Address	192.168.0.100
Subnet Mask	255.255.255.0
Gateway	192.168.0.1
Use DHCP to obtain DNS server addresses	<input type="checkbox"/>
Preferred DNS Server	
Alternate DNS Server	

Figure 31. IPv4 Settings

Default settings for **IPv4 Settings**:

- IPv4: Enabled
- Use DHCP: Unchecked
- IP Address: 192.168.0.100
- Subnet Mask: 255.255.255.0

- Gateway: 192.168.0.1
- Preferred/Alternate DNS Server: Blank

IPv6 Settings

Enabled	<input checked="" type="checkbox"/>
Use DHCP	<input checked="" type="checkbox"/>
Use Stateless	<input type="checkbox"/>
IP Address 1	<input type="text" value="::0"/>
IP Address 2	<input type="text" value="::0"/>
Gateway	<input type="text" value="::"/>
Link Local Address	fe80::6eae:8bff:fe08:1057/64
Use DHCP to obtain DNS server addresses	<input type="checkbox"/>
Preferred DNS Server	<input type="text" value="::"/>
Alternate DNS Server	<input type="text" value="::"/>

Figure 32. IPv6 Settings

Default settings for **IPv6 Settings**:

- IPv6: Enabled
- Auto configuration = Checked (IP = LLA)
- Use DHCP to obtain DNS server addresses = Unchecked
- Preferred/Alternate DNS Server = Blank

VLAN Settings

Enable VLAN ID	<input type="checkbox"/>
VLAN ID	<input type="text" value="0"/>
Priority	<input type="text" value="0"/>

Figure 33. VLAN Settings

Default settings for **VLAN Settings**:

- VLAN: Disabled

Time Setting

This page is used to configure system time.

Network Time Protocol

Configure the Network Time Protocol and Time Zone settings.

Operation Mode	<input type="text" value="Disabled"/>
NTP Server 1	<input type="text"/>
NTP Server 2	<input type="text"/>
NTP Server 3	<input type="text"/>
Requested Modes' Update Frequency (minutes)	<input type="text" value="5"/>
Time Synchronization Method	<input checked="" type="radio"/> Step Mode <input type="radio"/> Slew Mode

Figure 34. Time Settings

Select date and time and apply. Once set, time is always kept even if user restores settings to default or uncheck **Preserve Setting** during the firmware update.

User Account

User Account page allows you to manage user roles.

There are three types of user roles:

- Administrator: Full access to all the web pages and can modify all the settings and configurations
- Operator: Full access to all the web pages except **User Account** page. Operator can only see its own account at the **User Account** page and no modification at the account page is allowed
- User: Full access and modification rights to all the pages except the following pages in **Configuration** tab: **SMTP/SNMP/PEF/Network Configuration/User Account/Web Service**. Only viewing right is allowed on these pages. Any modification is not allowed.

n,233.4mm,sfx)="graphics:graphic96AF5DAB9EB8CCD2266A2E554C0BD9F6"

Figure 35. User Account page for User and Operator

Password Policy Check Enabled by default. User Privileges = admin, User name= USERID, Password = PASSWORD

User Account

Refresh

To configure a particular user, click the User ID. If Password policy check is enabled, password strength checking will be enabled while updating user configuration.

☒ Password Policy Check Enable

User ID	State	User Name	User Role	IPMI LAN Privilege
1	Disabled		None	None
2	Disabled		None	None
3	Enabled	USERID	Administrator	Admin
4	Disabled		None	None
5	Disabled		None	None
6	Disabled		None	None
7	Disabled		None	None
8	Disabled		None	None
9	Disabled		None	None
10	Disabled		None	None
11	Disabled		None	None
12	Disabled		None	None
13	Disabled		None	None
14	Disabled		None	None
15	Disabled		None	None
16	Disabled		None	None

Apply

Figure 36. User Account - Administrator

The image shows **User Account** page for Administrator

User Configuration

[Back](#)

Password Policy

Password Policy Check Enabled	No
-------------------------------	----

General

User ID	1
Enable User	<input checked="" type="checkbox"/>
User Name	<input type="text" value="World"/>
Change Password	<input type="checkbox"/>
New Password	<input type="password" value="•••••"/>
Confirm New Password	<input type="password" value="•••••"/>

User Privileges

User Role	<input type="text" value="User"/>
IPMI LAN Privilege	<input type="text" value="None"/>

Figure 37. Password Policy

Click on one of the listed account leads to **User Configuration**. User can enable/disable/delete account, set user name, set/change password, and select user privileges here. When **Password Policy Check Enable** box is checked, account password needs to follow the password policy rule (at least 8 characters with numbers, letters, and a character)

Notes:

1. User assigns account user name in **User Name** field with up to 16 characters using alphanumeric characters a-z, A-Z and 0-9, - (hyphen) and _ (underscore). Click the **Apply Changes** button. If validation fails, the GUI displays an error message. Creating new user account with existing user name is not allowed.
2. User can set/change password in **New Password** field using up to 20 printable US-ASCII (Code: 33-126) characters. Password must contains characters from three of the following four categories:
 - English uppercase characters (A through Z)
 - English lowercase characters (a through z)
 - Base 10 digits (0 through 9)
 - Non-alphabetic characters (for example, !, \$, #, %)

If validation fails, the GUI displays an error message.

Web Service

You can configure different HTTPS ports for connection and enable/disable IPMI service state at **Services** page.

Web Service

Web Server

HTTP Port Number	<input type="text" value="80"/>
HTTPS Port Number	<input type="text" value="443"/>
Timeout	<input type="text" value="1800"/> seconds
Max Sessions	32
Active Sessions	1

Figure 38. Web services

Default settings for **Services**:

- HTTP Port Number = 80
- HTTPS Port Number = 443
- Timeout = 1800s

Web Certificate

The web certificate page displays current certificate information.

A web server might require that a valid certificate and corresponding private encryption key be installed for the communication between FPC web and the server to be secure. Two methods are available for generating the private key and required web certificate: using a self-signed certificate and using a certificate that is signed by a certificate authority. FPC by default is equipped with a self-signed web certificate with RSA-2048 key encryption. If user would like to provide a self-signed certificate or would like to use a certificate-authority-signed certificate for the FPC web, web certificate provides the option.

To generate a new private encryption key and certificate-signing request (CSR), complete the following steps:

1. In the left navigation pane, click **Configuration** and click **Web Certificate** tab on the right.
2. Click on **Generate CSR**.

Web Certificate

[Generate CSR](#) [Import Certificate](#)

Current Certificate

Serial Number	: 886ED526F409EA3A
Subject Information:	
Country Code (CC)	: US
State (S)	: FL
Locality (L)	: Sunrise
Organization (O)	: Avocent
Organizational Unit (OU)	: AESS
Common Name (CN)	: avocent.com
Issuer Information:	
Country Code (CC)	: US
State (S)	: FL
Locality (L)	: Sunrise
Organization (O)	: Avocent
Organizational Unit (OU)	: AESS
Common Name (CN)	: avocent.com
Valid From	: 21 Jan 2010, 03:42:11 (UTC+8)
Valid To	: 19 Jan 2020, 03:42:11 (UTC+8)

Figure 39. Web Certificate

3. A generate certificate page is displayed..

Web Certificate

[Back to Main Page](#)

Generate Certificate Signing Request (CSR)

Common Name	<input type="text"/>
Organization Name	<input type="text"/>
Organization Unit	<input type="text"/>
Locality	<input type="text"/>
State Name	<input type="text"/>
Country Code	<input type="text" value="Afghanistan"/>
Email	<input type="text"/>

[Download CSR](#)

Figure 40. Web Certificate

4. Fill in the information.

- **Common Name (required)**

Use this field to indicate the FPC host name that currently appears in the browser Web address bar. Make sure that the value that you typed in this field exactly matches the host name as it is known by the Web browser. The browser compares the host name in the resolved Web address to the name that appears in the certificate. To prevent certificate warnings from the browser, the value that is used in this field must match the host name that is used by the browser to connect to the FPC. For

example, if the address in the Web address bar is <http://mm11.xyz.com/private/main.ssi>, the value that is used for the XCC Host Name field must be mm11.xyz.com. This field can contain a maximum of 60 characters.

- **Organization Name (required)**

Use this field to indicate the company or organization that owns the FPC. When this is used to generate a certificate-signing request, the issuing certificate authority can verify that the organization that is requesting the certificate is legally entitled to claim ownership of the given company or organization name. This field can contain a maximum of 60 characters.

- **Organization Unit (optional)** Use this field to indicate the unit within the company or organization that owns the FPC. This field can contain a maximum of 60 characters.

- **Locality (required)**

Use this field to indicate the city or locality where the FPC is physically located. This field can contain a maximum of 50 characters.

- **State Name (required)**

Use this field to indicate the state or province where the FPC is physically located. This field can contain a maximum of 30 characters.

- **Country Code (required)**

Use this field to indicate the country where the FPC is physically located. This field must contain the 2-character country code.

- **Email (required)**

Use this field to indicate the e-mail address of a contact person who is responsible for the FPC. This field can contain a maximum of 60 characters.

5. Once the required information are completed. Click on **Download CSR** to save the CSR file.
6. Send the CSR to your certificate authority. When the certificate authority returns your signed certificate, upload the signed CSR by click on **Import Certificate**.
7. A file selection page is displayed.

[Back to Main Page](#)

Import a Signed Certificate

File Path	<input type="text" value="瀏覽... 未選擇檔案。"/>	<input type="button" value="Import Certificate"/>
-----------	---	---

Support importing certificate in PEM Format, you can convert your DER certificate to PEM format by

```
openssl x509 -inform der -in certificate.cer -out certificate.pem
```

After importing certificate, you have to reconnect your FPC web.

Figure 41. Signed Certificate

8. Select the signed certificate file and click on the blue **Import Certificate** button.

Notes:

- FPC only support importing certificate file in PEM format.
- CSR generated will be encrypted with RSA-2048 cryptography.

Chapter 4. IPMI Command

The section provides detailed IPMI commands.

- **Name**

GetPSUCollectedData (Sum)

NetFn

0x32

CMD

0x90

Request data / Response data

Request:

- Byte 1: Input type 1: AC-IN

2: DC-OUT

3: PSU fan power

Response:

(when AC-IN, DC-OUT)

Byte 1 – completion code (0x00)

Byte 2 – Sum of MIN AC-IN /(DC- OUT) LSB

Byte 3 – Sum of MIN AC-IN /(DC- OUT) MSB

Byte 4 – Sum of average AC-IN/(DC-OUT) LSB

Byte 5 – Sum of average AC-IN/(DC-OUT) MSB

Byte 6 – Sum of MAX AC-IN /(DC- OUT) LSB

Byte 7 – Sum of MAX AC-IN /(DC- OUT) MSB

(when Fan power)

Byte 1 – completion code (0x00)

Byte 2 - Sum of FAN_Power LSB

Byte 3 - Sum of FAN_Power Byte 2

Byte 4 - Sum of FAN_Power MSB

Comments

This command is used to show regularly collected data from PMBUS.

1 Unit = 1 W

Note: Only FAN power unit using 10 mW = 0.01 W FAN total power = (MSB * 256* 256) + Byte2 (256) + LSB (10 mW)

- **Name**

GetPSUStatus

NetFn

0x32

CMD

0x91

Request data / Response data

Request:

- None

Response:

Byte 1 – completion code (0x00)

Byte 2 – PS_EPOW

Byte 3 – PS_THROTTLE

Byte 4 – PS_PRESENT

Byte 5 – PS_PWR_GOOD

Byte 6 – EPOW_OUT

Byte 7 – THROTTLE

Comments

This command is used to show the PSU related register or Status (From PSOC)

Bit: 0-5 = PSU1-6

0: not trigger , 1: trigger

- **Name**

GetSySLED

NetFn

0x32

CMD

0x96

Request data / Response data

Request:

- None

Response:

Byte 1 – completion code (0x00)

Byte 2 – SysLocater LED

Byte 3 – CheckLog LED

Comments

This command is used to get the FPC LED status.

0: Off

1: On

2: Blink (Locater only)

- **Name**

SetSySLED

NetFn

0x32

CMD

0x97

Request data / Response data

Request:

Byte 1: Input type

- 1: SysLocater LED
- 2: CheckLog LED

Byte 2:

- 0: Disable
- 1: Enable
- 2 blink (SysLocater only)

Response:

Byte 1 – completion code (0x00) PARAM_OUT_OF_RANGE (0xC9)

Comments

This command is used to get the FPC LED status.

0: Off

1: On

2: Blink (Locater only)

- **Name**

ShowNodePowerConsume

NetFn

0x32

CMD

0x98

Request data / Response data

Request:

Byte 1 –Node number (0x1~0x0d Node 1-12 , Chassis 13)

Response:

Byte 1 – completion code
Byte 2 – Power minimum (LSB)
Byte 3 – Power minimum (MSB)
Byte 4 – Power average (LSB)
Byte 5 – Power average (MSB)
Byte 6 – Power maximum (LSB)
Byte 7 – Power maximum (MSB)

Comments

This is used to show the Node power consume by MSG_POWER_READING command. Unit = 1 W

- **Name**

ShowInfoNodeSize

NetFn

0x32

CMD

0x99

Request data / Response data

Request:

Byte 1 –Node number (0x1~0x0c Node 1-12)

Response:

Byte 1 – completion code
Byte 2 – Node Physical Width
Byte 3 – Node Physical Hight
Byte 4 – AddOn Vaild
Byte 5 – AddOn Width
Byte 6 – AddOn Hight

Comments

This is used to show Node size info by MSG_GET_NODE_SIZE command got from XCC.

- **Name**

SetPSUFFS

NetFn

0x32

CMD

0x9a

Request data / Response data

Request:

Byte 1: FFS number(1-2)

Byte 2: input value (0/1)

Response:

Byte 1 – completion code OUT_OF_RANGE (0xC9)

Comments

This is used to set PSU FFS 0: not triggered

1: triggered

- **Name**

SetAcousticMode

NetFn

0x32

CMD

0x9b

Request data / Response data**Request:**

Byte 1 – Acoustic mode

Response:

Byte 1 – completion code (0x0) OUT_OF_RANGE (0xC9) PCIe priority high(0x01)

Comments

0x00 = Disable

0x01 = Mode1 Enable

System fan cannot exceed 20 duty.

0x02 = Mode2 Enable

System fan cannot exceed 50 duty.

0x03 = Mode3 Enable

System fan cannot exceed 80 duty.

- **Name**

SetOverSubMode

NetFn

0x32

CMD

0x9c

Request data / Response data**Request:**

Byte 1 – Over Subscription mode

Response:

Byte 1 – completion code (0x00) CUR_NOT_SUPPORT(0xd5) PARAM_OUT_OF_RANGE(0xc9)

Comments

0x0 = Disable

0x1 = Enable

Note: The OVS enable.

Total power bank would become $TP * 1.20$. Only exception is $TP * 1.20 > \text{current available power (number of PWRGD * power type)}$. The power bank would be current available power.

- **Name**

GetCappingCapity

NetFn

0x32

CMD

0x9d

Request data / Response data

Request:

Byte 1 –Node number (0x1~0x0d : Node 0x1~0xc , Chassis 0x0d)

Response:

Byte1 – completion code (0x00) Out of Range (0xc9)

Byte2 – Min. capping value LSB

Byte3 – Min. capping value MSB

Byte4 – Max. capping value LSB

Byte5 – Max. capping value MSB

Comments

Node Capping Range:

$(\text{Node min power capacity}) < \text{Cap} < (\text{Node max power capacity})$

Chassis Capping Range: $(\text{Sum of Node min power capacity}) < \text{Cap}$) The Min power should consider the permission pass nodes.

Note: Capping will only be applied in OS-runtime. The configuration of chassis level current capping is not the same behavior with sum of node level.

- **Name**

SetCappingValue

NetFn

0x32

CMD

0x9e

Request data / Response data

Request:

Byte 1 –Node number (0x1~0x0d : Node 0x1~0xc , Chassis 0x0d)

Byte 2 – Capping Value LSB Byte 3 – Capping Value MSB **Response:**

Byte 1 – completion code (0x00) OUT_OF_RANGE (0xC9) CUR_NOT_SUPPORT(0xD5)

Comments

Note: Capping / Saving not support when node with no permission

Capping value range (1~32767)

- **Name**

SetCappingSavingState

NetFn

0x32

CMD

0x9f

Request data / Response data

Request:

Byte 1 –Node number (0x1~0x0d : Node 0x1~0xc , Chassis 0x0d)

Byte 2 – Capping disable /enable Byte 3 – Saving mode **Response:**

Byte 1 – completion code (0x00) OUT_OF_RANGE (0xC9)

Comments

Note: Capping / Saving not support when node with no permission

Byte 3 : Saving mode 0x00 = Disable

0x01 = Saving mode1

0x02 = Saving mode2

0x03 = Saving mode3

- **Name**

GetCappingSavingState

NetFn

0x32

CMD

0xa0

Request data / Response data

Request:

Byte 1 –Node number (0x1~0x0d : Node 0x1~0xc , Chassis 0x0d)

Response:

Byte 1 – completion code (0x00) OUT_OF_RANGE (0xC9)

Byte 2 – Capping disable /enable

Byte 3 – Capping Value LSB

Byte 4 – Capping Value MSB

Byte 5 – Saving mode

Comments

Capping mode: 0x00 = Disable 0x01 = Enable Saving mode: 0x00 = Disable

0x01 = Saving mode1 0x02 = Saving mode2 0x03 = Saving mode3

- **Name**

SetSysTime

NetFn

0x32

CMD

0xa1

Request data / Response data**Request:**

Byte 1 – Year_MSB(1970 ~2037)

Byte 2 – Year_LSB (1970 ~2037)

Byte 3 – Month (0x01~0x12)

Byte 4 – Date (0x01~0x31)

Byte 5 – Hour (0x00~0x23)

Byte 6 – Minute (0x00~0x59)

Byte 7 – Second (0x00~0x59)

Response:

Byte 1 – completion code (0x00)

Comments

For user input convenient, the input data is decimal format.

Example: Year 2010 byte1 : 0x20

- **Name**

GetPSUPolicyBank

NetFn

0x32

CMD

0xa2

Request data / Response data

Request:

- None

Response:

Byte 1 – completion code (0x00) Byte 2 – PSU_Policy

Byte 2 – PSU_Policy

- 0: No-Redundant
- 1: N+1 Policy
- 2: N+N Policy

Byte 3 – Oversubscription Mode

- 0: disable
- 1: enable

Byte 4 – PowerBankLSB

Byte 5 – PowerBankMSB

Comments

This command is used for get PSU policy and total power bank. (Unit :1W)

- **Name**

SetPSUPolicy

NetFn

0x32

CMD

0xa3

Request data / Response data

Request:

Byte 1 – PSU_Policy: 0: No-Redundant

- 1: N+1 Policy
- 2: N+N Policy

Response:

Byte 1 – completion code (0x00) Out of Range (0xC9) PSU_CONFIG_NOT_ALLOW(0x01) PSU_BANK_LACK(0x02)

Comments

This command is used for set PSU policy.

We may not set the PSU policy successful because configuration invalid.

- **Name**

ResetNodeByUser

NetFn

0x32

CMD

0xa4

Request data / Response data

Request:

Byte 1 – Node number (0x1~0x0c Node 1-12)

Byte 2 – Reset Action

- 1: reset (imm-reset)
- 2: reseal (aux-off -> aux-on)

Response:

Byte 1 – completion code (0x00) CUR_NOT_SUPPORT (0xd5)

Comments

This command is used for Reset/Reseat node by user If node not present, it would response 0xd5

- **Name**

OEMGetPSUFanStatus

NetFn

0x32

CMD

0xa5

Request data / Response data

Request:

Byte 1 – PSU FAN number (0x1~0x06 FAN 1-6)

Response:

Byte 1 – FAN_Speed_LSB (rpm)

Byte 2 – FAN_Speed_MSB (rpm)

Byte 3 – FAN speed (0~100%)

Byte 4 – FAN health

- 0 : Not Present 1 : Ab-Normal
- 2 : Normal

Comments

This command is used for get PSU fan status

Note: Ab-Normal means PSU rpm is lower than 3000 rpms

- **Name**

OEMSetStorage

NetFn

0x32

CMD

0xa6

Request data / Response data

Request:

Byte 1 – Actions

- 1: USB Back Up
- 2: USB Restore config
- 3: Get USB restore status
- 4: Restore to default config

Response:

Byte 1 – 0x00 (Action activated)

- 0x01 (Device busy)
- 0x02 (Device not installed)
- 0x03 (BackUp config invalid) Only when Get USB restore status :
 - Byte 1 - Restore status
 - Byte 2 - Node Capping fail LSB
 - Byte 3 - Node Capping fail MSB
 - Byte 4 - Node Saving fail LSB
 - Byte 5 - Node Saving fail MSB

Comments

Note: The input “Get USB restore status” show the Restore action status.

The restore action must take at least 5 seconds.

USB restore status: 0x00: Restore success

Bitmask when bit is on:

- Bit-0: Set PSU_Policy_fail
- Bit-1: Set PSU_OVS_fail
- Bit-2: Chassis Capping fail
- Bit-3: Chassis Saving fail
- Bit-4: Acoustic fail
- Bit-5: Node power restore policy fail
- Bit-6: Smart Redundant fail

- **Name**

OEMGetNodeStatus

NetFn

0x32

CMD

0xa7

Request data / Response data

Request:

Byte 1 – Node number (0x1~0x0C)

Response:

Byte 1 – completion code (0x00) Out of Range (0xC9)

Byte 2 – Node Power State Byte 3 – Width

Byte 4 – Height

Byte 5 – Permission state

Comments

Bit-Mask of Node Power State :

- 0x00 = Power OFF
- 0x10 = S3
- 0x20 = No Permission
- 0x40 = Fault
- 0x80 = Power ON

Permission state :

- 0x00 = Not present
- 0x01 = Standby
- 0x02 = First_permission_fail
- 0x03 = Second_permission_fail
- 0x04 = Permission pass (Secondary boot pass)

- **Name**

GetFPCStatus

NetFn

0x32

CMD

0xa8

Request data / Response data

Request:

- None

Response:

Byte 1 – completion code (0x00)

Byte 2 – FPC major version

Byte 3 – FPC minor version

Byte 4 – PSOC major version

Byte 5 – PSOC minor version

Byte 6 – Boot Flash number (0x1- 0x2)

Byte 7 – Build major number

Byte 8 – Build minor number

Comments

The build minor is using ASCII value

ex: 0x41 = 'A'

- **Name**

SetRestorePolicy

NetFn

0x32

CMD

0xa9

Request data / Response data

Request:

Byte 1 – Node number LSB (BIT_MASK : 0x0~0x3F)

Byte 2 – Node number MSB (BIT_MASK : 0x0~0x3F)

Response:

Byte 1 – completion code (0x00) Out of Range (0xC9)

Comments

Example:

If set node 1-3 enable, then Byte 1 = 0x7 (0000 0111)

- **Name**

GetRestorePolicy

NetFn

0x32

CMD

0xaa

Request data / Response data

Request:

- None

Response:

Byte 1 – completion code (0x00)

Byte 2 – Node number LSB

Byte 3 – Node number MSB

Comments

- **Name**

SetSmartRedundant

NetFn

0x32

CMD

0xab

Request data / Response data

Request:

Byte 1 – mode:

Response:

Byte 1 – completion code (0x00) Out of Range (0xC9) Not Support (0x01)

Comments

Mode (0-3):

0 : disable

1: per 10 minutes update

2: per 30 minutes update

3: per 60 minutes update (If PSU in “not support” or “mismatch “stage, the PSU smart-redundant also not support.

- **Name**

GetSmartRedundantStauts

NetFn

0x32

CMD

0xac

Request data / Response data

Request:

- None

Response:

Byte 1 – completion code (0x00)

Byte 2 – mode

Byte 3 – Status

Comments

Status:

0x00: Normal

0x01: Not support

- **Name**

SetFPCResetDefault

NetFn

0x32

CMD

0xad

Request data / Response data

Request:

- None

Response:

Byte 1 – completion code (0x00)

Comments

This command is used for reset FPC to default value by user

- **Name**

CmdCipherSuiteChange

NetFn

0x32

CMD

0xb1

Request data / Response data

Request:

Byte 1 – cipher suite level 0x0: get current cipher suite

- 0x1: set cipher suite to level 1
- 0x2: set cipher suite to level 2

Response:

Byte 1 – completion code (0x00)

Comments

This command is used for get/set current cipher suite level.

- **Name**

Failsafe Logging

NetFn

0x32

CMD

0xD2

Request data / Response data

Request:

Byte 1 – Status

- 0x00: Disable (default setting)
- 0x01: Enable

Response:

Byte 00 – Completion code

Byte 01 – Last status

Byte 02 – Set status

Comments

While enabled, FPC will assert a SEL when the node enter failsafe state for over 3 seconds; then, FPC will log chassis status in USB dongle when the node enter failsafe state for over 7 minutes.

Note: This command is only available for the 1.08, FHET30M or later versions.

- **Name**

Failsafe Virtual Reseat

NetFn

0x32

CMD

0xD3

Request data / Response data

Request:

Byte 1 – Status

- 0x00: Disable (default setting)
- 0x01: Enable

Response:

Byte 00 – Completion code

Byte 01 – Last status

Byte 02 – Set status

Comments

When enabled, FPC will proceed a virtual reseat for the node which enters failsafe state for over 7 minutes.

Note: This command is only available for the 1.08, FHET30M or later versions.

Index

A

- abstract 1
- Acoustic
 - Mode 17
- Acoustic Mode 17

C

- chassis
 - VPD 18
- Chassis
 - front 7
 - overview 7
 - rear 7
- Chassis Front Overview 7
- Chassis Rear Overview 7
- chassis VPD 18
- Configuration 23
- Cooling 15
 - Overview 15
- Cooling Overview 15

E

- Event
 - Log 20
- Event Log 20

F

- Firmware 24
- FPC
 - Recovery 21
 - VPD 19
- FPC Recovery 21
- FPC VPD 19
- front
 - chassis 7

I

- Interface
 - Access 3
- Introduction 1
- IPMI Command 35

M

- Midplane
 - VPD 19
- Midplane VPD 19

P

- power
 - capping 13
 - consumption 10
- Power 9
 - Restore

- policy 14
- Power Capping 13
- Power consumption overview 10
- Power Restore Policy 14
- PSU
 - Configuration 11
 - fan
 - speed 17
 - VPD 20
- PSU Configuration 11
- PSU Fan Speed 17
- PSU VPD 20

R

- rear
 - chassis 7

S

- server
 - cooling 15
- server power 9
- SMTP
 - PEF 25
 - SNMP 25
- SMTP/SNMP/PEF 25
- Summary 6
- system
 - information 18
- System information 18

T

- Time
 - Setting 29
- Time Setting 29

U

- Update 24
- User
 - account 30
- User Account 30

V

- Voltage
 - Overview 14
- Voltage Overview 14

W

- Web
 - Certificate 32
 - service 31
- Web Certificate 32
- Web Interface Access 3
- Web Service 31



Part Number: SP47A31703

Printed in China

(1P) P/N: SP47A31703

