

# ThinkSystem SR630 Setup Guide

Machine Types: 7X01 and 7X02

#### Note

Before using this information and the product it supports, be sure to read and understand the safety information and the safety instructions, which are available at: http://thinksystem.lenovofiles.com/help/topic/safety\_documentation/pdf\_files.html

In addition, be sure that you are familiar with the terms and conditions of the Lenovo warranty for your server, which can be found at: http://datacentersupport.lenovo.com/warrantylookup

### Twentieth Edition (May 2023)

#### © Copyright Lenovo 2017, 2023.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration (GSA) contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

# Contents

Contents	. <b>. i</b>
Chapter 1. Introduction	1
Server package contents	2
Features	3
Specifications	4
Particulate contamination	. 14
Management offerings	. 15
Chapter 2. Server components	. 19
Front view	. 19
Operator information panel	. 21
Rear view	. 22
Rear view LEDs	. 28
System board components	. 30
Internal cable routing	. 31
Server models with four 3.5-inch SAS/SATA drives	. 32
Server models with four 3.5-inch SAS/SATA/	35
Server models with eight 2.5-inch SAS/SATA	
drives	. 38
Server models with ten 2.5-inch SAS/SATA/	
NVMe drives	. 42
Server models with ten 2.5-inch NVMe	51
	57
	. 57 61
	. 01
Chapter 3. Server hardware setup	. 63
Server setup checklist	. 63
Installation Guidelines	. 64
Safety inspection checklist.	. 65
System reliability guidelines	. 66
Working inside the server with the power on .	. 66
Handling static-sensitive devices	. 66
Install server hardware options	. 67
Remove the security bezel	. 67
Remove the top cover	. 68
Remove the air baffle	. 70
Install a processor-heat-sink module.	. 72
Install a system fan.	. 73
Install a memory module	. 75
Install a hot-swap power supply	. 92
Install the RAID adapter	. 95
Install the rear hot-swap drive assembly	. 96
Install the M.2 backplane and M.2 drive	. 99

Install the LOM adapter	. 102
Install a PCIe adapter and riser assembly	. 103
Install a full-height half-length GPU with the GPU upgrade kit.	. 106
Install the serial port module	. 108
Install a RAID super capacitor module on the bottom of the air baffle	. 110
Install the RAID super capacitor module on the chassis	. 112
Install the air baffle	. 115
Install the top cover	. 117
Install a hot-swap drive	. 118
Install the server in a rack	. 120
Cable the server	. 120
Power on the server	. 120
Validate server setup.	. 121
Power off the server	. 121
Chapter 4 System configuration	103
Set the network connection for the Lenove VClarity	. 120
	. 123
Update the firmware	. 124
Configure the firmware	. 127
Memory configuration	128
Configuring DC Persistent Memory Module (DCPMM)	. 129
Configuring DC Persistent Memory Module (DCPMM)	. 129
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135 . 135
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135 . 135
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135 . 135 . 135
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135 . 135 . 135 . 135 . 137
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135 . 135 . 135 . 135 . 135
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135 . 135 . 135 . 135 . 137
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135 . 135 . 135 . 135 . 137
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135 . 135 . 135 . 135 . 137
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135 . 135 . 135 . 135 . 137 .139
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135 . 135 . 135 . 135 . 137 .139 .139 .143
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135 . 135 . 135 . 135 . 135 . 137 .139 .139 .143 . 143 . 144
Configuring DC Persistent Memory Module (DCPMM)       .         RAID configuration       .         Deploy the operating system       .         Back up the server configuration       .         Update the Vital Product Data (VPD)       .         Update the Universal Unique Identifier (UUID)       .         Update the asset tag       .         Appendix A. Getting help and technical assistance       .         Before you call       .         Contacting Support       .	. 129 . 133 . 134 . 135 . 135 . 135 . 135 . 137 .139 .139 .143 . 143 . 144 . 145
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135 . 135 . 135 . 135 . 137 .139 .139 .143 . 143 . 144 . 145 .147
Configuring DC Persistent Memory Module (DCPMM)	. 129 . 133 . 134 . 135 . 135 . 135 . 135 . 135 . 137 .139 .139 .143 . 143 . 144 . 145 . 147

# **Chapter 1. Introduction**

The ThinkSystem<sup>™</sup> SR630 server is a 1U rack server designed to be highly flexible to support many kinds of Information Technology (IT) workloads. This high-performance, multi-core server is ideally suited for IT environments that require superior processor performance, input/output (I/O) flexibility, and flexible manageability.

Performance, ease of use, reliability, and expansion capabilities were key considerations in the design of the server. These design features make it possible for you to customize the system hardware to meet your needs today and provide flexible expansion capabilities for the future.

The server comes with a limited warranty. For details about the warranty, see: https://support.lenovo.com/us/en/solutions/ht503310

For details about your specific warranty, see: http://datacentersupport.lenovo.com/warrantylookup

#### Identifying your server

When you contact Lenovo for help, the machine type and serial number information helps support technicians to identify your server and provide faster service.

The machine type and serial number are on the ID label on the right rack latch in the front of the server.



#### Figure 1. Location of the ID label

#### XClarity Controller network access label

The XClarity<sup>®</sup> Controller network access label is attached on the top side of the pull-out information tab. After you get the server, peel the XClarity Controller network access label away and store it in a safe place.



Figure 2. Location of the XClarity Controller network access label

#### Quick response code

The system service label, which is on the top cover, provides a quick response (QR) code for mobile access to service information. Scan the QR code with a mobile device and a QR code reader application to get quick access to the Lenovo Service web site for this server. The Lenovo Service Information Web site provides additional information for parts installation and replacement videos, and error codes for server support.

The following illustration shows the QR code: https://support.lenovo.com/p/servers/sr630



Figure 3. QR code

### Server package contents

When you receive your server, verify that the shipment contains everything that you expected to receive.

The server package includes the following items:



Note: Items marked with asterisk (\*) are available on some models only.

- 1 Server
- Z Rail kit\*. Detailed instructions for installing the rail kit are provided in the package with the rail kit.
- B Cable management arm\*
- A Material box, including items such as accessory kit, power cords\* and documentation

# **Features**

Performance, ease of use, reliability, and expansion capabilities were key considerations in the design of your server. These design features make it possible for you to customize the system hardware to meet your needs today and provide flexible expansion capabilities for the future.

Your server implements the following features and technologies:

#### • Lenovo XClarity Controller (XCC)

The Lenovo XClarity Controller is the common management controller for Lenovo ThinkSystem server hardware. The Lenovo XClarity Controller consolidates multiple management functions in a single chip on the server system board.

Some of the features that are unique to the Lenovo XClarity Controller are enhanced performance, higherresolution remote video, and expanded security options. For additional information about the Lenovo XClarity Controller, see:

http://sysmgt.lenovofiles.com/help/topic/com.lenovo.systems.management.xcc.doc/product\_page.html

#### • UEFI-compliant server firmware

Lenovo ThinkSystem firmware is Unified Extensible Firmware Interface (UEFI) compliant. UEFI replaces BIOS and defines a standard interface between the operating system, platform firmware, and external devices.

Lenovo ThinkSystem servers are capable of booting UEFI-compliant operating systems, BIOS-based operating systems, and BIOS-based adapters as well as UEFI-compliant adapters.

Note: The server does not support DOS (Disk Operating System).

#### • Large system-memory capacity

The server supports registered DIMMs (RDIMMs), load-reduced DIMMs (LRDIMMs), three-dimensional stack registered DIMMs (3DS RDIMMs), and DC Persistent Memory Module (DCPMM). For more information about the specific types and maximum amount of memory, see "Specifications" on page 4.

For a list of supported memory modules, see: https://static.lenovo.com/us/en/serverproven/index.shtml

#### Integrated Trusted Platform Module (TPM)

This integrated security chip performs cryptographic functions and stores private and public secure keys. It provides the hardware support for the Trusted Computing Group (TCG) specification. You can download the software to support the TCG specification.

Trusted Platform Module (TPM) has two versions - TPM 1.2 and TPM 2.0. You can change the TPM version from 1.2 to 2.0 and back again.

For more information on TPM configurations, see "Enable TPM/TCM" in the Maintenance Manual.

**Note:** For customers in the People's Republic of China, a Lenovo-qualified TPM 2.0 adapter or a Trusted Cryptographic Module (TCM) adapter (sometimes called a daughter card) may be pre-installed.

#### • Large data-storage capacity and hot-swap capability

With the hot-swap feature, you can add, remove, or replace drives without turning off the server.

#### Mobile access to Lenovo Service Information website

The server provides a QR code on the system service label, which is on the cover of the server, that you can scan using a QR code reader and scanner with a mobile device to get quick access to the Lenovo Service Information website. The Lenovo Service Information website provides additional information for parts installation, replacement videos, and error codes for server support.

#### Redundant networking connection

The Lenovo XClarity Controller provides failover capability to a redundant Ethernet connection with the applicable application installed. If a problem occurs with the primary Ethernet connection, all Ethernet traffic that is associated with the primary connection is automatically switched to the optional redundant Ethernet connection. If the applicable device drivers are installed, this switching occurs without data loss and without user intervention.

#### • Redundant cooling and optional power capabilities

The server supports a maximum of two 550-watt, 750-watt, or 1100-watt hot-swap power supplies and seven hot-swap fans, which provide redundancy for a typical configuration. The redundant cooling by the fans in the server enables continued operation if one of the fans fails.

Note: You cannot mix 550-watt, 750-watt, and 1100-watt power supplies in the server.

### **Specifications**

The following information is a summary of the features and specifications of the server. Depending on the model, some features might not be available, or some specifications might not apply.

#### Table 1. Server specifications

Specification	Description
Dimension	<ul> <li>1U</li> <li>Height: 43.0 mm (1.7 inches)</li> <li>Width: <ul> <li>With rack latches: 482.0 mm (19.0 inches)</li> <li>Without rack latches: 434.4 mm (17.1 inches)</li> </ul> </li> <li>Depth: 778.3 mm (30.7 inches)</li> <li>Note: The depth is measured with rack latches and power supply installed, but without security bezel installed.</li> </ul>
Weight	Up to 19.0 kg (41.9 lb)
Processor (depending on the model)	<ul> <li>Up to two Intel<sup>®</sup> Xeon<sup>®</sup> Scalable Processors <ul> <li>Designed for Land Grid Array (LGA) 3647 socket</li> <li>Up to 28 cores</li> <li>Thermal Design Power (TDP): up to 205 watts</li> </ul> </li> <li>For more important information about the processor, refer to "Important information for system board, processor, and heat sink" on page 12.</li> <li>For a list of supported processors, see: https://static.lenovo.com/us/en/serverproven/index.shtml</li> </ul>
Memory	<ul> <li>For 1st Generation Intel Xeon Scalable Processor (Intel Xeon SP Gen 1) :</li> <li>Slots: 24 memory module slots</li> <li>Minimum: 8 GB</li> <li>Maximum: <ul> <li>768 GB using registered memory modules (RDIMMs)</li> <li>1.5 TB using load-reduced memory modules (LRDIMMs)</li> <li>3 TB using three-dimensional stack registered memory modules (3DS RDIMMs)</li> </ul> </li> <li>Trype (depending on the model): <ul> <li>TruDDR4 2666, ingle-rank/dual-rank, 8 GB/16 GB/32 GB RDIMM</li> <li>TruDDR4 2666, quad-rank, 64 GB LRDIMM</li> <li>TruDDR4 2666, octa-rank, 128 GB 3DS RDIMM</li> </ul> </li> <li>For 2nd Generation Intel Xeon Scalable Processor (Intel Xeon SP Gen 2):</li> <li>Slots: 24 memory module slots</li> <li>Minimum: 8 GB</li> </ul> <li>Maximum: <ul> <li>1.5 TB using registered memory modules (RDIMMs)</li> <li>3 TB using three-dimensional stack registered memory modules (3DS RDIMMs)</li> <li>6 Ts using registered memory modules (RDIMMs)</li> <li>a 3 TB using three-dimensional stack registered memory modules (3DS RDIMMs)</li> <li>6 TB using DC Persistent Memory Module (DCPMM) and RDIMMs/3DS RDIMMs in Memory Mode</li> </ul> </li> <li>Type: (depending on the model) <ul> <li>TruDDR4 2666, quad-rank, 64 GB 3DS RDIMMs</li> <li>TruDDR4 2933, single-rank/dual-rank, 16 GB/32 GB RDIMMs</li> <li>TruDDR4 2933, engle-rank/dual-rank, 8 GB/16 GB/32 GB/64 GB RDIMMs</li> <li>TruDDR4 2933, guad-rank, 128 GB 3DS RDIMMs</li> <li>TruDDR4 2933, quad-rank, 128 GB 3DS RDIMMs</li> <li>PCCPMMs are not supported if any GPU is installed.</li> </ul> </li> <li>Notes: <ul> <li>Operating speed and total memory capacity depend on the processor model and UEFI settings.</li> <li>Rear drive assembly and 256 GB/512 GB DCPMM are not installed at the same time.</li> </ul> </li> <li>For a list of supported memory, see the Lenovo ServerProven Web site: https:// static.lenovo.com/us/en/ser</li>

Table 1. Server specifications (continued)

Specification	Description
Operating systems	<ul> <li>Supported and certified operating systems:</li> <li>Microsoft Windows Server</li> <li>VMware ESXi</li> <li>Red Hat Enterprise Linux</li> <li>SUSE Linux Enterprise Server</li> <li>References:</li> <li>Complete list of available operating systems: https://lenovopress.com/osig.</li> <li>OS deployment instructions: "Deploy the operating system" on page 134.</li> </ul>
Internal drives	<ul> <li>Up to two M.2 drives</li> <li>Up to four 3.5-inch hot-swap SAS/SATA drives</li> <li>Up to four 3.5-inch hot-swap SAS/SATA/NVMe drives</li> <li>Up to eight 2.5-inch hot-swap SAS/SATA drives</li> <li>Up to ten 2.5-inch hot-swap SAS/SATA/NVMe drives (NVMe drives are supported only in drive bays 6–9)</li> <li>Up to ten 2.5-inch hot-swap NVMe drives</li> <li>Up to two 2.5-inch hot-swap SAS/SATA drives in the rear (the processor TDP should be less than or equal to 125 watts)</li> </ul>
	<ul> <li>Notes:</li> <li>NVMe drives means Non-Volatile Memory express drives.</li> <li>Only use M.2 drives provided by Lenovo.</li> <li>The backplane for ten 2.5-inch hot-swap NVMe drives is supported only when the following configuration requirements are met: <ul> <li>Intel Xeon 6144, 6146, 6154, 6240C, 6240Y, 6242R, 6244, 6246, 6246R, 6248R, 6252N, 6254R, 8168, 8171M, 8180, 8180M, 8268, 8270, 8280, 8280L, and 8280M processors are not installed.</li> <li>The power of the hot-swap power supply is 1100 watts.</li> <li>Rear hot-swap drive assembly is not installed.</li> <li>GPU is not installed.</li> <li>NVMe PCle flash adapter is not installed.</li> <li>256 GB/512 GB DCPMM is not installed.</li> </ul> </li> </ul>
PCIe slots	Depending on the model, your server supports up to three PCIe slots in the rear. For detailed information, see "Rear view" on page 22. <b>Note:</b> For ThinkSystem Mellanox ConnectX-6 HDR/200GbE QSFP56 1-port PCIe adapter, when AOC cable and transceiver are installed, the system operating temperature must be less than or equal to 30°C; when other DAC cable is installed, the system operating temperature must be less than or equal to 35°C.

Table 1. Server specifications (continued)

Specification	Description
Graphics processing unit (GPU)	<ul> <li>Your server supports the following GPUs:</li> <li>One NVIDIA Quadro P2000 PCIe Active GPU (full-height, 3/4 length)</li> <li>One NVIDIA Quadro P2200 PCIe Active GPU (full-height, 3/4 length)</li> <li>One NVIDIA Quadro P4000 PCIe Active GPU (full-height, full-length)</li> <li>One NVIDIA Quadro RTX4000 PCIe Active GPU (full-height, full-length)</li> <li>One NVIDIA Quadro RTX4000 PCIe Active GPU (full-height, full-length)</li> <li>Up to two NVIDIA Tesla P4 8GB PCIe Passive GPU (low-profile)</li> <li>Up to two NVIDIA Tesla T4 8GB PCIe Passive GPU (low-profile)</li> <li>Up to two NVIDIA A2 16GB PCIe Gen4 Passive GPU (half-height, half-length)</li> <li>Up to three NVIDIA Quadro P600 2GB PCIe Active GPU (low-profile)</li> <li>Up to three NVIDIA Quadro P620 PCIe Active GPU (low-profile)</li> </ul>
	<ul> <li>Location for installing GPUs:</li> <li>Install P2000/P2200/P4000/RTX4000 GPU only in the full-height PCIe slot 2.</li> <li>Install the first A2/P4/T4 GPU in PCIe slot 3 and install the second A2/P4/T4 GPU in PCIe slot 1.</li> <li>Install the first P600 GPU in PCIe slot 3, install the second P600 GPU in PCIe slot 1, and install the third P600 GPU in PCIe slot 2.</li> <li>Install the first P620 GPU in PCIe slot 3, install the second P620 GPU in PCIe slot 1, and install the third P620 GPU in PCIe slot 2.</li> </ul>
	<ul> <li>GPU installation requirements:</li> <li>P2000/P2200 GPU is supported only when the following configuration requirements are met: <ul> <li>Processor TDP is less than or equal to 140 watts.</li> <li>No RAID adapter is installed on the RAID adapter slot on the system board. If you want to install a RAID adapter, install it in PCIe slot 1.</li> <li>The power of the hot-swap power supply is 750 watts or 1100 watts.</li> <li>The backplane for ten 2.5-inch NVMe drives is not installed.</li> <li>Rear hot-swap drive assembly is not installed.</li> <li>P4000/RTX4000 GPU is supported only when the following configuration requirements are met:</li> <li>Intel Xeon 6144, 6146, 6246, or 6252N processor is not installed and processor TDP is less than or equal to 165 watts.</li> <li>No RAID adapter is installed on the RAID adapter slot on the system board. If you want to install a RAID adapter, install it in PCIe slot 1.</li> <li>The power of the hot-swap power supply is 750 watts or 1100 watts.</li> <li>The backplane for ten 2.5-inch NVMe drives is not installed and processor TDP is less than or equal to 165 watts.</li> <li>No RAID adapter is installed on the RAID adapter slot on the system board. If you want to install a RAID adapter, install it in PCIe slot 1.</li> <li>The power of the hot-swap power supply is 750 watts or 1100 watts.</li> <li>The backplane for ten 2.5-inch NVMe drives is not installed.</li> <li>Rear hot-swap drive assembly is not installed.</li> <li>A2/P4/T4 GPU is supported only when the following configuration requirements are met:</li> <li>Intel Xeon 6144, 6146, 6246, or 6252N processor is not installed and processor TDP is less than or equal to 165 watts.</li> <li>The backplane for ten 2.5-inch NVMe drives is not installed.</li> <li>Rear hot-swap drive assembly is not installed.</li> <li>A2/P4/T4 GPU is installed, the power of the hot-swap power supply must be 750 watts or 1100 watts.</li> <li>If two A2/P4/T4 GPU is installed, the power of the hot-swap power supply must be 1100 watts.</li> <li></li></ul></li></ul>

Table 1. Server specifications (continued)

Specification	Description
	<ul> <li>P600 GPU is supported only when the following configuration requirements are met: <ul> <li>Intel Xeon 6144, 6146, 6246, or 6252N processor is not installed and processor TDP is less than or equal to 165 watts.</li> <li>If one or two P600 GPUs are installed, the power of the hot-swap power supply is 750 watts or 1100 watts; if three P600 GPUs are installed, the power of the hot-swap power supply is 1100 watts.</li> <li>The backplane for ten 2.5-inch NVMe drives is not installed.</li> <li>Rear hot-swap drive assembly is not installed.</li> <li>No system fan is failed.</li> </ul> </li> <li>P620 GPU is supported only when the following configuration requirements are met: <ul> <li>Intel Xeon 6144, 6146, 6246, or 6252N processor is not installed and processor TDP is less than or equal to 165 watts.</li> <li>If one or two P620 GPUs are installed, the power of the hot-swap power supply is 750 watts or 1100 watts; if three P620 GPUs are installed and processor TDP is less than or equal to 165 watts.</li> <li>If one or two P620 GPUs are installed, the power of the hot-swap power supply is 750 watts or 1100 watts; if three P620 GPUs are installed, the power of the hot-swap power supply is 750 watts or 1100 watts; if three P620 GPUs are installed, the power of the hot-swap power supply is 750 watts or 1100 watts; if three P620 GPUs are installed, the power of the hot-swap power supply is 750 watts or 1100 watts.</li> <li>The backplane for ten 2.5-inch NVMe drives is not installed.</li> <li>Rear hot-swap drive assembly is not installed.</li> </ul> </li> </ul>
Input/Output (I/O) features	<ul> <li>Front panel: <ul> <li>One VGA connector (available on some models)</li> <li>One XClarity Controller USB 2.0 connector</li> <li>One USB 3.0 connector</li> </ul> </li> <li>Rear panel: <ul> <li>One VGA connector</li> <li>Two USB 3.0 connectors</li> <li>One XClarity Controller network connector</li> <li>Two or four Ethernet connectors on the LOM adapter (available on some models)</li> <li>One serial port (available on some models)</li> </ul> </li> </ul>
RAID adapters (depending on the model)	<ul> <li>Onboard SATA ports with software RAID support (Intel VROC SATA RAID, formerly known as Intel RSTe)</li> <li>Note: VROC is not supported with the VMware ESXi yet.</li> <li>Onboard NVMe ports with software RAID support (Intel VROC NVMe RAID) <ul> <li>VROC Intel-SSD-Only (also known as Intel VROC standard): supports RAID levels 0, 1, 5, and 10 with Intel NVMe drives only</li> <li>VROC Premium: supports RAID levels 0, 1, 5, and 10 with non-Intel NVMe drives</li> </ul> </li> <li>Note: VROC is not supported with the VMware ESXi yet.</li> <li>An HBA 430-8e or 430-16e SAS/SATA adapter that support JBOD mode but does not support RAID</li> <li>An HBA 430-8i or 430-16i SAS/SATA adapter that support JBOD mode but does not support RAID</li> <li>An HBA 440-8i or 440-16i SAS/SATA adapter that support JBOD mode but does not support RAID</li> <li>An HBA 440-8e SAS/SATA adapter that support JBOD mode but does not support RAID</li> <li>An HBA 440-8i or 440-16i SAS/SATA adapter that support JBOD mode but does not support RAID</li> <li>An HBA 440-8e SAS/SATA adapter that support JBOD mode but does not support RAID</li> <li>An HBA 440-8e SAS/SATA adapter that support JBOD mode but does not support RAID</li> <li>An HBA 440-16e SAS/SATA adapter that support JBOD mode but does not support RAID</li> <li>An HBA 440-16e SAS/SATA adapter that support JBOD mode but does not support RAID</li> <li>An HBA 440-16e SAS/SATA adapter that support JBOD mode but does not support RAID</li> <li>An HBA 440-16e SAS/SATA adapter that support JBOD mode but does not support RAID</li> <li>An HBA 440-16e SAS/SATA adapter that support JBOD mode but does not support RAID</li> <li>An HBA 440-16e SAS/SATA adapter that support JBOD mode but does not support RAID</li> </ul>

Table 1. Server specifications (continued)

Specification	Description
Specification	<ul> <li>Description</li> <li>A RAID 5350-8i SAS/SATA adapter that supports JBOD mode and RAID levels 0, 1, 5, and 10</li> <li>A RAID 530-8i SAS/SATA adapter that supports JBOD mode and RAID levels 0, 1, 5, 10, and 50</li> <li>A RAID 540-8i SAS/SATA adapter that supports JBOD mode and RAID levels 0, 1, and 10</li> <li>A RAID 730-8i 1G Cache SAS/SATA adapter that supports JBOD mode and RAID levels 0, 1, and 10</li> <li>A RAID 730-8i 1G Cache SAS/SATA adapter that supports JBOD mode and RAID levels 0, 1, 5, 10, and 50 (for Chinese Mainland only)</li> <li>A RAID 730-8i 2GB Cache SAS/SATA adapter that supports JBOD mode and RAID levels 0, 1, 5, 6, 10, 50, and 60</li> <li>A RAID 930-8e SAS/SATA adapter that supports JBOD mode and RAID levels 0, 1, 5, 6, 10, 50, and 60</li> <li>A RAID 930-8i or 930-16i SAS/SATA adapter that supports JBOD mode and RAID levels 0, 1, 5, 6, 10, 50, and 60</li> <li>A RAID 930-8i or 930-16i SAS/SATA adapter that supports JBOD mode and RAID levels 0, 1, 5, 6, 10, 50, and 60</li> <li>A RAID 930-8i or 930-16i SAS/SATA adapter that supports JBOD mode and RAID levels 0, 1, 5, 6, 10, 50, and 60</li> <li>A RAID 930-8i or 930-16i SAS/SATA adapter that supports JBOD mode and RAID levels 0, 1, 5, 6, 10, 50, and 60</li> </ul>
	<ul> <li>mode and RAID levels 0, 1, 5, 6, 10, 50 and 60</li> <li>A RAID 940-8i or 940-16i SAS/SATA adapter that supports JBOD mode and RAID levels 0, 1, 5, 6, 10, 50, and 60</li> <li>Notes:</li> <li>RAID 730-8i 2GB SAS/SATA adapter, RAID 930-8i SAS/SATA adapter, RAID 930-16i SAS/SATA adapter, and RAID 930-8e SAS/SATA adapter cannot be mixed.</li> <li>If RAID 730-8i 1GB/2GB Cache SAS/SATA adapter is installed, ThinkSystem 2.5" PM1653/PM1655 Read Intensive/Mixed Use SAS 24Gb SSD cannot be installed.</li> <li>A RAID super capacitor module must be installed if RAID 730-8i 2GB, 930-8e, 930-8i, 930-16i, 940-8e 4GB, 940-8i, 940-16i, 9350-8i, or 9350-16i SAS/SATA adapter is installed.</li> <li>HBA 440-8i/440-16i SAS/SATA adapter and HBA 430-8i/430-16i SAS/SATA adapter cannot be mixed.</li> <li>HBA 440-8i, 440-16i, 540-8i, 940-8i, 940-16i, 5350-8i, 9350-8i, or 9350-16i SAS/SATA adapter cannot be installed in the inner raid adapter slot.</li> <li>HBA 540-16i SAS/SATA adapter can only be installed in the PCle slot 1.</li> <li>HBA 440-8e, 440-16e, or 940 8e 4GB SAS/SATA adapters can be supported when the following configuration requirements are met: <ul> <li>Can only be installed in the PCle slots 2, 3, and 1 for the server models with one processor.</li> <li>Can only be installed in the PCle slots 1, 2, and 3.</li> <li>Can not be mixed with HBA/RAID 430-8i, 430-16i, 440-8i, 440-16i, 530-8i, 730-8i, 930-8i, 930-8i, 930-8i, 930-8i, 930-8i, 930-8i, or 940-16i SAS/SATA adapters.</li> </ul> </li> <li>RAID 4350-8i SAS/SATA adapter can be supported when the following configuration requirements are met: <ul> <li>Can only be installed in the PCle slots 1, 2, and 3.</li> <li>Can not be mixed with HBA/RAID 430-8i, 430-16i, 440-8i, 440-16i, 530-8i, 730-8i, 930-8i, 930-8i, 930-8i, or 940-8i, or 940-16i, 540-8i, 440-16i, 530-8i, 730-8i, 930-8i, 930-8i, 930-8i, 930-8i, 930-8i, or 940-16i SAS/SATA adapters.</li> <li>RAID 4550-8i SAS/SATA adapter can be supported when the following configuration requirements are met: <ul> <li>Can not be m</li></ul></li></ul></li></ul>
System fans	<ul> <li>a), 930-86, 930-81, 930-161, 940-81, or 940-161 SAS/SATA adapters.</li> <li>RAID 940-8i or 940-16i SAS/SATA adapter can be supported when the following configuration requirements are met: <ul> <li>Only one RAID 940 adapter is supported.</li> <li>Can be installed in PCIe slot 1 only.</li> <li>A RAID super capacitor module must be installed.</li> <li>No rear HDD</li> <li>Can not be mixed with 930-8i or 930-16i SAS/SATA adapter.</li> <li>Can be mixed with HBA 440-8i or 440-16i SAS/SATA adapter.</li> </ul> </li> <li>One processor: five dual-rotor hot-swap fans (including one redundant fan rotor)</li> </ul>
System fans	One processor: five dual-rotor hot-swap fans (including one redundant fan rotor)

Table 1. Server specifications (continued)

Specification	Description
	<ul> <li>Two processors: seven dual-rotor hot-swap fans (including one redundant fan rotor)</li> <li>Notes:</li> </ul>
	<ul> <li>When the system is powered off but still plugged in to AC power, fans 1 and 2 may continue to spin at a much lower speed. This is the system design to provide proper cooling.</li> <li>For server models installed with Intel Xeon 6144, 6146, 6154, 6240C, 6240Y, 6242R, 6244, 6246, 6246R, 6248R, 6252N, 6254, 6258R, 8168, 8171M, 8180, 8180M, 8268, 8270, 8280, 8280L, and 8280M processors, fan rotor redundancy is not supported. If one fan rotor fails, the server performance will be degraded.</li> <li>If your server comes with only one processor, five system fans (fan 1 to fan 5) are adequate to provide proper cooling. However, you must keep the locations for fan 6 and fan 7 occupied by a fan filler to ensure proper airflow.</li> <li>When 256 GB/512 GB DCPMM is installed, and the ambient temperature is more than 30°C, fan rotor redundancy is not supported.</li> </ul>
Power supplies	<ol> <li>CAUTION:         <ol> <li>240 V dc input (input range: 180-300 V dc) is ONLY supported in Chinese Mainland.</li> <li>Power supplies with 240 V dc are not hot-swappable. To remove the power cord, ensure you have turned off the server or disconnected the dc power sources at the breaker panel.</li> <li>In order for the ThinkSystem products to operate error free in both a DC or AC electrical environment, a TN-S earthing system which complies to 60364-1 IEC 2005 standard has to be present or installed.</li> </ol> </li> </ol>
	<ul> <li>One or two hot-swap power supplies for redundancy support</li> <li>550-watt ac 80 PLUS Platinum</li> <li>750-watt ac 80 PLUS Platinum</li> <li>750-watt ac 80 PLUS Titanium</li> <li>1100-watt ac 80 PLUS Platinum</li> </ul>
Minimal configuration for debugging	<ul> <li>One processor in processor socket 1</li> <li>One memory module in slot 5</li> <li>One power supply</li> <li>One HDD drive or one M.2 drive (if OS is needed for debugging)</li> <li>Five system fans (fan 1 to fan 5)</li> </ul>
Acoustical noise emissions	<ul> <li>Sound power levels, idle <ul> <li>4.9 bels, minimum</li> <li>5.0 bels, typical</li> <li>5.8 bels, maximum</li> </ul> </li> <li>Sound power levels, operating <ul> <li>5.3 bels, minimum</li> <li>6.1 bels, typical</li> <li>6.2 bels, maximum</li> </ul> </li> <li>Notes: <ul> <li>These sound power levels are measured in controlled acoustical environments according to procedures specified by ISO 7779 and are reported in accordance with ISO 9296.</li> </ul> </li> <li>The declared acoustic noise levels are based on specified configurations and they may change depending on configuration/conditions.</li> <li>The declared acoustic noise levels may increase greatly if high-power components are installed, for example, some high-power NICs, CPUs, and GPUs.</li> </ul>

Table 1. Server specifications (continued)

Specification	Description
Electrical input	<ul> <li>Sine-wave input (50–60 Hz) required</li> <li>Input voltage low range: <ul> <li>Minimum: 100 V ac</li> <li>Maximum: 127 V ac</li> </ul> </li> <li>Input voltage high range: <ul> <li>Minimum: 200 V ac</li> <li>Maximum: 240 V ac</li> </ul> </li> </ul>
	<b>Note:</b> For server models with 750-watt ac 80 PLUS Titanium power supplies, 100–127 V ac input voltage is not supported.
	CAUTION: 240 V dc input (input range: 180-300 V dc) is supported in Chinese Mainland ONLY. Power supply with 240 V dc input cannot support hot plugging power cord function. Before removing the power supply with dc input, please turn off server or disconnect dc power sources at the breaker panel or by turning off the power source. Then, remove the power cord.
Environment	The server is supported in the following environment:
	<ul> <li>Note: This server is designed for standard data center environment and recommended to be placed in industrial data center.</li> <li>Air temperature: <ul> <li>Operating:</li> <li>ASHRAE class A2: 10–35°C (50–95°F); when the altitude exceeds 900 m (2953 ft), the maximum ambient temperature value decreases by 1°C (1.8°F) with every 300 m (884 ft) of altitude increase.</li> <li>ASHRAE class A3: 5-40°C (41–104°F); when the altitude exceeds 900 m (2953 ft), the maximum ambient temperature value decreases by 1°C (1.8°F) with every 175 m (574 ft) of altitude increase.</li> <li>ASHRAE class A4: 5-45°C (41–113°F); when the altitude exceeds 900 m (2953 ft), the maximum ambient temperature value decreases by 1°C (1.8°F) with every 125 m (410 ft) of altitude increase.</li> <li>Server off: 5–45°C (41–113°F)</li> <li>Shipping or storage: -40–60°C (-40–140°F)</li> </ul> </li> <li>Maximum altitude: 3050 m (10 000 ft)</li> <li>Relative humidity (non-condensing): <ul> <li>Operating:</li> <li>ASHRAE class A2: 8%–80%; maximum dew point: 21°C (70°F)</li> <li>ASHRAE class A3: 8%–85%; maximum dew point: 24°C (75°F)</li> <li>ASHRAE class A3: 8%–90%</li> </ul> </li> <li>Particulate contamination</li> <li>Attention: Airborne particulates and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the server.</li> </ul> <li>Note: Your server complies with ASHRAE class A2 specifications. The server performance might be impacted when the system operating temperature is outside the ASHRAE A2 specifications. Depending on the hardware configuration, some server models comply with ASHRAE class A4 specifications, the server models must meet the following hardware configuration requirements at the same time:</li> <li>Two power supplies are installed.</li> <li>NVMe drive is not installed.</li> <li>NVMe drive is not installed.</li>

Table 1. Server specifications (continued)

Specification	Description
	<ul> <li>P2200 GPU is not installed.</li> <li>P4000 GPU is not installed.</li> <li>RTX4000 GPU is not installed.</li> <li>No A2 GPU is installed in PCIe slot 1.</li> <li>No P4 GPU is installed in PCIe slot 1.</li> <li>No T4 GPU is installed in PCIe slot 1.</li> <li>No P600 GPU is installed in PCIe slot 2.</li> <li>No P620 GPU is installed in PCIe slot 2.</li> <li>Innova-2 FPGA Smart NIC active GPU is not installed.</li> <li>ThinkSystem Mellanox ConnectX-6 100 Gbs 1P/2P PCIe adapter is not installed.</li> <li>ThinkSystem Mellanox ConnectX-6 HDR/200GbE QSFP56 1-port PCIe adapter is not installed.</li> <li>For server models with 2.5-inch drive bays, the RAID super capacitor module cannot be installed on the bottom of the air baffle, but only can be installed on the chassis.</li> <li>The backplane for ten 2.5-inch NVMe drives is not installed.</li> <li>The following processors are not installed: <ul> <li>Processors with TDP higher than or equal to 150 watts</li> <li>Intel Xeon 4112, 5122, 6126, 6128, 6132, 6134, 6134M, and 8156 processors</li> </ul> </li> </ul>

#### Important information about EU ecodesign requirements

To meet the EU ecodesign requirements for energy-related products (ErP) Lot 9, your server must meet the following requirements:

- Minimum memory: 16 GB
- If your server is configured with one processor, Intel Xeon 3104 is not supported.

#### Important information for system board, processor, and heat sink

There are two types of system board for your server:

- Left: System board with large lift handle 1
- Right: System board with small lift handle 2





Figure 4. Two types of system board

There are two shape types of heat sink for your server:

- Left: Small-size heat sink
- Right: Large-size heat sink



Figure 5. Two types of heat sink

The following table lists the important information for the system board, heat sink, and processor.

System board installed	Heat sink installed	Important information
System board with large lift handle or system board with small lift handle	Small size heat sink	<ul> <li>For server models installed with Intel Xeon 6144, 6146, 6154, 6240C, 6240Y, 6242R, 6244, 6246, 6246R, 6248R, 6252N, 6254, 6258R, 8168, 8171M, 8180, 8180M, 8268, 8270, 8280, 8280L, and 8280M processors, the following parts are not supported:</li> <li>Front backplane and front hot-swap SAS/SATA/NVMe drives</li> <li>Rear hot-swap drive assembly</li> <li>RAID super capacitor module on the bottom of the air baffle</li> <li>NVMe PCle flash adapter</li> <li>GPU</li> </ul>
System board with small lift handle	Large size heat sink	<ul> <li>For server models installed with large size heat sink, the air baffle and the RAID super capacitor module on the bottom of the air baffle are not supported.</li> <li>For server models installed with Intel Xeon 6144, 6146, 6244, 6246, 6252N, 8168, 8171M, 8180, 8180M, 8268, 8270, 8280, 8280L, and 8280M processors, ensure that the following configuration requirements are met: <ul> <li>The backplane for ten 2.5-inch NVMe drives is not installed.</li> <li>No system fan is failed.</li> <li>Rear hot-swap drive assembly is not installed.</li> <li>GPU is not installed.</li> </ul> </li> <li>For server models installed with the backplane for ten 2.5-inch SAS/SATA/NVMe drives, intel Xeon 6154, 6240C, 6240Y, 6242R, 6246R, 6248R, 6254, and 6258R, processor is supported with the condition that the following configuration requirements are met: <ul> <li>No system fan is failed.</li> <li>GPU is not installed.</li> </ul> </li> <li>For server models installed with the backplane for ten 2.5-inch SAS/SATA/NVMe drives, intel Xeon 6154, 6240C, 6240Y, 6242R, 6246R, 6248R, 6254, and 6258R, processor is supported with the condition that the following configuration requirements are met: <ul> <li>No system fan is failed.</li> <li>Only four SAS/SATA/NVMe drives are installed in drive bays 6–9.</li> <li>Rear hot-swap drive assembly is not installed.</li> <li>MVMe PCle flash adapter is not installed.</li> <li>GPU is not installed.</li> </ul> </li> <li>Figure 6. Front view of server models installed with Intel Xeon 6154, 6254 and 6240Y processor</li> </ul>

# Particulate contamination

**Attention:** Airborne particulates (including metal flakes or particles) and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the device that is described in this document.

Risks that are posed by the presence of excessive particulate levels or concentrations of harmful gases include damage that might cause the device to malfunction or cease functioning altogether. This specification sets forth limits for particulates and gases that are intended to avoid such damage. The limits must not be viewed or used as definitive limits, because numerous other factors, such as temperature or moisture content of the air, can influence the impact of particulates or environmental corrosives and gaseous contaminant transfer. In the absence of specific limits that are set forth in this document, you must implement practices that maintain particulate and gas levels that are consistent with the protection of human health and safety. If Lenovo determines that the levels of particulates or gases in your environment have caused damage to the device, Lenovo may condition provision of repair or replacement of devices or parts on implementation of appropriate remedial measures to mitigate such environmental contamination. Implementation of such remedial measures is a customer responsibility.

Table 2. Limits for particulates and gases

Contaminant	Limits
Reactive gases	Severity level G1 as per ANSI/ISA 71.04-1985 <sup>1</sup> :
	• The copper reactivity level shall be less than 200 Angstroms per month (Å/month $\approx$ 0.0035 $\mu g/$ cm²-hour weight gain).²
	• The silver reactivity level shall be less than 200 Angstroms per month (Å/month $\approx$ 0.0035 µg/ cm²-hour weight gain). <sup>3</sup>
	• The reactive monitoring of gaseous corrosivity must be conducted approximately 5 cm (2 in.) in front of the rack on the air inlet side at one-quarter and three-quarter frame height off the floor or where the air velocity is much higher.
Airborne particulates	Data centers must meet the cleanliness level of ISO 14644-1 class 8.
	For data centers without airside economizer, the ISO 14644-1 class 8 cleanliness might be met by choosing one of the following filtration methods:
	The room air might be continuously filtered with MERV 8 filters.
	• Air entering a data center might be filtered with MERV 11 or preferably MERV 13 filters.
	For data centers with airside economizers, the choice of filters to achieve ISO class 8 cleanliness depends on the specific conditions present at that data center.
	<ul> <li>The deliquescent relative humidity of the particulate contamination should be more than 60% RH.<sup>4</sup></li> </ul>
	• Data centers must be free of zinc whiskers. <sup>5</sup>
<sup>1</sup> ANSI/ISA-71.0 contaminants. I	04-1985. Environmental conditions for process measurement and control systems: Airborne nstrument Society of America, Research Triangle Park, North Carolina, U.S.A.
<sup>2</sup> The derivation product in Å/mo	of the equivalence between the rate of copper corrosion growth in the thickness of the corrosion onth and the rate of weight gain assumes that Cu <sub>2</sub> S and Cu <sub>2</sub> O grow in equal proportions.
<sup>3</sup> The derivation product in Å/mo	of the equivalence between the rate of silver corrosion growth in the thickness of the corrosion onth and the rate of weight gain assumes that Ag2S is the only corrosion product.
<sup>4</sup> The deliquesc enough water to	ent relative humidity of particulate contamination is the relative humidity at which the dust absorbs b become wet and promote ionic conduction.
<sup>5</sup> Surface debris electrically cond reveals no zinc	is randomly collected from 10 areas of the data center on a 1.5 cm diameter disk of sticky ductive tape on a metal stub. If examination of the sticky tape in a scanning electron microscope whiskers, the data center is considered free of zinc whiskers.

# **Management offerings**

The XClarity portfolio and other system management offerings described in this section are available to help you manage the servers more conveniently and efficiently.

#### Overview

Offerings	Description			
	Baseboard management controller (BMC).			
	Consolidates the service processor functionality, Super I/O, video controller, and remote presence capabilities into a single chip on the server system board.			
	Interface			
	CLI application			
Lenovo XClarity Controller	Web GUI interface			
	Mobile application			
	REST API			
	Usage and downloads			
	http://sysmgt.lenovofiles.com/help/topic/com.lenovo.systems.management.xcc.doc/ product_page.html			
	Centralized interface for multi-server management.			
	Interface			
	GUI application			
	Mobile application			
Lenovo XClarity Administrator	Web interface			
	REST API			
	Usage and downloads			
	http://sysmgt.lenovofiles.com/help/topic/com.lenovo.lxca.doc/aug_product_page.html			
	Portable and light toolset for server configuration, data collection, and firmware updates. Suitable both for single-server or multi-server management contexts.			
	Interface			
Lanava VClarity Ecoantiala	OneCLI: CLI application			
toolset	Bootable Media Creator: CLI application, GUI application			
	UpdateXpress: GUI application			
	Usage and downloads			
	http://sysmgt.lenovofiles.com/help/topic/xclarity_essentials/overview.html			
	UEFI-based GUI tool on a single server that can simplify management tasks.			
	Interface			
Lanava VClarity Dravisianing	Web interface (BMC remote access)			
Manager	GUI application			
	Usage and downloads			
	https://sysmgt.lenovofiles.com/help/topic/lxpm_frontend/lxpm_about.html			

Offerings	Description
	Series of applications that can integrate management features of Lenovo XClarity Administrator and your server with software used in a certain deployment infrastructure, such as VMware vCenter, Microsoft Admin Center, or Microsoft System Center.
Lenovo XClarity Integrator	Interface
	GUI application
	Usage and downloads
	https://sysmgt.lenovofiles.com/help/topic/lxci/lxci_product_page.html
	Application that can manage and monitor server power and temperature.
	Interface
Lenovo XClarity Energy	GUI application
Manager	Web Interface
	Usage and downloads
	https://datacentersupport.lenovo.com/solutions/Invo-Ixem
	Application that supports power consumption planning for a server or rack.
	Interface
Lenovo Capacity Planner	GUI application
	Web Interface
	Usage and downloads
	https://datacentersupport.lenovo.com/solutions/Invo-Icp

#### Functions

			Functions						
(	Offerings	Multi- system mgmt	OS deploy- ment	System configu- ration	Firm- ware up- dates <sup>1</sup>	Event- s/alert moni- toring	Inven- tory/ logs	Pow- er mgmt	Power planning
Lenovo XC	Clarity Controller			$\checkmark$	$\sqrt{2}$	$\checkmark$	$\sqrt{4}$		
Lenovo XC Administra	Clarity ator	$\checkmark$	$\checkmark$	$\checkmark$	$\sqrt{2}$	$\checkmark$	$\sqrt{4}$		
Lenovo	OneCLI	$\checkmark$		$\checkmark$	$\sqrt{2}$	$\checkmark$	$\sqrt{4}$		
XClarity Essen- tials	Bootable Media Creator			$\checkmark$	$\sqrt{2}$		$\sqrt{4}$		
toolset	UpdateXpress			$\checkmark$	$\sqrt{2}$				
Lenovo XC Manager	Clarity Provisioning		$\checkmark$	$\checkmark$	$\sqrt{3}$		$\sqrt{5}$		
Lenovo XC	Clarity Integrator	$\checkmark$	$\sqrt{6}$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\sqrt{7}$	

	Functions							
Offerings	Multi- system mgmt	OS deploy- ment	System configu- ration	Firm- ware up- dates <sup>1</sup>	Event- s/alert moni- toring	Inven- tory/ logs	Pow- er mgmt	Power planning
Lenovo XClarity Energy Manager	$\checkmark$				$\checkmark$		$\checkmark$	
Lenovo Capacity Planner								√8

#### Notes:

- 1. Most options can be updated through the Lenovo tools. Some options, such as GPU firmware or Omni-Path firmware, require the use of supplier tools.
- 2. The server UEFI settings for option ROM must be set to **Auto** or **UEFI** to update firmware using Lenovo XClarity Administrator, Lenovo XClarity Essentials, or Lenovo XClarity Controller.
- 3. Firmware updates are limited to Lenovo XClarity Provisioning Manager, Lenovo XClarity Controller, and UEFI updates only. Firmware updates for optional devices, such as adapters, are not supported.
- 4. The server UEFI settings for option ROM must be set to **Auto** or **UEFI** for detailed adapter card information, such as model name and firmware levels, to be displayed in Lenovo XClarity Administrator, Lenovo XClarity Controller, or Lenovo XClarity Essentials.
- 5. Limited inventory.
- 6. The Lenovo XClarity Integrator deployment check for System Center Configuration Manager (SCCM) supports Windows operating system deployment.
- 7. Power management function is supported only by Lenovo XClarity Integrator for VMware vCenter.
- 8. It is highly recommended that you check the power summary data for your server using Lenovo Capacity Planner before purchasing any new parts.

# Chapter 2. Server components

Use the information in this section to learn about each of the components associated with your server.

# **Front view**

The front view of the server varies by model. Depending on the model, your server might look slightly different from the illustrations in this topic.



Figure 7. Front view of server models with four 3.5-inch drive bays



Figure 8. Front view of server models with eight 2.5-inch drive bays



Figure 9. Front view of server models with ten 2.5-inch drive bays

Table 3.	Components	on the	front of	the server

VGA connector (available on some models)	2 Pull-out information tab
XClarity Controller USB connector	4 USB 3.0 connector
Operator information panel	8 Rack latch (right)

Table 3. Components on the front of the server (continued)

T Hot-swap drive bays	Drive status LED (yellow)
9 Drive activity LED (green)	10 Rack latch (left)

#### VGA connector (available on some models)

Used to attach a high-performance monitor, a direct-drive monitor, or other devices that use a VGA connector.

#### 2 Pull-out information tab

The XClarity Controller network access label is attached on the pull-out information tab.

#### **B** XClarity Controller USB connector

Depending on the setting, this connector supports USB 2.0 function, XClarity Controller management function, or both.

- If the connector is set for USB 2.0 function, you can attach a device that requires a USB 2.0 connection, such as a keyboard, a mouse, or a USB storage device.
- If the connector is set for XClarity Controller management function, you can attach a mobile device installed with the application to run XClarity Controller event logs.
- If the connector is set to have both functions, you can press the ID button for three seconds to switch between the two functions.

For more information, see "Set the network connection for the Lenovo XClarity Controller" on page 123.

#### 4 USB 3.0 connector

Attach a USB-compatible device, such as a USB keyboard, USB mouse, or USB storage device.

#### Operator information panel

For information about the controls and status LEDs on the operator information panel, see "Operator information panel" on page 21.

#### 6 10 Rack latches

If your server is installed in a rack, you can use the rack latches to help you slide the server out of the rack. You also can use the rack latches and screws to secure the server in the rack so that the server cannot slide out, especially in vibration-prone areas. For more information, refer to the *Rack Installation Guide* that comes with your rail kit.

#### 7 Hot-swap drive bays

The number of the installed drives in your server varies by model. When you install drives, follow the order of the drive bay numbers.

The EMI integrity and cooling of the server are protected by having all drive bays occupied. The vacant drive bays must be occupied by drive fillers.

#### 8 Drive status LED

#### Drive activity LED

Each hot-swap drive has two LEDs.

Drive LED	Status	Description	
8 Drive status LED (right)	Solid yellow	The drive has an error.	
	Blinking yellow (blinking slowly, about one flash per second)	The drive is being rebuilt.	
	Blinking yellow (blinking rapidly, about four flashes per second)	The RAID adapter is locating the drive.	
9 Drive activity LED (left)	Solid green	The drive is powered but not active.	
	Blinking green	The drive is active.	

# **Operator information panel**

The operator information panel of the server provides controls and LEDs.

The following illustration shows the operator information panel of the server.



Figure 10. Operator information panel

Table 4. Components on the operator information panel

Power button with power status LED	2 Network activity LED
System ID button with system ID LED	4 System error LED

#### Power button with power status LED

You can press the power button to power on the server when you finish setting up the server. You also can hold the power button for several seconds to power off the server if you cannot shut down the server from the operating system. The power status LED helps you to determine the current power status.

Status	Color	Description
Solid on	Green	The server is on and running.
Slow blinking (about one flash per second)	Green	The server is off and is ready to be powered on (standby state).
Fast blinking (about four flashes per second)	Green	The server is off, but the XCIarity Controller is initializing, and the server is not ready to be powered on.
Off	None	There is no ac power applied to the server.

#### Network activity LED

The network activity LED on the operator information panel helps you identify the network connectivity and activity.

Status	Color	Description
On	Green	The server is connected to a network.
Blinking	Green	The network is connected and active.
Off	None	The server is disconnected from the network.

Compatibility of the NIC adapter and the network activity LED:

NIC adapter	Network activity LED
LOM adapter	Support
ML2 NIC adapter	Support
PCIe NIC adapter	Not support

#### System ID button with system ID LED

Use this system ID button and the blue system ID LED to visually locate the server. A system ID LED is also located on the rear of the server. Each time you press the system ID button, the state of both the system ID LEDs changes. The LEDs can be changed to on, blinking, or off. You can also use the Lenovo XClarity Controller or a remote management program to change the state of the system ID LEDs to assist in visually locating the server among other servers.

If the XClarity Controller USB connector is set to have both the USB 2.0 function and XClarity Controller management function, you can press the system ID button for three seconds to switch between the two functions.

#### A System error LED

The system error LED helps you to determine if there are any system errors.

Status	Color	Description	Action	
On	YellowAn error has been detected on the server. Causes might include but not limited to the following errors:Check the event log to detected cause of the error.• The temperature of the server reached the non-critical temperature threshold.Check the event log to detected cause of the error.	Check the event log to determine the exact cause of the error. For information about troubleshooting, see		
		The temperature of the server reached the non-critical temperature threshold.	Chapter 5 "Resolving installation issues" on page 139.	
	<ul> <li>The voltage of the server reached the non-critical voltage threshold.</li> </ul>			
		• A fan has been detected to be running at low speed.		
		A hot-swap fan has been removed.		
		The power supply has a critical error.		
		• The power supply is not connected to the power.		
Off	None	The server is off or the server is on and is working correctly.	None.	

### **Rear view**

The rear of the server provides access to several connectors and components, including the power supplies, PCIe adapters, hot-swap drive bays, serial port, and Ethernet connectors.

- "Rear view of server models with three PCIe slots" on page 23
- "Rear view of server models with two PCIe slots" on page 24
- "Rear view of server models with two hot-swap drive bays and one PCIe slot" on page 26

#### Rear view of server models with three PCIe slots

The following illustration shows the rear view of server models with three PCIe slots. Depending on the model, your server might look slightly different from the illustration below.



Figure 11. Rear view of server models with three PCIe slots

Table 5. Components on the rear of the server

PCIe slot 1 on riser 1 assembly	PCIe slot 2 on riser 1 assembly	
PCIe slot 3 on riser 2 assembly	Power supply 1	
Power supply 2 (available on some models)	NMI button	
TUSB 3.0 connectors	8 VGA connector	
XClarity Controller network connector	<b>10</b> Ethernet connectors on LOM adapter (available on some models)	

#### **1 2** PCIe slots on riser 1 assembly

Your server supports three types of riser cards for riser 1 assembly.

- Type 1
  - Slot 1: PCIe x16 (x8, x4, x1), low-profile
  - Slot 2: PCIe x16 (x16, x8, x4, x1), low-profile
- Type 2
  - Slot 1: ML2 x8 (x8, x4, x1), low-profile
  - Slot 2: PCIe x16 (x16, x8, x4, x1), low-profile
- Type 3
  - Slot 1: ML2 x16 (x16, x8, x4, x1), low-profile
  - Slot 2: PCIe x16 (x8, x4, x1), low-profile

#### B PCle slot on riser 2 assembly

Slot 3: PCle x16 (x16, x8, x4, x1), low-profile

Note: PCIe slot 3 is supported only when two processors are installed.

#### 4 Power supply 1

#### S Power supply 2 (available on some models)

The hot-swap redundant power supplies help you avoid significant interruption to the operation of the system when a power supply fails. You can purchase a power supply option from Lenovo and install the power supply to provide power redundancy without turning off the server.

On each power supply, there are three status LEDs near the power cord connector. For information about the LEDs, see "Rear view LEDs" on page 28.

#### 6 NMI button

Press this button to force a nonmaskable interrupt (NMI) to the processor. By this way, you can make the operating system halt (such as Windows Blue Screen of Death) and take a memory dump. You might have to use a pen or the end of a straightened paper clip to press the button.

#### **7 USB 3.0 connectors (2)**

Used to attach a device that requires a USB 2.0 or 3.0 connection, such as a USB keyboard, USB mouse, or USB storage device.

#### 8 VGA connector

Used to attach a high-performance monitor, a direct-drive monitor, or other devices that use a VGA connector.

#### S XClarity Controller network connector

Used to attach an Ethernet cable to manage the system using XClarity Controller.

#### 10 Ethernet connectors on LOM adapter (available on some models)

The LOM adapter provides two or four extra Ethernet connectors for network connections.

The leftmost Ethernet connector on the LOM adapter can be set as XClarity Controller network connector. To set the Ethernet connector as XClarity Controller network connector, start Setup utility, go to **BMC Settings** → **Network Settings** → **Network Interface Port** and select **Shared**. Then, go to **Shared NIC on** and select **PHY Card**.

#### Rear view of server models with two PCIe slots

The following illustration shows the rear view of the server models with two PCIe slots. Depending on the model, your server might look slightly different from the illustration below.





Table 6. Components on the rear of the server

PCIe slot 1 on riser 1 assembly	2 PCIe slot 2 on riser 1 assembly
Power supply 1	4 Power supply 2 (available on some models)
S NMI button	لا USB 3.0 connectors

Table 6. Components on the rear of the server (continued)

7 VGA connector	3 XClarity Controller network connector
Ethernet connectors on LOM adapter (available on some models)	

#### **1** PCIe slots on riser 1 assembly

Your server supports three types of riser cards for riser 1 assembly.

- Type 1
  - Slot 1: PCIe x16 (x8, x4, x1), low-profile
  - Slot 2: PCIe x16 (x16, x8, x4, x1), full-height, half-length
- Type 2
  - Slot 1: ML2 x8 (x8, x4, x1), low-profile
  - Slot 2: PCIe x16 (x16, x8, x4, x1), full-height, half-length
- Type 3
  - Slot 1: ML2 x16 (x16, x8, x4, x1), low-profile
  - Slot 2: PCIe x16 (x8, x4, x1), full-height, half-length

#### B Power supply 1

#### Power supply 2 (available on some models)

The hot-swap redundant power supplies help you avoid significant interruption to the operation of the system when a power supply fails. You can purchase a power supply option from Lenovo and install the power supply to provide power redundancy without turning off the server.

On each power supply, there are three status LEDs near the power cord connector. For information about the LEDs, see "Rear view LEDs" on page 28.

#### 5 NMI button

Press this button to force a nonmaskable interrupt (NMI) to the processor. By this way, you can make the operating system halt (such as Windows Blue Screen of Death) and take a memory dump. You might have to use a pen or the end of a straightened paper clip to press the button.

#### USB 3.0 connectors (2)

Used to attach a device that requires a USB 2.0 or 3.0 connection, such as a USB keyboard, USB mouse, or USB storage device.

#### VGA connector

Used to attach a high-performance monitor, a direct-drive monitor, or other devices that use a VGA connector.

#### **3** XClarity Controller network connector

Used to attach an Ethernet cable to manage the system using XClarity Controller.

#### Ethernet connectors on LOM adapter (available on some models)

The LOM adapter provides two or four extra Ethernet connectors for network connections.

The leftmost Ethernet connector on the LOM adapter can be set as XClarity Controller network connector. To set the Ethernet connector as XClarity Controller network connector, start Setup utility, go to **BMC Settings** → **Network Settings** → **Network Interface Port** and select **Shared**. Then, go to **Shared NIC on** and select **PHY Card**.

#### Rear view of server models with two hot-swap drive bays and one PCIe slot

The following illustration shows the rear view of the server models with two hot-swap drive bays and one PCIe slot. Depending on the model, your server might look slightly different from the illustration below.



Figure 13. Rear view of server models with two hot-swap drive bays and one PCIe slot

Table 7. Components on the rear of the server

Rear 2.5-inch drive bays	2 PCIe slot 3
B Power supply 1	Power supply 2 (available on some models)
5 NMI button	usb 3.0 connectors کا
VGA connector	8 XClarity Controller network connector
Ethernet connectors on LOM adapter (available on some models)	

#### Rear 2.5-inch drive bays

Used to install two 2.5-inch hot-swap drives on the rear of the server.

The number of the installed drives in your server varies by model. When you install drives, follow the order of the drive bay numbers.

The EMI integrity and cooling of the server are protected by having all drive bays occupied. The vacant drive bays must be occupied by drive bay fillers or drive fillers.

#### 2 PCIe slot 3

Slot 3: PCle x16 (x16, x8, x4, x1), low-profile

Note: PCle slot 3 is supported only when two processors are installed.

#### B Power supply 1

#### Power supply 2 (available on some models)

The hot-swap redundant power supplies help you avoid significant interruption to the operation of the system when a power supply fails. You can purchase a power supply option from Lenovo and install the power supply to provide power redundancy without turning off the server.

On each power supply, there are three status LEDs near the power cord connector. For information about the LEDs, see "Rear view LEDs" on page 28.

#### 5 NMI button

Press this button to force a nonmaskable interrupt (NMI) to the processor. By this way, you can make the operating system halt (such as Windows Blue Screen of Death) and take a memory dump. You might have to use a pen or the end of a straightened paper clip to press the button.

#### USB 3.0 connectors (2)

Used to attach a device that requires a USB 2.0 or 3.0 connection, such as a USB keyboard, USB mouse, or USB storage device.

#### VGA connector

Used to attach a high-performance monitor, a direct-drive monitor, or other devices that use a VGA connector.

#### **3** XClarity Controller network connector

Used to attach an Ethernet cable to manage the system using XClarity Controller.

#### Ethernet connectors on LOM adapter (available on some models)

The LOM adapter provides two or four extra Ethernet connectors for network connections.

The leftmost Ethernet connector on the LOM adapter can be set as XClarity Controller network connector. To set the Ethernet connector as XClarity Controller network connector, start Setup utility, go to **BMC Settings**  $\rightarrow$  **Network Settings**  $\rightarrow$  **Network Interface Port** and select **Shared**. Then, go to **Shared NIC on** and select **PHY Card**.



Figure 14. Rear view of server models with a shipping bracket

#### Shipping bracket (available on some models)

For server models with two hot-swap drive bays in the rear, if the server is installed in a rack and shipped to you, the server comes with a shipping bracket installed.

#### Attention:

- Before turning on the server, ensure that you remove the shipping bracket.
- For server models with two hot-swap drive bays in the rear, if the server is installed in a rack for shipping, be sure to install the shipping bracket.

To remove the shipping bracket, hold the two handles **1** and remove the shipping bracket from the server.



Figure 15. Shipping bracket removal

To install the shipping bracket, align the two handles **1** with the system error LED hole and system ID LED hole and insert the shipping bracket into the rear of the server until it is firmly installed.





# **Rear view LEDs**

The rear of the server provides system ID LED, system error LED, Ethernet LEDs, and power supply LEDs.

The following illustration shows the LEDs on the rear view of server models with three PCIe slots. The LEDs on the rear view of other server models are the same.



#### Figure 17. Rear view LEDs

Table 8. LEDs on the rear view of the server

Ethernet link LED	Ethernet activity LED
Power input LED	4 Power output LED
Power supply error LED	System error LED
System ID LED	

# Ethernet link LED Ethernet activity LED

The XClarity Controller network connector has two status LEDs.

Ethernet status LED	Color	Status	Description
1 Ethernet link LED	Green	On	Network link is established.
	None	Off	Network link is disconnected.
2 Ethernet activity LED	Green	Blinking	Network link is connected and active.
	None	Off	The server is disconnected from a LAN.

#### **B 4 5** Power supply LEDs

Each hot-swap power supply has three status LEDs.

LED	Description
I Power input LED	<ul><li>Green: The power supply is connected to the ac power source.</li><li>Off: The power supply is disconnected from the ac power source or a power problem occurs.</li></ul>
Power output LED	<ul> <li>Green: The server is on and the power supply is working normally.</li> <li>Blinking green: The power supply is in the zero-output mode (standby). When the server power load is low, one of the installed power supplies enters into the standby state while the other one delivers the entire load. When the power load increases, the standby power supply will switch to active state to provide sufficient power to the system.</li> <li>To disable zero-output mode, start the Setup utility, go to System Settings → Power → Zero Output and select Disable. If you disable the zero-out mode, both power supplies will be in the active state.</li> <li>Off: The server is powered off, or the power supply is not working properly. If the server is powered on but the LED is off, replace the power supply.</li> </ul>
S Power supply error LED	<ul><li>Yellow: The power supply has failed. To resolve the issue, replace the power supply.</li><li>Off: The power supply is working normally.</li></ul>

#### System error LED

The system error LED helps you to determine if there are any system errors. For details, see "System error LED" on page 22.

#### System ID LED

The blue system ID LED helps you to visually locate the server. A system ID LED is also located on the front of the server. Each time you press the system ID button, the state of both the system ID LEDs changes. The LEDs can be changed to on, blinking, or off. You can also use the Lenovo XClarity Controller or a remote management program to change the state of the system ID LEDs to assist in visually locating the server among other servers.

# System board components

The illustration in this section shows the component locations on the system board.



Figure 18.	System	board	components
------------	--------	-------	------------

Serial-port-module connector	2 RAID adapter slot (slot 4)	
BIOS ROM programming connector	A Riser 1 slot	
LOM adapter connector	XCC ROM programming connector	
Front USB connector	Operator-information-panel connector	
P Rear-backplane power connector	10 Front VGA connector	

TCM <sup>1</sup> /TPM <sup>2</sup> connector (for Chinese Mainland only)	12 Processor 1 socket
B Memory module slots (24)	System fan 1 connector
System fan 2 connector	<b>15</b> System fan 3 connector
System fan 4 connector	18 System fan 5 connector
19 System fan 6 connector	20 System fan 7 connector
21 Processor 2 socket	22 Front-backplane power connector
23 NVMe 2-3 connector	24 NVMe 0-1 connector
25 CMOS battery	25 M.2 module slot (SATA/PCle slot 5)
27 Riser 2 slot	

#### Notes:

- <sup>1</sup> Trusted Cryptography Module
- <sup>2</sup> Trusted Platform Module

### Internal cable routing

Some of the components in the server have internal cables and cable connectors.

To connect cables, observe the following guidelines:

- Power off the server before you connect or disconnect any internal cables.
- See the documentation that comes with any external devices for additional cabling instructions. It might be easier for you to route cables before you connect the devices to the server.
- Cable identifiers of some cables are printed on the cables that come with the server and optional devices. Use these identifiers to connect the cables to the correct connectors.
- Ensure that the relevant cables pass through the cable clips.
- Oversubscription may exist in some configurations installed with NVMe 810-4P/1611-8P switch adapters.

#### Notes:

- Oversubscription occurs when the system supports NVMe 810-4P , NVMe 1611-8P, and NVMe 1611-8P switch adapters.
- Disengage all latches, release tabs, or locks on cable connectors when you disconnect cables from the system board. Failing to release them before removing the cables will damage the cable sockets on the system board, which are fragile. Any damage to the cable sockets might require replacing the system board.



# Server models with four 3.5-inch SAS/SATA drives

Use this section to understand the connectors on the backplane and internal cable routing for server models with four 3.5-inch SAS/SATA drives.



Figure 19. Connectors on the backplane for four 3.5-inch SAS/SATA drives

1 SAS 0 connector

2 Power connector
#### Server models with four 3.5-inch SAS/SATA drives and rear drive assembly

**Note:** The cable routing illustration is based on the scenario that the rear hot-swap drive assembly is installed. Depending on the model, the rear hot-swap drive assembly might not be available on your server.



Figure 20. Cable routing for server models with four 3.5-inch SAS/SATA drives and rear drive assembly

Cable	From	То
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board
SAS signal cable for front backplane	SAS 0 connector on the front backplane	C0 connector on the RAID adapter
SAS signal cable for rear backplane	SAS connector on the rear backplane	C1 connector on the RAID adapter
Power cable for rear backplane	Power connector on the rear backplane	Rear-backplane power connector on the system board

Server models with four 3.5-inch SAS/SATA drives and a full-height half-length GPU Note: Cable II is only available for P4000/RTX4000 GPU.



Figure 21. Cable routing for server models with four 3.5-inch SAS/SATA drives and a full-height half-length GPU

Cable	From	То
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board
SAS signal cable for front backplane	SAS 0 connector on the front backplane	C0 connector on the RAID adapter
GPU power cable (only available for P4000/RTX4000 GPU)	Power connector on P4000/ RTX4000 GPU	Rear-backplane power connector on the system board

## Server models with four 3.5-inch SAS/SATA/NVMe drives

Use this section to understand the connectors on the backplane and internal cable routing for server models with four 3.5-inch SAS/SATA/NVMe drives.



Figure 22. Connectors on the backplane for four 3.5-inch SAS/SATA/NVMe drives

1 NVMe 1 connector

3 NVMe 0 connector

2 SAS 0 connector

4 Power connector

#### Server models with four 3.5-inch SAS/SATA/NVMe drives and rear drive assembly

**Note:** The cable routing illustration is based on the scenario that the rear hot-swap drive assembly is installed. Depending on the model, the rear hot-swap drive assembly might not be available on your server.



Figure 23. Cable routing for server models with four 3.5-inch SAS/SATA/NVMe drives and rear drive assembly

Cable	From	То
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board
2 SAS signal cable for front backplane	SAS 0 connector on the front backplane	C0 connector on the RAID adapter
NVMe signal cable for front backplane	NVMe 0 and NVMe 1 connectors on the front backplane	NVMe 0-1 connector and NVMe 2-3 connector on the system board
SAS signal cable for rear backplane	SAS connector on the rear backplane	C1 connector on the RAID adapter
Power cable for rear backplane	Power connector on the rear backplane	Rear-backplane power connector on the system board

Server models with four 3.5-inch SAS/SATA/NVMe drives and a full-height half-length GPU Note: Cable I is only available for P4000/RTX4000 GPU.



Figure 24. Cable routing for server models with four 3.5-inch SAS/SATA/NVMe drives and a full-height half-length GPU

Cable	From	То
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board
NVMe signal cable for front backplane	NVMe 0 and NVMe 1 connectors on the front backplane	NVMe 0-1 connector and NVMe 2-3 connector on the system board
SAS signal cable for front backplane	SAS 0 connector on the front backplane	C0 connector on the RAID adapter
GPU power cable (only available for P4000/ RTX4000 GPU)	Power connector on P4000/ RTX4000 GPU	Rear-backplane power connector on the system board

### Server models with four 3.5-inch SAS/SATA/NVMe drives and one 1610-4P NVMe switch adapter

Note: This configuration is supported in server models installed with one processor.



Figure 25. Cable routing for server models with four 3.5-inch SAS/SATA/NVMe drives and one 1610-4P NVMe switch adapter in PCIe slot 2

Cable	From	То
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board
SAS signal cable for front backplane	SAS 0 connector on the front backplane	C0 connector on the RAID adapter
NVMe signal cable for front backplane	NVMe 0 and NVMe 1 connectors on the front backplane	C0, C1, C2, and C3 connectors on the NVMe switch adapter installed in PCIe slot 2

## Server models with eight 2.5-inch SAS/SATA drives

Use this section to understand the connectors on the backplane and internal cable routing for server models with eight 2.5-inch SAS/SATA drives.



Figure 26. Connectors on the backplane for eight 2.5-inch SAS/SATA drives

1 SAS 1 connector

2 Power connector

3 SAS 0 connector

### Server models with eight 2.5-inch SAS/SATA drives and one 8i HBA/RAID adapter

- Gen 4 HBA/RAID adapter cannot be installed in the inner raid adapter slot.
- \*When Gen 4 HBA/RAID adapter is installed, ensure you use Gen 4 SAS signal cable (ThinkSystem SR530/SR570/SR630 2.5" SAS/SATA 8-Bay X40 RAID Cable Kit).



Figure 27. Cable routing for server models with eight 2.5-inch SAS/SATA drives and one 8i HBA/RAID adapter

Cable	From	То
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board
2 SAS signal cable for front	SAS 0 and SAS 1 connectors on	8i HBA/RAID adapter
backplane*	the front backplane	• Gen 3: C0C1
		• Gen 4: C0

# Server models with eight 2.5-inch SAS/SATA drives, one 16i HBA/RAID adapter, and rear drive assembly

- The cable routing illustration is based on the scenario that the rear hot-swap drive assembly is installed. Depending on the model, the rear hot-swap drive assembly might not be available on your server.
- Gen 4 HBA/RAID adapter cannot be installed in the inner raid adapter slot.
- \*When Gen 4 HBA/RAID adapter is installed, ensure you use Gen 4 SAS signal cable (ThinkSystem SR570/SR630 2.5" AnyBay 10-Bay X40 RAID Cable Kit).



Figure 28. Cable routing for server models with eight 2.5-inch SAS/SATA drives, one 16i HBA/RAID adapter, and rear drive assembly

Cable	From	То
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board
SAS signal cable for front	SAS signal cable for front SAS 0 and SAS 1 connectors on the	
backplane*	front backplane	• Gen 3: C0C1
		• Gen 4: C0
SAS signal cable for rear	SAS connector on the rear backplane	16i HBA/RAID adapter
backplane*		• Gen 3: C2
		• Gen 4: C1
Power cable for rear backplane	Power connector on the rear backplane	Rear-backplane power connector on the system board

## Server models with eight 2.5-inch SAS/SATA drives and a full-height half-length GPU

Note: Cable II is only available for P4000/RTX4000 GPU.



Figure 29. Cable routing for server models with eight 2.5-inch SAS/SATA drives and a full-height half-length GPU

Cable	From	То
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board
2 SAS signal cable for front backplane	SAS 0 and SAS 1 connectors on the front backplane	C0 and C1 connectors on the RAID adapter
GPU power cable (only available for P4000/ RTX4000 GPU)	Power connector on P4000/RTX4000 GPU	Rear-backplane power connector on the system board

## Server models with ten 2.5-inch SAS/SATA/NVMe drives

Use this section to understand the connectors on the backplane and the internal cable routing for server models with ten 2.5-inch SAS/SATA/NVMe drives.



Figure 30. Connectors on the backplane for ten 2.5-inch SAS/SATA/NVMe drives

1 SAS 2 connector	2 SAS 1 connector	3 Power connector	4 SAS 0 connector
5 NVMe 1 connector	6 NVMe 0 connector	7 NVMe 3 connector	8 NVMe 2 connector

# Server models with six 2.5-inch SAS/SATA drives, four 2.5-inch SAS/SATA/NVMe drives, one 16i HBA/ RAID adapter, and rear drive assembly

- The cable routing illustration is based on the scenario that the rear hot-swap drive assembly is installed. Depending on the model, the rear hot-swap drive assembly might not be available on your server.
- NVMe drives are only supported in drive bays 6–9.
- Gen 4 HBA/RAID adapter cannot be installed in the inner raid adapter slot.
- \*When Gen 4 HBA/RAID adapter is installed, ensure you use Gen 4 SAS signal cable (ThinkSystem SR570/SR630 2.5" AnyBay 10-Bay X40 RAID Cable Kit).



Figure 31. Cable routing for server models with six 2.5-inch SAS/SATA drives, four 2.5-inch SAS/SATA/NVMe drives, one 16i HBA/RAID adapter, and rear drive assembly

Cable	From	То
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board
2 SAS signal cable for front	SAS 0, SAS 1, and SAS 2 connectors	16i HBA/RAID adapter
backplane*	on the front backplane	• Gen 3: C0C1C2
		• Gen 4: C0C1
Power cable for rear backplane	Power connector on the rear backplane	Rear-backplane power connector on the system board
SAS signal cable for rear	SAS connector on the rear backplane	16i HBA/RAID adapter
backplane*		• Gen 3: C3
		• Gen 4: C1
NVMe signal cable for front backplane	NVMe 0, NVMe 1, NVMe 2, and NVMe 3 connectors on the front backplane	NVMe 0-1 connector and NVMe 2-3 connector on the system board

# Server models with six 2.5-inch SAS/SATA drives, four 2.5-inch NVMe drives, and one 8i HBA/RAID adapter

- NVMe drives are only supported in drive bays 6–9.
- Gen 4 HBA/RAID adapter cannot be installed in the inner raid adapter slot.
- \*When Gen 4 HBA/RAID adapter is installed, ensure you use Gen 4 SAS signal cable (ThinkSystem SR530/SR570/SR630 2.5" SAS/SATA 8-Bay X40 RAID Cable Kit).



Figure 32. Cable routing for server models with six 2.5-inch SAS/SATA drives, four 2.5-inch NVMe drives, and one 8i HBA/RAID adapter

Cable	From	То
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board
2 SAS signal cable for front	SAS 0 and SAS 1 connectors on the	8i HBA/RAID adapter
backplane*	front backplane	• Gen 3: C0C1
		• Gen 4: C0
NVMe signal cable for front backplane	NVMe 0, NVMe 1, NVMe 2, and NVMe 3 connectors on the front backplane	NVMe 0-1 connector and NVMe 2-3 connector on the system board

# Server models with six 2.5-inch SAS/SATA drives, four 2.5-inch SAS/SATA/NVMe drives, and a full-height half-length GPU

- NVMe drives are only supported in drive bays 6–9.
- Cable **I** is only available for P4000/RTX4000 GPU.



Figure 33. Cable routing for server models with six 2.5-inch SAS/SATA drives, four 2.5-inch SAS/SATA/NVMe drives, and a full-height half-length GPU

Cable	From	То
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board
SAS signal cable for front backplane	SAS 0, SAS 1, and SAS 2 connectors on the front backplane	C0, C1, and C2 connectors on the RAID adapter
GPU power cable (only available for P4000/ RTX4000 GPU)	Power connector on P4000/RTX4000 GPU	Rear-backplane power connector on the system board
NVMe signal cable for front backplane	NVMe 0, NVMe 1, NVMe 2, and NVMe 3 connectors on the front backplane	NVMe 0-1 connector and NVMe 2-3 connector on the system board

# Server models with six 2.5-inch SAS/SATA drives, four 2.5-inch NVMe drives, one 8i HBA/RAID adapter, and one 1610-4P NVMe switch adapter

- NVMe drives are only supported in drive bays 6–9.
- This configuration is supported in server models installed with one processor.
- Gen 4 HBA/RAID adapter cannot be installed in the inner raid adapter slot.
- \*When Gen 4 HBA/RAID adapter is installed, ensure you use Gen 4 SAS signal cable (ThinkSystem SR530/SR570/SR630 2.5" SAS/SATA 8-Bay X40 RAID Cable Kit).



Figure 34. Cable routing for server models with six 2.5-inch SAS/SATA drives, four 2.5-inch NVMe drives, one 8i HBA/ RAID adapter, and one 1610-4P NVMe switch adapter in PCIe slot 2

Cable	From	То		
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board		
<b>2</b> SAS signal cable for front SAS 0 and SAS 1 connectors on the		8i HBA/RAID adapter		
backplane*	front backplane	• Gen 3: C0C1		
		• Gen 4: C0		
NVMe signal cable for front backplane	NVMe 0, NVMe 1, NVMe 2, and NVMe 3 connectors on the front backplane	C0, C1, C2, and C3 connectors on the NVMe switch adapter installed in PCIe slot 2		

# Server models with Intel Xeon 6154, 6254, and 6240Y processor, four 2.5-inch SAS/SATA/NVMe drives, and one 16i HBA/RAID adapter

- NVMe drives are only supported in drive bays 6-9.
- Gen 4 HBA/RAID adapter cannot be installed in the inner raid adapter slot.
- \*When Gen 4 HAB/RAID adapter is installed, ensure you use Gen 4 SAS signal cable (ThinkSystem SR570/SR630 2.5" AnyBay 10-Bay X40 RAID Cable Kit).



Figure 35. Cable routing for server models with Intel Xeon 6154, 6254, and 6240Y processor, four 2.5-inch SAS/SATA/ NVMe drives, and one 16i HBA/RAID adapter

Cable	From	То		
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board		
SAS signal cable for front backplane*	SAS 0, SAS 1, and SAS 2 connectors on the front backplane	<ul><li>16i HBA/RAID adapter</li><li>Gen 3: C0C1C2</li><li>Gen 4: C0C1</li></ul>		
NVMe signal cable for front backplane	NVMe 0, NVMe 1, NVMe 2, and NVMe 3 connectors on the front backplane	NVMe 0-1 connector and NVMe 2-3 connector on the system board		

# Server models with six 2.5-inch SAS/SATA drives, four 2.5-inch NVMe drives, one 16i HBA/RAID adapter, and one 1610-4P NVMe switch adapter

- NVMe drives are only supported in drive bays 6–9.
- This configuration is supported in server models installed with one processor.
- Gen 4 HBA/RAID adapter cannot be installed in the inner raid adapter slot.
- \*When Gen 4 HBA/RAID adapter is installed, ensure you use Gen 4 SAS signal cable (ThinkSystem SR570/SR630 2.5" AnyBay 10-Bay X40 RAID Cable Kit).



Figure 36. Cable routing for server models with six 2.5-inch SAS/SATA drives, four 2.5-inch NVMe drives, one 16i HBA/ RAID adapter, and one 1610-4P NVMe switch adapter in PCIe slot 2

Cable	From	То	
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board	
SAS signal cable for front	SAS 0, SAS 1 SAS 2 connectors on	16i HBA/RAID adapter	
backplane*	the front backplane	• Gen 3: C0C1C2	
		• Gen 4: C0C1	
NVMe signal cable for front backplane	NVMe 0, NVMe 1, NVMe 2, and NVMe 3 connectors on the front backplane	C0, C1, C2, and C3 connectors on the NVMe switch adapter installed in PCIe slot 2	

Server models with four 2.5-inch NVMe drives and no RAID adapter

Note: NVMe drives are only supported in drive bays 6–9.



Figure 37. Cable routing for server models with four 2.5-inch NVMe drives, and no RAID adapter

Cable	From	То	
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board	
NVMe signal cable for front backplane	NVMe 0, NVMe 1, NVMe 2, and NVMe 3 connectors on the front backplane	NVMe 0-1 connector and NVMe 2-3 connector on the system board	

## Server models with ten 2.5-inch NVMe drives

Use this section to understand the connectors on the backplane and the internal cable routing for server models with ten 2.5-inch NVMe drives.



Figure 38. Connectors on the backplane for ten 2.5-inch NVMe drives

- 0 NVMe 0 connector
- 4 NVMe 4 connector 5 NVMe 5 connector
- 8 NVMe 8 connector
- 9 NVMe 9 connector

NVMe 1 connector

- NVMe 2 connector
  NVMe 6 connector
  Power connector
- 3 NVMe 3 connector
- 7 NVMe 7 connector





Figure 39. Cable routing for server models with ten 2.5-inch NVMe drives, one 1610-4P NVMe switch adapter in PCIe slot 2, and one 1610-4P NVMe switch adapter in PCIe slot 3

Cable	From	То
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board
NVMe signal cable for front backplane	NVMe 0, NVMe 1, NVMe 2, and NVMe 3 connectors on the front backplane	NVMe 0-1 connector and NVMe 2-3 connector on the system board
NVMe signal cable for front backplane	NVMe 4, NVMe 5, NVMe 6, and NVMe 7 connectors on the front backplane	C0, C1, C2, and C3 connectors on the NVMe switch adapter installed in PCIe slot 3
4 NVMe signal cable for front backplane	NVMe 8 and NVMe 9 connectors on the front backplane	C0 and C1 connectors on the NVMe switch adapter installed in PCIe slot 2





Figure 40. Cable routing for server models with ten 2.5-inch NVMe drives, one 1610-4P NVMe switch adapter in PCIe slot 2, and one 810-4P NVMe switch adapter in the RAID adapter slot

Cable	From	То	
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board	
NVMe signal cable for front backplane	NVMe 0, NVMe 1, NVMe 2, and NVMe 3 connectors on the front backplane	NVMe 0-1 connector and NVMe 2-3 connector on the system board	
NVMe signal cable for front backplane	NVMe 4 and NVMe 5 connectors on the front backplane	C0, C1, C2, and C3 connectors on the NVMe switch adapter installed in the RAID adapter slot	
4 NVMe signal cable for front backplane	NVMe 6 and NVMe 7 connectors on the front backplane	C0 and C1 connectors on the NVMe switch adapter installed in PCIe slot 2	
S NVMe signal cable for front backplane	NVMe 8 and NVMe 9 connectors on the front backplane	C2 and C3 connectors on the NVMe switch adapter installed in PCIe slot 2	

Server model with ten 2.5-inch NVMe drives and one NVMe 1611-8P switch adapter in PCIe slot 2



Figure 41. Cable routing for server models with ten 2.5-inch NVMe drives and one NVMe 1611-8P switch adapter in PCIe slot 2

Cable	From	То	
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board	
2 NVMe signal cable for front backplane	NVMe 8 and NVMe 9 connectors on the front backplane	C2 and C3 connectors on the NVMe switch adapter installed in PCIe slot 2	
NVMe signal cable for front backplane	NVMe 4, NVMe 5, NVMe 6, and NVMe 7 connectors on the front backplane	C0 and C1 connectors on the NVMe switch adapter installed in PCIe slot 2	

Server models with eight 2.5-inch NVMe drives and one 810-4P NVMe switch adapter in the RAID adapter slot



Figure 42. Cable routing for server models with eight 2.5-inch NVMe drives and one 810-4P NVMe switch adapter in the RAID adapter slot

Cable	From	То	
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board	
NVMe signal cable for front backplane	NVMe 0, NVMe 1, NVMe 2, and NVMe 3 connectors on the front backplane	NVMe 0-1 connector and NVMe 2-3 connector on the system board	
NVMe signal cable for front backplane	NVMe 4 and NVMe 5 connectors on the front backplane	C0 and C1 connectors on the NVMe switch adapter installed in the RAID adapter slot	
NVMe signal cable for front backplane	NVMe 6 and NVMe 7 connectors on the front backplane	C2 and C3 connectors on the NVMe switch adapter installed in the RAID adapter slot	





Figure 43. Cable routing for server models with eight 2.5-inch NVMe drives, one 810-4P NVMe switch adapter in PCIe slot 1, and one 810-4P NVMe switch adapter in the RAID adapter slot

Cable	From	То	
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board	
NVMe signal cable for front backplane	NVMe 0, NVMe 1, NVMe 2, and NVMe 3NVMe 0-1 connector and NVMe 2-3connectors on the front backplaneconnector on the system board		
NVMe signal cable for front backplane	NVMe 4 and NVMe 5 connectors on the front backplane	C0, C1, C2, and C3 connectors on the NVMe switch adapter installed in the RAID adapter slot	
4 NVMe signal cable for front backplane	NVMe 6 and NVMe 7 connectors on the front backplane	C0, C1, C2, and C3 connectors on the NVMe switch adapter installed in PCIe slot 1	

Server models with eight 2.5-inch NVMe drives and one NVMe 1611-8P switch adapter in PCIe slot 2



Figure 44. Cable routing for server models with eight 2.5-inch NVMe drives and one NVMe 1611-8P switch adapter in PCIe slot 2

Cable	From	То	
Power cable for front backplane	Power connector on the front backplane	Front-backplane power connector on the system board	
NVMe signal cable for front backplane	NVMe 0, NVMe 1, NVMe 2, and NVMe 3 connectors on the front backplane	C2 and C3 connectors on the NVMe switch adapter installed in PCIe slot 2	
NVMe signal cable for front backplane	NVMe 4, NVMe 5, NVMe 6, and NVMe 7 connectors on the front backplane	C0 and C1 connectors on the NVMe switch adapter installed in PCIe slot 2	

## Parts list

Use the parts list to identify each of the components that are available for your server.

For more information about ordering the parts shown in Figure 45 "Server components" on page 58, go to:

http://datacentersupport.lenovo.com/us/en/products/servers/thinksystem/sr630/7x01/parts

**Note:** Depending on the model, your server might look slightly different from the illustration. Some of the components might not be available on your server.



Figure 45. Server components

The parts listed in the following table are identified as one of the following:

- Tier 1 customer replaceable unit (CRU): Replacement of Tier 1 CRUs is your responsibility. If Lenovo installs a Tier 1 CRU at your request with no service agreement, you will be charged for the installation.
- **Tier 2 customer replaceable unit (CRU):** You may install a Tier 2 CRU yourself or request Lenovo to install it, at no additional charge, under the type of warranty service that is designated for your server.
- Field replaceable unit (FRU): FRUs must be installed only by trained service technicians.
- **Consumable and Structural parts:** Purchase and replacement of consumable and structural parts (components, such as a cover or bezel) is your responsibility. If Lenovo acquires or installs a structural component at your request, you will be charged for the service.

Table 9. Parts list

Index	Description	Tier 1 CRU	Tier 2 CRU	FRU	Consumable and Structural parts
For mo	re information about ordering the parts shown in	Figure 45 "Serv	er components	" on pag	<mark>e 58</mark> , go to:
http://d	atacentersupport.lenovo.com/us/en/products/serv	ers/thinksystem/s	sr630/7x01/parts	;	
lt is hig before	hly recommended that you check the power sun purchasing any new parts.	nmary data for ye	our server using	Lenovo	Capacity Planner
1	Top cover	$\checkmark$			
2	Air baffle				$\checkmark$
3	RAID adapter on the system board	$\checkmark$			
4	LOM adapter	$\checkmark$			
5	Riser 1 bracket (two low-profile slots)	$\checkmark$			
6	Riser 2 bracket (one low-profile slot)	$\checkmark$			
7	Riser 1 bracket (one low-profile slot and one full-height half-length slot)	$\checkmark$			
8	Serial port module	$\checkmark$			
9	Riser card	$\checkmark$			
10	TCM/TPM adapter (only available in Chinese Mainland)			$\checkmark$	
11	System board			$\checkmark$	
12	M.2 retainer	$\checkmark$			
13	M.2 drive backplane	$\checkmark$			
14	M.2 drive	$\checkmark$			
15	RAID super capacitor module	$\checkmark$			
16	RAID super capacitor module holder				$\checkmark$
17	Rear hot-swap drive cage				$\checkmark$
18	Rear backplane	$\checkmark$			
19	Power supply	$\checkmark$			
20	Power supply filler				$\checkmark$
211	Chassis with four 3.5-inch drive bays Chassis with eight 2.5-inch drive bays Chassis with ten 2.5-inch drive bays			$\checkmark$	
22	PCle adapter	$\checkmark$			
23	Security bezel	√			
24	Front I/O assembly for server models with four 3.5-inch drive bays	$\checkmark$			
25	Front I/O assembly for server models with eight 2.5-inch drive bays	$\checkmark$			

Table 9.	Parts list	(continued)
----------	------------	-------------

Index	Description	Tier 1 CRU	Tier 2 CRU	FRU	Consumable and Structural parts
26	Front I/O assembly for server models with ten 2.5-inch drive bays	$\checkmark$			
27	2.5-inch drive filler				$\checkmark$
28	2.5-inch hot-swap drive	$\checkmark$			
29	3.5-inch drive filler				$\checkmark$
30	3.5-inch hot-swap drive	$\checkmark$			
31	System fan	$\checkmark$			
32	CMOS battery				$\checkmark$
33	Backplane for server models with ten 2.5- inch drive bays	$\checkmark$			
34	Backplane for server models with eight 2.5- inch drive bays	$\checkmark$			
35	Backplane for server models with four 3.5- inch drive bays	$\checkmark$			
36	Memory module (DCPMM module might look slightly different from the illustration.)	$\checkmark$			
37	Processor			$\checkmark$	
38	Heat sink			$\checkmark$	

## **Power cords**

Several power cords are available, depending on the country and region where the server is installed.

To view the power cords that are available for the server:

1. Go to:

#### http://dcsc.lenovo.com/#/

- 2. Click Preconfigured Model or Configure to order.
- 3. Enter the machine type and model for your server to display the configurator page.
- 4. Click **Power**  $\rightarrow$  **Power Cables** to see all line cords.

- For your safety, a power cord with a grounded attachment plug is provided to use with this product. To avoid electrical shock, always use the power cord and plug with a properly grounded outlet.
- Power cords for this product that are used in the United States and Canada are listed by Underwriter's Laboratories (UL) and certified by the Canadian Standards Association (CSA).
- For units intended to be operated at 115 volts: Use a UL-listed and CSA-certified cord set consisting of a minimum 18 AWG, Type SVT or SJT, three-conductor cord, a maximum of 15 feet in length and a parallel blade, grounding-type attachment plug rated 15 amperes, 125 volts.
- For units intended to be operated at 230 volts (U.S. use): Use a UL-listed and CSA-certified cord set consisting of a minimum 18 AWG, Type SVT or SJT, three-conductor cord, a maximum of 15 feet in length and a tandem blade, grounding-type attachment plug rated 15 amperes, 250 volts.
- For units intended to be operated at 230 volts (outside the U.S.): Use a cord set with a grounding-type attachment plug. The cord set should have the appropriate safety approvals for the country in which the equipment will be installed.
- Power cords for a specific country or region are usually available only in that country or region.

## Chapter 3. Server hardware setup

To set up the server, install any options that have been purchased, cable the server, configure and update the firmware, and install the operating system.

## Server setup checklist

Use the server setup checklist to ensure that you have performed all tasks that are required to set up your server.

The server setup procedure varies depending on the configuration of the server when it was delivered. In some cases, the server is fully configured and you just need to connect the server to the network and an ac power source, and then you can power on the server. In other cases, the server needs to have hardware options installed, requires hardware and firmware configuration, and requires an operating system to be installed.

The following steps describe the general procedure for setting up a server:

- 1. Unpack the server package. See "Server package contents" on page 2.
- 2. Set up the server hardware.
  - a. Install any required hardware or server options. See the related topics in "Install server hardware options" on page 67.
  - b. If necessary, install the server into a standard rack cabinet by using the rail kit shipped with the server. See the *Rack Installation Guide* that comes with optional rail kit.
  - c. Connect the Ethernet cables and power cords to the server. See "Rear view" on page 22 to locate the connectors. See "Cable the server" on page 120 for cabling best practices.
  - d. Power on the server. See "Power on the server" on page 120.

**Note:** You can access the management processor interface to configure the system without powering on the server. Whenever the server is connected to power, the management processor interface is available. For details about accessing the management server processor, see:

http://sysmgt.lenovofiles.com/help/topic/com.lenovo.systems.management.xcc.doc/dw1lm\_c\_chapter2\_ openingandusing.html

- e. Validate that the server hardware was set up successfully. See "Validate server setup" on page 121.
- 3. Configure the system.
  - a. Connect the Lenovo XClarity Controller to the management network. See "Set the network connection for the Lenovo XClarity Controller" on page 123.
  - b. Update the firmware for the server, if necessary. See "Update the firmware" on page 124.
  - c. Configure the firmware for the server. See "Configure the firmware" on page 127.

The following information is available for RAID configuration:

- https://lenovopress.com/lp0578-lenovo-raid-introduction
- https://lenovopress.com/lp0579-lenovo-raid-management-tools-and-resources
- d. Install the operating system. See "Deploy the operating system" on page 134.
- e. Back up the server configuration. See "Back up the server configuration" on page 135.
- f. Install the applications and programs for which the server is intended to be used.

## **Installation Guidelines**

Use the installation guidelines to install components in your server.

Before installing optional devices, read the following notices carefully:

**Attention:** Prevent exposure to static electricity, which might lead to system halt and loss of data, by keeping static-sensitive components in their static-protective packages until installation, and handling these devices with an electrostatic-discharge wrist strap or other grounding system.

- Read the safety information and guidelines to ensure that you work safely.
  - A complete list of safety information for all products is available at:
    - http://thinksystem.lenovofiles.com/help/topic/safety\_documentation/pdf\_files.html
  - The following guidelines are available as well: "Handling static-sensitive devices" on page 66 and "Working inside the server with the power on" on page 66.
- Make sure the components you are installing are supported by the server. For a list of supported optional components for the server, see <a href="https://static.lenovo.com/us/en/serverproven/index.shtml">https://static.lenovo.com/us/en/serverproven/index.shtml</a>.
- When you install a new server, download and apply the latest firmware. This will help ensure that any known issues are addressed, and that your server is ready to work with optimal performance. Go to ThinkSystem SR630 Drivers and Software to download firmware updates for your server.

**Important:** Some cluster solutions require specific code levels or coordinated code updates. If the component is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.

- It is good practice to make sure that the server is working correctly before you install an optional component.
- Keep the working area clean, and place removed components on a flat and smooth surface that does not shake or tilt.
- Do not attempt to lift an object that might be too heavy for you. If you have to lift a heavy object, read the following precautions carefully:
  - Make sure that you can stand steadily without slipping.
  - Distribute the weight of the object equally between your feet.
  - Use a slow lifting force. Never move suddenly or twist when you lift a heavy object.
  - To avoid straining the muscles in your back, lift by standing or by pushing up with your leg muscles.
- Make sure that you have an adequate number of properly grounded electrical outlets for the server, monitor, and other devices.
- Back up all important data before you make changes related to the disk drives.
- Have a small flat-blade screwdriver, a small Phillips screwdriver, and a T8 torx screwdriver available.
- To view the error LEDs on the system board and internal components, leave the power on.
- You do not have to turn off the server to remove or install hot-swap power supplies, hot-swap fans, or hotplug USB devices. However, you must turn off the server before you perform any steps that involve removing or installing adapter cables, and you must disconnect the power source from the server before you perform any steps that involve removing or installing a riser card.
- Blue on a component indicates touch points, where you can grip to remove a component from or install it in the server, open or close a latch, and so on.
- Orange on a component or an orange label on or near a component indicates that the component can be hot-swapped if the server and operating system support hot-swap capability, which means that you can remove or install the component while the server is still running. (Orange can also indicate touch points on

hot-swap components.) See the instructions for removing or installing a specific hot-swap component for any additional procedures that you might have to perform before you remove or install the component.

• The Red strip on the drives, adjacent to the release latch, indicates that the drive can be hot-swapped if the server and operating system support hot-swap capability. This means that you can remove or install the drive while the server is still running.

**Note:** See the system specific instructions for removing or installing a hot-swap drive for any additional procedures that you might need to perform before you remove or install the drive.

• After finishing working on the server, make sure you reinstall all safety shields, guards, labels, and ground wires.

## Safety inspection checklist

Use the information in this section to identify potentially unsafe conditions with your server. As each machine was designed and built, required safety items were installed to protect users and service technicians from injury.

### Notes:

- 1. The product is not suitable for use at visual display workplaces according to §2 of the Workplace Regulations.
- 2. The set-up of the server is made in the server room only.

### CAUTION:

This equipment must be installed or serviced by trained personnel, as defined by the NEC, IEC 62368-1 & IEC 60950-1, the standard for Safety of Electronic Equipment within the Field of Audio/Video, Information Technology and Communication Technology. Lenovo assumes you are qualified in the servicing of equipment and trained in recognizing hazards energy levels in products. Access to the equipment is by the use of a tool, lock and key, or other means of security, and is controlled by the authority responsible for the location.

**Important:** Electrical grounding of the server is required for operator safety and correct system function. Proper grounding of the electrical outlet can be verified by a certified electrician.

Use the following checklist to verify that there are no potentially unsafe conditions:

- 1. Make sure that the power is off and the power cord is disconnected.
- 2. Check the power cord.
  - Make sure that the third-wire ground connector is in good condition. Use a meter to measure thirdwire ground continuity for 0.1 ohm or less between the external ground pin and the frame ground.
  - Make sure that the power cord is the correct type.

To view the power cords that are available for the server:

a. Go to:

#### http://dcsc.lenovo.com/#/

- b. Click Preconfigured Model or Configure to order.
- c. Enter the machine type and model for your server to display the configurator page.
- d. Click **Power**  $\rightarrow$  **Power Cables** to see all line cords.
- Make sure that the insulation is not frayed or worn.
- 3. Check for any obvious non-Lenovo alterations. Use good judgment as to the safety of any non-Lenovo alterations.

- 4. Check inside the server for any obvious unsafe conditions, such as metal filings, contamination, water or other liquid, or signs of fire or smoke damage.
- 5. Check for worn, frayed, or pinched cables.
- 6. Make sure that the power-supply cover fasteners (screws or rivets) have not been removed or tampered with.

## System reliability guidelines

Review the system reliability guidelines to ensure proper system cooling and reliability.

Make sure the following requirements are met:

- When the server comes with redundant power, a power supply must be installed in each power-supply bay.
- Adequate space around the server must be spared to allow server cooling system to work properly. Leave approximately 50 mm (2.0 in.) of open space around the front and rear of the server. Do not place any object in front of the fans.
- For proper cooling and airflow, refit the server cover before you turn the power on. Do not operate the server for more than 30 minutes with the server cover removed, for it might damage server components.
- Cabling instructions that come with optional components must be followed.
- A failed fan must be replaced within 48 hours since malfunction.
- A removed hot-swap fan must be replaced within 30 seconds after removal.
- A removed hot-swap drive must be replaced within two minutes after removal.
- A removed hot-swap power supply must be replaced within two minutes after removal.
- Every air baffle that comes with the server must be installed when the server starts (some servers might come with more than one air baffle). Operating the server with a missing air baffle might damage the processor.
- All processor sockets must contain either a socket cover or a processor with heat sink.
- When more than one processor is installed, fan population rules for each server must be strictly followed.

## Working inside the server with the power on

Guidelines to work inside the server with the power on.

**Attention:** The server might stop and loss of data might occur when internal server components are exposed to static electricity. To avoid this potential problem, always use an electrostatic-discharge wrist strap or other grounding systems when working inside the server with the power on.

- Avoid loose-fitting clothing, particularly around your forearms. Button or roll up long sleeves before working inside the server.
- Prevent your necktie, scarf, badge rope, or long hair from dangling into the server.
- Remove jewelry, such as bracelets, necklaces, rings, cuff links, and wrist watches.
- Remove items from your shirt pocket, such as pens and pencils, in case they fall into the server as you lean over it.
- Avoid dropping any metallic objects, such as paper clips, hairpins, and screws, into the server.

## Handling static-sensitive devices

Use this information to handle static-sensitive devices.

**Attention:** Prevent exposure to static electricity, which might lead to system halt and loss of data, by keeping static-sensitive components in their static-protective packages until installation, and handling these devices with an electrostatic-discharge wrist strap or other grounding system.

- Limit your movement to prevent building up static electricity around you.
- Take additional care when handling devices during cold weather, for heating would reduce indoor humidity and increase static electricity.
- Always use an electrostatic-discharge wrist strap or other grounding system, particularly when working inside the server with the power on.
- While the device is still in its static-protective package, touch it to an unpainted metal surface on the outside of the server for at least two seconds. This drains static electricity from the package and from your body.
- Remove the device from the package and install it directly into the server without putting it down. If it is necessary to put the device down, put it back into the static-protective package. Never place the device on the server or on any metal surface.
- When handling a device, carefully hold it by the edges or the frame.
- Do not touch solder joints, pins, or exposed circuitry.
- Keep the device from others' reach to prevent possible damages.

## Install server hardware options

This section includes instructions for performing initial installation of optional hardware. Each component installation procedure references any tasks that need to be performed to gain access to the component being replaced.

Installation procedures are presented in the optimum sequence to minimize work.

**Attention:** To ensure the components you install work correctly without problems, read the following precautions carefully.

- Make sure the components you are installing are supported by the server. For a list of supported optional components for the server, see https://static.lenovo.com/us/en/serverproven/index.shtml.
- Always download and apply the latest firmware. This will help ensure that any known issues are addressed, and that your server is ready to work with optimal performance. Go to ThinkSystem SR630 Drivers and Software to download firmware updates for your server.
- It is good practice to make sure that the server is working correctly before you install an optional component.
- Follow the installation procedures in this section and use appropriate tools. Incorrectly installed components can cause system failure from damaged pins, damaged connectors, loose cabling, or loose components.

## **Remove the security bezel**

Use this information to remove the security bezel.



To remove the security bezel, complete the following steps:

#### Watch the procedure

A video of this procedure is available at https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE.

Step 1. Use the key to unlock the security bezel.



Figure 46. Security bezel unlock

Step 2. Press the blue release latch **I** and pivot the security bezel outward to remove it from the chassis.





**Attention:** Before you ship the rack with the server installed, reinstall and lock the security bezel into place.

## Remove the top cover

Use this information to remove the top cover.


S033



#### CAUTION:

Hazardous energy present. Voltages with hazardous energy might cause heating when shorted with metal, which might result in spattered metal, burns, or both.

S014



# CAUTION:

Hazardous voltage, current, and energy levels might be present. Only a qualified service technician is authorized to remove the covers where the label is attached.

To remove the top cover, complete the following steps:

#### Watch the procedure

A video of this procedure is available at https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE.



Figure 48. Top cover removal

- Step 1. Use a screwdriver to turn the cover lock to the unlocked position as shown.
- Step 2. Press the release button on the cover latch and then fully open the cover latch.
- Step 3. Slide the top cover to the rear of the server until it is disengaged from the chassis. Then, lift the top cover off the chassis and place it on a flat clean surface.

### Attention:

- Handle the top cover carefully. Dropping the top cover with the cover latch open might damage the cover latch.
- For proper cooling and airflow, install the top cover before you power on the server.

# Remove the air baffle

Use this information to remove the air baffle.



<u>S033</u>



### CAUTION:

Hazardous energy present. Voltages with hazardous energy might cause heating when shorted with metal, which might result in spattered metal, burns, or both.

<u>S017</u>



# CAUTION: Hazardous moving fan blades nearby. Keep fingers and other body parts away.

Note: Depending on the model, your server might not have an air baffle installed.

Before removing the air baffle, if there is a RAID super capacitor module installed on the bottom of the air baffle, disconnect the RAID super capacitor module cable first.

To remove the air baffle, complete the following step:

#### Watch the procedure

A video of this procedure is available at https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE.



Figure 49. Air baffle removal

Step 1. Grasp the air baffle and carefully lift it out of the server.

**Attention:** For proper cooling and airflow, install the air baffle before you power on the server. Operating the server with the air baffle removed might damage server components.

After removing the air baffle, begin installing any options that you have purchased.

# Install a processor-heat-sink module

The processor and heat sink are installed together as part of a processor-heat-sink-module (PHM) assembly. PHM installation requires a Torx T30 driver.

**Note:** If you are installing multiple options relating to the system board, the PHM installation should be performed first.



# Attention:

- Intel Xeon SP Gen 2 are supported on the system board with part number 01PE846. If you use the system board with part number 01GV276, 00MX552, 01PE248, or 01PE933, update your system firmware to the latest level before installing a Intel Xeon SP Gen 2. Otherwise, the system cannot be powered on.
- Each processor socket must always contain a cover or a PHM. When removing or installing a PHM, protect empty processor sockets with a cover.
- Do not touch the processor socket or processor contacts. Processor-socket contacts are very fragile and easily damaged. Contaminants on the processor contacts, such as oil from your skin, can cause connection failures.
- Remove and install only one PHM at a time. If the system board supports multiple processors, install the PHMs starting with the first processor socket.
- Do not allow the thermal grease on the processor or heat sink to come in contact with anything. Contact with any surface can compromise the thermal grease, rendering it ineffective. Thermal grease can damage components, such as electrical connectors in the processor socket. Do not remove the grease cover from a heat sink until you are instructed to do so.
- To ensure the best performance, check the manufacturing date on the new heat sink and make sure it does not exceed 2 years. Otherwise, wipe off the existing thermal grease and apply the new grease onto it for optimal thermal performance.

#### Notes:

- PHMs are keyed for the socket where they can be installed and for their orientation in the socket.
- See https://static.lenovo.com/us/en/serverproven/index.shtml for a list of processors supported for your server. All processors on the system board must have the same speed, number of cores, and frequency.
- Before you install a new PHM or replacement processor, update your system firmware to the latest level. See "Update the firmware" on page 124.
- Installing an additional PHM can change the memory requirements for your system. See "Memory module installation rules" on page 78 for a list of processor-to-memory relationships.
- Optional devices available for your system might have specific processor requirements. See the documentation that comes with the optional device for information.
- For some important information about system board, processor, and heat sink, refer to "Important information for system board, processor, and heat sink" on page 12.

Complete the following steps to install a PHM.

# Watch the procedure

A video of this procedure is available at https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8c69INMcmE

- Step 1. Remove the processor socket cover, if one is installed on the processor socket, by placing your fingers in the half-circles at each end of the cover and lifting it from the system board.
- Step 2. Install the processor-heat-sink module on the system board.



Figure 50. Installing a PHM

a. Align the triangular marks and guide pins on the processor socket with the PHM; then, insert the PHM into the processor socket.

**Attention:** To prevent damage to components, make sure that you follow the indicated tightening sequence.

b. Fully tighten the Torx T30 captive fasteners in the installation sequence shown on the heat-sink label. Tighten the screws until they stop; then, visually inspect to make sure that there is no gap between the screw shoulder beneath the heat sink and the processor socket. (For reference, the torque required for the nuts to fully tighten is 1.4 - 1.6 newton-meters, 12 - 14 inch-pounds).

After installing the PHM option:

1. Remove the fan filler and install two new system fans that comes with the processor option kit. See "Install a system fan" on page 73.

**Note:** The Cascade Lake processor does not come with a system fan. If you have installed a Cascade Lake processor, ensure that you have ordered the ThinkSystem SR630 FAN Option Kit and install it.

2. If there are memory modules to install, install them. See "Install a memory module" on page 75.

# Install a system fan

Use this information to install a system fan.



"**Read** the installation Guidelines" on page 64



"ATTENTION: Static Sensitive Device Ground package before opening" on page 66

<u>S033</u>



# CAUTION:

Hazardous energy present. Voltages with hazardous energy might cause heating when shorted with metal, which might result in spattered metal, burns, or both.

# <u>S017</u>



# CAUTION: Hazardous moving fan blades nearby. Keep fingers and other body parts away.

Before installing a system fan:

- Remove the fan filler.
- Touch the static-protective package that contains the new system fan to any unpainted surface on the outside of the server. Then, take the new system fan out of the package and place it on a static-protective surface.

To install a system fan, complete the following steps:

# Watch the procedure

A video of this procedure is available at https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE.



Figure 51. System fan installation

- Step 1. Align the two holes in the system fan with the two pins on the chassis.
- Step 2. Press the system fan down until it is seated correctly in the slot. Ensure that the fan connector is installed correctly to the connector on the system board.

# Install a memory module

Use this information to install a memory moduleM.



# Attention:

- Disconnect all power cords for this task.
- Memory modules are sensitive to static discharge and require special handling. In addition to the standard guidelines for "Handling static-sensitive devices" on page 66:
  - Always wear an electrostatic-discharge strap when removing or installing memory modules. Electrostatic-discharge gloves can also be used.
  - Never hold two or more memory modules together so that they touch. Do not stack memory modules directly on top of each other during storage.
  - Never touch the gold memory module connector contacts or allow these contacts to touch the outside of the memory module connector housing.
  - Handle memory modules with care: never bend, twist, or drop a memory module.
  - Do not use any metal tools (such as jigs or clamps) to handle the memory modules, because the rigid metals may damage the memory modules.
  - Do not insert memory modules while holding packages or passive components, which can cause package cracks or detachment of passive components by the high insertion force.

Before installing a memory module:

**Note:** If you are installing DC Persistent Memory Module (DCPMM) for the first time, follow the instructions in "DC Persistent Memory Module (DCPMM) setup" on page 77.

- 1. Touch the static-protective package that contains the new memory module to any unpainted surface on the outside of the server. Then, take the new memory module out of the package and place it on a static-protective surface.
- 2. Locate the required memory module slot on the system board. See "Memory module installation rules" on page 78. Ensure that you observe the installation rules and sequence.
- 3. If you are going to install a DCPMM, refer to "DC Persistent Memory Module (DCPMM) setup" on page 77.

**Note:** A DCPMM module looks slightly different from a DRAM DIMM in the illustration, but the installation method is the same.

To install a memory module, complete the following steps:

#### Watch the procedure

A video of this procedure is available at https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE.





Step 1. Open the retaining clips on each end of the memory module slot.

**Attention:** To avoid breaking the retaining clips or damaging the memory module slots, open and close the clips gently.

- Step 2. Align the memory module with the slot, and gently place the memory module on the slot with both hands.
- Step 3. Firmly press both ends of the memory module straight down into the slot until the retaining clips snap into the locked position.

**Note:** If there is a gap between the memory module and the retaining clips, the memory module has not been correctly inserted; open the retaining clips, remove the memory module, and then reinsert it.

# DC Persistent Memory Module (DCPMM) setup

Follow the instructions in this section to complete required setup before installing DCPMMs for the first time, determine the most suitable configuration, and install memory modules accordingly.

Complete the following steps to finish system setup to support DCPMM, and install the memory modules according to the designated combination.

- 1. Update the system firmware to the latest version that supports DCPMM (see "Update the firmware" on page 124).
- 2. Make sure to meet all the following requirements before installing DCPMMs.
  - All the DCPMMs that are installed must be of the same Lenovo part number.
  - All DRAM memory modules that are installed must be of the same type, rank, and capacity with minimum capacity of 16 GB. It is recommended to use Lenovo DRAM memory modules of the same part number.
- 3. Refer to "Memory module installation rules" on page 78 to determine the most suitable combination and the following:
  - Number and capacity of the DCPMMs and DRAM memory modules to install
  - Check if the presently installed processors support the combination. If not, replace the processors with ones that support the combination.
- 4. Based on the determined DCPMM combination, acquire the DCPMMs, DRAM memory modules and processors if necessary.
- 5. Replace the processors if necessary (see "Processor and heat sink replacement" in *Maintenance Manual*).
- 6. Remove all the memory modules that are installed (see "Remove a memory module" in *Maintenance Manual*).
- 7. Follow the slot combination in "DIMM installation rules" on page 78 to install all the DCPMMs and DRAM memory modules (see "Install a memory module" on page 75).
- 8. Disable security on all the installed DCPMMs (see "Configuring DC Persistent Memory Module (DCPMM)" on page 129).
- 9. Make sure the DCPMM firmware is the latest version. If not, update it to the latest version (see (lxca\_fw\_update)).
- 10. Configure DCPMMs so that the capacity is available for use (see "Configuring DC Persistent Memory Module (DCPMM)" on page 129.

#### Adding memory modules to configuration with DCPMMs

Follow the instructions in this section to add memory modules to the existing configuration with DCPMMs.

If DCPMMs are already installed and configured in the system, complete the following steps to add new memory modules.

- 1. Update the system firmware to the latest version (see "Update the firmware" on page 124).
- 2. Consider the following DCPMM requirements before acquiring new DCPMM units.
  - All the DCPMMs that are installed must be of the same part number.
  - All the DRAM DIMMs that are installed must be of the same type, rank, and capacity with minimum capacity of 16 GB. It is recommended to use Lenovo DRAM DIMMs of the same part number.
- 3. See "Memory module installation rules" in *ThinkSystem SR630 Maintenance Manual* to determine the new configuration, and acquire memory modules accordingly.
- If the DCPMMs are in Memory Mode and will stay in Memory Mode after new units are installed, follow the combination in "Memory Mode" on page 90 to install the new modules in the correct slots. Otherwise, go to the next step.
- 5. Make sure to back up the stored data.
- 6. If the App Direct capacity is interleaved:
  - a. Delete all the created namspaces and filesystems in the operating system.
  - b. Perform secure erase on all the DCPMMs that are installed. Go to Intel Optane DCPMMs → Security → Press to Secure Erase to perform secure erase.

**Note:** If one or more DCPMMs are secured with passphrase, make sure security of every unit is disabled before performing secure erase. In case the passphrase is lost or forgotten, contact Lenovo service.

- 7. Follow the slot combination in "Memory module installation rules" in *ThinkSystem SR630 Maintenance Manual* to install all the DCPMMs and DRAM DIMMs.
- 8. Disable security on all the installed DCPMMs (see "Configuring DC Persistent Memory Module (DCPMM)" on page 129).
- 9. Make sure the DCPMM firmware is the latest version. If not, update it to the latest version (see https:// sysmgt.lenovofiles.com/help/topic/com.lenovo.lxca.doc/update\_fw.html).
- 10. Configure DCPMMs so that the capacity is available for use (see "Configuring DC Persistent Memory Module (DCPMM)" on page 129).
- 11. Restore the data that have been backed up.

# Memory module installation rules

Memory modules must be installed in a specific order based on the memory configuration that you implement on your server.

Your server has 24 memory module slots. It supports up to 12 memory modules when one processor is installed, and up to 24 memory modules when two processors are installed. It has the following features:

For Intel Xeon SP Gen 1:

- Supporting memory module type is as follows:
  - TruDDR4 2666, single-rank or dual-rank, 8 GB/16 GB/32 GB RDIMM
  - TruDDR4 2666, quad-rank, 64 GB LRDIMM
  - TruDDR4 2666, octa-rank, 128 GB 3DS RDIMM
- The minimum system memory is 8 GB.
- The maximum system memory is as follows:

- 768 GB using RDIMMs
- 1.5 TB using LRDIMMs
- 3 TB using 3DS RDIMMs

For Intel Xeon SP Gen 2:

- Supporting memory module type is as follows:
  - TruDDR4 2666, single-rank or dual-rank, 16 GB/32 GB RDIMM
  - TruDDR4 2933, single-rank or dual-rank, 8 GB/16 GB/32 GB/64 GB RDIMM
  - TruDDR4 2933, single-rank or dual-rank, 16 GB/32 GB/64 GB Performance+ RDIMM
  - TruDDR4 2666, quad-rank, 64 GB 3DS RDIMM
  - TruDDR4 2933, quad-rank, 128 GB 3DS RDIMM
  - TruDDR4 2933, quad-rank, 128 GB Performance+ 3DS RDIMM
  - 128 GB/256 GB/512 GB DCPMM
- The minimum system memory is 8 GB.
- The maximum system memory is as follows:
  - 1.5 TB using RDIMMs
  - 3 TB using 3DS RDIMMs
  - 6 TB with DCPMM and 3DS RDIMMs/RDIMMs in Memory Mode

For a list of supported memory module options, see: https://static.lenovo.com/us/en/serverproven/index.shtml

Depending on the memory modules installed, refer to below topics for detailed installation rules:

- Without DCPMMs: "DRAM DIMM installation rules" on page 79
- With DCPMMs: "DCPMM installation rules" on page 84

# **DRAM DIMM installation rules**

For RDIMMs or LRDIMMs, the following memory modes are available:

- "Independent mode" on page 80
- "Mirroring mode" on page 83
- "Rank sparing mode" on page 82

The following illustration helps you to locate the memory module slots on the system board.

Note: It is recommended to install memory modules with the same rank in each channel.



Figure 53. memory module slots on the system board

#### Independent mode

Independent mode provides high performance memory capability. You can populate all channels with no matching requirements. Individual channels can run at different memory module timings, but all channels must run at the same interface frequency.

#### Notes:

- All memory modules to be installed must be the same type.
- All Performance+ DIMMs in the server must be of the same type, rank, and capacity (the same Lenovo part number) to operate at 2933 MHz in the configurations with two DIMMs per channel. Performance+ DIMMs cannot be mixed with other DIMMs.
- When you install memory modules with same rank and different capacity, install the memory module that has the highest capacity first.

The following table shows the memory module population sequence for independent mode when only one processor (Processor 1) is installed.

# Notes:

- If there are three identical memory modules to be installed for Processor 1, and the three memory modules have the same Lenovo part number, move the memory module to be installed in slot 8 to slot 1.
- If there are ten identical memory modules to be installed for Processor 1, and the ten memory modules have the same Lenovo part number, move the memory module to be installed in slot 6 to slot 12.

Total						Proce	essor 1						Total
DIMMs	12	11	10	9	8	7	6	5	4	3	2	1	DIMMs
1								5					1
2					8			5					2
3					8			5		3			3
4			10		8			5		3			4
5			10		8			5		3		1	5
6	12		10		8			5		3		1	6
7	12		10		8		6	5	4	3			7
8			10	9	8	7	6	5	4	3			8

Table 10. Independent mode with one processor

Table	10. Indepe	ndent mode	with one	processor	(continued)
-------	------------	------------	----------	-----------	-------------

Total						Proce	essor 1						Total
DIMMs	12	11	10	9	8	7	6	5	4	3	2	1	DIMMs
9	12		10		8		6	5	4	3	2	1	9
10			10	9	8	7	6	5	4	3	2	1	10
11	12		10	9	8	7	6	5	4	3	2	1	11
12	12	11	10	9	8	7	6	5	4	3	2	1	12

The following table shows the memory module population sequence for independent mode when two processors (Processor 1 and Processor 2) are installed.

#### Notes:

- If there are three identical memory modules to be installed for Processor 1, and the three memory modules have the same Lenovo part number, move the memory module to be installed in slot 8 to slot 1.
- If there are three identical memory modules to be installed for Processor 2, and the three memory modules have the same Lenovo part number, move the memory module to be installed in slot 20 to slot 13.
- If there are ten identical memory modules to be installed for Processor 1, and the ten memory modules have the same Lenovo part number, move the memory module to be installed in slot 2 to slot 12.
- If there are ten identical memory modules to be installed for Processor 2, and the ten memory modules have the same Lenovo part number, move the memory module to be installed in slot 14 to slot 24.

Total					Р	roce	esso	r 2				Processor 1										Total			
DIMMs	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	DIMMs
2								17												5					2
3								17									8			5					3
4					20			17									8			5					4
5					20			17									8			5		3			5
6					20			17		15							8			5		3			6
7					20			17		15					10		8			5		3			7
8			22		20			17		15					10		8			5		3			8
9			22		20			17		15					10		8			5		3		1	9
10			22		20			17		15		13			10		8			5		3		1	10
11			22		20			17		15		13	12		10		8			5		3		1	11
12	24		22		20			17		15		13	12		10		8			5		3		1	12
13	24		22		20			17		15		13	12		10		8		6	5	4	3			13
14	24		22		20		18	17	16	15			12		10		8		6	5	4	3			14
15	24		22		20		18	17	16	15					10	9	8	7	6	5	4	3			15
16			22	21	20	19	18	17	16	15					10	9	8	7	6	5	4	3			16
17			22	21	20	19	18	17	16	15			12		10		8		6	5	4	3	2	1	17
18	24		22		20		18	17	16	15	14	13	12		10		8		6	5	4	3	2	1	18

Table 11. Independent mode with two processors

Total		Processor 2															P	roce	ssoi	· 1					Total
DIMMs	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	DIMMs
19	24		22		20		18	17	16	15	14	13			10	9	8	7	6	5	4	3	2	1	19
20			22	21	20	19	18	17	16	15	14	13			10	9	8	7	6	5	4	3	2	1	20
21	24		22		20		18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	21
22	24		22	21	20	19	18	17	16	15	14	13	12		10	9	8	7	6	5	4	3	2	1	22
23	24		22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	23
24	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	24

Table 11. Independent mode with two processors (continued)

# Rank sparing mode

In rank sparing mode, one rank of a memory module works as the spare rank for the other ranks on the same channel. The spare rank is not available as system memory.

#### Notes:

- All memory modules to be installed must be the same type with the same capacity, frequency, voltage, and ranks.
- All Performance+ DIMMs in the server must be of the same type, rank, and capacity (the same Lenovo part number) to operate at 2933 MHz in the configurations with two DIMMs per channel. Performance+ DIMMs cannot be mixed with other DIMMs.
- If the rank of installed memory modules is one rank, follow the installation rules listed in the following tables. If the rank of installed memory modules is more than one rank, follow the installation rules of independent mode.

The following table shows the memory module population sequence for rank sparing mode when only one processor (Processor 1) is installed.

Total						Proce	essor 1						Total
DIMMs	12	11	10	9	8	7	6	5	4	3	2	1	DIMMs
2							6	5					2
4					8	7	6	5					4
6					8	7	6	5	4	3			6
8			10	9	8	7	6	5	4	3			8
10			10	9	8	7	6	5	4	3	2	1	10
12	12	11	10	9	8	7	6	5	4	3	2	1	12

Table 12. Rank sparing mode with one processor

The following table shows the memory module population sequence for rank sparing mode when two processors (Processor 1 and Processor 2) are installed.

Total					Р	roce	esso	r 2									Pr	oce	ssor	1					Total
DIMMs	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	DIMMs
4							18	17											6	5					4
6							18	17									8	7	6	5					6
8					20	19	18	17									8	7	6	5					8
10					20	19	18	17									8	7	6	5	4	3			10
12					20	19	18	17	16	15							8	7	6	5	4	3			12
14					20	19	18	17	16	15					10	9	8	7	6	5	4	3			14
16			22	21	20	19	18	17	16	15					10	9	8	7	6	5	4	3			16
18			22	21	20	19	18	17	16	15					10	9	8	7	6	5	4	3	2	1	18
20			22	21	20	19	18	17	16	15	14	13			10	9	8	7	6	5	4	3	2	1	20
22			22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	22
24	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	24

Table 13. Rank sparing mode with two processors

# Mirroring mode

In mirroring mode, each memory module in a pair must be identical in size and architecture. The channels are grouped in pairs with each channel receiving the same data. One channel is used as a backup of the other, which provides redundancy.

# Notes:

- Partial memory mirroring is a sub-function of memory mirroring, which requires to follow the installation rules of mirroring mode.
- All memory modules to be installed must be the same type with the same capacity, frequency, voltage, and ranks.
- All Performance+ DIMMs in the server must be of the same type, rank, and capacity (the same Lenovo part number) to operate at 2933 MHz in the configurations with two DIMMs per channel. Performance+ DIMMs cannot be mixed with other DIMMs.

The following table shows the memory module population sequence for mirroring mode when only one processor (Processor 1) is installed.

Total						Proce	essor 1						Total
DIMMs	12	11	10	9	8	7	6	5	4	3	2	1	DIMMs
2								5		3			2
3								5		3		1	3
4			10		8			5		3			4
6	12		10		8			5		3		1	6
8			10	9	8	7	6	5	4	3			8
9	12		10		8		6	5	4	3	2	1	9
12	12	11	10	9	8	7	6	5	4	3	2	1	12

Table 14. Mirroring mode with one processor

The following table shows the memory module population sequence for mirroring mode when two processors (Processor 1 and Processor 2) are installed.

Total					Р	roce	sso	r 2									Pr	oce	ssor	· 1					Total
DIMMs	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	DIMMs
4								17		15										5		3			4
5								17		15										5		3		1	5
6								17		15		13								5		3		1	6
7								17		15		13			10		8			5		3			7
8			22		20			17		15					10		8			5		3			8
9								17		15		13	12		10		8			5		3		1	9
10			22		20			17		15			12		10		8			5		3		1	10
12	24		22		20			17		15		13	12		10		8			5		3		1	12
13			22		20			17		15			12		10		8		6	5	4	3	2	1	13
14			22	21	20	19	18	17	16	15			12		10		8			5		3		1	14
15	24		22		20			17		15		13	12		10		8		6	5	4	3	2	1	15
16			22	21	20	19	18	17	16	15					10	9	8	7	6	5	4	3			16
17			22	21	20	19	18	17	16	15			12		10		8		6	5	4	3	2	1	17
18	24		22		20		18	17	16	15	14	13	12		10		8		6	5	4	3	2	1	18
20			22	21	20	19	18	17	16	15			12	11	10	9	8	7	6	5	4	3	2	1	20
21	24		22		20		18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	21
24	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	24

Table 15. Mirroring mode with two processors

# **DCPMM** installation rules

For DC Persistent Memory Module (DCPMM), the following memory modes are available:

- "App Direct Mode" on page 85
- "Memory Mode" on page 90
- "Mixed Memory Mode" on page 88

#### Notes:

- Before installing DCPMMs and DRAM DIMMs, refer to "DC Persistent Memory Module (DCPMM) setup" on page 77 and make sure to meet all the requirements.
- To verify if the presently installed processors support DCPMMs, examine the four digits in the processor description. Only the processor with description meeting *both* of the following requirements support DCPMMs.
  - The first digit is **5** or a larger number.

Note: The only exception to this rule is Intel Xeon Silver 4215, which also supports DCPMM.

- The second digit is **2**.

Example: Intel Xeon 5215L and Intel Xeon Platinum 8280M

Note: Processor 4215 also supports DCPMMs.

If the presently installed processors do not support DCPMMs, replace them with the processors that support DCPMMs.

- DCPMMs are supported only by Intel Xeon SP Gen 2. For a list of supported processors and memory modules, see <a href="http://www.lenovo.com/us/en/serverproven/">http://www.lenovo.com/us/en/serverproven/</a>
- When you install two or more DCPMMs, all DCPMMs must have the same Lenovo part number.
- All DRAM memory modules installed must have the same Lenovo part number.
- 16 GB RDIMM has two different types: 16 GB 1Rx4 and 16 GB 2Rx8. The part number of the two types are different.
- Supported memory capacity range varies with the following types of DCPMMs.
  - Large memory tier (L): The processors with L after the four digits (for example: Intel Xeon 5215L)
  - Medium memory tier (M): The processors with M after the four digits (for example: Intel Xeon Platinum 8280M)
  - Other: Other processors that support DCPMMs (for example: Intel Xeon Gold 5222)
- In addition, you can take advantage of a memory configurator, which is available at the following site:http://1config.lenovo.com/#/memory\_configuration.

The following illustration helps you to locate the memory module slots on the system board.



Figure 54. memory module slots on the system board

#### App Direct Mode

In this mode, DCPMMs act as independent and persistent memory resources directly accessible by specific applications, and DRAM DIMMs act as system memory.

**Note:** Before installing DCPMM, refer to "Memory configuration" on page 128 and "Configuring DC Persistent Memory Module (DCPMM)" on page 129 for the requirements.

#### App Direct Mode with one processor

**Note:** When adding one or more DCPMMs and DIMMs during a memory upgrade, you might need to move other DIMMs that are already installed to new locations.

			•									
D: All supported D	DR4 DI	MM exce	pt 8GB <sup>-</sup>	1Rx8 RDI	IMM							
P: Only Data Cent	er Persis	stent Mer	mory Mo	dule (DC	PMM) c	an be ins	stalled on	the corre	espondin	g DIMM	slots.	
Configuration						Proc	essor 1					
Configuration	12	11	10	9	8	7	6	5	4	3	2	1
1 DCPMM and 6 DIMMs	D		D		D	Р		D		D		D

Table 16. App Direct Mode with one processor

2 DCPMMs and 4 DIMMs	Р		D		D			D		D		Р
2 DCPMMs and 6 DIMMs	D		D		D	Ρ	Р	D		D		D
2 DCPMMs and 8 DIMMs	Р		D	D	D	D	D	D	D	D		Ρ
4 DCPMMs and 6 DIMMs	D		D	Р	D	Р	Р	D	Р	D		D
6 DCPMMs and 6 DIMMs	D	Р	D	Р	D	Р	Р	D	Р	D	Р	D

 Table 16. App Direct Mode with one processor (continued)

Table 17	Supported DCPMM	capacity in App	Direct Mode with	one processor
rabic ir.		cupacity in ripp	Direct Widde With	0110 0100003301

Total DCPMMs	Total DIMMs	Processor Family	128 GB DCPMM	256 GB DCPMM	512 GB DCPMM
		L	$\checkmark$	$\checkmark$	$\checkmark$
1	6	М	$\checkmark$	$\checkmark$	$\checkmark$
		Other	$\checkmark$	$\checkmark$	$\sqrt{2}$
		L	$\checkmark$	$\checkmark$	$\checkmark$
2	4	м	$\checkmark$	$\checkmark$	$\checkmark$
		Other	$\checkmark$	$\checkmark$	
		L	$\checkmark$	$\checkmark$	$\checkmark$
2	6	м	$\checkmark$	$\checkmark$	$\checkmark$
		Other	$\checkmark$	$\sqrt{2}$	
		L	$\checkmark$	$\checkmark$	$\checkmark$
2	8	М	$\checkmark$	$\checkmark$	$\checkmark$
		Other	$\sqrt{2}$	$\sqrt{2}$	
		L	$\checkmark$	$\checkmark$	$\checkmark$
4	6	М	$\checkmark$	$\checkmark$	
		Other	$\sqrt{2}$		
		L	$\checkmark$	$\checkmark$	$\checkmark$
6	6	М	$\checkmark$	$\sqrt{2}$	
		Other	$\sqrt{1}$		

#### Notes:

- 1. Supported DIMM capacity is up to 32 GB.
- 2. Supported DIMM capacity is up to 64 GB.

# App Direct Mode with two processors

**Note:** When adding one or more DCPMMs and DIMMs during a memory upgrade, you might need to move other DCPMMs and DIMMs that are already installed to new locations.

# Table 18. App Direct Mode with two processors

<b>D</b> : All supported I	З: Ан supported DDR4 DIMM except 8GB TRX8 RDIMM																							
P: Only Data Center Persistent Memory Module (DCPMM) can be installed on the corresponding DIMM slots.																								
Configuration					F	roce	esso	r 2									P	roce	essor	· 1				
	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
1 DCPMM and 12 DIMMs	D		D		D			D		D		D	D		D		D		Ρ	D		D		D
2 DCPMMs and 12 DIMMs	D		D		D		Ρ	D		D		D	D		D		D		Ρ	D		D		D
4 DCPMMs and 8 DIMMs	Ρ		D		D			D		D		Ρ	Ρ		D		D			D		D		Ρ
4 DCPMMs and 12 DIMMs	D		D		D	Ρ	Ρ	D		D		D	D		D		D	Ρ	Ρ	D		D		D
4 DCPMMs and 16 DIMMs	Ρ		D	D	D	D	D	D	D	D		Ρ	Ρ		D	D	D	D	D	D	D	D		Ρ
8 DCPMMs and 12 DIMMs	D		D	Ρ	D	Ρ	Ρ	D	Ρ	D		D	D		D	Ρ	D	Ρ	Ρ	D	Ρ	D		D
12 DCPMMs and 12 DIMMs	D	Ρ	D	Ρ	D	Ρ	Ρ	D	Ρ	D	Ρ	D	D	Ρ	D	Ρ	D	Ρ	Ρ	D	Ρ	D	Ρ	D

# D: All supported DDR4 DIMM except 8GB 1Rx8 RDIMM

Total DCPMMs	Total DIMMs	Processor Family	128 GB DCPMM	256 GB DCPMM	512 GB DCPMM
		L	$\checkmark$	$\checkmark$	$\checkmark$
1	12	м	$\checkmark$	$\checkmark$	$\checkmark$
		Other	$\checkmark$	$\checkmark$	$\sqrt{2}$
		L	$\checkmark$	$\checkmark$	$\checkmark$
2	12	М	$\checkmark$	$\checkmark$	$\checkmark$
		Other	$\checkmark$	$\checkmark$	$\sqrt{2}$
		L	$\checkmark$	$\checkmark$	$\checkmark$
4	8	м	$\checkmark$	$\checkmark$	$\checkmark$
		Other	$\checkmark$	$\checkmark$	
		L	$\checkmark$	$\checkmark$	$\checkmark$
4	12	м	$\checkmark$	$\checkmark$	$\checkmark$
		Other	$\checkmark$	$\sqrt{2}$	
		L	$\checkmark$	$\checkmark$	$\checkmark$
4	16	м	$\checkmark$	$\checkmark$	$\checkmark$
		Other	$\sqrt{2}$	$\sqrt{2}$	
8	10	L	$\checkmark$	$\checkmark$	$\checkmark$
0	12	М	$\checkmark$	$\checkmark$	

Table 19. Supported DCPMM capacity in App Direct Mode with two processors

1

Table 19. Supported DCPMM capacity in App Direct Mode with two processors (continued)

		Other	$\sqrt{2}$		
		L	$\checkmark$	$\checkmark$	$\checkmark$
12	12	М	$\checkmark$	$\sqrt{2}$	
		Other	$\sqrt{1}$		

#### Notes:

- 1. Supported DIMM capacity is up to 32 GB.
- 2. Supported DIMM capacity is up to 64 GB.

#### Mixed Memory Mode

In this mode, some percentage of DCPMM capacity is directly accessible to specific applications (App Direct), while the rest serves as system memory. The App Direct part of DCPMM is displayed as persistent memory, while the rest of DCPMM capacity is displayed as system memory. DRAM DIMMs act as cache in this mode.

**Note:** Before installing DCPMM, refer to "Memory configuration" on page 128 and "Configuring DC Persistent Memory Module (DCPMM)" on page 129 to define the percentage of DCPMM capacity.

#### Mixed Memory Mode with one processor

**Note:** When adding one or more DCPMMs and DIMMs during a memory upgrade, you might need to move other DIMMs that are already installed to new locations.

Table 20	Mixed Memor	v Mode with	one processor
10016 20.	WINED WEITION		0116 010063301

D: All supported D	D: All supported DDR4 DIMM except 8GB 1Rx8 RDIMM												
P: Only Data Center Persistent Memory Module (DCPMM) can be installed on the corresponding DIMM slots.													
Processor 1													
Comguration	12	11	10	9	8	7	6	5	4	3	2	1	
2 DCPMMs and 4 DIMMs	Ρ		D		D			D		D		P	
2 DCPMMs and 6 DIMMs	D		D		D	Р	Р	D		D		D	
4 DCPMMs and 6 DIMMs	D		D	Р	D	Ρ	Р	D	Ρ	D		D	
6 DCPMMs and 6 DIMMs	D	Р	D	Р	D	Р	Р	D	Ρ	D	Р	D	

Table 21. Supported DCPMM capacity in Mixed Memory Mode with one processor

Total DCPMMs	Total DIMMs	Processor Family	128 GB DCPMM	256 GB DCPMM	512 GB DCPMM
		L		$\sqrt{1}$	$\sqrt{2}$
2	4	М		$\sqrt{1}$	$\sqrt{2}$
		Other		$\sqrt{1}$	
2	6	L		$\sqrt{1}$	$\sqrt{2}$

T-61-01	Currence and a di DODMANA		A diversal A disease and	· · · · · · · · · · · · · · · · · · ·		(
I ANIE Z I	SUDDOTED DU PIVIVI	сапаситу іп	Wilken Wemon	v ivioae with or	e nrocessor	icontinueai
Tuble LT.	Supported Dor Min	oupuony m	winked wienner		0 pi 000000i	(00//////////00///

		М		$\sqrt{1}$	$\sqrt{2}$
		Other		$\sqrt{1}$	
		L	$\sqrt{1}$	$\sqrt{2}$	$\sqrt{3}$
4	6	М	$\sqrt{1}$	$\sqrt{2}$	
		Other	$\sqrt{1}$		
		L	$\sqrt{1}$	$\sqrt{2}$	$\sqrt{3}$
6	6	М	$\sqrt{1}$	$\sqrt{2}$	
		Other	$\sqrt{1}$		

# Notes:

- 1. Supported DIMM capacity is 16 GB.
- 2. Supported DIMM capacity is 16 to 32 GB.
- 3. Supported DIMM capacity is 16 to 64 GB.

#### Mixed Memory Mode with two processors

Table 22. Mixed Memory Mode with two processors

D: All supported DDR4 DIMM except 8GB 1Rx8 RDIMM																								
P: Only Data Center Persistent Memory Module (DCPMM) can be installed on the corresponding DIMM slots.																								
Configuration	Processor 2 Processor 1																							
Conngulation	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
4 DCPMMs and 8 DIMMs	Ρ		D		D			D		D		Ρ	Ρ		D		D			D		D		Ρ
4 DCPMMs and 12 DIMMs	D		D		D	Ρ	Ρ	D		D		D	D		D		D	Ρ	Ρ	D		D		D
8 DCPMMs and 12 DIMMs	D		D	Ρ	D	Ρ	Ρ	D	Ρ	D		D	D		D	Ρ	D	Ρ	Ρ	D	Ρ	D		D
12 DCPMMs and 12 DIMMs	D	Ρ	D	Ρ	D	Ρ	Ρ	D	Ρ	D	Ρ	D	D	Ρ	D	Ρ	D	Ρ	Ρ	D	Ρ	D	Ρ	D

Table 23. Supported DCPMM capacity in Mixed Memory Mode with two processors

Total DCPMMs	Total DIMMs	Processor Family	128 GB DCPMM	256 GB DCPMM	512 GB DCPMM
		L		$\sqrt{1}$	$\sqrt{2}$
4	8	М		$\sqrt{1}$	$\sqrt{2}$
		Other		$\sqrt{1}$	
		L		$\sqrt{1}$	$\sqrt{2}$
4	12	М		$\sqrt{1}$	$\sqrt{2}$
		Other		$\sqrt{1}$	
8	12	L	$\sqrt{1}$	$\sqrt{2}$	$\sqrt{3}$

Table 23. Supported DCPMM capacity in Mixed Memory Mode with two processors (continued)

		М	$\sqrt{1}$	$\sqrt{2}$	
		Other	$\sqrt{1}$		
		L	$\sqrt{1}$	$\sqrt{2}$	$\sqrt{3}$
12	12	М	$\sqrt{1}$	$\sqrt{2}$	
		Other	$\sqrt{1}$		

#### Notes:

- 1. Supported DIMM capacity is 16 GB.
- 2. Supported DIMM capacity is 16 to 32 GB.
- 3. Supported DIMM capacity is 16 to 64 GB.

# Memory Mode

In this mode, DCPMMs act as volatile system memory, while DRAM DIMMs act as cache. Ensure that the ratio of DRAM DIMM capacity to DCPMM capacity is between 1:2 and 1:16.

# **Note:** Before installing DCPMM, refer to "Memory configuration" on page 128 and "Configuring DC Persistent Memory Module (DCPMM)" on page 129 for the requirements.

#### Memory Mode with one processor

Table 24. Memory Mode with one processor

D: All supported DDR4 DIMM except 8GB 1Rx8 RDIMM

P: Only Data Center Persistent Memory Module (DCPMM) can be installed on the corresponding DIMM slots.

Configuration	Processor 1											
Configuration	12	11	10	9	8	7	6	5	4	3	2	1
2 DCPMMs and 4 DIMMs	Ρ		D		D			D		D		P
2 DCPMMs and 6 DIMMs	D		D		D	Р	Р	D		D		D
4 DCPMMs and 6 DIMMs	D		D	Р	D	Р	Р	D	Р	D		D
6 DCPMMs and 6 DIMMs	D	Р	D	Р	D	Р	Р	D	Р	D	Р	D

Table 25.	Supported DCPMM	capacity in Memory	Mode with one processor
-----------	-----------------	--------------------	-------------------------

Total DCPM- Ms	Total DIMMs	Processor Family	128 GB DCPMM	256 GB DCPMM	512 GB DCPMM
		L	$\sqrt{1}$	$\sqrt{2}$	$\sqrt{3}$
2	4	м	$\sqrt{1}$	$\sqrt{2}$	$\sqrt{3}$
		Other	$\sqrt{1}$	$\sqrt{2}$	
0	6	L		$\sqrt{1}$	$\sqrt{2}$
2	O	М		$\sqrt{1}$	$\sqrt{2}$

		Other		$\sqrt{1}$	
		L	$\sqrt{1}$	$\sqrt{2}$	$\sqrt{4}$
4	6	М	$\sqrt{1}$	$\sqrt{2}$	
		Other	$\sqrt{1}$		
		L	$\sqrt{2}$	$\sqrt{3}$	$\sqrt{5}$
6	6	М	$\sqrt{2}$	$\sqrt{3}$	
		Other	$\sqrt{2}$		

Table 25. Supported DCPMM capacity in Memory Mode with one processor (continued)

#### Notes:

- 1. Supported DIMM capacity is 16 GB.
- 2. Supported DIMM capacity is 16 to 32 GB.
- 3. Supported DIMM capacity is 16 GB to 64 GB.
- 4. Supported DIMM capacity is 32 GB to 64 GB.
- 5. Supported DIMM capacity is 32 GB to 128 GB.

#### Memory Mode with two processors

Table 26. Memory Mode with two processors

D: All supported DDR4 DIMM except 8GB 1Rx8 RDIMM

**P**: Only Data Center Persistent Memory Module (DCPMM) can be installed on the corresponding DIMM slots.

Configuration						Proc	esso	r 2									Ρ	roce	ssor	1				
Configuration	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
4 DCPMMs and 8 DIMMs	Ρ		D		D			D		D		Ρ	Ρ		D		D			D		D		Ρ
4 DCPMMs and 12 DIMMs	D		D		D	Ρ	Ρ	D		D		D	D		D		D	Ρ	Р	D		D		D
8 DCPMMs and 12 DIMMs	D		D	Ρ	D	Ρ	Ρ	D	Ρ	D		D	D		D	Ρ	D	Ρ	Ρ	D	Ρ	D		D
12 DCPMMs and 12 DIMMs	D	Ρ	D	Ρ	D	Ρ	Ρ	D	Ρ	D	Ρ	D	D	Ρ	D	Ρ	D	Ρ	Р	D	Ρ	D	Ρ	D

Table 27. Supported DCPMM capacity in Memory Mode with two processors

Total DCPMMs	Total DIMMs	Processor Family	128 GB DCPMM	256 GB DCPMM	512 GB DCPMM
		L	$\sqrt{1}$	$\sqrt{2}$	$\sqrt{3}$
4	8	М	$\sqrt{1}$	$\sqrt{2}$	$\sqrt{3}$
		Other	$\sqrt{1}$	$\sqrt{2}$	
		L		$\sqrt{1}$	$\sqrt{2}$
4	12	М		$\sqrt{1}$	$\sqrt{2}$
		Other		$\sqrt{1}$	

		L	$\sqrt{1}$	$\sqrt{2}$	$\sqrt{4}$
8	12	М	$\sqrt{1}$	$\sqrt{2}$	
		Other	$\sqrt{1}$		
		L	$\sqrt{2}$	$\sqrt{3}$	$\sqrt{5}$
12	12	М	$\sqrt{2}$	$\sqrt{3}$	
		Other	$\sqrt{2}$		

Table 27. Supported DCPMM capacity in Memory Mode with two processors (continued)

#### Notes:

- 1. Supported DIMM capacity is 16 GB.
- 2. Supported DIMM capacity is 16 to 32 GB.
- 3. Supported DIMM capacity is 16 GB to 64 GB.
- 4. Supported DIMM capacity is 32 GB to 64 GB.
- 5. Supported DIMM capacity is 32 GB to 128 GB.

# Install a hot-swap power supply

Use this information to install a hot-swap power supply.



The following tips describe the type of power supply that the server supports and other information that you must consider when you install a power supply:

- The standard shipping has only one power supply installed in the server. For redundancy and hot-swap support, you must install an additional hot-swap power supply. Certain customized models might be shipped with two power supplies installed.
- Ensure that the devices that you are installing are supported. For a list of supported optional devices for the server, see

https://static.lenovo.com/us/en/serverproven/index.shtml

#### Notes:

- Ensure that the two power supplies installed on the server have the same wattage.
- If you are replacing the existing power supply with a new power supply of different wattage, attach the power rating label that comes with this option onto the existing label on the top cover near the power supply.



Figure 55. Hot-swap power supply label on the cover

# <u>S035</u>



#### CAUTION:

Never remove the cover on a power supply or any part that has this label attached. Hazardous voltage, current, and energy levels are present inside any component that has this label attached. There are no serviceable parts inside these components. If you suspect a problem with one of these parts, contact a service technician.

S002



# CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

<u>S001</u>





Electrical current from power, telephone, and communication cables is hazardous. To avoid a shock hazard:

- · Connect all power cords to a properly wired and grounded electrical outlet/source.
- Connect any equipment that will be attached to this product to properly wired outlets/sources.
- When possible, use one hand only to connect or disconnect signal cables.
- Never turn on any equipment when there is evidence of fire, water, or structural damage.
- The device might have more than one power cord, to remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

The following tips describe the information that you must consider when you install a power supply with dc input.

#### CAUTION:

240 V dc input (input range: 180-300 V dc) is supported in Chinese Mainland ONLY. Power supply with 240 V dc input cannot support hot plugging power cord function. Before removing the power supply with dc input, please turn off server or disconnect dc power sources at the breaker panel or by turning off the power source. Then, remove the power cord.



在直流输入状态下,若电源供应器插座不支持热插拔功能,请务必不要对设备电源线进行热插拔。此操作可能 导致设备损坏及数据丢失。因错误执行热插拔导致的设备故障或损坏,不属于保修范围。

NEVER CONNECT AND DISCONNECT THE POWER SUPPLY CABLE AND EQUIPMENT WHILE YOUR EQUIPMENT IS POWERED ON WITH DC SUPPLY (hot-plugging). Otherwise you may damage the equipment and result in data loss, the damages and losses result from incorrect operation of the equipment will not be covered by the manufacturers' warranty.

#### **S035**



#### CAUTION:

Never remove the cover on a power supply or any part that has this label attached. Hazardous voltage, current, and energy levels are present inside any component that has this label attached. There are no serviceable parts inside these components. If you suspect a problem with one of these parts, contact a service technician.

<u>S019</u>



#### CAUTION:

The power-control button on the device does not turn off the electrical current supplied to the device. The device also might have more than one connection to dc power. To remove all electrical current from the device, ensure that all connections to dc power are disconnected at the dc power input terminals.

Before installing a hot-swap power supply, touch the static-protective package that contains the new hotswap power supply to any unpainted surface on the outside of the server. Then, take the new hot-swap power supply out of the package and place it on a static-protective surface.

To install a hot-swap power supply, complete the following steps:

Watch the procedure. A video of the installation process is available:

- Youtube: https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE
- Youku: http://list.youku.com/albumlist/show/id\_50462008

Step 1. Remove the power-supply filler.



Figure 56. Hot-swap power supply filler removal

Step 2. Slide the new hot-swap power supply into the bay until the release latch clicks into place.



Figure 57. Hot-swap power supply installation

# Install the RAID adapter

Use this information to install the RAID adapter on the system board.



Notes:

- The following procedure applies to RAID adapter installed on the system board. For the procedure about installing the RAID adapter installed on the riser assembly, refer to "Install a PCIe adapter and riser assembly" on page 103.
- Ensure that you follow the priority sequence when you install a RAID adapter:
  - 1. The RAID adapter slot on the system board
  - 2. A PCIe slot on the riser card

Before installing the RAID adapter:

- 1. Touch the static-protective package that contains the new RAID adapter to any unpainted surface out of the server. Then, take the new RAID adapter out of the package and place it on a static-protective surface.
- 2. If the new RAID adapter is installed with a bracket, remove the bracket.

To install the RAID adapter on the system board, complete the following steps:

#### Watch the procedure

A video of this procedure is available at https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE.



Figure 58. RAID adapter installation

- Step 1. Place the RAID adapter into the slot at an angle.
- Step 2. Rotate the RAID adapter down.
- Step 3. Push the right-side latch open.
- Step 4. Push the RAID adapter to the fully horizontal position and insert it into the RAID adapter slot.
- Step 5. Slide the left-side latch to the locked position.

After installing the RAID adapter on the system board, connect cables to the new RAID adapter. See "Internal cable routing" on page 31.

# Install the rear hot-swap drive assembly

Use this information to install the rear hot-swap drive assembly.



Before installing the rear hot-swap drive assembly, touch the static-protective package that contains the new rear hot-swap drive assembly to any unpainted surface on the outside of the server. Then, take the new rear hot-swap drive assembly out of the package and place it on a static-protective surface.

To install the rear hot-swap drive assembly, complete the following steps:

Step 1. Gently press and hold the tab on the rear hot-swap drive assembly as shown and remove the air baffle from the rear hot-swap drive assembly.



Figure 59. Air baffle removal

Step 2. Connect the SAS signal cable to connector **1** on the rear backplane and connect the power cable to connector **2** on the rear backplane.



Figure 60. Rear backplane connectors

Step 3. Install the air baffle into the rear hot-swap drive assembly as shown.



Figure 61. Air baffle installation

Step 4. Align the three pins on the rear hot-swap drive assembly with the holes and slot in the chassis. Then, lower the rear hot-swap drive assembly into the chassis until it is fully seated.



Figure 62. Rear hot-swap drive assembly installation

Step 5. Connect the SAS signal cable to the RAID adapter and connect the power cable to the system board. See "Internal cable routing" on page 31.

After installing the rear hot-swap drive assembly, install the rear hot-swap drives. See "Install a hot-swap drive" on page 118.

# Install the M.2 backplane and M.2 drive

Use this information to install the M.2 backplane and M.2 drive.



Before installing the M.2 backplane and M.2 drive:

- 1. Touch the static-protective package that contains the new M.2 backplane and M.2 drive to any unpainted surface on the outside of the server. Then, take the new M.2 backplane and M.2 drive out of the package and place them on a static-protective surface.
- 2. Adjust the retainer on the M.2 backplane to accommodate the particular size of the M.2 drive you wish to install. See "Adjust the retainer on the M.2 backplane" on page 101.
- 3. Locate the connector on each side of the M.2 backplane.

#### Notes:

- Some M.2 backplanes support two identical M.2 drives. When two M.2 drives are installed, align and support both M.2 drives when sliding the retainer forward to secure the M.2 drives.
- Install the M.2 drive in slot 0 first.



Figure 63. M.2 drive slot

To install the M.2 backplane and M.2 drive, complete the following steps:

#### Watch the procedure

A video of this procedure is available at https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE.



Figure 64. M.2 drive installation

Step 1. Insert the M.2 drive at an angle of approximately 30 degrees into the connector.

**Note:** If your M.2 backplane supports two M.2 drives, insert the M.2 drives into the connectors at both sides.

- Step 2. Rotate the M.2 drive down until the notch II catches on the lip of the retainer II.
- Step 3. Slide the retainer forward (toward the connector) to secure the M.2 drive into place.

**Attention:** When sliding the retainer forward, ensure that the two nubs **I** on the retainer enter the small holes **I** on the M.2 backplane. Once they enter the holes, you will hear a soft "click" sound.



Figure 65. Instruction for sliding the retainer

Step 4. Align the blue plastic supports at each end of the M.2 backplane with the guide pins on the system board. Then, insert the M.2 backplane into the M.2 slot on the system board and press it down to fully seat it.



Figure 66. M.2 backplane installation

After installing the M.2 drive and M.2 backplane, use the Lenovo XClarity Provisioning Manager to configure the RAID. For more information, see:

http://sysmgt.lenovofiles.com/help/topic/LXPM/RAID\_setup.html

# Adjust the retainer on the M.2 backplane

Use this information to adjust the retainer on the M.2 backplane.



Before adjusting the retainer on the M.2 backplane, locate the correct keyhole that the retainer should be installed into to accommodate the particular size of the M.2 drive you wish to install.

To adjust the retainer on the M.2 backplane, complete the following steps:

#### Watch the procedure

A video of this procedure is available at https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE.



Figure 67. M.2 retainer adjustment

- Step 1. Press both sides of the retainer 1.
- Step 2. Move the retainer forward until it is in the large opening of the keyhole.
- Step 3. Take the retainer out of the keyhole.
- Step 4. Insert the retainer into the correct keyhole.
- Step 5. Press both sides of the retainer.
- Step 6. Slide the retainer backwards until it is seated in place.

# Install the LOM adapter

Use this information to install the LOM adapter.



Before installing the LOM adapter:

- 1. If riser 1 assembly is installed, remove it to access the LOM adapter slot.
- 2. If the server comes with a LOM adapter slot bracket, remove it with a tool first. Store the bracket in case that you later remove the LOM adapter and need the bracket to cover the place.

# CAUTION:

# Use a tool to remove the LOM adapter slot bracket to avoid injury.

3. Touch the static-protective package that contains the new LOM adapter to any unpainted surface on the outside of the server. Then, take the new LOM adapter out of the package and place it on a static-protective surface.

To install the LOM adapter, complete the following steps:

#### Watch the procedure

A video of this procedure is available at https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE.



Figure 68. LOM adapter installation

- Step 1. Insert the LOM adapter into the rear of the chassis at an angle as shown.
- Step 2. Lower the LOM adapter and slide it to the rear of the chassis until the LOM adapter stops.
- Step 3. Push the LOM adapter as shown to insert it into the connector on the system board.
- Step 4. Tighten the thumbscrew to secure the LOM adapter.

# Install a PCIe adapter and riser assembly

Use this information to install a PCIe adapter and riser assembly.



#### Notes:

- For information about installing a Mellanox ConnectX-6 HDR/200GbE QSFP56 1-port PCIe adapter with the ThinkSystem Mellanox HDR/200GbE 2x PCIe Aux Kit on the riser assembly, refer to the most up-to-date documentation at https://thinksystem.lenovofiles.com/help/index.jsp?topic=%2Fthinksystem\_mellanox\_hdr\_200gbe\_2x\_pcie\_aux\_kit%2FThinkSystem\_Mellanox\_HDR200GbE\_2xPCIe\_Aux\_Kit.html&cp=7\_9\_4.
- The ThinkSystem Broadcom 57454 10/25GbE SFP28 4-port PCIe Ethernet Adapter\_Refresh (V2) requires a full-height bracket and must be installed in a full-height slot.
- ThinkSystem Xilinx Alveo U50 Data Center Accelerator Adapter is supported only when the following requirement are met:
  - Only for server modules installed with four 3.5-inch SAS/SATA drives, four 3.5-inch SAS/SATA/NVMe drives, eight 2.5-inch SAS/SATA drives, or ten 2.5-inch SAS/SATA/NVMe drives.
  - For server models installed with one CPU, only one adapter is supported and must be installed in PCIe slot 1.
  - For server models installed with two CPUs, up to two adapters are supported and must be installed in PCIe slot 1 and slot 3.
  - The maximum supported processor TDP is 165 watts
  - The maximum operating temperature is 30°C.
  - No fan fails.

Before installing a PCIe adapter and riser assembly:

- 1. Touch the static-protective package that contains the new PCIe adapter to any unpainted surface on the outside of the server. Then, take the new PCIe adapter out of the package and place it on a static-protective surface.
- 2. Touch the static-protective package that contains the new riser assembly to any unpainted surface on the outside of the server. Then, take the new riser assembly out of the package and place it on a static-protective surface.
- 3. Locate the correct PCIe slot for the PCIe adapter. For information about the PCIe slots and supported PCIe adapters, see "Rear view" on page 22.

Your server comes with one of the following riser assembly configurations:



#### Figure 69. Configuration 1

Note: Riser 2 assembly might not be available on some models.



Figure 70. Configuration 2


Figure 71. Configuration 3

Note: Riser 2 assembly might not be available on some models.

To install a PCIe adapter and riser assembly, complete the following steps:

Watch the procedure. A video of the installation process is available:

- Youtube: https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE
- Youku: http://list.youku.com/albumlist/show/id\_50462008

Step 1. Install the PCIe adapter into the riser assembly.





- Step 2. Connect cables to the PCIe adapter in the riser assembly. See "Internal cable routing" on page 31.
- Step 3. Position the riser assembly on the chassis. Align the two pins on the bracket with the two holes in the chassis and align the riser card with the riser slot on the system board. Then, carefully press the riser assembly straight down into the slot until it is fully seated.

**Note:** The riser assembly you want to install might be different from the following illustration, but the installation method is the same.



Figure 75. Riser assembly installation

# Install a full-height half-length GPU with the GPU upgrade kit

Use this information to install a full-height half-length GPU and the GPU upgrade kit.



### Notes:

- For information about the form factor of GPUs, refer to GPU specifications.
- For server models with a RAID adapter installed on the RAID adapter slot on the system board, if you want to install a full-height half-length GPU to upgrade your server, you need to use the GPU upgrade kit. The GPU upgrade kit contains the following items:
  - Low-profile bracket for RAID 930-8i or 930-16i adapter (part number on the bracket label: SB47A19064)
  - Low-profile bracket for RAID 730-8i adapter (part number on the bracket label: SB47A19108)
  - Low-profile bracket for RAID 530-8i, 430-8i, or 430-16i adapter (part number on the bracket label: SB47A19050)
  - Two screws
  - ThinkSystem 8x2.5" HDD backplane signal cable
  - ThinkSystem 10x2.5" HDD backplane signal cable
- The full-height half-length GPU can be installed in the full-height half length PCIe slot 2 only.

Before installing a full-height half-length GPU with the GPU upgrade kit, touch the static-protective package that contains the new GPU to any unpainted surface on the outside of the server. Then, take the new GPU out of the package and place it on a static-protective surface.

To install a full-height half-length GPU and the GPU upgrade kit, complete the following steps:

## Watch the procedure. A video of the installation process is available:

- Youtube: https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE
- Youku: http://list.youku.com/albumlist/show/id\_50462008

Step 1. Remove the RAID adapter from the RAID adapter slot on the system board by doing the following:



Figure 76. RAID adapter removal

- 1. Slide the left-side latch to the unlocked position.
- 2. Push and hold the right-side latch in the direction as shown.

3. Grasp the RAID adapter by its edges and carefully remove it from the RAID adapter slot on the system board.

Step 2. Select the corresponding low-profile bracket for the RAID adapter and install the bracket to the RAID adapter with the two screws provided in the GPU upgrade kit.



Figure 77. Installing the low-profile bracket to the RAID adapter

- Step 3. Install the RAID adapter in PCIe slot 1 and install the GPU in the full-height half-length PCIe slot 2. See "Install a PCIe adapter and riser assembly" on page 103.
- Step 4. Connect the RAID adapter to the backplane by doing one of the following:
  - For server models with four 3.5-inch drive bays, connect the SAS signal cable on your server to the RAID adapter.
  - For server models with eight 2.5-inch drive bays, remove the old SAS signal cable from the backplane and use the 8x2.5" cable in the GPU upgrade kit to connect the RAID adapter to the backplane.
  - For server models with ten 2.5-inch drive bays, remove the old SAS signal cable from the backplane and use the 10x2.5" cable in the GPU upgrade kit to connect the RAID adapter to the backplane.

For information about how to connect the cables for server models with a full-height half-length GPU, see "Internal cable routing" on page 31.

# Install the serial port module

Use this information to install the serial port module.



Before installing the serial port module, touch the static-protective package that contains the new serial port module to any unpainted surface out of the server. Then, take the new serial port module out of the package and place it on a static-protective surface.

To install the serial port module, complete the following steps:

**Note:** The serial port module can be installed on riser 1 assembly or riser 2 assembly. The following steps are based on the scenario that the serial port module is to be installed on riser 2 assembly. The installation procedure is the same for the serial port module to be installed on riser 1 assembly.

Step 1. Grasp the riser assembly by its edges and carefully lift it out of the server.



Figure 78. Riser assembly removal

Step 2. If the riser assembly is covered with a PCIe slot bracket, remove the bracket first. Then, install the serial port module into the riser assembly.



Figure 79. Serial port module installation

Step 3. Insert the riser assembly into the riser slot on the system board. Ensure that the riser assembly is fully seated.

Step 4. Connect the cable of the serial port module to the serial-port-module connector on the system board. For the location of the serial-port-module connector, refer to "System board components" on page 30. If the serial port module is installed in PCIe slot 1, route the cable of the serial port module as shown.



Figure 80. Cable routing for serial port module installed in PCIe slot 1

After installing the serial port module, do one of the following to enable it according to the installed operating system:

• For Linux operating system:

Open the ipmitool and enter the following command to disable the Serial over LAN (SOL) feature:

- -Ilanplus -HIP -UUSERID -P PASSWORD sol deactivate
- For Microsoft Windows operating system:
  - 1. Open the ipmitool and enter the following command to disable the SOL feature:
    - -Ilanplus -HIP -U USERID -P PASSWORD sol deactivate
  - 2. Open Windows PowerShell and enter the following command to disable the Emergency Management Services (EMS) feature:

Bcdedit /ems no

3. Restart the server to ensure that the EMS setting takes effect.

# Install a RAID super capacitor module on the bottom of the air baffle

Use this information to install a RAID super capacitor module on the bottom of the air baffle.



Notes: Your server supports up to two RAID super capacitor modules.

- For server models with 3.5-inch drive bays, install the first RAID super capacitor module in location **1** and install the second RAID super capacitor module in location **2**.
- For server models with 2.5-inch drive bays:
  - If you have a RAID super capacitor module holder in location 3, install the first RAID super capacitor module in location 3 and install the second RAID super capacitor module in location 1.
  - If you do not have a RAID super capacitor module holder in location 3, you can install the first RAID super capacitor module in location 3 and install the second RAID super capacitor module in location 2.



Figure 81. RAID super capacitor module location

Before installing a RAID super capacitor module on the bottom of the air baffle, touch the static-protective package that contains the new RAID super capacitor module to any unpainted surface on the outside of the server. Then, take the new RAID super capacitor module out of the package and place it on a static-protective surface.

To install a RAID super capacitor module on the bottom of the air baffle, complete the following steps:

### Watch the procedure

A video of this procedure is available at https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE.



Figure 82. Installation of a RAID super capacitor module on the bottom of the air baffle

- Step 1. Insert the RAID super capacitor module into the slot at the bottom of the air baffle as shown.
- Step 2. Gently press the tab on the air baffle as shown.
- Step 3. Press down the RAID super capacitor module to install it into the slot.

After installing the RAID super capacitor module, connect the RAID super capacitor module to a RAID adapter with the extension cable that comes with the RAID super capacitor module.

# Install the RAID super capacitor module on the chassis

Use this information to install a RAID super capacitor module.



Notes: Your server supports up to two RAID super capacitor modules.

- For server models with 3.5-inch drive bays, install the first RAID super capacitor module in location **1** and install the second RAID super capacitor module in location **2**.
- For server models with 2.5-inch drive bays:
  - If you have a RAID super capacitor module holder in location 3, install the first RAID super capacitor module in location 3 and install the second RAID super capacitor module in location 1.
  - If you do not have a RAID super capacitor module holder in location 3, you can install the first RAID super capacitor module in location 3 and install the second RAID super capacitor module in location 2.



Figure 83. RAID super capacitor module location

Before installing the RAID super capacitor module on the chassis, touch the static-protective package that contains the new RAID super capacitor module to any unpainted surface on the outside of the server. Then, take the new RAID super capacitor module out of the package and place it on a static-protective surface.

To install the RAID super capacitor module on the chassis, complete the following steps:

Step 1. Remove the tray that covers the place of the RAID super capacitor module on the chassis.





Step 2. Install the RAID super capacitor module holder on the chassis.



Figure 85. RAID super capacitor module holder installation

Step 3. Open the retention clip on the holder, put the RAID super capacitor module into the holder and press it down to secure it into the holder.



Figure 86. Installation of the RAID super capacitor module on the chassis

After installing the RAID super capacitor module, connect the RAID super capacitor module to a RAID adapter with the extension cable that comes with the RAID super capacitor module.

# Install the air baffle

Use this information to install the air baffle.



<u>S033</u>



# CAUTION:

Hazardous energy present. Voltages with hazardous energy might cause heating when shorted with metal, which might result in spattered metal, burns, or both.

<u>S017</u>



# CAUTION: Hazardous moving fan blades nearby. Keep fingers and other body parts away.

**Note:** For server models installed with large size heat sink, the air baffle is not supported. See "Important information for system board, processor, and heat sink" on page 12.

To install the air baffle, complete the following steps:

### Watch the procedure

A video of this procedure is available at https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE.



Figure 87. Air baffle installation

- Step 1. Align the tabs on both sides of the air baffle with the corresponding slots on both sides of the chassis.
- Step 2. Lower the air baffle into the chassis and press the air baffle down until it is securely seated.

After installing the air baffle, if there is a RAID super capacitor module installed on the bottom of the air baffle, connect it to the RAID adapter with the extension cable that comes with the RAID super capacitor module.

# Install the top cover

Use this information to install the top cover.



<u>S033</u>



# CAUTION:

Hazardous energy present. Voltages with hazardous energy might cause heating when shorted with metal, which might result in spattered metal, burns, or both.

<u>S014</u>



#### CAUTION:

Hazardous voltage, current, and energy levels might be present. Only a qualified service technician is authorized to remove the covers where the label is attached.

Before installing the top cover:

- 1. Ensure that all cables, adapters, and other components are installed and seated correctly and that you have not left loose tools or parts inside the server.
- 2. Ensure that all internal cables are correctly routed. See "Internal cable routing" on page 31.

To install the top cover, complete the following steps:

#### Watch the procedure

A video of this procedure is available at https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE.



Figure 88. Top cover installation

**Note:** Before you slide the top cover forward, ensure that all the tabs on the top cover engage the chassis correctly. If the tabs do not engage the chassis correctly, it will be very difficult to remove the top cover later.

- Step 1. Ensure that the cover latch is in the open position. Lower the top cover onto the chassis until both sides of the top cover engage with the guides on both sides of the chassis.
- Step 2. Pivot the cover latch and slide the top cover to the front of the chassis at the same time until the top cover snaps into position. Ensure that the cover latch is completely closed.
- Step 3. Use a screwdriver to turn the cover lock to the locked position.

# Install a hot-swap drive

Use this information to install a hot-swap drive.







The following notes describe the type of drives that your server supports and other information that you must consider when you install a drive.

- Depending on your server models, your server supports the following types of drives:
  - SAS/SATA HDD
  - SAS/SATA SSD
  - NVMe SSD

For a list of supported drives, see: https://static.lenovo.com/us/en/serverproven/index.shtml

- The drive bays are numbered to indicate the installation order (starting from number "0"). Follow the installation order when you install a drive. See "Front view" on page 19.
- You can mix drives of different types and different capacities in one system, but not in one RAID array. The following order is recommended when installing the drives:
  - Drive type priority: NVMe SSD, SAS SSD, SATA SSD, SAS HDD, SATA HDD
  - Drive capacity priority: the lowest capacity first
- For server models with ten 2.5-inch drive bays in the front, NVMe drives are supported in drive bays 6–9.
- The drives in a single RAID array must be the same type, same size, and same capacity.

Before installing a hot-swap drive:

1. Remove the drive filler from the drive bay. Keep the drive filler in a safe place.



### Figure 89. Drive filler removal

2. Touch the static-protective package that contains the new drive to any unpainted surface on the outside of the server. Then, take the new drive out of the package and place it on a static-protective surface.

To install a hot-swap drive, complete the following steps:

Watch the procedure. A video of the installation process is available:

• Youtube: https://www.youtube.com/playlist?list=PLYV5R7hVcs-C\_GGjNudxYy8-c69INMcmE

• Youku: http://list.youku.com/albumlist/show/id\_50462008



Figure 90. Hot-swap drive installation

- Step 1. Ensure that the drive tray handle is in the open position. Slide the drive into the drive bay until it snaps into position.
- Step 2. Close the drive tray handle to lock the drive in place.
- Step 3. Continue to install additional hot-swap drives if necessary.

# Install the server in a rack

To install the server in a rack, follow the instructions that are provided in the Rail Installation Kit for the rails on which the server will be installed.

# Cable the server

Attach all external cables to the server. Typically, you will need to connect the server to a power source, to the data network, and to storage. In addition, you will need to connect the server to the management network.

#### **Connect to power**

Connect the server to power.

#### **Connect to the network**

Connect the server to the network.

#### **Connect to storage**

Connect the server to any storage devices.

# Power on the server

After the server performs a short self-test (power status LED flashes quickly) when connected to input power, it enters a standby state (power status LED flashes once per second).

The server can be turned on (power LED on) in any of the following ways:

- You can press the power button.
- The server can restart automatically after a power interruption.
- The server can respond to remote power-on requests sent to the Lenovo XClarity Controller.

For information about powering off the server, see "Power off the server" on page 121.

# Validate server setup

After powering up the server, make sure that the LEDs are lit and that they are green.

# Power off the server

The server remains in a standby state when it is connected to a power source, allowing the Lenovo XClarity Controller to respond to remote power-on requests. To remove all power from the server (power status LED off), you must disconnect all power cables.

To place the server in a standby state (power status LED flashes once per second):

**Note:** The Lenovo XClarity Controller can place the server in a standby state as an automatic response to a critical system failure.

- Start an orderly shutdown using the operating system (if supported by your operating system).
- Press the power button to start an orderly shutdown (if supported by your operating system).
- Press and hold the power button for more than 4 seconds to force a shutdown.

When in a standby state, the server can respond to remote power-on requests sent to the Lenovo XClarity Controller. For information about powering on the server, see "Power on the server" on page 120.

# Chapter 4. System configuration

Complete these procedures to configure your system.

# Set the network connection for the Lenovo XClarity Controller

Before you can access the Lenovo XClarity Controller over your network, you need to specify how Lenovo XClarity Controller will connect to the network. Depending on how the network connection is implemented, you might need to specify a static IP address as well.

The following methods are available to set the network connection for the Lenovo XClarity Controller if you are not using DHCP:

• If a monitor is attached to the server, you can use Lenovo XClarity Provisioning Manager to set the network connection.

Complete the following steps to connect the Lenovo XClarity Controller to the network using the Lenovo XClarity Provisioning Manager.

- 1. Start the server.
- 2. When you see <F1> Setup, press F1 to open up the Lenovo XClarity Provisioning Manager.
- Go to LXPM → UEFI Setup → BMC Settings to specify how the Lenovo XClarity Controller will connect to the network.
  - If you choose a static IP connection, make sure that you specify an IPv4 or IPv6 address that is available on the network.
  - If you choose a DHCP connection, make sure that the MAC address for the server has been configured in the DHCP server.
- 4. Click **OK** to apply the setting and wait for two to three minutes.
- 5. Use an IPv4 or IPv6 address to connect Lenovo XClarity Controller.

**Important:** The Lenovo XClarity Controller is set initially with a user name of USERID and password of PASSW0RD (with a zero, not the letter O). This default user setting has Supervisor access. It is required to change this user name and password during your initial configuration for enhanced security.

 If no monitor attached to the server, you can set the network connection through the Lenovo XClarity Controller interface. Connect an Ethernet cable from your laptop to Lenovo XClarity Controller connector, which is located at the rear of the server. For the location of the Lenovo XClarity Controller connector, see "Rear view" on page 22.

**Note:** Make sure that you modify the IP settings on the laptop so that it is on the same network as the server default settings.

The default IPv4 address and the IPv6 Link Local Address (LLA) is provided on the Lenovo XClarity Controller Network Access label that is affixed to the Pull Out Information Tab.

• If you are using the Lenovo XClarity Administrator Mobile app from a mobile device, you can connect to the Lenovo XClarity Controller through the Lenovo XClarity Controller USB connector on the front of the server. For the location of the Lenovo XClarity Controller USB connector, see "Front view" on page 19.

**Note:** The Lenovo XClarity Controller USB connector mode must be set to manage the Lenovo XClarity Controller (instead of normal USB mode). To switch from normal mode to Lenovo XClarity Controller management mode, hold the blue ID button on the front panel for at least 3 seconds until its LED flashes slowly (once every couple of seconds).

To connect using the Lenovo XClarity Administrator Mobile app:

- 1. Connect the USB cable of your mobile device to the Lenovo XClarity Administrator USB connector on the front panel.
- 2. On your mobile device, enable USB tethering.
- 3. On your mobile device, launch the Lenovo XClarity Administrator mobile app.
- 4. If automatic discovery is disabled, click **Discovery** on the USB Discovery page to connect to the Lenovo XClarity Controller.

For more information about using the Lenovo XClarity Administrator Mobile app, see:

http://sysmgt.lenovofiles.com/help/topic/com.lenovo.lxca.doc/lxca\_usemobileapp.html

# Update the firmware

Several options are available to update the firmware for the server.

You can use the tools listed here to update the most current firmware for your server and the devices that are installed in the server.

Best practices related to updating firmware is available at the following site:

### http://lenovopress.com/LP0656

The latest firmware can be found at the following site:

http://datacentersupport.lenovo.com/us/en/products/servers/thinksystem/sr630/7X01/downloads

## UpdateXpress System Packs (UXSPs)

Lenovo typically releases firmware in bundles called UpdateXpress System Packs (UXSPs). To ensure that all of the firmware updates are compatible, you should update all firmware at the same time. If you are updating firmware for both the Lenovo XClarity Controller and UEFI, update the firmware for Lenovo XClarity Controller first.

### Update method terminology

- **In-band update**. The installation or update is performed using a tool or application within an operating system that is executing on the server's core CPU.
- **Out-of-band update**. The installation or update is performed by the Lenovo XClarity Controller collecting the update and then directing the update to the target subsystem or device. Out-of-band updates have no dependency on an operating system executing on the core CPU. However, most out-of-band operations do require the server to be in the S0 (Working) power state.
- **On-Target update.** The installation or update is initiated from an Operating System executing on the server's operating system.
- **Off-Target update.** The installation or update is initiated from a computing device interacting directly with the server's Lenovo XClarity Controller.
- UpdateXpress System Packs (UXSPs). UXSPs are bundled updates designed and tested to provide the interdependent level of functionality, performance, and compatibility. UXSPs are server machine-type specific and are built (with firmware and device driver updates) to support specific Windows Server, Red Hat Enterprise Linux (RHEL) and SUSE Linux Enterprise Server (SLES) operating system distributions. Machine-type-specific firmware-only UXSPs are also available.

See the following table to determine the best Lenovo tool to use for installing and setting up the firmware:

Tool	Update Methods Suppor- ted	Core System Firmware Updates	I/O Devices Firm- ware Updates	Graphi- cal user interface	Com- mand line interface	Supports UXSPs
Lenovo XClarity Provisioning Manager (LXPM)	In-band <sup>2</sup> On-	$\checkmark$		$\checkmark$		
	Target					
Lenovo XClarity Controller (XCC)	Out-of- √ S band Off- Target		Selected I/O devices	$\checkmark$		
Lenovo XClarity Essentials OneCLI (OneCLI)	In-band Out-of- band	V	All I/O devices		$\checkmark$	$\checkmark$
	On- Target					
	Off- Target					
Lenovo XClarity Essentials UpdateXpress (LXCE)	In-band Out-of- band	V	All I/O devices	V		V
	On- Target Off- Target					
Lenovo XClarity Essentials Bootable Media Creator <sup>3</sup> (BOMC)	In-band On- Target	V	All I/O devices	√ (BOMC applica- tion)	√ (BOMC applica- tion)	V
Lenovo XClarity Administrator (LXCA)	In-band <sup>1</sup> Out-of- band <sup>2</sup> Off- Target	V	√ All I/O √ devices			V
Lenovo XClarity Integrator (LXCI) for VMware vCenter	Out-of- band Off- Target	$\checkmark$	Selected I/O devices			

ΤοοΙ	Update Methods Suppor- ted	Core System Firmware Updates	I/O Devices Firm- ware Updates	Graphi- cal user interface	Com- mand line interface	Supports UXSPs
Lenovo XClarity Integrator (LXCI) for Microsoft Windows Admin Center	In-band Out-of- band On- Target Off- Target	$\checkmark$	All I/O devices	$\checkmark$		$\checkmark$
Lenovo XClarity Integrator (LXCI) for Microsoft System Center Configuration Manager	In-band On- Target	$\checkmark$	All I/O devices	$\checkmark$		$\checkmark$
Notes: 1. For I/O firmware updates. 2. For BMC and UEFI firmware updates.						

# • Lenovo XClarity Provisioning Manager

From Lenovo XClarity Provisioning Manager, you can update the Lenovo XClarity Controller firmware, the UEFI firmware, and the Lenovo XClarity Provisioning Manager software.

**Note:** By default, the Lenovo XClarity Provisioning Manager Graphical User Interface is displayed when you press F1. If you have changed that default to be the text-based system setup, you can bring up the Graphical User Interface from the text-based system setup interface.

Additional information about using Lenovo XClarity Provisioning Manager to update firmware is available at:

### http://sysmgt.lenovofiles.com/help/topic/LXPM/platform\_update.html

### • Lenovo XClarity Controller

If you need to install a specific update, you can use the Lenovo XClarity Controller interface for a specific server.

### Notes:

 To perform an in-band update through Windows or Linux, the operating system driver must be installed and the Ethernet-over-USB (sometimes called LAN over USB) interface must be enabled.

Additional information about configuring Ethernet over USB is available at:

http://sysmgt.lenovofiles.com/help/topic/com.lenovo.systems.management.xcc.doc/NN1ia\_c\_ configuringUSB.html

- If you update firmware through the Lenovo XClarity Controller, make sure that you have downloaded and installed the latest device drivers for the operating system that is running on the server.

Specific details about updating firmware using Lenovo XClarity Controller are available at:

http://sysmgt.lenovofiles.com/help/topic/com.lenovo.systems.management.xcc.doc/NN1ia\_c\_ manageserverfirmware.html

## • Lenovo XClarity Essentials OneCLI

Lenovo XClarity Essentials OneCLI is a collection of command line applications that can be used to manage Lenovo servers. Its update application can be used to update firmware and device drivers for your servers. The update can be performed within the host operating system of the server (in-band) or remotely through the BMC of the server (out-of-band).

Specific details about updating firmware using Lenovo XClarity Essentials OneCLI is available at:

http://sysmgt.lenovofiles.com/help/topic/toolsctr\_cli\_lenovo/onecli\_c\_update.html

#### Lenovo XClarity Essentials UpdateXpress

Lenovo XClarity Essentials UpdateXpress provides most of OneCLI update functions through a graphical user interface (GUI). It can be used to acquire and deploy UpdateXpress System Pack (UXSP) update packages and individual updates. UpdateXpress System Packs contain firmware and device driver updates for Microsoft Windows and for Linux.

You can obtain Lenovo XClarity Essentials UpdateXpress from the following location:

https://datacentersupport.lenovo.com/solutions/Invo-xpress

### Lenovo XClarity Essentials Bootable Media Creator

You can use Lenovo XClarity Essentials Bootable Media Creator to create bootable media that is suitable for applying firmware updates, running preboot diagnostics, and deploying Microsoft Windows operating systems.

You can obtain Lenovo XClarity Essentials BoMC from the following location:

https://datacentersupport.lenovo.com/solutions/Invo-bomc

### Lenovo XClarity Administrator

If you are managing multiple servers using the Lenovo XClarity Administrator, you can update firmware for all managed servers through that interface. Firmware management is simplified by assigning firmwarecompliance policies to managed endpoints. When you create and assign a compliance policy to managed endpoints, Lenovo XClarity Administrator monitors changes to the inventory for those endpoints and flags any endpoints that are out of compliance.

Specific details about updating firmware using Lenovo XClarity Administrator are available at:

http://sysmgt.lenovofiles.com/help/topic/com.lenovo.lxca.doc/update\_fw.html

### Lenovo XClarity Integrator offerings

Lenovo XClarity Integrator offerings can integrate management features of Lenovo XClarity Administrator and your server with software used in a certain deployment infrastructure, such as VMware vCenter, Microsoft Admin Center, or Microsoft System Center.

Specific details about updating firmware using Lenovo XClarity Integrator offerings are available at:

https://sysmgt.lenovofiles.com/help/topic/lxci/lxci\_product\_page.html

# Configure the firmware

Several options are available to install and set up the firmware for the server.

**Important:** Do not configure option ROMs to be set to **Legacy** unless directed to do so by Lenovo Support. This setting prevents UEFI drivers for the slot devices from loading, which can cause negative side effects for Lenovo software, such as Lenovo XClarity Administrator and Lenovo XClarity Essentials OneCLI, and to the Lenovo XClarity Controller. The side effects include the inability to determine adapter card details, such as model name and firmware levels. When adapter card information is not available, generic information for the

model name, such as "Adapter 06:00:00" instead of the actually model name, such as "ThinkSystem RAID 930-16i 4GB Flash." In some cases, the UEFI boot process might also hang.

### Lenovo XClarity Provisioning Manager

From Lenovo XClarity Provisioning Manager, you can configure the UEFI settings for your server.

**Note:** The Lenovo XClarity Provisioning Manager provides a Graphical User Interface to configure a server. The text-based interface to system configuration (the Setup Utility) is also available. From Lenovo XClarity Provisioning Manager, you can choose to restart the server and access the text-based interface. In addition, you can choose to make the text-based interface the default interface that is displayed when you press F1.

#### Lenovo XClarity Essentials OneCLI

You can use the config application and commands to view the current system configuration settings and make changes to Lenovo XClarity Controller and UEFI. The saved configuration information can be used to replicate or restore other systems.

For information about configuring the server using Lenovo XClarity Essentials OneCLI, see:

http://sysmgt.lenovofiles.com/help/topic/toolsctr\_cli\_lenovo/onecli\_c\_settings\_info\_commands.html

#### Lenovo XClarity Administrator

You can quickly provision and pre-provision all of your servers using a consistent configuration. Configuration settings (such as local storage, I/O adapters, boot settings, firmware, ports, and Lenovo XClarity Controller and UEFI settings) are saved as a server pattern that can be applied to one or more managed servers. When the server patterns are updated, the changes are automatically deployed to the applied servers.

Specific details about updating firmware using Lenovo XClarity Administrator are available at:

http://sysmgt.lenovofiles.com/help/topic/com.lenovo.lxca.doc/server\_configuring.html

#### • Lenovo XClarity Controller

You can configure the management processor for the server through the Lenovo XClarity Controller Web interface or through the command-line interface.

For information about configuring the server using Lenovo XClarity Controller, see:

http://sysmgt.lenovofiles.com/help/topic/com.lenovo.systems.management.xcc.doc/NN1ia\_c\_ manageserverfirmware.html

# Memory configuration

Memory performance depends on several variables, such as memory mode, memory speed, memory ranks, memory population and processor.

More information about optimizing memory performance and configuring memory is available at the Lenovo Press website:

https://lenovopress.com/servers/options/memory

In addition, you can take advantage of a memory configurator, which is available at the following site:

http://1config.lenovo.com/#/memory\_configuration

For specific information about the required installation order of memory modules in your server based on the system configuration and memory mode that you are implementing, see "DIMM installation rules" on page 78.

Table 29. Channel and slot information of DIMMs around processor 1 and 2

The memory-channel configuration table is a three-column table that shows the relationship between the processors, memory controllers, memory channels, slot number and the DIMM connectors.

Integrated Memory Controller (iMC)	Controller 0						Controller 1					
Channel	Channel 2 Channel 1		Channel 0		Channel 0		Channel 1		Channel 2			
Slot	0	1	0	1	0	1	1	0	1	0	1	0
DIMM connector (processor 1)	1	2	3	4	5	6	7	8	9	10	11	12
DIMM connector (processor 2)	13	14	15	16	17	18	19	20	21	22	23	24

# **Configuring DC Persistent Memory Module (DCPMM)**

Follow the instructions in this section to configure DCPMMs and DRAM DIMMs.

DCPMM capacity could act as accessible persistent memory for applications or volatile system memory. Based on the approximate percentage of DCPMM capacity invested in volatile system memory, the following three operating modes are available for choice:

• App direct mode (0% of DCPMM memory acts as system memory):

In this mode, DCPMMs act as independent and persistent memory resources directly accessible by specific applications, and DRAM DIMMs act as system memory.

The total displayed volatile system memory in this mode is the sum of DRAM DIMM capacity.

# Notes:

- In App Direct Mode, the DRAM DIMMs that are installed can be configured to mirror mode.
- When only one DCPMM is installed for each processor, only not-interleaved App direct mode is supported.
- Mixed memory mode (1-99% of DCPMM memory acts as system memory):

In this mode, some percentage of DCPMM capacity is directly accessible to specific applications (App direct), while the rest serves as system memory. The App direct part of DCPMM is displayed as persistent memory, while the rest of DCPMM capacity is displayed as system memory. DRAM DIMMs act as cache in this mode.

The total displayed volatile system memory in this mode is the DCPMM capacity that is invested in volatile system memory.

• Memory mode (100% of DCPMM memory acts as system memory):

In this mode, DCPMMs act as volatile system memory, while DRAM DIMMs act as cache. Only DCPMM capacity is displayed as system memory in this mode.

The total displayed volatile system memory in this mode is the sum of DCPMM capacity.

# **DCPMM Management options**

DCPMMs can be managed with the following tools:

• Lenovo XClarity Provisioning Manager (LXPM)

To open LXPM, power on the system and press **F1** as soon as the logo screen appears. If a password has been set, enter the password to unlock LXPM.

Go to **UEFI Setup** → **System Settings** → **Intel Optane DCPMMs** to configure and manage DCPMMs.

For more details, see https://sysmgt.lenovofiles.com/help/topic/LXPM/UEFI\_setup.html.

**Note:** If the text-based interface of Setup Utility opens instead of Lenovo XClarity Provisioning Manager, go to **System Settings**  $\rightarrow$  <**F1**> **Start Control** and select **Tool Suite**. Then, reboot the system and press **F1** as soon as the logo screen appears to open Lenovo XClarity Provisioning Manager.

# • Setup Utility

To enter Setup Utility:

- 1. Power on the system and press F1 to open LXPM.
- 2. Go to **UEFI Settings** → **System Settings**, click on the pull-down menu on the upper right corner of the screen, and select **Text Setup**.
- 3. Reboot the system, and press F1 as soon as the logo screen appears.

Go to System Configuration and Boot Management  $\rightarrow$  System Settings  $\rightarrow$  Intel Optane DCPMMs to configure and manage DCPMMs.

• Lenovo XClarity Essentials OneCLI

Some management options are available in commands that are executed in the path of Lenovo XClarity Essentials OneCLI in the operating system. See <a href="https://sysmgt.lenovofiles.com/help/topic/toolsctr\_cli\_lenovo/onecli\_t\_download\_use\_tcscli.html">https://sysmgt.lenovofiles.com/help/topic/toolsctr\_cli\_lenovo/onecli\_t\_download\_use\_tcscli.html</a> to learn how to download and use Lenovo XClarity Essentials OneCLI.

Following are the available management options:

# • Intel Optane DCPMM details

Select this option to view the following details concerning each of the the installed DCPMMs:

- Firmware version
- Configuration status
- Raw capacity
- Memory capacity
- App Direct capacity
- Unconfigured capacity
- Inaccessible capacity
- Reserved capacity
- Percentage remaining
- Security state

Alternatively, view DCPMM details with the following command in OneCLI:

onecli.exe config show IntelOptaneDCPMM

--imm USERID:PASSWORD@10.104.195.86

### Notes:

- USERID stands for XCC user ID.
- PASSWORD stands for XCC user password.
- 10.104.195.86 stands for IP address.
- Goals
  - Memory Mode [%]

Select this option to define the percentage of DCPMM capacity that is invested in system memory, and hence decide the DCPMM mode:

- 0%: App Direct Mode
- 1-99%: Mixed Memory Mode
- 100%: Memory Mode

Go to Goals → Memory Mode [%], input the memory percentage, and reboot the system.

#### Notes:

- Before changing from one mode to another:
  - 1. Back up all the data and delete all the created namespaces. Go to Namespaces → View/ Modify/Delete Namespaces to delete the created namespaces.
  - Perform secure erase on all the installed DCPMMs. Go to Security → Press to Secure Erase to perform secure erase.
- Make sure the capacity of installed DCPMMs and DRAM DIMMs meets system requirements for the new mode (see "DCPMM installation rules" on page 84).
- After the system is rebooted and the input goal value is applied, the displayed value in System Configuration and Boot Management → Intel Optane DCPMMs → Goals will go back to the following default selectable options:
  - Scope: [Platform]
  - Memory Mode [%]: 0
  - Persistent Memory Type: [App Direct]

These values are selectable options for DCPMM settings, and do not represent the current DCPMM status.

In addition, you can take advantage of a memory configurator, which is available at the following site: http://1config.lenovo.com/#/memory\_configuration

Alternatively, set DCPMM Goals with the following commands in OneCLI:

1. Set create goal status.

onecli.exe config set IntelOptaneDCPMM.CreateGoal Yes --imm USERID:PASSWORD@10.104.195.86

2. Define the DCPMM capacity that is invested in system volatile memory.

onecli.exe config set IntelOptaneDCPMM.MemoryModePercentage 20
--imm USERID:PASSWORD@10.104.195.86

Where 20 stands for the percentage of capacity that is invested in system volatile memory.

3. Set the DCPMM mode.

onecli.exe config set IntelOptaneDCPMM.PersistentMemoryType "App Direct"
--imm USERID:PASSWORD@10.104.195.86

Where App Direct stands for the DCPMM mode.

### - Persistent Memory Type

In App Direct Mode and Mixed Memory Mode, the DCPMMs that are connected to the same processor are by default interleaved (displayed as **App Direct**), while memory banks are used in turns. To set them as not interleaved in the Setup Utility, go to **Intel Optane DCPMMs**  $\rightarrow$  **Goals**  $\rightarrow$  **Persistent Memory Type [(DCPMM mode)]**, select **App Direct Not Interleaved** and reboot the system.

**Note:** Setting DCPMM App Direct capacity to not interleaved will turn the displayed App Direct regions from one region per processor to one region per DCPMM.

# • Regions

After the memory percentage is set and the system is rebooted, regions for the App Direct capacity will be generated automatically. Select this option to view the App Direct regions.

#### Namespaces

App Direct capacity of DCPMMs requires the following steps before it is truly available for applications.

- 1. Namespaces must be created for region capacity allocation.
- 2. Filesystem must be created and formatted for the namespaces in the operating system.

Each App Direct region can be allocated into one namespace. Create namespaces in the following operating systems:

- Windows: Use *Pmem* command.
- Linux: Use ndctl command.
- VMware: Reboot the system, and VMware will create namespaces automatically.

After creating namespaces for App Direct capacity allocation, make sure to create and format filesystem in the operating system so that the App Direct capacity is accessible for applications.

#### • Security

- Enable Security

DCPMMs can be secured with passphrases. Two types of passphrase protection scope are available for DCPMM:

Platform: Choose this option to run security operation on all the installed DCPMM units at once. A
platform passphrase is stored and automatically applied to unlock DCPMMs before operating
system starts running, but the passphrase still has to be disabled manually for secure erase.

Alternatively, enable/disable platform level security with the following commands in OneCLI:

- Enable security:
  - 1. Enable security.

```
onecli.exe config set IntelOptaneDCPMM.SecurityOperation "Enable Security"
--imm USERID:PASSWORD@10.104.195.86
```

2. Set the security passphrase.

onecli.exe config set IntelOptaneDCPMM.SecurityPassphrase "123456" --imm USERID:PASSWORD@10.104.195.86

Where 123456 stands for the passphrase.

- 3. Reboot the system.
- Disable security:
  - 1. Disable security.

onecli.exe config set IntelOptaneDCPMM.SecurityOperation "Disable Security" --imm USERID:PASSWORD@10.104.195.86

2. Enter passphrase.

onecli.exe config set IntelOptaneDCPMM.SecurityPassphrase "123456" --imm USERID:PASSWORD@10.104.195.86

- 3. Reboot the system.
- Single DCPMM: Choose this option to run security operation on one or more selected DCPMM units.

#### Notes:

- Single DCPMM passphrases are not stored in the system, and security of the locked units needs to be disabled before the units are available for access or secure erase.
- Always make sure to keep records of the slot number of locked DCPMMs and corresponding passphrases. In the case the passphrases are lost or forgotten, the stored data cannot be backed up or restored, but you can contact Lenovo service for administrative secure erase.
- After three failed unlocking attempts, the corresponding DCPMMs enter "exceeded" state with a system warning message, and the DCPMM unit can only be unlocked after the system is rebooted.

To enable passphrase, go to Security → Press to Enable Security.

- Secure Erase

**Note:** If the DCPMMs to be secure erased are protected with a passphrase, make sure to disable security and reboot the system before performing secure erase.

Secure erase cleanses all the data that is stored in the DCPMM unit, including encrypted data. This data deletion method is recommended before returning or disposing a malfunctioning unit, or changing DCPMM mode. To perform secure erase, go to **Security**  $\rightarrow$  **Press to Secure Erase**.

Alternatively, perform platform level secure erase with the following command in OneCLI:

onecli.exe config set IntelOptaneDCPMM.SecurityOperation "Secure Erase Without Passphrase" --imm USERID:PASSWORD@10.104.195.86

#### • DCPMM Configuration

DCPMM contains spared internal cells to stand in for the failed ones. When the spared cells are exhausted to 0%, there will be an error message, and it is advised to back up data, collect service log, and contact Lenovo support.

There will also be a warning message when the percentage reaches 1% and a selectable percentage (10% by default). When this message appears, it is advised to back up data and run DCPMM diagnostics (see https://sysmgt.lenovofiles.com/help/topic/LXPM/running\_diagnostics.html). To adjust the selectable percentage that the warning message requires, go to Intel Optane DCPMMs  $\rightarrow$  DCPMM Configuration, and input the percentage.

Alternatively, change the selectable percentage with the following command in OneCLI:

onecli.exe config set IntelOptaneDCPMM.PercentageRemainingThresholds 20 --imm USERID:PASSWORD@10.104.195.86

Where 20 is the selectable percentage.

# **RAID** configuration

Using a Redundant Array of Independent Disks (RAID) to store data remains one of the most common and cost-efficient methods to increase server's storage performance, availability, and capacity.

RAID increases performance by allowing multiple drives to process I/O requests simultaneously. RAID can also prevent data loss in case of a drive failure by reconstructing (or rebuilding) the missing data from the failed drive using the data from the remaining drives.

RAID array (also known as RAID drive group) is a group of multiple physical drives that uses a certain common method to distribute data across the drives. A virtual drive (also known as virtual disk or logical drive) is a partition in the drive group that is made up of contiguous data segments on the drives. Virtual drive

is presented up to the host operating system as a physical disk that can be partitioned to create OS logical drives or volumes.

An introduction to RAID is available at the following Lenovo Press website:

https://lenovopress.com/lp0578-lenovo-raid-introduction

Detailed information about RAID management tools and resources is available at the following Lenovo Press website:

https://lenovopress.com/lp0579-lenovo-raid-management-tools-and-resources

# Deploy the operating system

Several options are available to deploy an operating system on the server.

#### Available operating systems

- Microsoft Windows Server
- VMware ESXi
- Red Hat Enterprise Linux
- SUSE Linux Enterprise Server

Complete list of available operating systems: https://lenovopress.com/osig.

#### **Tool-based deployment**

• Multi-server

Available tools:

- Lenovo XClarity Administrator

http://sysmgt.lenovofiles.com/help/topic/com.lenovo.lxca.doc/compute\_node\_image\_deployment.html

Lenovo XClarity Essentials OneCLI

http://sysmgt.lenovofiles.com/help/topic/toolsctr\_cli\_lenovo/onecli\_r\_uxspi\_proxy\_tool.html

- Lenovo XClarity Integrator deployment pack for SCCM (for Windows operating system only)

https://sysmgt.lenovofiles.com/help/topic/com.lenovo.lxci\_deploypack\_sccm.doc/dpsccm\_c\_endtoend\_ deploy\_scenario.html

#### • Single-server

Available tools:

- Lenovo XClarity Provisioning Manager

https://sysmgt.lenovofiles.com/help/topic/LXPM/os\_installation.html

Lenovo XClarity Essentials OneCLI

http://sysmgt.lenovofiles.com/help/topic/toolsctr\_cli\_lenovo/onecli\_r\_uxspi\_proxy\_tool.html

- Lenovo XClarity Integrator deployment pack for SCCM (for Windows operating system only)

https://sysmgt.lenovofiles.com/help/topic/com.lenovo.lxci\_deploypack\_sccm.doc/dpsccm\_c\_endtoend\_ deploy\_scenario.html

#### Manual deployment

If you cannot access the above tools, follow the instructions below, download the corresponding OS *Installation Guide*, and deploy the operating system manually by referring to the guide.

- 1. Go to https://datacentersupport.lenovo.com/solutions/server-os.
- 2. Select an operating system from the navigation pane and click **Resources**.
- 3. Locate the "OS Install Guides" area and click the installation instructions. Then, follow the instructions to complete the operation system deployment task.

# Back up the server configuration

After setting up the server or making changes to the configuration, it is a good practice to make a complete backup of the server configuration.

Make sure that you create backups for the following server components:

Management processor

You can back up the management processor configuration through the Lenovo XClarity Controller interface. For details about backing up the management processor configuration, see:

http://sysmgt.lenovofiles.com/help/topic/com.lenovo.systems.management.xcc.doc/NN1ia\_c\_backupthexcc.html

Alternatively, you can use the save command from Lenovo XClarity Essentials OneCLI to create a backup of all configuration settings. For more information about the save command, see:

http://sysmgt.lenovofiles.com/help/topic/toolsctr\_cli\_lenovo/onecli\_r\_save\_command.html

Operating system

Use your own operating-system and user-data backup methods to back up the operating system and user data for the server.

# Update the Vital Product Data (VPD)

After initial setup of the system, you can update some Vital Product Data (VPD), such as asset tag and Universal Unique Identifier (UUID).

# Update the Universal Unique Identifier (UUID)

Optionally, you can update the Universal Unique Identifier (UUID).

There are two methods available to update the UUID:

· From Lenovo XClarity Provisioning Manager

To update the UUID from Lenovo XClarity Provisioning Manager:

- 1. Start the server and press F1 to display the Lenovo XClarity Provisioning Manager interface.
- 2. If the power-on Administrator password is required, enter the password.
- 3. From the System Summary page, click **Update VPD**.
- 4. Update the UUID.
- From Lenovo XClarity Essentials OneCLI

Lenovo XClarity Essentials OneCLI sets the UUID in the Lenovo XClarity Controller. Select one of the following methods to access the Lenovo XClarity Controller and set the UUID:

- Operate from the target system, such as LAN or keyboard console style (KCS) access
- Remote access to the target system (TCP/IP based)

To update the UUID from Lenovo XClarity Essentials OneCLI:

1. Download and install Lenovo XClarity Essentials OneCLI.

To download Lenovo XClarity Essentials OneCLI, go to the following site:

https://datacentersupport.lenovo.com/solutions/HT116433

- 2. Copy and unpack the OneCLI package, which also includes other required files, to the server. Make sure that you unpack the OneCLI and the required files to the same directory.
- 3. After you have Lenovo XClarity Essentials OneCLI in place, type the following command to set the UUID:

onecli config createuuid SYSTEM\_PROD\_DATA.SysInfoUUID [access\_method]

Where:

#### [access\_method]

The access method that you select to use from the following methods:

- Online authenticated LAN access, type the command:

[--bmc-username <xcc\_user\_id> --bmc-password <xcc\_password>]

Where:

xcc\_user\_id

The BMC/IMM/XCC account name (1 of 12 accounts). The default value is USERID.

xcc\_password The BMC/IMM/XCC account password (1 of 12 accounts).

Example command is as follows: onecli config createuuid SYSTEM\_PROD\_DATA.SysInfoUUID --bmc-username <xcc\_user\_id> --bmc-password <xcc\_password>

- Online KCS access (unauthenticated and user restricted):

You do not need to specify a value for access\_method when you use this access method.

```
Example command is as follows:
onecli config createuuid SYSTEM_PROD_DATA.SysInfoUUID
```

**Note:** The KCS access method uses the IPMI/KCS interface, which requires that the IPMI driver be installed.

- Remote LAN access, type the command:

[--bmc <xcc\_user\_id>:<xcc\_password>@<xcc\_external\_ip>]

Where:

xcc\_external\_ip

The BMC/IMM/XCC external IP address. There is no default value. This parameter is required.

xcc\_user\_id

The BMC/IMM/XCC account name (1 of 12 accounts). The default value is USERID.

xcc\_password

The BMC/IMM/XCC account password (1 of 12 accounts).

**Note:** BMC, IMM, or XCC external IP address, account name, and password are all valid for this command.

Example command is as follows: onecli config createuuid SYSTEM\_PROD\_DATA.SysInfoUUID --bmc <xcc\_user\_id>:<xcc\_password>@<xcc\_external\_ip>

- 4. Restart the Lenovo XClarity Controller.
- 5. Restart the server.

# Update the asset tag

Optionally, you can update the asset tag.

There are two methods available to update the asset tag:

• From Lenovo XClarity Provisioning Manager

To update the asset tag from Lenovo XClarity Provisioning Manager:

- 1. Start the server and press F1 to display the Lenovo XClarity Provisioning Manager interface.
- 2. If the power-on Administrator password is required, enter the password.
- 3. From the System Summary page, click Update VPD.
- 4. Update the asset tag information.
- From Lenovo XClarity Essentials OneCLI

Lenovo XClarity Essentials OneCLI sets the asset tag in the Lenovo XClarity Controller. Select one of the following methods to access the Lenovo XClarity Controller and set the asset tag:

- Operate from the target system, such as LAN or keyboard console style (KCS) access
- Remote access to the target system (TCP/IP based)

To update the asset tag from Lenovo XClarity Essentials OneCLI:

1. Download and install Lenovo XClarity Essentials OneCLI.

To download Lenovo XClarity Essentials OneCLI, go to the following site:

https://datacentersupport.lenovo.com/solutions/HT116433

- 2. Copy and unpack the OneCLI package, which also includes other required files, to the server. Make sure that you unpack the OneCLI and the required files to the same directory.
- 3. After you have Lenovo XClarity Essentials OneCLI in place, type the following command to set the DMI:

onecli config set SYSTEM\_PROD\_DATA.SysEncloseAssetTag <asset\_tag> [access\_method]

Where:

### <asset\_tag>

### [access\_method]

The access method that you select to use from the following methods:

- Online authenticated LAN access, type the command:

[--bmc-username <xcc\_user\_id> --bmc-password <xcc\_password>]

Where:

xcc\_user\_id

The BMC/IMM/XCC account name (1 of 12 accounts). The default value is USERID.

xcc\_password

The BMC/IMM/XCC account password (1 of 12 accounts).

Example command is as follows: onecli config set SYSTEM\_PROD\_DATA.SysEncloseAssetTag <asset\_tag> --bmc-username <xcc\_user\_id> --bmc-password <xcc\_password>

- Online KCS access (unauthenticated and user restricted):

You do not need to specify a value for *access\_method* when you use this access method.

Example command is as follows: onecli config set SYSTEM PROD DATA.SysEncloseAssetTag <asset tag>

**Note:** The KCS access method uses the IPMI/KCS interface, which requires that the IPMI driver be installed.

 Remote LAN access, type the command: [--bmc <xcc\_user\_id>:<xcc\_password>@<xcc\_external\_ip>]

Where:

xcc\_external\_ip

The BMC/IMM/XCC IP address. There is no default value. This parameter is required.

xcc\_user\_id

The BMC/IMM/XCC account (1 of 12 accounts). The default value is USERID.

xcc\_password

The BMC/IMM/XCC account password (1 of 12 accounts).

**Note:** BMC, IMM, or XCC internal LAN/USB IP address, account name, and password are all valid for this command.

Example command is as follows: onecli config set SYSTEM\_PROD\_DATA.SysEncloseAssetTag <asset\_tag> --bmc <xcc\_user\_id>:<xcc\_password>@<xcc\_external\_ip>

4. Reset the Lenovo XClarity Controller to the factory defaults. Go to https://sysmgt.lenovofiles.com/help/ topic/com.lenovo.systems.management.xcc.doc/NN1ia\_c\_resettingthexcc.html for more information.

# Chapter 5. Resolving installation issues

Use this information to resolve issues that you might have when setting up your system.

Use the information in this section to diagnose and resolve problems that you might encounter during the initial installation and setup of your server.

- "Server does not power on" on page 139
- "The server immediately displays the POST Event Viewer when it is turned on" on page 139
- "Embedded hypervisor is not in the boot list" on page 139
- "Server cannot recognize a hard drive" on page 140
- "Displayed system memory less than installed physical memory" on page 141
- "A Lenovo optional device that was just installed does not work." on page 142
- "Voltage planar fault is displayed in the event log" on page 142

#### Server does not power on

Complete the following steps until the problem is resolved:

- 1. Check the event log for any events related to the server not powering on.
- 2. Check for any LEDs that are flashing amber.
- 3. Check the power LED on the system board.
- 4. Reseat the power supply.
- 5. Replace the power supply.

### The server immediately displays the POST Event Viewer when it is turned on

Complete the following steps until the problem is solved.

- 1. Correct any errors that are indicated by the light path diagnostics LEDs.
- 2. Make sure that the server supports all the processors and that the processors match in speed and cache size.

You can view processor details from system setup.

To determine if the processor is supported for the server, see https://static.lenovo.com/us/en/serverproven/index.shtml.

- 3. (Trained technician only) Make sure that processor 1 is seated correctly
- 4. (Trained technician only) Remove processor 2 and restart the server.
- 5. Replace the following components one at a time, in the order shown, restarting the server each time:
  - a. (Trained technician only) Processor
  - b. (Trained technician only) System board

### Embedded hypervisor is not in the boot list

Complete the following steps until the problem is solved.

- 1. If the server has been installed, moved, or serviced recently, or if this is the first time the embedded hypervisor is being used, make sure that the device is connected properly and that there is no physical damage to the connectors.
- 2. See the documentation that comes with the optional embedded hypervisor flash device for setup and configuration information.

- 3. Check https://static.lenovo.com/us/en/serverproven/index.shtml to validate that the embedded hypervisor device is supported for the server.
- 4. Make sure that the embedded hypervisor device is listed in the list of available boot options. From the management controller user interface, click **Server Configuration** → **Boot Options**.

For information about accessing the management controller user interface, see the XClarity Controller product documentation:

http://sysmgt.lenovofiles.com/help/topic/com.lenovo.systems.management.xcc.doc/dw1lm\_c\_chapter2\_ openingandusing.html

- 5. Check http://datacentersupport.lenovo.com for any tech tips (service bulletins) related to the embedded hypervisor and the server.
- 6. Make sure that other software works on the server to ensure that it is working properly.

### Server cannot recognize a hard drive

Complete the following steps until the problem is solved.

- 1. Observe the associated yellow hard disk drive status LED. If the LED is lit, it indicates a drive fault.
- 2. If the LED is lit, remove the drive from the bay, wait 45 seconds, and reinsert the drive, making sure that the drive assembly connects to the hard disk drive backplane.
- 3. Observe the associated green hard disk drive activity LED and the yellow status LED:
  - If the green activity LED is flashing and the yellow status LED is not lit, the drive is recognized by the controller and is working correctly. Run the diagnostics tests for the hard disk drives. When you start a server and press F1, the Lenovo XClarity Provisioning Manager interface is displayed by default. You can perform hard drive diagnostics from this interface. From the Diagnostic page, click Run Diagnostic → HDD test.
  - If the green activity LED is flashing and the yellow status LED is flashing slowly, the drive is recognized by the controller and is rebuilding.
  - If neither LED is lit or flashing, check the hard disk drive backplane.
  - If the green activity LED is flashing and the yellow status LED is lit, replace the drive. If the activity of the LEDs remains the same, go to step Hard disk drive problems. If the activity of the LEDs changes, return to step 1.
- 4. Make sure that the hard disk drive backplane is correctly seated. When it is correctly seated, the drive assemblies correctly connect to the backplane without bowing or causing movement of the backplane.
- 5. Reseat the backplane power cable and repeat steps 1 through 3.
- 6. Reseat the backplane signal cable and repeat steps 1 through 3.
- 7. Suspect the backplane signal cable or the backplane:
  - Replace the affected backplane signal cable.
  - Replace the affected backplane.
- Run the diagnostics tests for the hard disk drives. When you start a server and press F1, the Lenovo XClarity Provisioning Manager interface is displayed by default. You can perform hard drive diagnostics from this interface. From the Diagnostic page, click **Run Diagnostic → HDD test**.

Based on those tests:

- If the adapter passes the test but the drives are not recognized, replace the backplane signal cable and run the tests again.
- Replace the backplane.
- If the adapter fails the test, disconnect the backplane signal cable from the adapter and run the tests again.
• If the adapter fails the test, replace the adapter.

### Displayed system memory less than installed physical memory

Complete the following steps until the problem is solved:

**Note:** Each time you install or remove a memory module, you must disconnect the solution from the power source; then, wait 10 seconds before restarting the solution.

- 1. Make sure that:
  - No error LEDs are lit on the operator information panel.
  - Memory mirrored channel does not account for the discrepancy.
  - The memory modules are seated correctly.
  - You have installed the correct type of memory module (see "Specifications" on page 4 for requirements).
  - If you changed the memory, you updated the memory configuration in the Setup utility.
  - All banks of memory are enabled. The solution might have automatically disabled a memory bank when it detected a problem, or a memory bank might have been manually disabled.
  - There is no memory mismatch when the solution is at the minimum memory configuration.
  - When DCPMMs are installed:
    - a. If the memory is set in App Direct or Mixed Memory Mode, all the saved data have been backed up, and created namespaces are deleted before any DCPMM is replaced.
    - b. Refer to "DC Persistent Memory Module (DCPMM) setup" on page 77 and see if the displayed memory fits the mode description.
    - c. If DCPMMs are recently set in Memory Mode, turn it back to App Direct Mode and examine if there is namespace that has not been deleted (see "DC Persistent Memory Module (DCPMM) setup" on page 77).
    - d. Go to the Setup Utility, select System Configuration and Boot Management → Intel Optane DCPMMs → Security, and make sure all the DCPMM units are unlocked.
- 2. Reseat the memory modules, and then restart the solution.
- 3. Check the POST error log:
  - If a memory module was disabled by a systems-management interrupt (SMI), replace the memory module.
  - If a memory module was disabled by the user or by POST, reseat the memory module; then, run the Setup utility and enable the memory module.
- Run memory diagnostics. Power on the system and press F1 when the logo screen appears, the Lenovo XClarity Provisioning Manager interface will start. Perform memory diagnostics with this interface. Go to Diagnostics → Run Diagnostic → Memory test or DCPMM test.

When DCPMMs are installed, run diagnostics based on the current DCPMM mode:

- App Direct Mode
  - Run **DCPMM Test** for DCPMMs.
  - Run Memory Test for DRAM DIMMs.
- Memory Mode and Mixed Memory Mode
  - Run **DCPMM Test** for App Direct capacity of DCPMMs.
  - Run Memory Test for memory capacity of DCPMMs.

**Note:** DRAM DIMMs in these two modes act as cache, and are not applicable to memory diagnostics.

5. Reverse the modules between the channels (of the same processor), and then restart the solution. If the problem is related to a memory module, replace the failing memory module.

Note: When DCPMMs are installed, only adopt this method in Memory Mode.

- 6. Re-enable all memory modules using the Setup Utility, and restart the system.
- 7. (Trained technician only) Install the failing memory module into a memory module connector for processor 2 (if installed) to verify that the problem is not the processor or the memory module connector.
- 8. (Trained technician only) Replace the node.

### A Lenovo optional device that was just installed does not work.

- 1. Make sure that:
  - The device is supported for the server (see https://static.lenovo.com/us/en/serverproven/index.shtml).
  - You followed the installation instructions that came with the device and the device is installed correctly.
  - You have not loosened any other installed devices or cables.
  - You updated the configuration information in system setup. When you start a server and press F1 to display the system setup interface. Whenever memory or any other device is changed, you must update the configuration.
- 2. Reseat the device that you just installed.
- 3. Replace the device that you just installed.

### Voltage planar fault is displayed in the event log

Complete the following steps until the problem is solved.

- 1. Revert the system to the minimum configuration. See "Specifications" on page 4 for the minimally required number of processors and memory modules.
- 2. Restart the system.
  - If the system restarts, add each of the items that you removed one at a time, restarting the system each time, until the error occurs. Replace the item for which the error occurs.
  - If the system does not restart, suspect the system board.

# Appendix A. Getting help and technical assistance

If you need help, service, or technical assistance or just want more information about Lenovo products, you will find a wide variety of sources available from Lenovo to assist you.

On the World Wide Web, up-to-date information about Lenovo systems, optional devices, services, and support are available at:

#### http://datacentersupport.lenovo.com

Note: IBM is Lenovo's preferred-service provider for ThinkSystem.

### Before you call

Before you call, there are several steps that you can take to try and solve the problem yourself. If you decide that you do need to call for assistance, gather the information that will be needed by the service technician to more quickly resolve your problem.

#### Attempt to resolve the problem yourself

You can solve many problems without outside assistance by following the troubleshooting procedures that Lenovo provides in the online help or in the Lenovo product documentation. The Lenovo product documentation also describes the diagnostic tests that you can perform. The documentation for most systems, operating systems, and programs contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the operating system or program.

You can find the product documentation for your ThinkSystem products at the following location:

#### http://thinksystem.lenovofiles.com/help/index.jsp

You can take these steps to try to solve the problem yourself:

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Check for updated software, firmware, and operating-system device drivers for your Lenovo product. The Lenovo Warranty terms and conditions state that you, the owner of the Lenovo product, are responsible for maintaining and updating all software and firmware for the product (unless it is covered by an additional maintenance contract). Your service technician will request that you upgrade your software and firmware if the problem has a documented solution within a software upgrade.
- If you have installed new hardware or software in your environment, check <a href="https://static.lenovo.com/us/en/serverproven/index.shtml">https://static.lenovo.com/us/en/serverproven/index.shtml</a> to make sure that the hardware and software is supported by your product.
- Go to http://datacentersupport.lenovo.com and check for information to help you solve the problem.
  - Check the Lenovo forums at https://forums.lenovo.com/t5/Datacenter-Systems/ct-p/sv\_eg to see if someone else has encountered a similar problem.

#### Gathering information needed to call Support

If you believe that you require warranty service for your Lenovo product, the service technicians will be able to assist you more efficiently if you prepare before you call. You can also see <a href="http://datacentersupport.lenovo.com/warrantylookup">http://datacentersupport.lenovo.com/warrantylookup</a> for more information about your product warranty.

Gather the following information to provide to the service technician. This data will help the service technician quickly provide a solution to your problem and ensure that you receive the level of service for which you might have contracted.

- Hardware and Software Maintenance agreement contract numbers, if applicable
- Machine type number (Lenovo 4-digit machine identifier)
- Model number
- Serial number
- Current system UEFI and firmware levels
- · Other pertinent information such as error messages and logs

As an alternative to calling Lenovo Support, you can go to https://support.lenovo.com/servicerequest to submit an Electronic Service Request. Submitting an Electronic Service Request will start the process of determining a solution to your problem by making the pertinent information available to the service technicians. The Lenovo service technicians can start working on your solution as soon as you have completed and submitted an Electronic Service Request.

## **Collecting service data**

To clearly identify the root cause of a server issue or at the request of Lenovo Support, you might need collect service data that can be used for further analysis. Service data includes information such as event logs and hardware inventory.

Service data can be collected through the following tools:

#### Lenovo XClarity Provisioning Manager

Use the Collect Service Data function of Lenovo XClarity Provisioning Manager to collect system service data. You can collect existing system log data or run a new diagnostic to collect new data.

#### • Lenovo XClarity Controller

You can use the Lenovo XClarity Controller web interface or the CLI to collect service data for the server. The file can be saved and sent to Lenovo Support.

- For more information about using the web interface to collect service data, see http:// sysmgt.lenovofiles.com/help/topic/com.lenovo.systems.management.xcc.doc/NN1ia\_c\_ servicesandsupport.html.
- For more information about using the CLI to collect service data, see <a href="http://sysmgt.lenovofiles.com/help/topic/com.lenovo.systems.management.xcc.doc/nn1ia\_r\_ffdccommand.html">http://sysmgt.lenovofiles.com/help/topic/com.lenovo.systems.management.xcc.doc/nn1ia\_r\_ffdccommand.html</a>.

#### • Lenovo XClarity Administrator

Lenovo XClarity Administrator can be set up to collect and send diagnostic files automatically to Lenovo Support when certain serviceable events occur in Lenovo XClarity Administrator and the managed endpoints. You can choose to send diagnostic files to Lenovo Support using Call Home or to another service provider using SFTP. You can also manually collect diagnostic files, open a problem record, and send diagnostic files to the Lenovo Support Center.

You can find more information about setting up automatic problem notification within the Lenovo XClarity Administrator at http://sysmgt.lenovofiles.com/help/topic/com.lenovo.lxca.doc/admin\_setupcallhome.html.

### Lenovo XClarity Essentials OneCLI

Lenovo XClarity Essentials OneCLI has inventory application to collect service data. It can run both inband and out-of-band. When running in-band within the host operating system on the server, OneCLI can collect information about the operating system, such as the operating system event log, in addition to the hardware service data. To obtain service data, you can run the getinfor command. For more information about running the getinfor, see http://sysmgt.lenovofiles.com/help/topic/toolsctr\_cli\_lenovo/onecli\_r\_getinfor\_command.html.

## **Contacting Support**

You can contact Support to obtain help for your issue.

You can receive hardware service through a Lenovo Authorized Service Provider. To locate a service provider authorized by Lenovo to provide warranty service, go to https://datacentersupport.lenovo.com/ serviceprovider and use filter searching for different countries. For Lenovo support telephone numbers, see https://datacentersupport.lenovo.com/supportphonelist for your region support details.

# Appendix B. Trademarks

LENOVO, THINKSYSTEM, and XCLARITY are trademarks of Lenovo.

Intel, Optane, and Xeon are trademarks of Intel Corporation in the United States, other countries, or both. Microsoft and Windows are trademarks of the Microsoft group of companies. Linux is a registered trademark of Linus Torvalds. All other trademarks are the property of their respective owners. © 2021 Lenovo.

# Index

## Α

```
air baffle
installing 115
removing 70
```

# В

back up the server configuration 135

# С

```
cable the server 120
collecting service data 144
Common installation issues 139
Configuration - ThinkSystem SR630 123
configure the firmware 127
contamination, particulate and gaseous 14
cover
installing 117
removing 68
CPU
option install 72
creating a personalized support web page 143
```

# D

DC Persistent Memory Module (DCPMM) 77 DCPMM 77, 84, 129 devices, static-sensitive handling 66 DIMM installing 75 DIMM installation order 85, 88, 90 Dynamic random access memory (DRAM) 79

# F

features 3

# G

gaseous contamination 14 Getting help 143 GPU GPU upgrade kit 106 installing 106 guidelines options installation 64 system reliability 66

# Η

handling static-sensitive devices 66 hard disk drive installing 118 hardware options installing 67 hardware service and support telephone numbers 145 help 143 hot-swap drive installing 118 hot-swap power supply installing 92

### I

```
Independent mode 80
install server in a rack 120
installation
  guidelines 64
installation guidelines
                      64
installing
  air baffle 115
          75
  DIMM
  GPU 106
  GPU upgrade kit 106
  hard disk drive 118
  hot-swap drive 118
  hot-swap power supply 92
LOM adapter 102
  PCIe adapter and riser assembly 103
  RAID adapter on the system board 95
  RAID super capacitor module on the bottom of the air
   baffle 110
  RAID super capacitor module on the chassis 112
  rear hot-swap drive assembly
                                96
  serial port module
                     108
  system fan 73
  top cover 117
internal cable routing
                     31
```

## L

Lenovo Capacity Planner 15 Lenovo XClarity Essentials 15 Lenovo XClarity Provisioning Manager 15 LOM adapter installing 102

## Μ

M.2 backplane and M.2 drive installing 99 management options 15 memory 77, 129 memory configuration 128–129, 133 memory module installation order 85, 88, 90 memory module installation rules 78 microprocessor option install 72 Mirroring mode 83

## 0

option install CPU 72 microprocessor 72 PHM 72 processor 72 processor 72 processor-heat-sink module 72

### Ρ

particulate contamination 14 parts list 57 PCIe adapter and riser assembly installing 103 PHM option install 72 power cords 61 power off the server 121 power on the server 120 processor option install 72 processor-heat-sink module option install 72

# R

RAID adapter on the system board installing 95
RAID super capacitor module on the bottom of the air baffle installing 110
RAID super capacitor module on the chassis installing 112
Rank sparing mode 82
rear hot-swap drive assembly installing 96
Rear view 22
removing air baffle 70 security bezel 67 top cover 68
retainer on M.2 backplane adjusting 101

## S

safety inspection checklist 65 security bezel removing 67 serial port module installing 108 server models with eight 2.5-inch SAS/SATA drives 38 server models with four 3.5-inch SAS/SATA drives 32 server models with four 3.5-inch SAS/SATA/NVMe drives 35 server models with ten 2.5-inch NVMe drives 51 server models with ten 2.5-inch SAS/SATA/NVMe drives 42 server setup 63 server setup checklist 63 service and support before you call 143 hardware 145 software 145 service data 144 software 19, 21 software service and support telephone numbers 145 static-sensitive devices handling 66 support web page, custom 143 system board components 30 System configuration - ThinkSystem SR630 123 system fan installing 73 system reliability guidelines 66

# Т

telephone numbers 145 top cover installing 117 removing 68 trademarks 147

## U

update the firmware 124 updating asset tag 137 Universal Unique Identifier (UUID) 135 Update the Vital Product Data (VPD) 135

## V

validate server setup 121

## W

working inside the server power on 66

