



System x3650 M3
Types 4255, 7945, and 7949
Installation and User's Guide





System x3650 M3
Types 4255, 7945, and 7949
Installation and User's Guide

Note

Note: Before using this information and the product it supports, read the general information in Appendix B, "Notices," on page 181; and read the *IBM Safety Information* and the *IBM Systems Environmental Notices and User Guide* on the IBM Documentation CD.

Eleventh Edition (June 2014)

© Copyright IBM Corporation 2013.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Safety	v
Safety statements	vii

Chapter 1. The System x3650 M3 server 1

The IBM Documentation CD	3
Hardware and software requirements	4
Using the Documentation Browser	4
Related documentation	5
Notices and statements in this document	6
Features and specifications.	6
What your server offers	10
Reliability, availability, and serviceability features.	13
IBM Systems Director	14
The UpdateXpress System Pack Installer	15
Server controls, LEDs, and power	15
Front view.	15
Operator information panel	16
Light path diagnostics panel.	17
Rear view	18
Power-supply LEDs	20
Server power features	23
Turning on the server	23
Turning off the server	23

Chapter 2. Installing optional devices 25

Instructions for IBM Business Partners	26
Server components	26
System-board internal connectors	28
System-board external connectors	28
System-board switches and jumpers	29
System-board LEDs.	33
System pulse LEDs	34
System-board optional device connectors	34
SAS riser-card connectors and LEDs	35
PCI riser-card adapter connectors	36
PCI riser-card assembly LEDs	37
Installation guidelines	37
System reliability guidelines.	39
Working inside the server with the power on	39
Handling static-sensitive devices	40
Internal cable routing and connectors.	40
Removing the cover	45
Removing a PCI riser-card assembly	46
Installing a PCI riser-card assembly	47
Removing the microprocessor 2 air baffle	48
Installing the microprocessor 2 air baffle.	49
Removing the DIMM air baffle	50
Installing the DIMM air baffle	51
Installing the full-length-adapter bracket.	52
Storing the full-length-adapter bracket	52
Installing a PCI adapter	53
Removing a PCI adapter	58
Installing an IBM Virtual Media Key	60
Installing a hard disk drive	61
Removing a hard disk drive	62

Installing a simple-swap hard disk drive	63
Removing a simple-swap hard disk drive	64
Installing a SAS/SATA 4 Pac HDD upgrade option	65
Installing a SAS/SATA 8 Pac HDD option	72
Installing a SAS/SATA 8 Pac HDD for 2 RAID kit with 2 M5015 adapters option	86
Installing an optional tape drive	100
Converting a 16 bay system to a 8 bay + tape system	101
Installing the tape drive option	103
Installing a second microprocessor	108
Thermal grease	114
Installing a memory module	115
DIMM installation sequence	118
Memory mirroring.	119
Online-spare memory	121
Installing a DIMM.	121
Installing a hot-swap ac power supply	123
Removing a hot-swap fan	127
Installing a hot-swap fan	128
Removing the SAS riser-card and controller assembly	129
Installing the SAS riser-card and controller assembly	130
Removing a ServeRAID SAS controller from the SAS riser-card	134
Installing a ServeRAID SAS controller on the SAS riser-card.	135
Installing an optional ServeRAID adapter advanced feature key	137
Installing a ServeRAID SAS controller battery on the remote battery tray	139
Moving the SAS controller retention bracket	145
Installing a USB hypervisor memory key	147
Removing a USB hypervisor memory key	148
Installing the optional two-port Ethernet adapter	149
Installing an optional DVD drive.	153
Completing the installation.	154
Replacing the server cover	155
Connecting the external cables.	155
Updating the server configuration	156

Chapter 3. Configuring the server . . 157

Using the Setup utility	158
Starting the Setup utility	159
Setup utility menu choices	159
Passwords	162
Power-on password	163
Administrator password.	163
Using the Boot Selection Menu program	164
Starting the backup server firmware.	164
Using the ServerGuide Setup and Installation CD	164
ServerGuide features	165
Setup and configuration overview	165
Typical operating-system installation	166

Installing your operating system without using ServerGuide	166
Using the integrated management module.	167
Using the USB memory key for VMware hypervisor	168
Using the remote presence capability and blue-screen capture	169
Enabling the remote presence feature	170
Obtaining the IP address for the Web interface access	170
Logging on to the Web interface	171
Enabling the Broadcom Gigabit Ethernet Utility program	171
Configuring the Gigabit Ethernet controller	172
Using the LSI Configuration Utility program	172
Starting the LSI Configuration Utility program	173
Formatting a hard disk drive	174
Creating a RAID array of hard disk drives	174
IBM Advanced Settings Utility program	175
Updating IBM Systems Director	175

Appendix A. Getting help and technical assistance 177

Before you call	177
Using the documentation	178
Getting help and information from the World Wide Web	178
How to send DSA data to IBM	178
Creating a personalized support web page	179
Software service and support	179
Hardware service and support	179

IBM Taiwan product service	179
--------------------------------------	-----

Appendix B. Notices 181

Trademarks	182
Important notes	182
Particulate contamination	183
Documentation format	184
Telecommunication regulatory statement	184
Electronic emission notices	185
Federal Communications Commission (FCC) statement.	185
Industry Canada Class A emission compliance statement.	185
Avis de conformité à la réglementation d'Industrie Canada	185
Australia and New Zealand Class A statement	185
European Union EMC Directive conformance statement.	186
Germany Class A statement	186
Japan VCCI Class A statement.	187
Japan Electronics and Information Technology Industries Association (JEITA) statement	188
Korea Communications Commission (KCC) statement.	188
Russia Electromagnetic Interference (EMI) Class A statement	188
People's Republic of China Class A electronic emission statement	188
Taiwan Class A compliance statement	189

Index 191

Safety

Before installing this product, read the Safety Information.

قبل تركيب هذا المنتج، يجب قراءة الملاحظات الأمنية

Antes de instalar este produto, leia as Informações de Segurança.

在安裝本产品之前，请仔细阅读 **Safety Information**
(安全信息)。

安裝本產品之前，請先閱讀「安全資訊」。

Prije instalacije ovog produkta obavezno pročitajte Sigurnosne Upute.

Před instalací tohoto produktu si přečtěte příručku bezpečnostních instrukcí.

Læs sikkerhedsforskrifterne, før du installerer dette produkt.

Lees voordat u dit product installeert eerst de veiligheidsvoorschriften.

Ennen kuin asennat tämän tuotteen, lue turvaohjeet kohdasta Safety Information.

Avant d'installer ce produit, lisez les consignes de sécurité.

Vor der Installation dieses Produkts die Sicherheitshinweise lesen.

Πριν εγκαταστήσετε το προϊόν αυτό, διαβάστε τις πληροφορίες ασφάλειας
(safety information).

לפני שתתקינו מוצר זה, קראו את הוראות הבטיחות.


A termék telepítése előtt olvassa el a Biztonsági előírásokat!

Prima di installare questo prodotto, leggere le Informazioni sulla Sicurezza.

製品の設置の前に、安全情報をお読みください。

본 제품을 설치하기 전에 안전 정보를 읽으십시오.

Пред да се инсталира овој продукт, прочитајте информацијата за безбедност.



Les sikkerhetsinformasjonen (Safety Information) før du installerer dette produktet.

Przed zainstalowaniem tego produktu, należy zapoznać się z książką "Informacje dotyczące bezpieczeństwa" (Safety Information).

Antes de instalar este produto, leia as Informações sobre Segurança.

Перед установкой продукта прочтите инструкции по технике безопасности.

Pred inštaláciou tohto zariadenia si pečítajte Bezpečnostné predpisy.

Pred namestitvijo tega proizvoda preberite Varnostne informacije.

Antes de instalar este producto, lea la información de seguridad.

Läs säkerhetsinformationen innan du installerar den här produkten.

ཐོན་ཁུངས་འདི་བདེ་སྤྱད་མ་བྱས་གོང་། སྐྱོར་གྱི་ཡིད་གཟབ་
བྱ་འདྲ་མིན་ཡིད་པའི་འོད་མེར་བལྟ་དགོས།

Bu ürünü kurmadan önce güvenlik bilgilerini okuyun.

مەزكۇر مەھسۇلاتنى ئورنىتىشتىن بۇرۇن بىخەتەرلىك ئۇچۇرلىرىنى ئوقۇپ چىقىڭ.

Youq mwngz yungh canjbinj neix gaxgonq, itdingh aeu doeg aen
canjbinj soengq cungj vahgangj ancien siusik.

Safety statements

These statements provide the caution and danger information that is used in this documentation.

Important:

Each caution and danger statement in this documentation is labeled with a number. This number is used to cross reference an English-language caution or danger statement with translated versions of the caution or danger statement in the *Safety Information* document.

For example, if a caution statement is labeled Statement 1, translations for that caution statement are in the *Safety Information* document under Statement 1.

Be sure to read all caution and danger statements in this documentation before you perform the procedures. Read any additional safety information that comes with your system or optional device before you install the device.

Statement 1



DANGER

Electrical current from power, telephone, and communication cables is hazardous.

To avoid a shock hazard:

- Do not connect or disconnect any cables or perform installation, maintenance, or reconfiguration of this product during an electrical storm.
- Connect all power cords to a properly wired and grounded electrical outlet.
- Connect to properly wired outlets any equipment that will be attached to this product.
- When possible, use one hand only to connect or disconnect signal cables.
- Never turn on any equipment when there is evidence of fire, water, or structural damage.
- Disconnect the attached power cords, telecommunications systems, networks, and modems before you open the device covers, unless instructed otherwise in the installation and configuration procedures.
- Connect and disconnect cables as described in the following table when installing, moving, or opening covers on this product or attached devices.

To Connect:

1. Turn everything OFF.
2. First, attach all cables to devices.
3. Attach signal cables to connectors.
4. Attach power cords to outlet.
5. Turn device ON.

To Disconnect:

1. Turn everything OFF.
2. First, remove power cords from outlet.
3. Remove signal cables from connectors.
4. Remove all cables from devices.

Statement 2



CAUTION:

When replacing the lithium battery, use only IBM® Part Number 33F8354 or an equivalent type battery recommended by the manufacturer. If your system has a module containing a lithium battery, replace it only with the same module type made by the same manufacturer. The battery contains lithium and can explode if not properly used, handled, or disposed of.

Do not:

- Throw or immerse into water
- Heat to more than 100°C (212°F)
- Repair or disassemble

Dispose of the battery as required by local ordinances or regulations.

Statement 3



CAUTION:

When laser products (such as CD-ROMs, DVD drives, fiber optic devices, or transmitters) are installed, note the following:

- Do not remove the covers. Removing the covers of the laser product could result in exposure to hazardous laser radiation. There are no serviceable parts inside the device.
- Use of controls or adjustments or performance of procedures other than those specified herein might result in hazardous radiation exposure.



DANGER

Some laser products contain an embedded Class 3A or Class 3B laser diode.
Note the following.


Laser radiation when open. Do not stare into the beam, do not view directly with optical instruments, and avoid direct exposure to the beam.

Class 1 Laser Product
Laser Klasse 1
Laser Klass 1
Luokan 1 Laserlaite
Appareil À Laser de Classe 1

Statement 4




CAUTION:
Use safe practices when lifting.



≥ 18 kg (39.7 lb)



≥ 32 kg (70.5 lb)




≥ 55 kg (121.2 lb)

Statement 5



CAUTION:
The power control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.



Statement 6



CAUTION:

If you install a strain-relief bracket option over the end of the power cord that is connected to the device, you must connect the other end of the power cord to an easily accessible power source.

Statement 8



CAUTION:

Never remove the cover on a power supply or any part that has the following label attached.



Hazardous voltage, current, and energy levels are present inside any component that has this label attached. There are no serviceable parts inside these components. If you suspect a problem with one of these parts, contact a service technician.

Statement 12



CAUTION:

The following label indicates a hot surface nearby.



Statement 26



CAUTION:

Do not place any object on top of rack-mounted devices.



Rack Safety Information, Statement 2



DANGER

- Always lower the leveling pads on the rack cabinet.
- Always install stabilizer brackets on the rack cabinet.
- Always install servers and optional devices starting from the bottom of the rack cabinet.
- Always install the heaviest devices in the bottom of the rack cabinet.

Chapter 1. The System x3650 M3 server

This contains instructions for setting up your IBM System x3650 M3 Types 4255, 7945, or 7949 server, instructions for installing optional devices, and instructions for starting and configuring the server. For diagnostic and troubleshooting information, see the *Problem Determination and Service Guide* that is on the IBM Documentation CD.

The IBM System x3650 M3 Types 4255, 7945, or 7949 server is a 2-U¹-high server that is ideally suited for networking environments that require superior microprocessor performance, efficient memory management, and flexibility.

Performance, ease of use, reliability, and expansion capabilities were key considerations in the design of the server. These design features make it possible for you to customize the system hardware to meet your needs today and provide flexible expansion capabilities for the future.

The server comes with a limited warranty. For information about the terms of the warranty and getting service and assistance, see the *Warranty Information* document on the IBM Documentation CD.

The server contains IBM Enterprise X-Architecture technologies, which help increase performance and reliability. For more information, see “What your server offers” on page 10 and “Reliability, availability, and serviceability features” on page 13.

You can obtain up-to-date information about the server and other IBM server products at <http://www.ibm.com/systems/x/>. At <http://www.ibm.com/support/mysupport/>, you can create a personalized support page by identifying IBM products that are of interest to you. From this personalized page, you can subscribe to weekly e-mail notifications about new technical documents, search for information and downloads, and access various administrative services.

If you participate in the IBM client reference program, you can share information about your use of technology, best practices, and innovative solutions; build a professional network; and gain visibility for your business. For more information about the IBM client reference program, see <http://www.ibm.com/ibm/clientreference/>.

The server comes with eight 2.5-inch SAS hot-swap hard disk drive bays. Most models contain a ServeRAID SAS controller and are capable of expansion to sixteen 2.5-inch SAS hot-swap hard disk drive bays.

The following illustration shows a server with eight SAS hard disk drive bays.

1. Racks are measured in vertical increments of 1.75 inches each. Each increment is called a “U”. A 1-U-high device is 1.75 inches tall.




Figure 1. SAS hard disk drive bays front view

You can purchase an optional kit to install the tape drive.





Figure 2. Optional SAS hard disk drive bays front view

Figure 3. SAS ID for each bay

You can purchase an optional kit to install the eight additional SAS hard disk drive bays.



The SAS ID for each bay is printed on the server front, above each bay.

If firmware and documentation updates are available, you can download them from the IBM Web site. The server might have features that are not described in the documentation that comes with the server, and the documentation might be updated occasionally to include information about those features, or technical updates might be available to provide additional information that is not included in the server documentation. To check for updates, complete the following steps.

Note: Changes are made periodically to the IBM Web site. Procedures for locating firmware and documentation might vary slightly from what is described in this document.

1. Go to <http://www.ibm.com/systems/support/>.
2. Under **Product support**, click **System x**.
3. Under **Popular links**, click **Software and device drivers** for firmware updates, or click **Publications lookup** for documentation updates.

Record information about the server in the following table.

Product name	IBM System x3650 M3 server
Machine type	4255, 7945, or 7949
Model number	_____
Serial number	_____

The model number and serial number are on the ID label on the bezel, as shown in the following illustration.

Note: The illustrations in this document might differ slightly from your hardware.




Figure 4. ID label

You can download an *IBM ServerGuide Setup and Installation CD* to help you configure the hardware, install device drivers, and install the operating system. For more information, see “Using the ServerGuide Setup and Installation CD” on page 164.

For a list of supported optional devices for the server, see <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/>.

See the *Rack Installation Instructions* document on the *IBM Documentation CD* for complete rack installation and removal instructions.

The IBM Documentation CD

The *IBM Documentation CD* contains documentation for your server in Portable Document Format (PDF) and includes the IBM Documentation Browser to help you find information quickly.

Hardware and software requirements

The hardware and software requirements of the IBM *Documentation* CD.

The IBM *Documentation* CD requires the following minimum hardware and software:

- Microsoft Windows XP, Windows 2000, or Red Hat Linux
- 100 MHz microprocessor
- 32 MB of RAM
- Adobe Acrobat Reader 3.0 (or later) or xpdf, which comes with Linux operating systems

Using the Documentation Browser

Use the Documentation Browser to browse the contents of the CD, read brief descriptions of the documents, and view documents, using Adobe Acrobat Reader or xpdf. The Documentation Browser automatically detects the regional settings in use in your server and displays the documents in the language for that region (if available). If a document is not available in the language for that region, the English-language version is displayed.

Use one of the following procedures to start the Documentation Browser:

- If Autostart is enabled, insert the CD into the CD or DVD drive. The Documentation Browser starts automatically.
- If Autostart is disabled or is not enabled for all users, use one of the following procedures:
 - If you are using a Windows operating system, insert the CD into the CD or DVD drive and click **Start --> Run**. In the **Open** field, type
`e:\win32.bat`

where *e* is the drive letter of the CD or DVD drive, and click **OK**.
 - If you are using Red Hat Linux, insert the CD into the CD or DVD drive; then, run the following command from the `/mnt/cdrom` directory:
`sh runlinux.sh`

Select your server from the **Product** menu. The **Available Topics** list displays all the documents for your server. Some documents might be in folders. A plus sign (+) indicates each folder or document that has additional documents under it. Click the plus sign to display the additional documents.

When you select a document, a description of the document appears under **Topic Description**. To select more than one document, press and hold the Ctrl key while you select the documents. Click **View Book** to view the selected document or documents in Acrobat Reader or xpdf. If you selected more than one document, all the selected documents are opened in Acrobat Reader or xpdf.

To search all the documents, type a word or word string in the **Search** field and click **Search**. The documents in which the word or word string appears are listed in order of the most occurrences. Click a document to view it, and press Ctrl+F to use the Acrobat search function, or press Alt+F to use the xpdf search function within the document.

Click **Help** for detailed information about using the Documentation Browser.

Related documentation

This *Installation and User's Guide* contains general information about the server, including how to set up the server, how to install supported optional devices, and how to configure the server.

The following documentation also comes with the server:

- *Warranty Information*

This printed document contains information about the terms of the warranty.

- *Safety Information*

This document is in PDF on the IBM *Documentation* CD. It contains translated caution and danger statements. Each caution and danger statement that appears in the documentation has a number that you can use to locate the corresponding statement in your language in the *Safety Information* document.

- *Rack Installation Instructions*

This printed document contains instructions for installing the server in a rack.

- *Problem Determination and Service Guide*

This document is in PDF on the IBM *Documentation* CD. It contains information to help you solve problems yourself, and it contains information for service technicians.

- *Environmental Notices and User Guide*

This document is in PDF on the IBM *Documentation* CD. It contains translated environmental notices.

- *IBM License Agreement for Machine Code*

This document is in PDF on the IBM *Documentation* CD. It provides translated versions of the *IBM License Agreement for Machine Code* for your product.

- *Licenses and Attributions Documents*

This document is in PDF. It contains information about the open-source notices.

Depending on the server model, additional documentation might be included on the IBM *Documentation* CD.

The System x and xSeries Tools Center is an online information center that contains information about tools for updating, managing, and deploying firmware, device drivers, and operating systems. The System x and xSeries Tools Center is at <http://publib.boulder.ibm.com/infocenter/toolsctr/v1r0/index.jsp>.

The server might have features that are not described in the documentation that comes with the server. The documentation might be updated occasionally to include information about those features, or technical updates might be available to provide additional information that is not included in the server documentation. These updates are available from the IBM Web site. To check for updated documentation and technical updates, complete the following steps.

Note: Changes are made periodically to the IBM Web site. The actual procedure might vary slightly from what is described in this document.

1. Go to <http://www.ibm.com/systems/support/>.
2. Under **Product support**, click **System x**.
3. Under **Popular links**, click **Publications lookup**.
4. From the **Product family** menu, select **System x3650 M3** and click **Continue**.

Notices and statements in this document

The caution and danger statements in this document are also in the multilingual *Safety Information* document, which is on the *Documentation* CD. Each statement is numbered for reference to the corresponding statement in your language in the *Safety Information* document.

The following notices and statements are used in this document:

- **Note:** These notices provide important tips, guidance, or advice.
- **Important:** These notices provide information or advice that might help you avoid inconvenient or problem situations.
- **Attention:** These notices indicate potential damage to programs, devices, or data. An attention notice is placed just before the instruction or situation in which damage might occur.
- **Caution:** These statements indicate situations that can be potentially hazardous to you. A caution statement is placed just before the description of a potentially hazardous procedure step or situation.
- **Danger:** These statements indicate situations that can be potentially lethal or extremely hazardous to you. A danger statement is placed just before the description of a potentially lethal or extremely hazardous procedure step or situation.

Features and specifications

The following information is a summary of the features and specifications of the server. Depending on the model, some features might not be available, or some specifications might not apply.

Racks are marked in vertical increments of 4.45 cm (1.75 inches). Each increment is referred to as a unit, or "U." A 1-U-high device is 1.75 inches tall.

Note:

1. Power consumption and heat output vary depending on the number and type of optional features that are installed and the power-management optional features that are in use.
2. The sound levels were measured in controlled acoustical environments according to the procedures specified by the American National Standards Institute (ANSI) S12.10 and ISO 7779 and are reported in accordance with ISO 9296. Actual sound-pressure levels in a given location might exceed the average values stated because of room reflections and other nearby noise sources. The declared sound-power levels indicate an upper limit, below which a large number of computers will operate.

Table 1. Features and specifications

<p>Microprocessor:</p> <ul style="list-style-type: none"> • Supports up to two Intel Xeon™ multi-core microprocessors (one installed) • Level-3 cache • QuickPath Interconnect (QPI) links speed up to 6.4 GT per second <p>Note:</p> <ul style="list-style-type: none"> • Do not install an Intel Xeon™ 5500 series microprocessor and an Xeon™ 5600 series microprocessor in the same server. • Use the Setup utility to determine the type and speed of the microprocessors. • For a list of supported microprocessors, see http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/. <p>Memory:</p> <ul style="list-style-type: none"> • Minimum: 2 GB • Maximum: 288 GB <ul style="list-style-type: none"> – 48 GB using unbuffered DIMMs (UDIMMs) – 288 GB using registered DIMMs (RDIMMs) • Type: PC3-10600R-999, 800, 1067, and 1333 MHz, ECC, DDR3 registered or unbuffered SDRAM DIMMs • Slots: 18 dual inline • Supports (depending on the model): <ul style="list-style-type: none"> – 2 GB and 4 GB unbuffered DIMMs – 2 GB, 4 GB, 8 GB, and 16 GB registered DIMMs <p>SATA optical drives (optional):</p> <ul style="list-style-type: none"> • DVD-ROM • Multi-burner <p>Hard disk drive expansion bays (depending on the model):</p> <ul style="list-style-type: none"> • Eight 2.5-inch SAS hot-swap bays for hard disk drive bays with option to add eight more 2.5-inch SAS hot-swap hard disk drive bays • Four 2.5-inch simple-swap, solid state SATA hard disk drive bays <p>PCI expansion slots:</p> <ul style="list-style-type: none"> • Two PCI Express riser cards with two PCI Express x8 slots (x8 lanes) each, standard • Support for the following optional riser cards: <ul style="list-style-type: none"> – Two 133 MHz/64-bit PCI-X 1.0a slots – One PCI Express x16 slot (x16 lanes) 	<p>Size (2U):</p> <ul style="list-style-type: none"> • Height: 85.2 mm (3.346 in.) • Depth: EIA flange to rear - 698 mm (27.480 in.), Overall - 729 mm (28.701 in.) • Width: With top cover - 443.6 mm (17.465 in.), With front bezel - 482.0 mm (18.976 in.) • Weight: approximately 21.09 kg (46.5 lb) to 25 kg (55 lb) depending upon configuration <p>Integrated functions:</p> <ul style="list-style-type: none"> • Integrated management module (IMM), which provides service processor control and monitoring functions, video controller, and (when the optional virtual media key is installed) remote keyboard, video, mouse, and remote hard disk drive capabilities • Dedicated or shared management network connections • Serial over LAN (SOL) and serial redirection over Telnet or Secure Shell (SSH) • One systems-management RJ-45 for connection to a dedicated systems-management network • Support for remote management presence through an optional virtual media key • Broadcom BCM5709 Gb Ethernet controller with TCP/IP Offload Engine (TOE) and Wake on LAN support • Four Ethernet ports (two on system board and two additional ports when the optional IBM Dual-Port 1 Gb Ethernet Daughter Card is installed) • One serial port, shared with the integrated management module (IMM) • Four Universal Serial Bus (USB) ports (two on front, two on rear of server), v2.0 supporting v1.1, plus one or more dedicated internal USB ports on the SAS riser-card • Two video ports (one on front and one on rear of server) • One SATA tape connector, one USB tape connector, and one tape power connector on SAS riser-card (some models) • Support for hypervisor function through an optional USB flash device on the SAS riser-card (not available on simple-swap models) <p>Note: In messages and documentation, the term <i>service processor</i> refers to the integrated management module (IMM).</p>	<p>Video controller (integrated into IMM):</p> <ul style="list-style-type: none"> • Matrox G200eV (two analog ports - one front and one rear that can be connected at the same time) <p>Note: The maximum video resolution is 1600 x 1200 at 75 Hz.</p> <ul style="list-style-type: none"> – SVGA compatible video controller – DDR2 250 MHz SDRAM video memory controller – Avocent Digital Video Compression – 16 MB of video memory (not expandable) <p>ServeRAID controller (depending on the model):</p> <ul style="list-style-type: none"> • A ServeRAID-BR10i v2 SAS/SATA adapter that provides RAID levels 0, 1, and 1E (comes standard on some hot-swap models). • An optional ServeRAID-BR10i SAS/SATA adapter that provides RAID levels 0, 1, and 1E can be ordered. • An optional ServeRAID-MR10i SAS/SATA adapter that provides RAID levels 0, 1, 5, 6, 10, 50, and 60 can be ordered. • An optional ServeRAID-M1015 SAS/SATA adapter that provides RAID levels 0, 1, and 10 with optional RAID 5/50 and SED (Self Encrypting Drive) upgrade. • An optional ServeRAID-M5014 SAS/SATA adapter that provides RAID levels 0, 1, 5, 10 and 50 with optional battery and RAID 6/60 and SED upgrade. • An optional ServeRAID-M5015 SAS/SATA adapter with battery that provides RAID levels 0, 1, 5, 10, and 50 with optional RAID 6/60 and SED upgrade <p>Note:</p> <ol style="list-style-type: none"> 1. RAID is supported in hot-swap models only. 2. The ServeRAID controllers are installed in a PCI Express x8 mechanical slot (x4 electrical); however, the controllers run at x4 bandwidth.
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Table 1. Features and specifications (continued)

Electrical input with hot-swap ac power supplies: <ul style="list-style-type: none"> • Sine-wave input (47 - 63 Hz) required • Input voltage range automatically selected • Input voltage low range: <ul style="list-style-type: none"> – Minimum: 100 V ac – Maximum: 127 V ac • Input voltage high range: <ul style="list-style-type: none"> – Minimum: 200 V ac – Maximum: 240 V ac • Input kilovolt-amperes (kVA) approximately: <ul style="list-style-type: none"> – Minimum: 0.090 kVA – Maximum: 0.700 kVA 	Environment: <ul style="list-style-type: none"> • Air temperature: <ul style="list-style-type: none"> – Server on: 10°C to 35°C (50.0°F to 95.0°F); altitude: 0 to 914.4 m (3000 ft). Decrease system temperature by 1°C for every 1000-foot increase in altitude. – Server off: 5°C to 45°C (41.0°F to 113.0°F); maximum altitude: 3048 m (10000 ft) – Shipment: -40°C to +60°C (-40°F to 140°F); maximum altitude: 3048 m (10000 ft) • Humidity: <ul style="list-style-type: none"> – Server on: 20% to 80%; maximum dew point: 21°C; maximum rate of change 5°C per hour. – Server off: 8% to 80%; maximum dew point: 27°C – Shipment: 5% to 100% • Particulate contamination: <p>Attention: Airborne particulates and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the server. For information about the limits for particulates and gases, see “Particulate contamination” on page 183.</p> 	Hot-swap fans: Three - provide redundant cooling. Power supply: <ul style="list-style-type: none"> • Up to two hot-swap power supplies for redundancy support <ul style="list-style-type: none"> – 460-watt ac – 675-watt ac – 675-watt high-efficiency ac – 675-watt dc <p>Note: You cannot mix 460-watt and 675-watt power supplies, or high-efficiency and non-high-efficiency power supplies, or ac and dc power supplies in the server.</p> <p>Acoustical noise emissions:</p> <ul style="list-style-type: none"> • Declared sound power, idle: 6.3 bel • Declared sound power, operating: 6.5 bel <p>Heat output: Approximate heat output:</p> <ul style="list-style-type: none"> • Minimum configuration: 662 Btu per hour (194 watts) • Maximum configuration: 2302 Btu per hour (675 watts)
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

EU Regulation 617/2013 Technical Documentation:

International Business Machines Corporation
New Orchard Road
Armonk, New York 10504
<http://www.ibm.com/customersupport/>

For more information on the energy efficiency program, go to
<http://www.ibm.com/systems/x/hardware/energy-star/index.html>

Product Type:

Computer Server

Year first manufactured:

2010

Internal/external power supply efficiency:

PSU 1: Go to http://www.pluginloadsolutions.com/psu_reports/IBM_7001578-XXXX_675W_SO-485_Report.pdf

PSU 2:

Table 2. Power supply efficiency (PSU 2)

IRMS A	PF	ITHD (%)	Load (%)	Input Watts	Output Watts	Efficiency %
0.41	0.811	39.8%	10%	77.25	67.50	87.38%
0.72	0.901	30.5%	20%	148.45	134.74	90.76%
1.65	0.956	21.8%	50%	361.99	336.34	92.91%

Table 2. Power supply efficiency (PSU 2) (continued)

IRMS A	PF	ITHD (%)	Load (%)	Input Watts	Output Watts	Efficiency %
3.28	0.976	17.5%	100%	736.58	670.10	90.97%

PSU 3:

Table 3. Power supply efficiency (PSU 3)

IRMS A	PF	ITHD (%)	Load (%)	Input Watts	Output Watts	Efficiency %
0.50	0.694	19.02%	10%	79.4	68.2	85.9%
0.74	0.867	15.1%	20%	148.4	134.8	90.8%
1.63	0.968	4.85%	50%	362.1	336.1	93.0%
3.24	0.988	5.3%	100%	737.3	672.3	91.2%

Maximum power (watts):

See Power supply.

Idle state power (watts):

120

Sleep mode power (watts):

N/A for servers

Off mode power (watts):

Not available

Noise levels (the declared A-weighted sound power level of the computer):

See Acoustical noise emissions.

Test voltage and frequency:

230V / 50 Hz or 60 Hz

Total harmonic distortion of the electricity supply system:

The maximum harmonic content of the input voltage waveform will be equal or less than 2%. The qualification is compliant with EN 61000-3-2.

Information and documentation on the instrumentation set-up and circuits used for electrical testing:

ENERGY STAR Test Method for Computer Servers; ECOVA Generalized Test Protocol for Calculating the Energy Efficiency of Internal Ac-Dc and Dc-Dc Power Supplies.

Measurement methodology used to determine information in this document:

ENERGY STAR Servers Version 2.0 Program Requirements; ECOVA Generalized Test Protocol for Calculating the Energy Efficiency of Internal Ac-Dc and Dc-Dc Power Supplies.

What your server offers

This section introduces features and technologies the server uses and provides.

The server uses the following features and technologies:

- **UEFI-compliant server firmware**

IBM System x Server Firmware offers several features, including Unified Extensible Firmware Interface (UEFI) 2.1 compliance, Active Energy Manager technology, enhanced RAS capabilities, and BIOS compatibility support. UEFI replaces the basic input/output system (BIOS) and defines a standard interface between the operating system, platform firmware, and external devices. UEFI-compliant System x servers are capable of booting UEFI-compliant operating systems, BIOS-based operating systems, and BIOS-based adapters as well as UEFI-compliant adapters.

Note: The server does not support DOS.

- **Integrated management module**

The integrated management module (IMM) combines service processor functions, video controller, and (when an optional virtual media key is installed) remote presence function in a single chip. The IMM provides advanced service-processor control, monitoring, and alerting function. If an environmental condition exceeds a threshold or if a system component fails, the IMM lights LEDs to help you diagnose the problem, records the error in the event log, and alerts you to the problem. Optionally, the IMM also provides a virtual presence capability for remote server management capabilities. The IMM provides remote server management through industry-standard interfaces:

- Intelligent Platform Management Interface (IPMI) version 2.0
- Simple Network Management Protocol (SNMP) version 3
- Common Information Model (CIM)
- Web browser

- **Remote presence capability and blue-screen capture**

The optional virtual media key is required to enable the remote presence and blue-screen capture features. The remote presence feature provides the following functions:

- Remotely viewing video with graphics resolutions up to 1600 x 1200 at 75 Hz, regardless of the system state
- Remotely accessing the server, using the keyboard and mouse from a remote client
- Mapping the CD or DVD drive, diskette drive, and USB flash drive on a remote client, and mapping ISO and diskette image files as virtual drives that are available for use by the server
- Uploading a diskette image to the IMM memory and mapping it to the server as a virtual drive

The blue-screen capture feature captures the video display contents before the IMM restarts the server when the IMM detects an operating-system hang condition. A system administrator can use the blue-screen capture to assist in determining the cause of the hang condition.

- **IBM Dynamic System Analysis Preboot diagnostics programs**

The Dynamic System Analysis (DSA) Preboot diagnostics programs are stored on the integrated USB memory. It collects and analyzes system information to aid in diagnosing server problems. The diagnostic programs collect the following information about the server:

- System configuration
- Network interfaces and settings
- Installed hardware
- Light path diagnostics status
- Service processor status and configuration
- Vital product data, firmware, and UEFI (formerly BIOS) configuration
- Hard disk drive health
- RAID controller configuration
- Event logs for ServeRAID controllers and service processors

The diagnostic programs create a merged log that includes events from all collected logs. The information is collected into a file that you can send to IBM service and support. Additionally, you can view the information locally through a generated text report file. You can also copy the log to a removable media and view the log from a Web browser.

For additional information about DSA Preboot diagnostics, see the *Problem Determination and Service Guide* on the IBM Documentation CD

- **IBM Systems Director**

IBM Systems Director is a workgroup-hardware-management tool that you can use to centrally manage System x and xSeries servers. For more information, see the IBM Systems Director documentation on the *IBM Systems Director* CD.

- **Active Energy Manager**

The Active Energy Manager solution is an IBM Systems Director extension that measures and reports server power consumption as it occurs. This enables you to monitor power consumption in correlation to specific software application programs and hardware configurations. You can obtain the measurement values through the systems-management interface and view them, using IBM Systems Director. For more information, see the IBM Director documentation on the *IBM Systems Director* CD, or see <http://www.ibm.com/systems/management/director/extensions/actengmrg.html>.

- **IBM X-Architecture technology**

IBM X-Architecture technology combines proven, innovative IBM designs to make your Intel-processor-based server powerful, scalable, and reliable. For more information, see <http://www.ibm.com/systems/management/director/extensions/actengmrg.html>.

- **Active™ Memory** The Active Memory™ feature improves the reliability of memory through memory mirroring. Memory mirroring stores data in two pairs of DIMMs simultaneously.
- **Large system-memory capacity**

The memory bus supports up to 288 GB of system memory when registered DIMMs are installed. The server supports up to 48 GB if unbuffered DIMMs are installed. The memory controller supports error correcting code (ECC) for up to 18 industry-standard PC3-10600R-999, 800, 1067, and 1333 MHz, DDR3 (third-generation double-data-rate), synchronous dynamic random access memory (SDRAM) dual inline memory modules (DIMMs).

- **IBM ServerGuide Setup and Installation CD**

The *ServerGuide Setup and Installation* CD, which you can download from the Web, provides programs to help you set up the server and install a Windows operating system. The ServerGuide program detects installed optional hardware devices and provides the correct configuration programs and device drivers. For more information about the *ServerGuide Setup and Installation* CD, see “Using the ServerGuide Setup and Installation CD” on page 164.

- **Integrated network support**

The server comes with two integrated Broadcom Gigabit Ethernet controllers, which support connection to a 10 Mbps, 100 Mbps, or 1000 Mbps network. For more information, see “Configuring the Gigabit Ethernet controller” on page 172

- **Large data-storage and hot-swap capability**

The server supports up to eight or sixteen 2.5-inch hot-swap hard disk drives in the hot-swap bays (depending on the model and optional devices installed). With the hot-swap feature, you can add, remove, or replace hard disk drives without turning off the server.

- **Light path diagnostics**

Light path diagnostics provides LEDs to help you diagnose problems. For more information, see the section about light path diagnostics in the *Problem Determination and Service Guide*.

- **PCI adapter capabilities**

The server supports up to four PCI interface slots. For more information, see “Installing a PCI adapter” on page 53

- **Memory mirroring**

Memory mirroring improves the availability of memory by writing information to the main memory and redundant locations in a mirrored pair of DIMMs.

- **Redundant connection**

The addition of the optional Ethernet daughter card provides failover capability to a redundant Ethernet connection with the applicable application installed. If a problem occurs with the primary Ethernet connection and the optional Ethernet daughter card is installed on the server, all Ethernet traffic that is associated with the primary connection is automatically switched to the optional redundant Ethernet daughter card connection. If the applicable device drivers are installed, this switching occurs without data loss and without user intervention.

- **Redundant cooling and optional power capabilities**

The server supports three hot-swap fans, which provide redundant cooling. Redundant cooling enables continued operation if one of the fans fails. The server supports a maximum of two 675-watt or 460-watt hot-swap power supplies, which provide redundancy and hot-swap capability for a typical configuration. The server comes with one 675-watt or 460-watt hot-swap power supply. You can order the second optional power supply for power redundancy. If the maximum load on the server is less than 675-watts (or 460-watt, depending on what kind of power supply you use) and a problem occurs with one of the power supplies, the other power supply can meet the power requirements.

Note: If the maximum load on the server is greater than 675-watts (or 460-watt, depending on what kind of power supply you use) and a problem occurs with one of the power supplies, Active Energy Manager can act to minimize the load somewhat so that the server can function with the remaining power supply.

- **ServeRAID support**

The server supports an internal ServeRAID SAS controller, which is required for you to use the hot-swap hard disk drives and to create redundant array of independent disks (RAID) configurations.

- **Systems-management capabilities**

The server contains an integrated management module (IMM) which enables you to manage the functions of the server locally and remotely. The addition of the optional IBM Virtual Media Key provides remote presence and blue-screen capture capability. The IMM also provides system monitoring, event recording, and dial-out alert capability.

- **TCP/IP offload engine (TOE) support**

The Ethernet controllers in the server support TOE, which is a technology that offloads the TCP/IP flow from the microprocessors and I/O subsystem to increase the speed of the TCP/IP flow. When an operating system that supports TOE is running on the server and TOE is enabled, the server supports TOE operation. See the operating-system documentation for information about enabling TOE.

Note: As of the date of this document, the Linux operating system does not support TOE.

Reliability, availability, and serviceability features

Three important computer design features are reliability, availability, and serviceability (RAS). The RAS features help to ensure the integrity of the data that is stored in the server, the availability of the server when you need it, and the ease with which you can diagnose and repair problems.

The server has the following RAS features:

- 3-year parts and 3-year labor limited warranty for machine types 7945 and 7949 and 4-year parts and 4-year labor limited warranty for machine type 4255
- Automatic error retry and recovery
- Automatic restart after a power failure
- Built-in monitoring for fan, power, temperature, voltage, and power-supply redundancy
- Cable-presence detection on most connectors
- Chipkill memory protection
- Dual redundant UEFI server firmware images
- Error codes and messages
- Error correcting code (ECC) L2 cache and system memory
- Hot-swap cooling fans with speed-sensing capability
- Hot-swap hard disk drives
- Information and light path diagnostics LED panels
- Integrated management module (service processor)
- Memory mirroring
- Menu-driven setup, system configuration, and redundant array of independent disks (RAID) configuration programs
- Parity checking or CRC checking on the serially-attached SCSI (SAS) bus and PCI buses
- Power management: compliance with Advanced Configuration and Power Interface (ACPI)
- Power-on self-test (POST)
- Predictive Failure Analysis (PFA) alerts on memory, SAS/SATA hard disk drives, fans, and power supplies
- Redundant Ethernet capabilities with failover support
- Redundant hot-swap power supplies
- Remind button to temporarily turn off the system-error LED
- Remote system problem-determination support
- Standby voltage for systems-management features and monitoring
- Startup (boot) from LAN through Preboot Execution Environment (PXE) boot agent utility or Dynamic Host Configuration Protocol/Boot Protocol (DHCP/BOOTP)
- System auto-configuring from the configuration menu
- System error logging (POST and service processor)
- Systems-management monitoring through the Inter-Integrated Circuit (I²C) bus

- Upgradeable POST, UEFI, diagnostics, service processor microcode, and read-only memory (ROM) resident code, locally or over the LAN
- Vital product data (VPD) on microprocessors, system board, power supplies, and SAS (hot-swap-drive) backplane
- Wake on LAN capability

IBM Systems Director

IBM Systems Director is a platform-management foundation that streamlines the way you manage physical and virtual systems in a heterogeneous environment. By using industry standards, IBM Systems Director supports multiple operating systems and virtualization technologies in IBM and non-IBM x86 platforms.

Through a single user interface, IBM Systems Director provides consistent views for viewing managed systems, determining how these systems relate to one another, and identifying their statuses, helping to correlate technical resources with business needs. A set of common tasks that are included with IBM Systems Director provides many of the core capabilities that are required for basic management, which means instant out-of-the-box business value. These common tasks include discovery, inventory, configuration, system health, monitoring, updates, event notification, and automation for managed systems.

The IBM Systems Director Web and command-line interfaces provide a consistent interface that is focused on driving these common tasks and capabilities:

- Discovering, navigating, and visualizing systems on the network with the detailed inventory and relationships to the other network resources
- Notifying users of problems that occur on systems and the ability to isolate the sources of the problems
- Notifying users when systems need updates and distributing and installing updates on a schedule
- Analyzing real-time data for systems and setting critical thresholds that notify the administrator of emerging problems
- Configuring settings of a single system and creating a configuration plan that can apply those settings to multiple systems
- Updating installed plug-ins to add new features and functions to the base capabilities
- Managing the life cycles of virtual resources

For more information about IBM Systems Director, see the documentation on the *IBM Systems Director* DVD that comes with the server and the IBM xSeries Systems Management Web page at <http://www.ibm.com/systems/management/>, which presents an overview of IBM Systems Management and IBM Systems Director.

The UpdateXpress System Pack Installer

The UpdateXpress System Pack Installer detects supported and installed device drivers and firmware in the server and installs available updates. For additional information and to download the UpdateXpress System Pack Installer, go to the System x and BladeCenter Tools Center at <http://publib.boulder.ibm.com/infocenter/toolsctr/v1r0/index.jsp> and click **UpdateXpress System Pack Installer**.

Server controls, LEDs, and power

This section describes the controls and light-emitting diodes (LEDs) and how to turn the server on and off.

Front view

The following illustration shows the controls, connectors, and hard disk drive bays on the front of the server.




Figure 5. Controls, connectors, and hard disk drive bays front view

Hard disk drive activity LED: Each hard disk drive has an activity LED. When this LED is flashing, it indicates that the drive is in use.

Hard disk drive status LED: Each hard disk drive has a status LED. When this LED is lit, it indicates that the drive has failed. When this LED is flashing slowly (one flash per second), it indicates that the drive is being rebuilt as part of a RAID configuration. When the LED is flashing rapidly (three flashes per second), it indicates that the controller is identifying the drive.

Video connector: Connect a monitor to this connector. The video connectors on the front and rear of the server can be used simultaneously.

USB connectors: Connect a USB device, such as USB mouse, keyboard, or other USB device, to either of these connectors.

Operator information panel: This panel contains controls, light-emitting diodes (LEDs), and connectors. For information about the controls and LEDs on the operator information panel, see "Operator information panel" on page 16.

Rack release latches: Press these latches to release the server from the rack.

Optional CD/DVD-eject button: Press this button to release a CD or DVD from the CD-RW/DVD drive.

Optional CD/DVD drive activity LED: When this LED is lit, it indicates that the CD-RW/DVD drive is in use.

Operator information panel

The following illustration shows the controls and LEDs on the operator information panel.




Figure 6. Controls and LEDs

The following controls and LEDs are on the operator information panel:

- **Power-control button and power-on LED:** Press this button to turn the server on and off manually or to wake the server from a reduced-power state. The states of the power-on LED are as follows:
 - **Off:** AC power is not present, or the power supply or the LED itself has failed.
 - **Flashing rapidly (4 times per second):** The server is turned off and is not ready to be turned on. The power-control button is disabled. This will last approximately 20 to 40 seconds.

Note: Approximately 40 seconds after the server is connected to ac power, the power-control button becomes active.

 - **Flashing slowly (once per second):** The server is turned off and is ready to be turned on. You can press the power-control button to turn on the server.
 - **Lit:** The server is turned on.
 - **Fading on and off:** The server is in a reduced-power state. To wake the server, press the power-control button or use the IMM Web interface. For information about logging on to the IMM Web interface, see “Logging on to the Web interface” on page 171.
- **Ethernet icon LED:** This LED lights the Ethernet icon.
- **Ethernet activity LEDs:** When any of these LEDs is lit, it indicates that the server is transmitting to or receiving signals from the Ethernet LAN that is connected to the Ethernet port that corresponds to that LED.
- **Information LED:** When this LED is lit, it indicates that a noncritical event has occurred. An LED on the light path diagnostics panel is also lit to help isolate the error.
- **System-error LED:** When this LED is lit, it indicates that a system error has occurred. An LED on the light path diagnostics panel is also lit to help isolate the error.

- **Release latch:** Slide this latch to the left to access the light path diagnostics panel, which is behind the operator information panel.
- **Locator button and locator LED:** Use this LED to visually locate the server among other servers. Press this button to turn on or turn off this LED locally. You can use IBM Systems Director to light this LED remotely.

Light path diagnostics panel

The light path diagnostics panel is on the top of the operator information panel.

To access the light path diagnostics panel, slide the blue release button on the operator information panel to the left. Pull forward on the operator information panel until the hinge of the panel is free of the server chassis. Then pull down on the operator information panel, so that you can view the light path diagnostics panel information.




Figure 7. Path diagnostics panel

The following illustration shows the controls and LEDs on the light path diagnostics panel.

Note:

1. Do not run the server for an extended period of time while the light path diagnostics panel is pulled out of the server.
2. Light path diagnostics LEDs remain lit only while the server is connected to power.




Figure 8. Controls and LEDs on the light path diagnostics panel

- **Remind button:** This button places the system-error LED on the front panel into Remind mode. In Remind mode, the system-error LED flashes once every 2 seconds until the problem is corrected, the server is restarted, or a new problem occurs.

By placing the system-error LED indicator in Remind mode, you acknowledge that you are aware of the last failure but will not take immediate action to correct the problem. The remind function is controlled by the IMM.

- **NMI button:** Press this button to force a nonmaskable interrupt to the microprocessor, if directed to do so by IBM service and support.
- **Reset button:** Press this button to reset the server and run the power-on self-test (POST). You might have to use a pen or the end of a straightened paper clip to press the button. The reset button is in the lower-right corner of the light path diagnostics panel.

For more information about light path diagnostics, see the *Problem Determination and Service Guide* on the IBM Documentation CD.

Rear view

The following illustration shows the connectors on the rear of the server.




Figure 9. Connectors rear view

Ethernet connectors: Use either of these connectors to connect the server to a network. When you use the Ethernet 1 connector, the network can be shared with the IMM through a single network cable.

Power-cord connector: Connect the power cord to this connector.

USB connectors: Connect a USB device, such as USB mouse, keyboard, or other USB device, to any of these connectors.

Serial connector: Connect a 9-pin serial device to this connector. The serial port is shared with the integrated management module (IMM). The IMM can take control of the shared serial port to perform text console redirection and to redirect serial traffic, using Serial over LAN (SOL).

Video connector: Connect a monitor to this connector. The video connectors on the front and rear of the server can be used simultaneously.

Note: The maximum video resolution is 1600 x 1200 at 75 Hz.

Systems-management Ethernet connector: Use this connector to connect the server to a network for systems-management information control. This connector is used only by the IMM.

The following illustration shows the LEDs on the rear of the server.




Figure 10. LEDs rear view

Ethernet activity LEDs: When these LEDs are lit, they indicate that the server is transmitting to or receiving signals from the Ethernet LAN that is connected to the Ethernet port.

Ethernet link LEDs: When these LEDs are lit, they indicate that there is an active link connection on the 10BASE-T, 100BASE-TX, or 1000BASE-TX interface for the Ethernet port.

AC power LED: Each hot-swap power supply has an ac power LED and a dc power LED. When the ac power LED is lit, it indicates that sufficient power is coming into the power supply through the power cord. During typical operation, both the ac and dc power LEDs are lit. For any other combination of LEDs, see the *Problem Determination and Service Guide* on the IBM Documentation CD.

IN OK power LED: Each hot-swap dc power supply has an IN OK power LED and an OUT OK power LED. When the IN OK power LED is lit, it indicates that sufficient power is coming into the power supply through the power cord. During typical operation, both the IN OK and OUT OK power LEDs are lit.

DC power LED: Each hot-swap power supply has a dc power LED and an ac power LED. When the dc power LED is lit, it indicates that the power supply is supplying adequate dc power to the system. During typical operation, both the ac and dc power LEDs are lit. For any other combination of LEDs, see the *Problem Determination and Service Guide* on the IBM Documentation CD.

OUT OK power LED: Each hot-swap dc power supply has an IN OK power LED and an OUT OK power LED. When the OUT OK power LED is lit, it indicates that the power supply is supplying adequate dc power to the system. During typical operation, both the IN OK and OUT OK power LEDs are lit.

Power-supply error LED: When the power-supply error LED is lit, it indicates that the power supply has failed.

Note: Power supply 1 is the default/primary power supply. If power supply 1 fails, you must replace the power supply immediately.

System-error LED: When this LED is lit, it indicates that a system error has occurred. An LED on the light path diagnostics panel is also lit to help isolate the error. This LED is the same as the system-error LED on the front of the server.

Locator LED: Use this LED to visually locate the server among other servers. You can use IBM Systems Director to light this LED remotely. This LED is the same as the system-locator LED on the front of the server.

Power-on LED: Press this button to turn the server on and off manually or to wake the server from a reduced-power state. The states of the power-on LED are as follows:

- **Off:** AC power is not present, or the power supply or the LED itself has failed.
- **Flashing rapidly (4 times per second):** The server is turned off and is not ready to be turned on. The power-control button is disabled. This will last approximately 20 to 40 seconds.

Note: Approximately 40 seconds after the server is connected to ac power, the power-control button becomes active.

- **Flashing slowly (once per second):** The server is turned off and is ready to be turned on. You can press the power-control button to turn on the server.
- **Lit:** The server is turned on.
- **Fading on and off:** The server is in a reduced-power state. To wake the server, press the power-control button or use the IMM Web interface. For information about logging on to the IMM Web interface, see “Logging on to the Web interface” on page 171.

Power-supply LEDs

The following illustration shows the power-supply LEDs on the rear of the server. For more information about solving power-supply problems, see the *Problem Determination and Service Guide*.




Figure 11. Power-supply LEDs rear view

The following table describes the problems that are indicated by various combinations of the power-supply LEDs and the power-on LED on the operator information panel and suggested actions to correct the detected problems.

Table 4. Power-supply LEDs

AC power-supply LEDs			Description	Action	Notes
AC	DC	Error			
Off	Off	Off	No ac power to the server or a problem with the ac power source	<ol style="list-style-type: none"> 1. Check the ac power to the server. 2. Make sure that the power cord is connected to a functioning power source. 3. Turn the server off and then turn the server back on. 4. If the problem remains, replace the power supply. 	This is a normal condition when no ac power is present.
Off	Off	On	No ac power to the server or a problem with the ac power source and the power supply had detected an internal problem	<ol style="list-style-type: none"> 1. Replace the power supply. 2. Make sure that the power cord is connected to a functioning power source. 	This happens only when a second power supply is providing power to the server.
Off	On	Off	Faulty power supply	Replace the power supply.	
Off	On	On	Faulty power supply	Replace the power supply.	
On	Off	Off	Power supply not fully seated, faulty system board, or faulty power supply	<ol style="list-style-type: none"> 1. (Trained service technician only) Reseat the power supply. 2. If a power channel error LED on the system board is not lit, replace the power-supply (see the documentation that comes with the power supply for instructions). 3. If a power channel error LED on the system board is lit, (trained service technician only) replace the system board. 	Typically indicates that a power supply is not fully seated.
On	Off or Flashing	On	Faulty power supply	Replace the power supply.	
On	On	Off	Normal operation		
On	On	On	Power supply is faulty but still operational	Replace the power supply.	

The following table describes the problems that are indicated by various combinations of the power-supply LEDs on a dc power supply and suggested actions to correct the detected problems.

DC power-supply LEDs			Description	Action	Notes
IN OK	OUT OK	Error (!)			
On	On	Off	Normal operation		

DC power-supply LEDs			Description	Action	Notes
IN OK	OUT OK	Error (!)			
Off	Off	Off	No dc power to the server or a problem with the dc power source.	<ol style="list-style-type: none"> 1. Check the dc power to the server. 2. Make sure that the power cord is connected to a functioning power source. 3. Restart the server. If the error remains, check the power-supply LEDs. 4. Replace the power-supply. 	This is a normal condition when no dc power is present.
Off	Off	On	No dc power to the server or a problem with the dc power source and the power-supply had detected an internal problem.	<ul style="list-style-type: none"> • Make sure that the power cord is connected to a functioning power source. • Replace the power supply (see the documentation that comes with the power supply for instructions). 	This happens only when a second power supply is providing power to the server.
Off	On	Off	Faulty power-supply	Replace the power supply.	
Off	On	On	Faulty power-supply	Replace the power supply.	
On	Off	Off	Power-supply not fully seated, faulty system board, or faulty power-supply	<ol style="list-style-type: none"> 1. (Trained service technician only) Reseat the power supply. 2. If a power channel error LED on the system board is not lit, replace the power-supply (see the documentation that comes with the power supply for instructions). 3. If a power channel error LED on the system board is lit, (trained service technician only) replace the system board. 	Typically indicates a power-supply is not fully seated.
On	Off	On	Faulty power-supply	Replace the power supply.	
On	On	On	Power-supply is faulty but still operational	Replace the power supply.	

Server power features

When the server is connected to a power source but is not turned on, the operating system does not run, and all core logic except for the integrated management module (IMM) is shut down; however, the server can respond to requests from the IMM, such as a remote request to turn on the server. The power-on LED flashes to indicate that the server is connected to power but is not turned on.

Turning on the server

Approximately 3 minutes after the server is connected to power, the power-control button becomes active, and one or more fans might start running to provide cooling while the server is connected to power. You can turn on the server and start the operating system by pressing the power-control button.

The server can also be turned on in any of the following ways:

- If a power failure occurs while the server is turned on, the server will restart automatically when power is restored.
- If your operating system supports the Wake on LAN feature, the Wake on LAN feature can turn on the server.

For 32-bit operating systems only: Some memory is reserved for various system resources and is unavailable to the operating system. The amount of memory that is reserved for system resources depends on the operating system, the configuration of the server, and the configured PCI options.

Turning off the server

When you turn off the server and leave it connected to power, the server can respond to requests from the IMM, such as a remote request to turn on the server. While the server remains connected to power, one or more fans might continue to run. To remove all power from the server, you must disconnect it from the power source.

Important: To view the error LEDs on the system board, leave the server connected to a power source.


Some operating systems require an orderly shutdown before you turn off the server. See your operating-system documentation for information about shutting down the operating system.

Statement 5



CAUTION:

The power control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.



The server can be turned off in any of the following ways:

- You can turn off the server from the operating system, if your operating system supports this feature. After an orderly shutdown of the operating system, the server will be turned off automatically.
- You can press the power-control button to start an orderly shutdown of the operating system and turn off the server, if your operating system supports this feature.
- If the operating system stops functioning, you can press and hold the power-control button for more than 4 seconds to turn off the server.
- The IMM can turn off the server as an automatic response to a critical system failure.
- You can turn off the server through a request from the IMM.

Chapter 2. Installing optional devices

This chapter provides detailed instructions for installing optional hardware devices in the server.

In addition to the instructions in this chapter for installing optional hardware devices, updating firmware and device drivers, and completing the installation, IBM Business Partners must also complete the steps in “Instructions for IBM Business Partners” on page 26.

Important: To help ensure that the devices that you install work correctly and do not introduce problems, observe the following precautions:

1. Make sure that the server and the installed firmware levels support the devices that you are installing. If necessary, update the UEFI and IMM firmware and any other firmware that is stored on the system boards. For information about where firmware is stored in the server, see Chapter 6, “Configuration information and instructions,” in the *Problem Determination and Service Guide*. For a list of supported optional devices for the server, see <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/>.
2. Before you install optional hardware devices, make sure that the server is working correctly. Start the server and make sure that the operating system starts, if an operating system is installed, or that a 19990305 error code is displayed, indicating that an operating system was not found but the server is otherwise working correctly. If the server is not working correctly, see the *Problem Determination and Service Guide* for information about how to run diagnostics.
3. Follow the installation procedures in this chapter and use the correct tools. Incorrectly installed devices can cause system failures because of damaged pins in sockets or connectors, loose cabling, or loose components.
4. Use the best practices to apply current firmware and device-driver updates for the server and optional devices. To download the *IBM System x Firmware Update Best Practices* document, go to www.ibm.com/support/entry/portal/docdisplay?lnodocid=5082923&brandind=5000008. Additional hints and tips are available from the following sites:
 - IBM support: <http://www.ibm.com/supportportal/>
 - System x configuration tools: <http://www.ibm.com/systems/x/hardware/configtools.html>

Instructions for IBM Business Partners

Instructions for IBM Business Partners on verifying the newly installed devices by running the Dynamic System Analysis (DSA) stress test.

In addition to the instructions in this chapter for installing optional hardware devices, updating firmware and device drivers, and completing the installation, IBM Business Partners must also complete the following steps:

1. Before you configure a server for a customer, complete the Solution Assurance checklist at <http://www.ibm.com/support/assure/assur30i.nsf/webindex/sa294/>.
2. After you have confirmed that the server starts correctly and recognizes the newly installed devices and that no error LEDs are lit, run the Dynamic System Analysis (DSA) stress tests. For information about using DSA, see “How to send DSA data to IBM” on page 178.
3. Shut down and restart the server multiple times to ensure that the server is correctly configured and functions correctly with the newly installed devices.
4. Save the DSA log as a file and send it to IBM.
5. To ship the server, repackage it in the original undamaged packing material and observe IBM procedures for shipping.

Support information for IBM Business Partners is available at <http://www.ibm.com/partnerworld/>.

Server components

The following illustrations show the major components in the server.

Note: The illustrations in this document might differ slightly from your hardware.




Figure 12. Server components

System-board internal connectors

The following illustration shows the internal connectors on the system board.




Figure 13. System-board internal connectors

System-board external connectors

The following illustration shows the external input/output connectors on the system board.




Figure 14. System-board external connectors

System-board switches and jumpers

The following illustration shows the location and description of the switches and jumpers.

Note: If there is a clear protective sticker on the top of the switch blocks, you must remove and discard it to access the switches.

The default positions for the UEFI and the IMM recovery jumpers are pins 1 and 2.




Figure 15. System-board switches and jumpers

The following table describes the jumpers on the system board.

Table 5. System board jumpers

Jumper number	Jumper name	Jumper setting
J29	UEFI boot recovery jumper	<ul style="list-style-type: none"> Pins 1 and 2: Normal (default) Loads the primary server firmware ROM page. Pins 2 and 3: Loads the secondary (backup) server firmware ROM page.
J147	IMM recovery jumper	<ul style="list-style-type: none"> Pins 1 and 2: Normal (default) Loads the primary IMM firmware ROM page. Pins 2 and 3: Loads the secondary (backup) IMM firmware ROM page.

Table 5. System board jumpers (continued)

Jumper number	Jumper name	Jumper setting
Note: <ol style="list-style-type: none"> 1. If no jumper is present, the server responds as if the pins are set to 1 and 2. 2. Changing the position of the UEFI boot recovery jumper from pins 1 and 2 to pins 2 and 3 before the server is turned on alters which flash ROM page is loaded. Do not change the jumper pin position after the server is turned on. This can cause an unpredictable problem. 		

The following illustration shows the jumper settings for switch blocks SW3 and SW4 on the system board.




Figure 16. SW3 and SW4

Table 6 on page 32 and Table 7 on page 32 describe the function of each switch on SW3 and SW4 switch blocks on the system board.

Table 6. System board switch block 3, switches 1 - 4

Switch number	Default value	Switch description
1	Off	Clear CMOS memory. When this switch is toggled to On, it clears the data in CMOS memory.
2	Off	Trusted Platform Module (TPM) physical presence. Turning this switch to the on position indicates a physical presence to the TPM.
3	Off	Reserved.
4	Off	Reserved.

Table 7. System board switch block 4, switches 1 - 4

Switch number	Default value	Switch description
1	Off	<p>Power-on password override. Changing the position of this switch bypasses the power-on password check the next time the server is turned on and starts the Setup utility so that you can change or delete the power-on password. You do not have to move the switch back to the default position after the password is overridden.</p> <p>Changing the position of this switch does not affect the administrator password check if an administrator password is set.</p> <p>See "Passwords" on page 162 for additional information about the power-on password.</p>
2	Off	Power-on override. When this switch is toggled to On and then to Off, you force a power-on which overrides the power-on and power-off button on the server and they become nonfunctional.
3	Off	Forced power permission overrides the IMM power-on checking process. (Trained service technician only)
4	Off	Reserved.

Important:

1. Before you change any switch settings or move any jumpers, turn off the server; then, disconnect all power cords and external cables. (Review the information in "Safety" on page v, "Installation guidelines" on page 37, and "Handling static-sensitive devices" on page 40.)
2. Any system-board switch or jumper blocks that are not shown in the illustrations in this document are reserved.

System-board LEDs

The following illustration shows the light-emitting diodes (LEDs) on the system board.

Note: Error LEDs remain lit only while the server is connected to power.




Figure 17. System-board LEDs

System pulse LEDs

The following LEDs are on the system board and monitor the system power-on and power-off sequencing and boot progress (see “System-board LEDs” on page 33 for the location of these LEDs).

Table 8. System-pulse LEDs

LED	Description	Action
Enclosure manager heartbeat	<p>Indicates the status of power-on and power-off sequencing.</p> <p>When the server is connected to power, this LED flashes slowly to indicate that the enclosure manager is working correctly.</p>	<p>(Trained service technician only) If the server is connected to power and the LED is not flashing, replace the system board.</p>
IMM heartbeat	<p>Indicates the status of the boot process of the IMM.</p> <p>When the server is connected to power this LED flashes quickly to indicate that the IMM code is loading. When the loading is complete, the LED stops flashing briefly and then flashes slowly to indicate that the IMM is fully operational and you can press the power-control button to start the server.</p>	<p>If the LED does not begin flashing within 30 seconds of when the server is connected to power, complete the following steps:</p> <ol style="list-style-type: none">1. (Trained service technician only) Use the IMM recovery jumper to recover the firmware (see Table 5 on page 30).2. (Trained service technician only) Replace the system board.

System-board optional device connectors

The following illustration shows the connectors on the system board for user-installable options.




Figure 18. System-board optional device connectors

SAS riser-card connectors and LEDs

The following illustrations show the connectors and LEDs on the SAS riser-cards.

Note: Error LEDs remain lit only while the server is connected to power.

A 16-drive-capable model server contains the riser card that is shown in the following illustration.




Figure 19. SAS riser-card connectors and LEDs

A tape-enabled model server contains the riser card that is shown in the following illustration.




Figure 20. The riser card

PCI riser-card adapter connectors

The following illustration shows the connectors on the PCI riser card for user-installable PCI adapters.




Figure 21. PCI riser-card adapter connectors

PCI riser-card assembly LEDs

The following illustration shows the light-emitting diodes (LEDs) on the PCI riser-card assembly.

Note: Error LEDs remain lit only while the server is connected to power.




Figure 22. PCI riser-card assembly LEDs

Installation guidelines

Use the installation guidelines to install the System x3650 M3 Types 4255, 7945, and 7949

Attention: Static electricity that is released to internal server components when the server is powered-on might cause the system to halt, which might result in the loss of data. To avoid this potential problem, always use an electrostatic-discharge wrist strap or other grounding system when removing or installing a hot-swap device.

Before you install optional devices, read the following information:

- Read the safety information that begins on page “Safety” on page v, the guidelines in “Working inside the server with the power on” on page 39, and “Handling static-sensitive devices” on page 40. This information will help you work safely.
- When you install your new server, take the opportunity to download and apply the most recent firmware updates. This step will help to ensure that any known issues are addressed and that your server is ready to function at maximum levels of performance. To download firmware updates for your server, complete the following steps:
 1. Go to <http://www.ibm.com/systems/support/>.
 2. Under **Product support**, click **System x**.
 3. Under **Popular links**, click **Software and device drivers**.
 4. Click **System x3650 M3** to display the matrix of downloadable files for the server.

For additional information about tools for updating, managing, and deploying firmware, see the System x and xSeries Tools Center at <http://publib.boulder.ibm.com/infocenter/toolctr/v1r0/index.jsp>.

- Before you install optional hardware, make sure that the server is working correctly. Start the server, and make sure that the operating system starts, if an operating system is installed, or that a 19990305 error code is displayed,

indicating that an operating system was not found but the server is otherwise working correctly. If the server is not working correctly, see the *Problem Determination and Service Guide* on the IBM System x Documentation CD for diagnostic information.

- Observe good housekeeping in the area where you are working. Place removed covers and other parts in a safe place.
- If you must start the server while the cover is removed, make sure that no one is near the server and that no tools or other objects have been left inside the server.
- Do not attempt to lift an object that you think is too heavy for you. If you have to lift a heavy object, observe the following precautions:
 - Make sure that you can stand safely without slipping.
 - Distribute the weight of the object equally between your feet.
 - Use a slow lifting force. Never move suddenly or twist when you lift a heavy object.
 - To avoid straining the muscles in your back, lift by standing or by pushing up with your leg muscles.
- Make sure that you have an adequate number of properly grounded electrical outlets for the server, monitor, and other devices.
- Back up all important data before you make changes to disk drives.
- Have a small flat-blade screwdriver available.
- To view the error LEDs on the system board and internal components, leave the server connected to power.
- You do not have to turn off the server to install or replace hot-swap fans, redundant hot-swap ac power supplies, or hot-plug Universal Serial Bus (USB) devices. However, you must turn off the server before you perform any steps that involve removing or installing adapter cables or non-hot-swap optional devices or components.
- Blue on a component indicates touch points, where you can grip the component to remove it from or install it in the server, open or close a latch, and so on.
- Orange on a component or an orange label on or near a component indicates that the component can be hot-swapped, which means that if the server and operating system support hot-swap capability, you can remove or install the component while the server is running. (Orange can also indicate touch points on hot-swap components.) See the instructions for removing or installing a specific hot-swap component for any additional procedures that you might have to perform before you remove or install the component.
- When you are finished working on the server, reinstall all safety shields, guards, labels, and ground wires.
- For a list of supported optional devices for the server, see <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/>.

System reliability guidelines

The system reliability guidelines to ensure proper system cooling.

To help ensure proper system cooling and system reliability, make sure that the following requirements are met:

- Each of the drive bays has a drive or a filler panel and electromagnetic compatibility (EMC) shield installed in it.
- If the server has redundant power, each of the power-supply bays has a power supply installed in it.
- There is adequate space around the server to allow the server cooling system to work properly. Leave approximately 50 mm (2.0 in.) of open space around the front and rear of the server. Do not place objects in front of the fans. For proper cooling and airflow, replace the server cover before you turn on the server. Operating the server for extended periods of time (more than 30 minutes) with the server cover removed might damage server components.
- You have followed the cabling instructions that come with optional adapters.
- You have replaced a failed fan within 48 hours.
- You have replaced a hot-swap fan within 30 seconds of removal.
- You have replaced a hot-swap drive within 2 minutes of removal.
- You do not operate the server without the air baffles installed. Operating the server without the air baffles might cause the microprocessors to overheat.
- Microprocessor 2 air baffle and DIMM air baffle are installed.
- The light path diagnostics panel is not pulled out of the server.

Working inside the server with the power on

Guidelines to work inside the server with the power on.

Attention: Static electricity that is released to internal server components when the server is powered-on might cause the server to halt, which might result in the loss of data. To avoid this potential problem, always use an electrostatic-discharge wrist strap or other grounding system when you work inside the server with the power on.

The server supports hot-plug, hot-add, and hot-swap devices and is designed to operate safely while it is turned on and the cover is removed. Follow these guidelines when you work inside a server that is turned on:

- Avoid wearing loose-fitting clothing on your forearms. Button long-sleeved shirts before working inside the server; do not wear cuff links while you are working inside the server.
- Do not allow your necktie or scarf to hang inside the server.
- Remove jewelry, such as bracelets, necklaces, rings, and loose-fitting wrist watches.
- Remove items from your shirt pocket, such as pens and pencils, that might fall into the server as you lean over it.
- Avoid dropping any metallic objects, such as paper clips, hairpins, and screws, into the server.

Handling static-sensitive devices

Attention: Static electricity can damage the server and other electronic devices. To avoid damage, keep static-sensitive devices in their static-protective packages until you are ready to install them.

To reduce the possibility of damage from electrostatic discharge, observe the following precautions:

- Limit your movement. Movement can cause static electricity to build up around you.
- The use of a grounding system is recommended. For example, wear an electrostatic-discharge wrist strap, if one is available. Always use an electrostatic-discharge wrist strap or other grounding system when working inside the server with the power on.
- Handle the device carefully, holding it by its edges or its frame.
- Do not touch solder joints, pins, or exposed circuitry.
- Do not leave the device where others can handle and damage it.
- While the device is still in its static-protective package, touch it to an unpainted metal surface on the outside of the server for at least 2 seconds. This drains static electricity from the package and from your body.
- Remove the device from its package and install it directly into the server without setting down the device. If it is necessary to set down the device, put it back into its static-protective package. Do not place the device on the server cover or on a metal surface.
- Take additional care when handling devices during cold weather. Heating reduces indoor humidity and increases static electricity.

Internal cable routing and connectors

The following illustration shows the internal routing and connectors for the two SAS signal cables (in server models with eight SAS drive bays).

Note:

1. To connect the SAS signal cables, make sure that you first connect the signal cable, and then the power cable and signal cable.
2. To disconnect the SAS signal cables, make sure that you first disconnect the power cable, and then the signal cable and configuration cable.




Figure 23. SAS signal cables

The SATA cable is a combination power and signal cable with a shared connector on both ends. The following illustration shows the internal routing and connector for the SATA cable.

Attention: To disconnect the optional optical drive cable, you must first press the connector release tab, and then disconnect the cable from the connector on the system board. Do not disconnect the cable by using excessive force. Failing to disconnect the cable properly may damage the connector on the system board. Any damage to the connector may require replacing the system board.




Figure 24. Disconnecting the optional optical drive cable

The following illustration shows the internal routing and connector for the operator information panel cable. The following notes describe additional information you must consider when you install or remove the operator information panel cable:

- You may remove the optional optical drive cable to obtain more room before you install or remove the operator information panel cable.
- To remove the operator information panel cable, slightly press the cable toward the chassis; then, pull to remove the cable from the connector on the system board. Pulling the cable out of the connector by excessive force might cause damage to the cable or connector.
- To connect the operator information panel cable on the system board, press evenly on the cable. Pressing on one side of the cable might cause damage to the cable or connector.

Attention: Failing to install or remove the cable with care may damage the connectors on the system board. Any damage to the connectors may require replacing the system board.





Figure 25. Operator information panel cable

The following illustration shows the internal routing and connector for the USB/video cable.

Note: The USB cable is routed under the video cable and then both the USB and video cables are routed under the cable retention tab and the top cover latch

receptacle.

Figure 26. USB cable and video cable



The following illustration shows the internal routing for the configuration cable.




Figure 27. configuration cable

The following illustrations show the internal routing for the SAS hard disk drive backplane cables (for a 16 hard disk drive model).




Figure 28. SAS hard disk drive backplane cables




Figure 29. SAS hard disk drive backplane cables

Removing the cover

The following illustration shows how to remove the cover.

About this task




Figure 30. Cover removal

Important: Before you install optional hardware, make sure that the server is working correctly. Start the server, and make sure that the operating system starts, if an operating system is installed, or that a 19990305 error code is displayed, indicating that an operating system was not found but the server is otherwise working correctly. If the server is not working correctly, see the *Problem Determination and Service Guide* for diagnostic information.

To remove the cover, complete the following steps:

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. If you are planning to view the error LEDs that are on the system board and components, leave the server connected to power and go directly to step 4.
3. If you are planning to install or remove a microprocessor, memory module, PCI adapter, battery, or other non-hot-swap optional device, turn off the server and all attached devices and disconnect all external cables and power cords (see “Turning off the server” on page 23).
4. Press down on the left and right side latches and slide the server out of the rack enclosure until both slide rails lock.

Note: You can reach the cables on the rear of the server when the server is in the locked position.

5. Press the blue latch **1** on the end of the cover-release latch and lift the cover-release latch **2**. Slide the cover toward the rear **3** and lift the cover off the server. Set the cover aside.

Attention: For proper cooling and airflow and to avoid damaging server components, replace the cover before you turn on the server. If you operate the server for extended periods of time (over 30 minutes) with the cover removed, the IMM turns off the server.

Removing a PCI riser-card assembly

Use this information to remove a PCI riser-card assembly.

About this task

The server comes with one riser-card assembly (with option to add one more) that each contain two PCI Express x8 connectors. You can replace a PCI Express riser-card assembly with a riser-card assembly that contains one PCI Express Gen 2 x16 connector or that contains two PCI-X 64-bit 133 MHz connectors. See <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/> for a list of riser-card assemblies that you can use with the server.




Figure 31. PCI riser-card assembly removal

To remove the riser-card assembly, complete the following steps:

Procedure

1. Read the safety information that begins on page "Safety" on page v and "Installation guidelines" on page 37.
2. Turn off the server and peripheral devices, and disconnect the power cord and all external cables.
3. Remove the cover (see "Removing the cover" on page 45).
4. Grasp the assembly at the front tab and rear edge and lift it to remove it from the server. Place the riser-card assembly on a flat, static-protective surface.

Installing a PCI riser-card assembly

To install a PCI riser-card assembly, complete the following steps.

About this task

Note: The illustrations in this document might differ slightly from your hardware.




Figure 32. PCI riser-card assembly installation

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Make sure that the server and all peripheral devices are turned off and that the power cords and all external cables are disconnected.
3. Reinstall any adapters and reconnect any internal cables that you removed in other procedures.
4. Align the PCI riser-card assembly with the selected PCI riser-card connector on the system board:
 - PCI riser-card connector 1: Carefully fit the two alignment slots on the side of the assembly onto the two alignment brackets in the side of the chassis.
 - PCI riser-card connector 2: Carefully align the bottom edge (the contact edge) of the riser-card assembly with the PCI riser-card connector on the system board.

5. Press down on the assembly. Make sure that the riser-card assembly is fully seated in the riser-card connector on the system board.

Results

If you have other devices to install, do so now. Otherwise, go to “Completing the installation” on page 154.

Removing the microprocessor 2 air baffle

Use this information to remove the microprocessor 2 air baffle.

About this task

When you work with some optional devices, you must first remove the microprocessor 2 air baffle to access certain components. The following illustration shows how to remove the microprocessor 2 air baffle.




Figure 33. Microprocessor 2 air baffle removal

To remove the microprocessor 2 air baffle, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.

2. Turn off the server and peripheral devices and disconnect all power cords and external cables (see “Turning off the server” on page 23).
3. Remove the cover (see “Removing the cover” on page 45).
4. Remove PCI riser-card assembly 2 if one is installed (see “Removing a PCI riser-card assembly” on page 46).
5. Grasp the top of the air baffle and lift the air baffle out of the server.

Important: For proper cooling and airflow, replace all air baffles before you turn on the server. Operating the server with any air baffle removed might damage server components.

Installing the microprocessor 2 air baffle

Use this information to install the microprocessor 2 air baffle.

About this task

Figure 34. Microprocessor 2 air baffle installation

To install the microprocessor 2 air baffle, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Make sure that the server and peripheral devices are turned off (see “Turning off the server” on page 23) and that all power cords and external cables are disconnected.
3. Remove the cover (see “Removing the cover” on page 45).
4. Align the tab on the left side of the microprocessor 2 air baffle with the slot in the right side of the power-supply cage.
5. Lower the microprocessor 2 air baffle into the server. Make sure that the pin on the end of the air baffle is inserted into the hole on the system board (see the illustration).

Attention: For proper cooling and airflow, replace all air baffles before you turn on the server. Operating the server with any air baffle removed might damage server components.

Removing the DIMM air baffle

Use this information to remove the DIMM air baffle.

About this task

When you work with some optional devices, you must first remove the DIMM air baffle to access certain components or connectors on the system board. The following illustration shows how to remove the DIMM air baffle.




Figure 35. DIMM air baffle removal

To remove the DIMM air baffle, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Turn off the server and peripheral devices and disconnect all power cords and external cables (see “Turning off the server” on page 23).
3. Remove the cover (see “Removing the cover” on page 45).
4. Remove PCI riser-card assembly 1, if needed (see “Removing a PCI riser-card assembly” on page 46).
5. Place your fingers under the front and back of the top of the air baffle; then, lift the air baffle out of the server.

Attention: For proper cooling and airflow, replace all air baffles before you turn on the server. Operating the server with any air baffle removed might damage server components.

Installing the DIMM air baffle

Use this information to install the DIMM air baffle.

About this task

The following illustration shows how to install the DIMM air baffle.




Figure 36. DIMM air baffle installation

To install the DIMM air baffle, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Make sure that the server and peripheral devices are turned off (see “Turning off the server” on page 23) and that all power cords and external cables are disconnected.
3. Remove the cover (see “Removing the cover” on page 45).
4. Make sure that PCI riser-card assembly 1 is removed (see “Removing a PCI riser-card assembly” on page 46).
5. Align the DIMM air baffle with the DIMMs and the back of the fans.
6. Lower the air baffle into place.
7. Install PCI riser-card assembly 1, if needed (see “Installing a PCI riser-card assembly” on page 47).

Results

Attention: For proper cooling and airflow, replace all air baffles before you turn on the server. Operating the server with any air baffle removed might damage server components.

Installing the full-length-adapter bracket

Use this information to install the full-length-adapter bracket.

About this task

If you are installing a full-length adapter in the upper riser-card PCI slot, you must first install the full-length-adapter bracket in the end of the riser-card assembly.

Figure 37. Full-length-adapter bracket installation

To install the full-length-adapter bracket, complete the following steps:

Procedure

1. Orient the riser-card assembly as shown.
2. Remove the full-length-adapter bracket from the storage location.
 - a. Press the bracket tab **3** and slide the bracket toward the end of the riser-card assembly.
 - b. Push the bracket out of the storage location on the riser-card assembly.
3. Align the bracket with the end of the riser-card assembly as shown.
4. Place the two hooks **1** in the two openings **2** in the end of the riser-card assembly.
5. Press the bracket tab **3** and slide the bracket to the right until it clicks into place.
6. Return to the adapter-installation instructions.

Storing the full-length-adapter bracket

Use this information to store the full-length-adapter bracket.

About this task

If you are removing a full-length adapter in the upper riser-card PCI slot and will replace it with a shorter adapter or no adapter, you must remove the full-length-adapter bracket from the end of the riser-card assembly and return the bracket to its storage location.




Figure 38. Full-length-adapter bracket removal

To remove and store the full-length-adapter bracket, complete the following steps:

1. Press the bracket tab **3** and slide the bracket to the left until the bracket falls free of the riser-card assembly.
2. Align the bracket with the storage location on the riser-card assembly as shown.
3. Place the two hooks **1** in the two openings **2** in the storage location on the riser-card assembly.
4. Press the bracket tab **3** and slide the bracket toward the expansion-slot-opening end of the assembly until the bracket clicks into place.
5. Return to “Installing a PCI adapter” or “Installing a PCI riser-card assembly” on page 47, as applicable.

Installing a PCI adapter

Use this information to install a PCI adapter.

About this task

The following illustration shows the PCI adapter expansion slots from the rear of the server.




Figure 39. PCI adapter expansion slots

The following notes describe the types of adapters that the server supports and other information that you must consider when you install an adapter:

- Locate the documentation that comes with the adapter and follow those instructions in addition to the instructions in this section. If you have to change switch settings or jumper settings on the adapter, follow the instructions that come with the adapter.
- To ensure that a ServeRAID-10i, ServeRAID-10is, or ServeRAID-10M adapter works correctly in your UEFI-based server, make sure that the adapter firmware is at the latest level.

Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.

- Some high performance video adapters are supported by your server. See <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/> for more information.
- The following notes describe important information about the NVIDIA video adapter that comes preinstalled in some server models:
 - Do not set the maximum digital video resolution above 1600 x 1200 at 75 Hz for an LCD monitor. This is the highest resolution that is supported for an optional video adapter in the server.
 - Any high-definition video-out connector or stereo connector on an optional video adapter is not supported.
- A PCI Express Gen 2 x16 riser card can support only one adapter.
- A PCI Express Gen 2 x8 riser card and a PCI-X riser card can each support two adapters.
- The expansion slots in the PCI riser cards accommodate the various form factors of the non-hot-plug adapters as follows:
 - Expansion slot 1: Full-height, full-length
 - Expansion slot 2: Low-profile with standard bracket
 - Expansion slot 3: Full-height, full-length
 - Expansion slot 4: Full-height, half-length

Note: If you are installing x3650 M3 PCI Express Gen 2 x8 riser card (part number 59Y3818), you cannot install any adaptor in slot 1.

If you install a different supported riser-card assembly, the supported adapter types might be different. For a list of supported riser-card assemblies, see <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/>.

- The system scans devices in the following order, if you have not changed the default boot precedence:
 - Video Unified Extensible Firmware Interface (UEFI) (fixed)
 - System board Ethernet 1 PXE (fixed)
 - System board Ethernet 2 PXE (fixed)
 - System board SAS (or RAID)

The following illustration shows the adapter connectors on the PCI riser-card assembly.





Figure 40. Adapter connectors on the PCI riser-card assembly

To install a PCI adapter, complete the following steps:

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Turn off the server and peripheral devices and disconnect all power cords and external cables (see “Turning off the server” on page 23).
3. Remove the cover (see “Removing the cover” on page 45).
4. Determine which expansion slot you will use for the adapter.
5. If you are installing an adapter in PCI expansion slot 1 or 2, remove PCI riser-card assembly 1; if you are installing an adapter in PCI expansion slot 3 or 4, remove PCI riser-card assembly 2. See “Removing a PCI riser-card assembly” on page 46.
6. Slide the expansion-slot cover out of the PCI riser-card assembly expansion slot.



7. Install the adapter:
 - a. If the adapter is a full-length adapter for the upper expansion slot in the riser card, remove the full-length-adapter bracket from underneath the top of the riser-card assembly and insert it in the end of the upper expansion slot of the riser-card assembly. See “Installing the full-length-adapter bracket” on page 52 for instructions.
 - b. Align the adapter with the adapter connector on the riser-card and the guide on the external end of the PCI riser-card assembly.

- c. Press the adapter firmly into the adapter connector on the riser card.




Figure 42. Adapter installation

8. Connect any required cables to the adapter.

Attention:

- When you route cables, do not block any connectors or the ventilated space around any of the fans.
 - Make sure that cables are not routed on top of components that are under the PCI riser-card assembly.
 - Make sure that cables are not pinched by the server components.
9. Align the PCI riser-card assembly with the selected PCI riser-card connector on the system board.




Figure 43. PCI riser-card assembly installation

- PCI riser-card connector 1: Carefully fit the two alignment slots on the side of the assembly onto the two alignment brackets in the side of the chassis; align the rear of the assembly with the guides on the rear of the server.
 - PCI riser-card connector 2: Carefully align the bottom edge (the contact edge) of the riser-card assembly with the PCI riser-card connector on the system board; align the rear of the assembly with the guides on the rear of the server.
10. Press down on the assembly. Make sure that the riser-card assembly is fully seated in the PCI riser-card connector on the system board.
 11. Perform any configuration tasks that are required for the adapter.

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Removing a PCI adapter

Use this information to remove a PCI adapter.

About this task

To remove an adapter from a PCI riser-card assembly, complete the following steps.




Figure 44. PCI adapter expansion slots

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Turn off the server and peripheral devices and disconnect all power cords and external cables (see “Turning off the server” on page 23).
3. Press down on the left and right side rack latches and slide the server out of the rack enclosure until both slide rails lock; then, remove the cover (see “Removing the cover” on page 45).




Figure 45. PCI riser-card assembly removal

4. Remove the PCI riser-card assembly that contains the adapter (see “Removing a PCI riser-card assembly” on page 46).
5. Disconnect any cables from the adapter (make note of the cable routing, in case you reinstall the adapter later).
6. Carefully grasp the adapter by its top edge or upper corners, and pull the adapter from the PCI expansion slot.

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Installing an IBM Virtual Media Key

The optional IBM Virtual Media Key enables the IMM remote presence and blue-screen capture capability. This feature provides graphical console redirection with remote keyboard and mouse interaction, plus remote diskette and CD/DVD drive support.

About this task




Figure 46. Virtual Media Key installation

To install a virtual media key, complete the following steps:

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Turn off the server and peripheral devices and disconnect all power cords and external cables (see “Turning off the server” on page 23).
3. Remove the cover (see “Removing the cover” on page 45).
4. Align the mounting bracket on the rear of the virtual media key with the mounting tab and slide it down the tab onto the virtual medial key connector on the system board. Press the virtual media key down into the connector until it is firmly seated on the system board.

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Installing a hard disk drive

Use this information to install a hard disk drive.

About this task

The following notes describe the type of hard disk drives that the server supports and other information that you must consider when you install a drive. For a list of supported drives, see <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/>.

Important: Do not install a SCSI hard disk drive in this server.

- Locate the documentation that comes with the hard disk drive and follow those instructions in addition to the instructions in this chapter.
- The server supports eight 2.5-inch hot-swap or simple-swap hard disk drives installed on Ultra-Slim hard disk drive trays. An optional 8-drive-bay kit is available for 16-drive-capable server models. For a list of supported 2.5-inch hard disk drives, see <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/>.
- All hot-swap drives in the server should have the same throughput speed rating. Using hard disk drives with different speed ratings will cause all drives to operate at the throughput speed of the slowest drive.
- The ID that is assigned to each bay is printed on the front of the server, above the drive bay.

The following illustration shows how to install a hot-swap hard disk drive.




Figure 47. Hot-swap hard disk drive installation

To install a drive in a hot-swap bay, complete the following steps.

Attention: To maintain proper system cooling, do not operate the server for more than 10 minutes without either a drive or a filler panel installed in each bay.

Procedure

1. Read the safety information that begins on page “Safety” on page v, “Installation guidelines” on page 37, and “Handling static-sensitive devices” on page 40.
2. Remove the filler panel from one of the empty hot-swap bays: Grasp the filler panel handle and pull the filler panel away from the server.

3. Install the hard disk drive in the hot-swap bay:
 - a. Orient the drive as shown in the illustration.
 - b. Make sure that the tray handle is open
 - c. Align the drive assembly with the guide rails in the bay.
 - d. Gently push the drive assembly into the bay until the drive stops **1**.
 - e. Push the tray handle to the closed (locked) position **2**
 - f. If the system is turned on, check the hard disk drive status LED to verify that the hard disk drive is operating correctly.

After you install a hard disk drive, the green activity LED flashes as the disk spins up. The amber LED turn off after about 1 minute. If the new drive starts to rebuild, the amber LED flashes slowly and the green activity LED remains lit during the rebuild process. If the amber LED remains lit, see the *Problem Determination and Service Guide* on the IBM Documentation CD for hard disk drive problem solutions.

Note: You might have to reconfigure the disk arrays after you install hard disk drives. See the RAID documentation on the IBM ServeRAID Support CD for information about RAID controllers.

Results

If you have other devices to install or remove, do so now. Otherwise, go to "Completing the installation" on page 154.

Removing a hard disk drive

Use this information to remove a hard disk drive.

About this task




Figure 48. Hot-swap hard disk drive removal

To remove a hot-swap hard disk drive, complete the following steps:

Procedure

1. Read the safety information that begins on page "Safety" on page v, "Installation guidelines" on page 37, and "Handling static-sensitive devices" on page 40.
2. Press up on the release latch at the top of the drive front.
3. Move the handle on the drive to the open position (perpendicular to the drive).

4. Pull the hot-swap drive assembly out of the bay approximately 25 mm (1 in.). Wait approximately 45 seconds while the drive spins down before you remove the drive assembly completely from the bay.

Note: You might have to reconfigure the disk arrays after you remove a hard disk drive. See the RAID documentation on the IBM *ServeRAID Support* CD for information about RAID controllers.

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Installing a simple-swap hard disk drive

Use this information to install a simple-swap hard disk drive .

About this task

Locate the documentation that comes with the hard disk drive and follow those instructions in addition to the instructions in this section.

Simple-swap models do not support the SAS hot-swap backplane or the SAS riser-card.

For information about the type of hard disk drive that the server supports and other information that you must consider when installing a hard disk drive, see the *Installation and User's Guide* on the IBM *Documentation* CD.

Important: Do not install a SCSI hard disk drive in this server.




Figure 49. Simple-swap model installation

To install a drive in a simple-swap bay, complete the following steps.

Attention: To maintain proper system cooling, do not operate the server for more than 10 minutes without either a drive or a filler panel installed in each bay.

Procedure

1. Remove the drive filler panel from the front of the server.
2. Orient the drive as shown in the illustration.
3. Align the drive assembly with the guide rails in the bay.
4. Gently push the drive assembly into the bay until the drive stops.

Results

Note: You might have to reconfigure the disk arrays after you install hard disk drives. See the RAID documentation on the IBM *ServeRAID Support* CD for information about RAID controllers.

Removing a simple-swap hard disk drive

Use this information to remove a simple-swap hard disk drive.

About this task




Figure 50. Simple-swap model removal

Attention: To maintain proper system cooling, do not operate the server for more than 10 minutes without either a drive or a filler panel installed in each bay.

To remove a hard disk drive from a simple-swap bay, complete the following steps.

Procedure

1. Read the safety information that begins on page “Safety” on page v, “Installation guidelines” on page 37, and “Handling static-sensitive devices” on page 40.
2. Remove the drive filler panel.
3. Push drive into the bay until it latches into place.
4. Replace the drive filler panel.

Installing a SAS/SATA 4 Pac HDD upgrade option

About this task

If the server is a 16-drive-capable model with four hard disk drive bays installed, you can install an IBM System x3650 M3 Hot-swap SAS/SATA 4 Pac HDD upgrade option. See <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/> for a list of supported optional devices. To order a SAS/SATA 4 Pac HDD upgrade option, contact your IBM marketing representative or authorized reseller.

Note: You need to install the SAS/SATA 4 Pac HDD upgrade option first in order to upgrade to either SAS/SATA 16 Pac HDD system or a 8 Pac HDD + tape system.

The SAS/SATA 4 Pac HDD upgrade option kit contains the following components:

- One 2.5-inch hard disk drive backplane
- Four M3.5 screws
- One blank EMC filler
- Four drive bay filler panels
- Two backplane brackets
- One ServeRaid controller
- One SAS signal cable
- One internal power cable
- One backplane bracket

To install a 4-disk-drive optional hard disk drive backplane in a 8-drive-capable server model, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Turn off the server and disconnect all power cords and external cables (see “Turning off the server” on page 23).
3. Remove the server cover (see “Removing the cover” on page 45).
4. Remove the three 4-drive filler panels that are to the right of drive bay 4, beneath the IDs 4 - 15 on the front bezel.




Figure 51. 4-drive filler panels removal

5. To obtain more working room, remove fans 2 and 3 (see “Removing a hot-swap fan” on page 127).
6. Pull the hard disk drives or fillers out of the server slightly to disengage them from the backplanes. For more information, see “Removing a hard disk drive” on page 62.
7. Disconnect the SAS signal cable from the SAS controller, which is connected to the SAS riser-card. Leave the other end of the SAS signal cable connected to the hard disk drive backplane.




Figure 52. SAS signal cable

8. Remove the SAS controller assembly from the server; then, remove the SAS controller from the SAS riser-card. See “Removing a ServeRAID SAS controller from the SAS riser-card” on page 134 for instructions.




Figure 53. SAS controller removal

9. Remove the SAS controller front retention bracket from the server.




Figure 54. SAS controller front retention bracket removal

10. Connect one end of the internal power cable that comes with the 4 Pac HDD upgrade option kit into the hot-swap SAS/SATA power connector on the system board.




Figure 55. Connecting internal power cable

11. Remove hard disk drive backplane from the server.




Figure 56. Hard disk drive backplane removal

- a. From backplane, disconnect the following cables in the order listed:
 - Power cable **1**
 - SAS signal cable **2**
 - Configuration cable **3**

- b. Lift the backplane out of the server by pulling it toward the rear of the server and then lifting it up.
12. Install the new backplane:
 - a. Move the SAS signal cable from the old hard disk drive backplane to the new backplane **1**. The new backplane comes with the option kit.




Figure 57. New backplane installation

- b. Connect the new power cable that comes with the option kit to the new hard disk drive backplane **2**.
 - c. Connect the configuration cable to the new backplane **3**.
 - d. Angle the new backplane and place the bottom edge into the slots for it on the chassis.
 - e. Rotate the backplane upright so that the bracket goes underneath the latch and tabs on the chassis and is engaged into the slots on the backplane bracket.
13. Make sure that the configuration cable is connected to the backplane.
14. Remove the rear controller retention bracket located in the battery bay above the power supplies by pulling up the release tab **1** and sliding the bracket outward **2**.




Figure 58. Rear controller retention bracket removal

15. Install the SAS controller front retention bracket that you got from step 14:
 - a. Align the retention bracket controller slot so that it faces the rear of the server.




Figure 59. SAS controller front retention bracket installation

- b. Place the bracket tabs in the holes on the chassis and slide the bracket to left until it clicks into place.
16. Remove the fillers (if they are installed) from the two connectors on the SAS controller that comes with the option kit.
17. Install the SAS controller:
 - a. Insert the SAS controller into the connector on the SAS riser-card.
 - b. Insert the front of the SAS controller into the front retention bracket.




Figure 60. SAS controller installation

- c. Install the SAS riser-card with the SAS controller into the connector on the system board, making sure that the alignment post goes through the hole in the controller. Press the riser card into place until the latch at the rear of the card snaps closed.
18. Connect the SAS signal cables to the SAS controller:
 - a. Connect the SAS signal cable from the right side of the hard disk drive backplane to the right front connector on the SAS controller (as facing the front of the server).




Figure 61. SAS signal cable connection

- b. Connect the SAS signal cable that comes with the 4 Pac HDD upgrade option kit from the left side of the hard disk drive backplane to the left front connector on the SAS controller (as facing the front of the server).
19. If you removed any fans, install them.
20. Insert the hard disk drives and the fillers the rest of the way into the bays.

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Installing a SAS/SATA 8 Pac HDD option

Use this information to install a SAS/SATA 8 Pac HDD option.

About this task

If the server is a 16-drive-capable model with eight hard disk drive bays installed, you can install an IBM System x3650 M3 Hot-swap SAS/SATA 8 Pac HDD option. See <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/> for a list of supported optional devices. To order a SAS/SATA 8 Pac HDD option, contact your IBM marketing representative or authorized reseller.

The SAS/SATA 8 Pac HDD option kit contains the following components:

- One 2.5-inch hard disk drive backplane
- One SAS expander card
- Four M3 screws
- One remote battery cable
- Eight blank EMC fillers
- Four SAS signal cables (one cable has a right-angle connector)
- One internal power cable
- Two backplane brackets

To install a 8-disk-drive optional hard disk drive backplane in a 16-drive-capable server model, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Turn off the server and disconnect all power cords and external cables (see “Turning off the server” on page 23).
3. Remove the server cover (see “Removing the cover” on page 45).
4. Remove the two 4-drive filler panels that are to the right of drive bay 8, beneath the IDs 8 - 15 on the front bezel.




Figure 62. 4-drive filler panels removal

5. To obtain more working room, remove fans 2 and 3 (see “Removing a hot-swap fan” on page 127).
6. Pull the hard disk drives or fillers out of the server slightly to disengage them from the backplanes. For more information, see “Removing a hard disk drive” on page 62.
7. Disconnect the SAS signal cables from the SAS controller, which is connected to the SAS riser-card. Leave the other end of the SAS signal cables connected to the hard disk drive backplanes.




Figure 63. Disconnecting SAS signal cables

8. Remove the SAS controller assembly from the server; then, remove the SAS controller from the SAS riser-card. See “Removing a ServeRAID SAS controller from the SAS riser-card” on page 134 for instructions.




Figure 64. SAS controller removal

9. Remove the SAS controller front retention bracket from the server.




Figure 65. SAS controller front retention bracket removal

10. Connect one end of the internal power cable that comes with the 8 Pac HDD option kit into the empty hot-swap SAS/SATA power connector on the system board.




Figure 66. Connecting internal power cable

11. Remove hard disk drive backplane 1 from the server.




Figure 67. Hard disk drive backplane 1 removal

- a. From backplane 1, disconnect the following cables in the order listed:
 - Power cable **1**
 - SAS signal cable **2**

- Configuration cable **3**
 - b. Lift backplane 1 out of the server by pulling it toward the rear of the server and then lifting it up.
12. Install the new backplane in slot 2:
- a. Move the SAS signal cable from hard disk drive backplane 1 to new backplane 2 **1**. The new backplane comes with the option kit.




Figure 68. SAS signal cable connection

- b. Connect the new power cable that comes with the option kit to new hard disk drive backplane 2 **2**.
- c. Connect the configuration cable to backplane 2 **3**.
- d. Angle the new backplane and place the bottom edge into the slots for backplane 2 on the chassis next to the optical drive.




Figure 69. New backplane installation

- e. Rotate the backplane upright so that the bracket goes underneath the latch and tabs on the chassis and is engaged into the slots on the backplane bracket.
13. Install hard disk drive backplane 1:
 - a. Connect the right-angle end of the longer SAS signal cable that comes with the option kit to hard disk drive backplane 1 **1**.




Figure 70. SAS signal cable connection

- b. Reconnect the power cable **2** to backplane 1.
 - c. Reconnect the configuration cable **3** to backplane 1.
 - d. Angle the backplane and place the bottom edge into the slots for backplane 1 on the chassis.
 - e. Rotate the backplane upright so that the bracket goes underneath the latch and tabs on the chassis and is engaged into the slots on the backplane bracket.
14. Make sure that the configuration cable is connected to all backplanes.
 15. Remove the rear controller retention bracket located in the battery bay above the power supplies by pulling up the release tab **1** and sliding the bracket outward **2**.




Figure 71. Rear controller retention bracket removal

16. Install the SAS controller front retention bracket that you got from step 15:
 - a. Align the retention bracket controller slot so that it faces the rear of the server.




Figure 72. SAS controller front retention bracket installation

- b. Place the bracket tabs in the holes on the chassis and slide the bracket to left until it clicks into place.
17. Remove the fillers (if they are installed) from the four connectors on the SAS expander card that comes with the option kit.




Figure 73. Fillers removal

18. Install the SAS expander card:

- a. Insert the SAS expander card into the connector on the SAS riser-card.
- b. Insert the front of the SAS expander card into the front retention bracket.




Figure 74. SAS expander card installation

- c. Install the SAS riser-card with the SAS expander card into the connector on the system board, making sure that the alignment post goes through the hole in the expander card. Press the riser card into place until the latch at the rear of the card snaps closed.
19. If a battery and battery carrier are attached to the SAS controller that you removed in step 8 on page 66, disconnect the battery carrier cable from the battery and remove the three screws that secure the battery carrier to the SAS controller. Set the battery and battery carrier aside.

Note: The illustrations in this document might differ slightly from your hardware.




Figure 75. Battery removal

20. Install the interposer card that comes with the option kit on the interposer card connector on the SAS controller:
 - a. Remove the interposer card and the loose screw from the bag.
 - b. Rotate the standoff so that it aligns with the hole in the ServeRAID controller, and position the interposer card connector over the SAS controller connector.




Figure 76. Interposer card installation

- c. Press the interposer card down onto the interposer card connector so that the interposer card is secured.
 - d. From the other side of the SAS controller, insert and tighten the screw to secure the interposer card to the SAS controller.
21. Remove the expansion-slot bracket that is screwed to the vertical wall above the power supply and install the expansion-slot bracket on the SAS controller:




Figure 77. PCI bracket removal

- a. Orient the SAS controller as shown in the illustration.




Figure 78. Orienting SAS controller

- b. Align the metal bracket so that the tabs are on the back side of the SAS controller and the holes on the tabs align with the holes on the SAS controller.

- c. From the front side of the SAS controller, install the two screws that hold the metal bracket onto the SAS controller.
22. If required, connect one end of the remote battery cable to the interposer card.

Attention: To avoid damage to the hardware, make sure that you align the black dot on the cable connector with the black dot on the connector on the interposer card. *Do not force the remote battery cable into the connector.*




Figure 79. Connecting remote battery cable

23. Connect the shorter SAS signal cable that comes with the option kit to the SAS controller connector that is labeled “Ports 7-4”




Figure 80. Connecting SAS signal cable

Note:

- a. If you are connecting the shorter SAS signal cable to a ServeRAID-BR10i v2 SAS/SATA Controller, the connectors are reversed. You must connect the shorter SAS signal cable to the connector that is labeled "Port 4-7", which is the connector that is not the closest to the edge of the controller.
 - b. If you are connecting the longer SAS signal cable to a ServeRAID-BR10i v2 SAS/SATA Controller, the connectors are reversed. You must connect the straight connector end of the longer SAS signal cable to the connector that is labeled "Port 0-3".
24. Remove the PCI riser-card assembly (see "Removing a PCI riser-card assembly" on page 46).
25. Orient the SAS controller so that the connectors are on the underside of the controller. Install the SAS controller in the connector on the PCI riser card. (See the previous illustration and see "Installing a PCI adapter" on page 53.)
26. Install the PCI riser-card assembly in the server (see "Removing a PCI riser-card assembly" on page 46).
27. Connect the free end of the remote battery cable to the battery on the remote battery tray. For more information, see "Installing a ServeRAID SAS controller battery on the remote battery tray" on page 139.
28. Connect the SAS signal cables to the SAS expander card:
 - a. Connect the SAS signal cables from hard disk drive backplane 2 to the right front connectors on the SAS expander card (as facing the front of the server).




Figure 81. Connecting SAS signal cables

- b. Connect the SAS signal cables from hard disk drive backplane 1 to the left front connectors on the SAS expander card (as facing the front of the server).
29. Connect the loose end of the SAS signal cables (the cables have straight connectors and are already connected to the ServeRAID controllers) to the rear connectors on the SAS expander card. Route the cable underneath the cable retention features on the baffle. See the illustration.

Note: The cables that connect to a ServeRAID-BR10i v2 SAS/SATA Controller are reversed.




Figure 82. Cable routing

30. If you removed any fans, install them.
31. Insert the hard disk drives and the fillers the rest of the way into the bays.

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Installing a SAS/SATA 8 Pac HDD for 2 RAID kit with 2 M5015 adapters option

About this task

If the server is a 16-drive-capable model with eight hard disk drive bays installed, you can install an IBM System x3650 M3 Hot-swap SAS/SATA 8 Pac HDD option. See <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/> for a list of supported optional devices. To order a SAS/SATA 8 Pac HDD for 2 RAID kit with 2 M5015 adapters option, contact your IBM marketing representative or authorized reseller.

The SAS/SATA 8 Pac HDD for 2 RAID kit with 2 M5015 adapters option contains the following components:

- One 2.5-inch hard disk drive backplane
- Two M5015 adapters

- Four M3 screws
- Eight blank EMC fillers
- Two SAS signal cables
- One remote battery cable
- One internal power cable
- Two backplane brackets

To install a SAS/SATA 8 Pac HDD for 2 RAID kit with 2 M5015 adapters in a 16-drive-capable server model, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v, “Installation guidelines” on page 37, and “Handling static-sensitive devices” on page 40.
2. Turn off the server and disconnect all power cords and external cables (see “Turning off the server” on page 23).
3. Remove the server cover (see “Removing the cover” on page 45).
4. Remove the two 4-drive filler panels that are to the right of drive bay 8, beneath the IDs 8 - 15 on the front bezel.




Figure 83. 4-drive filler panels removal

5. To obtain more working room, remove fans 2 and 3 (see “Removing a hot-swap fan” on page 127).
6. Pull the hard disk drives or fillers out of the server slightly to disengage them from the backplanes. For more information, see “Removing a hard disk drive” on page 62.
7. Disconnect the SAS signal cables from the SAS controller, which is connected to the SAS riser-card. Leave the other end of the SAS signal cables connected to the hard disk drive backplanes.




Figure 84. Disconnecting SAS signal cables

8. Remove the SAS controller assembly from the server; then, remove the SAS controller from the SAS riser-card. See "Removing a ServeRAID SAS controller from the SAS riser-card" on page 134 for instructions.




Figure 85. SAS controller removal

9. Remove the SAS controller front retention bracket from the server.




Figure 86. SAS controller front retention bracket removal

10. Connect one end of the internal power cable that comes with the 8 Pac HDD option kit into the empty hot-swap SAS/SATA power connector on the system board.




Figure 87. Connecting internal power cable

11. Remove hard disk drive backplane 1 from the server.




Figure 88. Hard disk drive backplane 1 removal

- a. From backplane 1, disconnect the following cables in the order listed:
 - Power cable **1**
 - SAS signal cable **2**
 - Configuration cable **3**
 - b. Lift backplane 1 out of the server by pulling it toward the rear of the server and then lifting it up.
12. Install the new backplane in slot 2:
- a. Move the SAS signal cable from hard disk drive backplane 1 to new backplane 2 **1**. The new backplane comes with the option kit.




Figure 89. SAS signal cable connection

- b. Connect the new power cable that comes with the option kit to new hard disk drive backplane 2 **2**.
- c. Connect the configuration cable to backplane 2 **3**.
- d. Angle the new backplane and place the bottom edge into the slots for backplane 2 on the chassis next to the optical drive.




Figure 90. New backplane installation

- e. Rotate the backplane upright so that the bracket goes underneath the latch and tabs on the chassis and is engaged into the slots on the backplane bracket.
13. Install hard disk drive backplane 1:
- a. Connect the right-angle end of the longer SAS signal cable that comes with the option kit to hard disk drive backplane 1 **1**.




Figure 91. SAS signal cable connection

- b. Reconnect the power cable **2** to backplane 1.
 - c. Reconnect the configuration cable **3** to backplane 1.
 - d. Angle the backplane and place the bottom edge into the slots for backplane 1 on the chassis.
 - e. Rotate the backplane upright so that the bracket goes underneath the latch and tabs on the chassis and is engaged into the slots on the backplane bracket.
14. Make sure that the configuration cable is connected to all backplanes.
15. Remove the rear controller retention bracket located in the battery bay above the power supplies by pulling up the release tab **1** and sliding the bracket outward **2**.




Figure 92. Rear controller retention bracket removal

16. Install the SAS controller front retention bracket that you got from step 15.
 - a. Align the retention bracket controller slot so that it faces the rear of the server.




Figure 93. SAS controller front retention bracket installation

- b. Place the bracket tabs in the holes on the chassis and slide the bracket to left until it clicks into place.
17. Remove the fillers (if they are installed) from the connectors on the M5015 adapters that come with the option kit.

18. Install one of the M5015 adapters:
 - a. Insert an M5015 adapter into the connector on the SAS riser-card.
 - b. Insert the front of the M5015 adapter into the front retention bracket.




Figure 94. M5015 adapter installation

- c. Install the SAS riser-card with the M5015 adapter into the connector on the system board, making sure that the alignment post goes through the hole in the controller. Press the riser card into place until the latch at the rear of the card snaps closed.
19. Remove the expansion-slot bracket that is screwed to the vertical wall above the power supply and install the expansion-slot bracket on another M5015 adapter:




Figure 95. PCI bracket removal

- a. Orient the M5015 adapter as shown in the illustration.




Figure 96. Orienting M5015 adapter

- b. Align the metal bracket so that the tabs are on the back side of the SAS controller and the holes on the tabs align with the holes on the SAS controller.
 - c. From the front side of the M5015 adapter, install the two screws that hold the metal bracket onto the M5015 adapter.
20. Connect the SAS signal cables to the connectors on the M5015 adapter:
 - a. Connect the shorter SAS signal cable that comes with the option kit to the M5015 adapter connector that is labeled "Ports 3-0".




Figure 97. Connecting SAS signal cables

- b. Connect the longer SAS signal cable to the other SAS connector that is labeled "Ports 7-4".
21. Remove the PCI riser-card assembly 2 (see the "Removing a PCI riser-card assembly" section of the IBM System x3650 M3 Installation and User's Guide).
22. Orient the M5015 adapter so that the connectors are on the underside of the controller. Install the M5015 adapter in the connector on the PCI riser card (PCI slot 4, see the previous illustration and see the "Installing a PCI adapter" section of the IBM System x3650 M3 Installation and User's Guide).
23. Install the PCI riser-card assembly 2 in the server (see the "Installing a PCI riser-card assembly" section of the IBM System x3650 M3 Installation and User's Guide).
24. Connect the SAS signal cables to the M5015 adapter installed on the bottom left corner (as facing the front of the server):
 - a. Connect the SAS signal cable from the left front connector of hard disk drive backplane 1 to the lower connector on the M5015 adapter (as facing the front of the server).




Figure 98. Connecting SAS signal cables

- b. Connect the SAS signal cable from the right front connector of hard disk drive backplane 1 to the upper connector on the M5015 adapter (as facing the front of the server).
- 25. Connect the SAS signal cables from the connectors on the M5015 adapter installed on the back of the server. Route the cable underneath the cable retention features on the baffle. See the illustration.
 - a. Connect the shorter SAS signal cable to the left front connector of hard disk drive backplane 2.
 - b. Connect the longer SAS signal cable to the right front connector of hard disk drive backplane 2.




Figure 99. Cable routing

26. If you removed any fans, install them.
27. Insert the hard disk drives the rest of the way into the bays.

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Installing an optional tape drive

Use this information to install an optional tape drive.

About this task

The IBM System x3650 M3 RDX-DDS internal enablement kit is used to install an IBM tape drive in an IBM System x3650 M3 server. The IBM System x3650 M3 RDX-DDS internal enablement kit is compatible only with the following tape drives:

- IBM DDS Generation 5 (DDS/5) SATA tape drive
- IBM DDS Generation 6 (DDS/6) USB tape drive
- IBM RDX USB Removable Hard Disk Drive

Note: If your server is with four SAS hard disk drive bays, you need to install the SAS/SATA 4 Pac HDD upgrade option first (see “Installing a SAS/SATA 4 Pac HDD upgrade option” on page 65) in order to upgrade to a 8 Pac HDD + tape system.

The RDX-DDS internal enablement kit contains the following components:

- One 3.5-inch DDS Gen 6 bezel
- One RDX bezel
- One 3.5-inch black bezel
- One cosmetic bezel
- One 3.5-inch RDX bezel
- One SAS riser-card, tape enablement kit
- One SAS riser-card and controller assembly
- One tape enablement tray
- EMC brackets
- One SAS signal cable
- One HDD configuration cable
- One HDD power cable
- One tape drive power cable
- Eight M3 x 0.5 screws
- Four M3 x 5 screws

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Converting a 16 bay system to a 8 bay + tape system

Use this information to convert a 16 bay system to a 8 bay + tape system.

About this task

Note: You can skip this section if you do not have a 16 bay model.

To convert a 16 bay system to a 8 + tape system, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v, “Installation guidelines” on page 37, and “Handling static-sensitive devices” on page 40.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables.
3. Remove the server cover (see “Removing the cover” on page 45).
4. Remove the front bezel.




Figure 100. Front bezel removal

- a. Remove the screws from the bezel.
 - b. Rotate the top of the bezel away from the server and remove the tabs on the bottom of the bezel from the slots on the underside of the chassis.
5. Move the hot-swap hard disk drives or fillers to the open drive bays:
 - a. Remove the hard disk drive or filler panel in drive bay 7 and replace it in bay 15. Slide the drive or filler panel most of the way into the drive bay, so that it is not fully seated.
 - b. One at a time, remove each remaining hard disk drive or filler panel and replace it in the rightmost available drive bay. Slide the drive or filler panel most of the way into the drive bay, so that it is not fully seated.
 6. Disconnect all cables from the SAS hard disk drive backplanes and from the SAS riser-card. Set the SAS signal cables and the configuration cable aside; these cables will be replaced by the tape enablement kit cables.
 7. Shift the SAS hard disk drive backplane to the right to create enough space to install a tape drive.






Figure 101. Shifting SAS hard disk drive backplane


- a. To obtain more working room, remove fans 2 and 3 (see “Removing a hot-swap fan” on page 127) and fan bracket.
- b. Lift the backplane out of the server by pulling it toward the rear of the server and then lifting it up.
- c. Move the backplane to the right backplane location.
8. Install the EMC brackets in the chassis:
 - a. Install the right EMC bracket by sliding it into the front of the chassis until it locks into place.
 - b. Install the left EMC bracket by sliding it into the front of the chassis until it locks into place.



- c. Make sure that the open side of the bottom EMC bracket faces away from the server. To install the bottom EMC bracket, insert and tighten two M3 x 0.5 screws in the countersunk holes in the bottom bracket down into the chassis.



- d. Make sure that the open side of the top EMC bracket faces away from the server. To install the top EMC bracket, insert and tighten two M3 x 0.5 screws in the threaded holes in the chassis down into the top bracket.



Installing the tape drive option

The following illustration shows how to install an optional tape drive.

About this task




Figure 102. Tape drive installation

To install a SATA or USB tape drive, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v, “Installation guidelines” on page 37, and “Handling static-sensitive devices” on page 40.
2. Turn off the server and peripheral devices, and disconnect the power cords and all external cables.
3. Install the tape drive on the tray as shown in the following illustration. If the tape drive comes with a metal spacer attached, remove the spacer before you install the tape drive on the tray.




Figure 103. Tape drive installation

4. Prepare the drive according to the instructions that come with the drive, setting any switches or jumpers.
5. Remove the SAS riser-card and controller assembly (see “Removing the SAS riser-card and controller assembly” on page 129).
6. Remove the SAS controller from the SAS riser-card.





Figure 104. SAS controller removal

To remove the SAS controller from the SAS riser-card, complete the following steps:

- a. Disconnect the SAS signal cables from the connectors on the SAS controller.
 - b. Pull the SAS controller horizontally out of the connector on the SAS riser-card.
7. Remove the configuration cable and install the SAS controller on the tape-enabled SAS riser-card:



- a. Disconnect and remove the configuration cable from the system board. This cable will be replaced by the tape-enabled configuration cable.
- b. Turn the SAS controller so that the keys on the bottom edge align correctly with the connector on the tape-enabled SAS riser-card in the SAS riser-card and controller assembly.
- c. Firmly press the SAS controller horizontally into the connector on the SAS riser-card.
- d. Gently press the opposite edge of the SAS controller into the adapter retention bracket on the SAS riser-card and controller assembly.

Note: Depending on the height of your SAS controller, you might have to remove the retention bracket from the tape-enabled SAS riser-card and controller assembly, install the SAS controller and riser card on the SAS riser-card and controller assembly, and replace the retention bracket.

8. Connect the following tape enablement kit cables to the connectors on the SAS riser-card and the hard disk drive backplanes:

- SAS signal cables into the SAS connectors on the hard disk drive backplanes
 - SAS backplane power cable (that is connected to the system board) to the hard disk drive backplanes
 - Configuration cable to the configuration connector on each hard disk drive backplane
9. Connect the tape-enabled configuration cable to the system board.
 10. Install the hard disk drive backplanes.




Figure 105. Hard disk drive backplanes installation

- a. Align the backplane with the backplane slot in the chassis and the small slots on top of the hard disk drive cage.
 - b. Lower the backplane into the slots on the chassis.
 - c. Rotate the top of the backplane until the front tab clicks into place into the latches on the chassis.
 - d. Insert the hard disk drives or the filler panels the rest of the way into the hard disk drive bays.
11. Make sure that the tape cables are connected securely to the following connectors on the SAS riser-card:
 - Tape power cable: tape power connector
 - Tape signal cable that came with the tape drive: SATA tape signal connector (SATA drive only) or USB tape connector (USB drive only)

The following illustration shows how to connect the SATA tape drive cables.




Figure 106. SATA tape drive cables

The following illustration shows how to connect the USB tape drive cables.




Figure 107. USB tape drive cables

12. Install the SAS riser-card and controller assembly (see “Installing the SAS riser-card and controller assembly” on page 130). Fold the excess length of the cables under the SAS controller assembly.




Figure 108. SAS riser-card installation

13. Slide the tape-drive assembly most of the way into the tape-drive bay.

14. Connect the signal and power cables from the SAS riser-card to the back of the tape drive.
Attention: Make sure that all the cables are positioned underneath the tape-drive assembly before you insert the assembly in the tape-drive bay. Otherwise, the cables might be damaged.
15. Slide the tape-drive assembly the rest of the way into the tape-drive bay.
16. Push the latch to the closed (locked) position.

Installing a second microprocessor

Use this information to install a second microprocessor.

About this task

The following notes describe the type of microprocessor that the server supports and other information that you must consider when you install a microprocessor:

Important: Always use the microprocessor installation tool to install a microprocessor. Failing to use the microprocessor installation tool may damage the microprocessor sockets on the system board. Any damage to the microprocessor sockets may require replacing the system board.

- The server supports certain Intel Xeon scalable multi-core microprocessors, which are designed for the LGA 1366 socket. These microprocessors are 64-bit dual-core or quad-core microprocessors with an integrated memory controller, quick-path interconnect, and shared last cache. See <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/> for a list of supported microprocessors.
- The server supports up to two microprocessors. If the server comes with one microprocessor, you can install a second microprocessor.
- Do not install an Intel Xeon™ 5500 series microprocessor and an Intel Xeon™ 5600 series microprocessor in the same server.
- Both microprocessors must have the same QuickPath Interconnect (QPI) link speed, integrated memory controller frequency, core frequency, power segment, cache size, and type.
- Read the documentation that comes with the microprocessor to determine whether you must update the server firmware for the server. To download the most current level of server firmware and many other code updates for your server, complete the following steps:
 1. Go to <http://www.ibm.com/systems/support/>.
 2. Under **Product support**, click **System x**.
 3. Under **Popular links**, click **Software and device drivers**.
 4. Click **System x3650 M3** to display the matrix of downloadable files for the server.
- (Optional) Obtain an SMP-capable operating system. For a list of supported operating systems and optional devices, see <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/>.
- To order additional microprocessor optional devices, contact your IBM marketing representative or authorized reseller.
- The microprocessor speeds are automatically set for this server; therefore, you do not have to set any microprocessor frequency-selection jumpers or switches.
- If you have to replace a microprocessor, call for service.

- If the thermal-grease protective cover (for example, a plastic cap or tape liner) is removed from the heat sink, do not touch the thermal grease on the bottom of the heat sink or set down the heat sink.
- Do not remove the first microprocessor from the system board to install the second microprocessor.

The following illustration shows the microprocessor socket locations on the system board.




Figure 109. Microprocessor socket locations

Attention:

- A startup (boot) microprocessor must always be installed in microprocessor socket 1 on the system board.
- To ensure correct server operation when you install an additional microprocessor, use microprocessors that are compatible and install at least one DIMM in a DIMM connector for microprocessor 2.

To install an additional microprocessor, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Turn off the server and disconnect all power cords and external cables (see “Turning off the server” on page 23).
3. Remove the server cover (see “Removing the cover” on page 45).

4. Remove PCI riser-card assembly 2 (see “Removing a PCI riser-card assembly” on page 46).
5. Remove the microprocessor air baffle (see “Removing the microprocessor 2 air baffle” on page 48).
6. Locate the second microprocessor socket on the system board.
7. Rotate the heat-sink release lever to the fully open position.
8. Install the microprocessor:
 - a. Rotate the microprocessor release lever on the socket from its closed and locked position until it stops in the fully open position.




Figure 110. Microprocessor release lever rotation

- b. Rotate the hinged microprocessor bracket frame into the open position.
- c. Remove the microprocessor socket dust cover from the surface of the microprocessor socket, if one is present. Store the dust cover in a safe place.
- d. Touch the static-protective package that contains the microprocessor to any unpainted metal surface on the server. Then, remove the microprocessor from the package.

Attention:

- Do not touch the microprocessor contacts; handle the microprocessor by the edges only. Contaminants on the microprocessor contacts, such as oil from your skin, can cause connection failures between the contacts and the socket.
- Handle the microprocessor carefully. Dropping the microprocessor during installation or removal can damage the contacts.
- Do not use excessive force when you press the microprocessor into the socket.
- Make sure that the microprocessor is oriented and aligned and positioned in the socket before you try to close the lever.




Figure 111. Microprocessor alignment

- e. If there is a plastic protective cover on the bottom of the microprocessor, carefully remove it.




Figure 112. Protective cover removal

- f. Locate the microprocessor installation tool that comes with the new microprocessor.

Note: The microprocessor installation tool assembly comes with the microprocessor and microprocessor cover attached to the tool. The microprocessor comes protected between the tool and the microprocessor cover.




Figure 113. Installation tool

- g. Remove the microprocessor installation tool assembly from the package.

Note: Do not rotate the handle on the tool until you are ready to install the microprocessor into the microprocessor socket.

- h. Remove the cover from the bottom of the microprocessor installation tool. Press both microprocessor cover release tabs outward (in opposite directions as shown in the illustration) and remove the microprocessor installation tool with the microprocessor attached.




Figure 114. Installation tool cover removal

- i. Carefully align the microprocessor installation tool over the microprocessor socket.

Attention: The microprocessor fits only one way on the socket. You must place a microprocessor straight down on the socket to avoid damaging the pins on the socket. The pins on the socket are fragile. Any damage to the pins may require replacing the system board.




Figure 115. Installation tool alignment

- j. Twist the handle on the microprocessor tool counterclockwise to insert the microprocessor into the socket.




Figure 116. Installation tool handle adjustment

- k. Close the microprocessor bracket frame.
- l. Carefully close the microprocessor release lever to the closed position to secure the microprocessor in the socket.
9. Install a heat sink on the microprocessor.

Attention: Do not touch the thermal grease on the bottom of the heat sink or set down the heat sink after you remove the plastic cover. Touching the thermal grease will contaminate it. If the thermal grease is contaminated, call IBM service and support to request a replacement thermal grease kit. For information about installing the replacement thermal grease, see “Thermal grease” on page 114.




Figure 117. Thermal grease

- a. Make sure that the heat-sink release lever is in the fully open position.
- b. Remove the plastic protective cover from the bottom of the heat sink.
- c. Align the heat sink above the microprocessor with the thermal-grease side down.




Figure 118. Heat sink alignment

- d. Slide the rear flange of the heat sink into the opening in the retainer bracket.
- e. Press down firmly on the front of the heat sink until it is seated securely.
- f. Rotate the heat-sink release lever to the closed position and hook it underneath the lock tab.
10. Install the microprocessor air baffle (see “Installing the microprocessor 2 air baffle” on page 49).
11. Install PCI riser-card assembly 2 (see “Installing a PCI riser-card assembly” on page 47).

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Thermal grease

The thermal grease must be replaced whenever the heat sink has been removed from the top of the microprocessor and is going to be reused or when debris is found in the grease.

About this task

To replace damaged or contaminated thermal grease on the microprocessor and heat exchanger, complete the following steps:

Procedure

1. Place the heat-sink assembly on a clean work surface.
2. Remove the cleaning pad from its package and unfold it completely.
3. Use the cleaning pad to wipe the thermal grease from the bottom of the heat exchanger.

Note: Make sure that all of the thermal grease is removed.

4. Use a clean area of the cleaning pad to wipe the thermal grease from the microprocessor; then, dispose of the cleaning pad after all of the thermal grease is removed.




Figure 119. Thermal grease distribution

5. Use the thermal-grease syringe to place nine uniformly spaced dots of 0.02 mL each on the top of the microprocessor.




Figure 120. Syringe

Note: 0.01mL is one tick mark on the syringe. If the grease is properly applied, approximately half (0.22 mL) of the grease will remain in the syringe.

Installing a memory module

The following notes describe the types of dual inline memory modules (DIMMs) that the server supports and other information that you must consider when you install DIMMs.

About this task




Figure 121. DIMM connectors location

- When you install or remove DIMMs, the server configuration information changes. When you restart the server, the system displays a message that indicates that the memory configuration has changed.
- The server supports only industry-standard double-data-rate 3 (DDR3), 800, 1066, or 1333 MHz, PC3-10600R-999, registered or unbuffered, synchronous dynamic random-access memory (SDRAM) dual inline memory modules (DIMMs) with error correcting code (ECC). See <http://www.ibm.com/systems/support/> for a list of supported memory modules for the server.

- The specifications of a DDR3 DIMM are on a label on the DIMM, in the following format.

ggg eRxff-PC3-wwwwm-aa-bb-cc

where:

- *ggg* is the total capacity of the DIMM (for example, 1GB, 2GB, or 4GB)
- *e* is the number of ranks
 - 1 = single-rank
 - 2 = dual-rank
 - 4 = quad-rank
- *ff* is the device organization (bit width)
 - 4 = x4 organization (4 DQ lines per SDRAM)
 - 8 = x8 organization
 - 16 = x16 organization
- *wwww* is the DIMM bandwidth, in MBps

6400 = 6.40 GBps (PC3-800 SDRAMs, 8-byte primary data bus)
 8500 = 8.53 GBps (PC3-1066 SDRAMs, 8-byte primary data bus)
 10600 = 10.66 GBps (PC3-1333 SDRAMs, 8-byte primary data bus)
 12800 = 12.80 GBps PC3-1600 SDRAMs, 8-byte primary data bus)

- *m* is the DIMM type
 - E = Unbuffered DIMM (UDIMM) with ECC (x72-bit module data bus)
 - R = Registered DIMM (RDIMM)
 - U = Unbuffered DIMM with no ECC (x64-bit primary data bus)
- *aa* is the CAS latency, in clocks at maximum operating frequency
- *bb* is the JEDEC SPD Revision Encoding and Additions level
- *cc* is the reference design file for the design of the DIMM
- *d* is the revision number of the reference design of the DIMM
- The following rules apply to DDR3 DIMM speed as it relates to the number of DIMMs in a channel:
 - When you install 1 DIMM per channel, the memory runs at 1333 MHz
 - When you install 2 DIMMs per channel, the memory runs at 1066 MHz
 - When you install 3 DIMMs per channel, the memory runs at 800 MHz
 - All channels in a server run at the fastest common frequency.
 - Do not install registered and unbuffered DIMMs in the same server.
- The maximum memory speed is determined by the combination of the microprocessor, DIMM speed, and the number of DIMMs installed in each channel.
- In two-DIMM-per-channel configuration, a server with an Intel Xeon X5600 series microprocessor automatically operates with a maximum memory speed of up to 1333 MHz when one of the following conditions is met:
 - Two 1.5 V single-rank or dual-rank RDIMMs are installed in the same channel. In the Setup utility, **Memory speed** is set to **Max performance** mode
 - Two 1.35 V single-rank or dual-rank RDIMMs are installed in the same channel. In the Setup utility, **Memory speed** is set to **Max performance** and **LV-DIMM power** is set to **Enhance performance** mode. The 1.35 V RDIMMs will function at 1.5 V
- The server supports a maximum of 18 single-rank or dual-rank RDIMMs. The server supports up to 12 single-rank or dual-rank UDIMMs or quad-rank RDIMMs.

Note: To determine the type of a DIMM, see the label on the DIMM. The information on the label is in the format xxxxx nRxxx PC3-xxxxx-xx-xx-xxx. The numeral in the sixth numerical position indicates whether the DIMM is single-rank (n=1), dual-rank (n=2), or quad-rank (n=4).

- The server supports three single-rank or dual-rank DIMMs per channel. The server supports a maximum of two quad-rank RDIMMs per channel. The following table shows an example of the maximum amount of memory that you can install using ranked DIMMs:

Table 9. Maximum memory installation using ranked DIMMs

Number of DIMMs	DIMM type	DIMM size	Total memory
12	Single-rank UDIMMs	2 GB	24 GB
12	Dual-rank UDIMMs	4 GB	48 GB
18	Single-rank RDIMMs	2 GB	36 GB

Table 9. Maximum memory installation using ranked DIMMs (continued)

Number of DIMMs	DIMM type	DIMM size	Total memory
18	Dual-rank RDIMMs	2 GB	36 GB
18	Dual-rank RDIMMs	4 GB	72 GB
18	Dual-rank RDIMMs	8 GB	144 GB
12	Quad-rank RDIMMs	16 GB	192 GB
18	Dual-rank RDIMMs	16 GB	288 GB

- The RDIMM options that are available for the server are 2 GB, 4 GB, 8 GB, and 16 GB. The server supports a minimum of 2 GB and a maximum of 288 GB of system memory using RDIMMs.

For 32-bit operating systems only: Some memory is reserved for various system resources and is unavailable to the operating system. The amount of memory that is reserved for system resources depends on the operating system, the configuration of the server, and the configured PCI devices.

- The UDIMM options that are available for the server are 2 GB and 4 GB. The server supports a minimum of 2 GB and a maximum of 48 GB of system memory using UDIMMs.

Note: The amount of usable memory is reduced depending on the system configuration. A certain amount of memory must be reserved for system resources. To view the total amount of installed memory and the amount of configured memory, run the Setup utility. For additional information, see Chapter 3, “Configuring the server,” on page 157.

- A minimum of one DIMM must be installed for each microprocessor. For example, you must install a minimum of two DIMMs if the server has two microprocessors installed. However, to improve system performance, install a minimum of three DIMMs for each microprocessor.
- DIMMs in the same system must be the same type (UDIMM or RDIMM) to ensure that the server will operate correctly.
- When you install one quad-rank RDIMM in a channel, install it in the DIMM connector furthest away from the microprocessor.
- Do not install one quad-rank RDIMM in one channel and three RDIMMs in another channel.

DIMM installation sequence

The server comes with a minimum of one 2 GB DIMM installed in slot 3. When you install additional DIMMs, install them in the order shown in the following table to optimize system performance. In non-mirroring mode, all three channels on the memory interface for each microprocessor can be populated in any order and have no matching requirements. When you install additional DIMMs, install them in the order shown in Table 10, to maintain performance.

Important: If you have configured the server to use memory mirroring, do not use the order in Table 10; go to “Memory mirroring” on page 119 and use the installation order shown there.

Table 10. DIMM installation sequence for non-mirroring (normal) mode

Installed microprocessors	DIMM connector population sequence
Microprocessor socket 1	Install the DIMMs in the following sequence: 3, 6, 9, 2, 5, 8, 1, 4, 7

Table 10. DIMM installation sequence for non-mirroring (normal) mode (continued)

Installed microprocessors	DIMM connector population sequence
Microprocessor socket 2	Install the DIMMs in the following sequence: 12, 15, 18, 11, 14, 17, 10, 13, 16

Memory mirroring

Memory-mirroring mode replicates and stores data on two pairs of DIMMs within two channels simultaneously. If a failure occurs, the memory controller switches from the primary pair of memory DIMMs to the backup pair of DIMMs. To enable memory mirroring through the Setup utility, select **System Settings** → **Memory**. For details about enabling memory mirroring, see “Using the Setup utility” on page 158. When you use the memory mirroring feature, consider the following information:

- When you use memory mirroring, you must install a pair of DIMMs at a time. One DIMM must be in channel 0, and the mirroring DIMM must be in the same connector in channel 1. The two DIMMs in each pair must be identical in size, type, rank (single, dual, or quad), and organization. They do not have to be identical in speed. The channels run at the speed of the slowest DIMM in any of the channels. See Table 12 on page 120 for the DIMM connectors that are in each pair.
- Channel 2, DIMM connectors 7, 8, 9, 16, 17, and 18 are not used in memory-mirroring mode.
- The maximum available memory is reduced to half of the installed memory when memory mirroring is enabled. For example, if you install 64 GB of memory using RDIMMs, only 32 GB of addressable memory is available when you use memory mirroring.

The following diagram shows the memory channel interface layout with the DIMM installation sequence for mirroring mode. The numbers within the boxes indicate the DIMM population sequence in pairs within the channels, and the numbers next to the boxes indicate the DIMM connectors within the channels. For example, the following illustration shows the first pair of DIMMs (indicated by ones (1) inside the boxes) should be installed in DIMM connector 1 on channel 0 and DIMM connector 2 on channel 1. DIMM connectors 3, 6, 9, 12, 15, and 18 on channel 2 are not used in memory-mirroring mode.




Figure 122. Memory channel interface layout

The following table lists the DIMM connectors on each memory channel.

Table 11. Connectors on each memory channel

Memory channel	DIMM connectors
Channel 0	1, 2, 3, 10, 11, 12
Channel 1	4, 5, 6, 13, 14, 15
Channel 2	7, 8, 9, 16, 17, 18

The following illustration shows the memory connector layout that is associated with each microprocessor. For example, DIMM connectors 10, 11, 12, 13, 14, 15, 16, 17, and 18 (DIMM connectors are shown underneath the boxes) are associated with microprocessor 2 slot (CPU2) and DIMM connectors 1, 2, 3, 4, 5, 6, 7, 8, and 9 are associated with microprocessor 1 slot (CPU1). The numbers within the boxes indicates the installation sequence of the DIMM pairs. For example, the first DIMM pair (indicated within the boxes by ones (1)) should be installed in DIMM connectors 1 and 2, which is associated with microprocessor 1 (CPU1).

Note: You can install DIMMs for microprocessor 2 as soon as you install microprocessor 2; you do not have to wait until all of the DIMM connectors for microprocessor 1 are filled.




Figure 123. Memory connectors associated with each microprocessor

The following table lists the installation sequence for installing DIMMs in memory-mirroring mode.

Table 12. Memory-mirroring mode DIMM population sequence

DIMMs	Number of installed microprocessors	DIMM connector
First pair of DIMMs	1	3, 6
Second pair of DIMMs	1	2, 5
Third pair of DIMMs	1	1, 4
Fourth pair of DIMMs	2	12, 15
Fifth pair of DIMMs	2	11, 14
Sixth pair of DIMMs	2	10, 13
Note: DIMM connectors 7, 8, 9, 16, 17, and 18 are not used in memory-mirroring mode.		

When you install or remove DIMMs, the server configuration information changes. When you restart the server, the system displays a message that indicates that the memory configuration has changed.

Online-spare memory

The server supports online-spare memory. This feature disables the failed memory from the system configuration and activates an online-spare DIMM to replace the failed active DIMM. You can enable either online-spare memory or memory mirroring in the Setup utility (see “Using the Setup utility” on page 158). When you use the memory online-spare feature, consider the following information:

- The memory online-spare feature is supported on server models with an Intel Xeon™ 5600 series microprocessor.
- When you enable the memory online-spare feature, you must install three DIMMs per microprocessor at a time. The first DIMM must be in channel 0, the second DIMM in channel 1, and the online-spare DIMM in channel 2. The DIMMs must be identical in size, type, rank, and organization, but not in speed. The channels run at the speed of the slowest DIMM in any of the channels.
- The maximum available memory is reduced to 2/3 of the installed memory when memory online-spare mode is enabled. For example, if you install 72 GB of memory using RDIMMs, only 48 GB of addressable memory is available when you use memory online-spare.

The following table shows the installation sequence for installing DIMMs for each microprocessor and the online-spare DIMM in memory online-spare mode:

Table 13. Memory online-spare mode DIMM population sequence

Installed Microprocessor	DIMM connector
Microprocessor 1	3, 6, 9
	3, 6, 9, 2, 5, 8
	3, 6, 9, 2, 5, 8, 1, 4, 7
Microprocessor 2	12, 15, 18,
	12, 15, 18, 11, 14, 17,
	12, 15, 18, 11, 14, 17, 10, 13, 16

Installing a DIMM

About this task

To install a DIMM, complete the following steps.




Figure 124. DIMM installation

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Turn off the server and peripheral devices, and disconnect the power cord and all external cables (see “Turning off the server” on page 23).
3. Remove the server cover (see “Removing the cover” on page 45).




Figure 125. PCI riser-card assembly 1 and DIMM air baffle removal

4. If PCI riser-card assembly 1 contains one or more adapters, remove riser-card assembly 1 (see “Removing a PCI riser-card assembly” on page 46).

5. Remove the DIMM air baffle (see “Removing the DIMM air baffle” on page 50).
Attention: To avoid breaking the retaining clips or damaging the DIMM connectors, open and close the clips gently.
6. Open the retaining clip on each end of the DIMM connector.
7. Touch the static-protective package that contains the DIMM to any unpainted metal surface on the server. Then, remove the DIMM from the package.
8. Turn the DIMM so that the DIMM keys align correctly with the connector.
9. Insert the DIMM into the connector by aligning the edges of the DIMM with the slots at the ends of the DIMM connector. Firmly press the DIMM straight down into the connector by applying pressure on both ends of the DIMM simultaneously. The retaining clips snap into the locked position when the DIMM is firmly seated in the connector.
Important: If there is a gap between the DIMM and the retaining clips, the DIMM has not been correctly inserted; open the retaining clips, remove the DIMM, and then reinsert it.
10. Install the DIMM air baffle (see “Installing the DIMM air baffle” on page 51).
11. Install PCI riser-card assembly 2, if you removed it (see “Installing a PCI riser-card assembly” on page 47).

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154. Go to the Setup utility and make sure all the installed DIMMs are present and enabled.

Installing a hot-swap ac power supply

About this task

The following notes describe the type of ac power supply that the server supports and other information that you must consider when you install a power supply:

- Make sure that the devices that you are installing are supported. For a list of supported optional devices for the server, see <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/>.
- Before you install an additional power supply or replace a power supply with one of a different wattage, you may use the IBM Power Configurator utility to determine current system power consumption. For more information and to download the utility, go to <http://www.ibm.com/systems/bladecenter/resources/powerconfig.html>.
- The server comes with one hot-swap 12-volt output power supply that connects to power supply bay 1. The input voltage is 110 V ac or 220 V ac auto-sensing.
- You cannot mix 460-watt and 675-watt power supplies, high-efficiency and non-high-efficiency power supplies, or ac and dc power supplies in the server.
- The following information applies when you install 460-watt power supplies in the server:
 - A warning message is generated if the total power consumption exceeds 400 watts and the server only has one operational 460-watt power supply. In this case, the server can still operate under normal condition. Before you install additional components in the server, you must install an additional power supply

- The server automatically shuts down if the total power consumption exceeds the total power supply output capacity
- You can enable the power capping feature in the Setup utility to control and monitor power consumption in the server (see “Setup utility menu choices” on page 159)

The following table lists the system status when you install 460-watt power supplies in the server:

Table 14. System status with 460-watt power supplies installed


Total system power consumption (in watts)	Number of 460-watt power supplies installed		
	One	Two	Two with one failure
< 400	Normal	Normal, redundant power	Normal
400 ~ 460	Normal, status warning	Normal, redundant power	Normal, status warning
> 460	System shutdown	Normal	System shutdown

- Power supply 1 is the default/primary power supply. If power supply 1 fails, you must replace the power supply immediately.
- You can order an optional power supply for redundancy.
- These power supplies are designed for parallel operation. In the event of a power-supply failure, the redundant power supply continues to power the system. The server supports a maximum of two power supplies.
- For instructions on how to install a hot-swap dc power supply, refer to the documentation that comes with the dc power supply.

Statement 5



CAUTION:
The power control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.



Statement 8



CAUTION:

Never remove the cover on a power supply or any part that has the following label attached.



Hazardous voltage, current, and energy levels are present inside any component that has this label attached. There are no serviceable parts inside these components. If you suspect a problem with one of these parts, contact a service technician.




Figure 126. Power supply installation

To install an ac power supply, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Remove the power-supply blank from the empty power-supply bay by pinching the side clip and pulling the power-supply blank from the bay. Save the power-supply blank in case you remove the power supply at a later time.

Important: During normal operation, each power-supply bay must contain either a power supply or power-supply blank for proper cooling.

3. Slide the ac power supply into the bay until the retention latch clicks into place. Make sure that the power supply connects firmly into the power-supply connector.

Attention: Do not install 460-watt and 675-watt power supplies, high-efficiency and non-high-efficiency power supplies, or ac and dc power supplies in the server.

4. Connect the power cord for the new ac power supply to the power-cord connector on the power supply.

The following illustration shows the ac power-supply connectors on the rear of the server.




Figure 127. Power-supply connectors

5. Route the power cord through the power-supply handle and through any cable clamps on the rear of the server, to prevent the power cord from being accidentally pulled out when you slide the server in and out of the rack.
6. Connect the power cord to a properly grounded electrical outlet.
7. Make sure that the ac power LED and the dc power LED on the ac power supply are lit, indicating that the power supply is operating correctly. The two green LEDs are to the right of the power-cord connector.
8. If you are replacing a power supply with one of a different wattage, apply the power information label provided with the new power supply over the existing power information label on the server.



Figure 128. Power information label

9. (IBM Business Partners only) Restart the server. Confirm that it starts correctly and recognizes the newly installed devices, and make sure that no error LEDs are lit.
10. (IBM Business Partners only) Complete the additional steps in “Instructions for IBM Business Partners” on page 26.

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Removing a hot-swap fan

The server comes with three replaceable fans.

About this task

Attention: To ensure proper server operation and cooling, if you remove a fan with the system running, you must install a replacement fan within 30 seconds or the system will shut down.

To remove a replaceable fan, complete the following steps.




Figure 129. Hot-swap fan removal

Procedure

1. Read the safety information that begins on page “Safety” on page v, “Installation guidelines” on page 37.
2. Leave the server connected to power.
3. Slide the server out of the rack and remove the cover (see “Removing the cover” on page 45). The LED near the failing fan will be lit.

Attention: To ensure proper system cooling, do not remove the top cover for more than 30 minutes during this procedure.

4. Lift the fan out of the server.
5. Replace the fan within 30 seconds (see “Installing a hot-swap fan” on page 128).

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Installing a hot-swap fan

The server comes with three replaceable double fans. For proper cooling, the server requires that all three fans be installed at all times.

About this task

Attention: To ensure proper server operation, if a fan fails, replace it within 30 seconds. Have a replacement fan ready to install as soon as you remove the failed fan.




Figure 130. Hot-swap fan installation

To install any of the three replaceable fans, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. If you have not done so already, slide the server out of the rack and remove the cover (see “Removing the cover” on page 45).

Attention: To ensure proper system cooling, do not remove the top cover for more than 30 minutes during this procedure.

3. Orient the new fan over its position in the fan bracket so that the connector on the bottom aligns with the fan connector on the system board.
4. Align the vertical tabs on the fan with the slots on the fan cage bracket.
5. Push the new fan into the fan connector on the system board. Press down on the top surface of the fan to seat the fan fully. Make sure that the amber LED next to the fan connector on the system board is off.

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Removing the SAS riser-card and controller assembly

To remove the SAS riser-card and controller assembly from the server, complete the steps for the applicable server model.

About this task

- **16-drive-capable server model:**




Figure 131. SAS riser-card and controller assembly removal

1. Press the assembly release latch toward the rear of the server and lift that end of the SAS controller assembly a little. Place your fingers underneath the upper portion of the SAS riser-card and lift the assembly from the system board.
2. Lift the assembly out of the server.

- **Tape-enabled server model:**




Figure 132. SAS controller assembly removal

1. Press down on the assembly release latch and lift up on the tab to release the SAS controller assembly, which includes the SAS riser-card, from the system board.
2. Lift the front and back edges of the assembly to remove the assembly from the server.

Installing the SAS riser-card and controller assembly

To install the SAS riser-card and controller assembly in the server, complete the steps for the applicable server model.

About this task

- **16-drive-capable server model:**




Figure 133. SAS riser-card and controller assembly installation

1. If you are replacing a ServeRAID-BR10il v2 SAS/SATA controller with a ServeRAID-M5015/M5014 SAS/SATA controller, you have to swap the controller retention brackets to fit the new SAS controller.




Figure 134. Controller retention brackets

- a. Remove the SAS controller front retention bracket from the server.




Figure 135. SAS controller front retention bracket removal

- b. Remove the rear controller retention bracket located in the battery bay above the power supplies by pulling up the release tab **1** and sliding the bracket outward **2**.




Figure 136. Rear controller retention bracket removal

- c. Install the controller retention bracket from step **b** by aligning the retention bracket controller slot and then placing the bracket tabs in the holes on the chassis and slide the bracket to left until it clicks into place.




Figure 137. Controller retention bracket installation

- d. Install the controller retention bracket from step **a** by sliding the bracket inward **1** and pressing down the release tab into place **2**.




Figure 138. Controller retention bracket installation

2. Place the front end of the SAS controller in the front retention bracket and align the SAS riser-card with the SAS riser-card connector on the system board.
 3. Press down on the SAS riser-card and the rear edge of the SAS controller until the SAS riser-card is firmly seated and the SAS controller card retention latch clicks into place.
- **Tape-enabled server model:**




Figure 139. SAS controller assembly installation

1. Align the pins on the back side of the SAS riser-card with the slots on the server chassis.
2. Make sure that any tape drive cables are routed correctly underneath the SAS riser-card. For information about the cable routing, see “Installing an optional tape drive” on page 100.
3. Press the SAS controller assembly into place. Make sure that the SAS riser-card is firmly seated and that the release latch and retention latch hold the assembly securely.

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Removing a ServeRAID SAS controller from the SAS riser-card

A ServeRAID SAS controller is installed in a dedicated slot on the SAS riser-card.

About this task

Important: If you have installed a SAS expander card in a 16-drive-capable server, the SAS controller is installed in a PCI riser-card assembly and is installed and removed the same way as any other PCI adapter. Do not use the instructions in this topic; use the instructions in “Installing a PCI adapter” on page 53 and “Removing a PCI adapter” on page 58.

Depending on the server model, the server comes with a ServeRAID-BR10iL v2 SAS/SATA controller or a ServeRAID-M1015 SAS/SATA controller installed.

You can replace the ServeRAID SAS controller with another supported ServeRAID SAS controller. For a list of supported ServeRAID SAS controllers, see <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/>.

Note: For brevity, in this documentation the ServeRAID SAS controller is often referred to as the *SAS controller*.

To remove the SAS controller from a SAS riser-card, complete the following steps:

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Turn off the server and peripheral devices and disconnect all power cords and external cables (see “Turning off the server” on page 23).
3. Remove the cover (see “Removing the cover” on page 45).
4. Locate the SAS riser-card and controller assembly near the left-front corner of the server.
5. Disconnect the SAS signal cables from the connectors on the SAS controller and note their locations.
6. Remove the SAS controller assembly, which includes the SAS riser-card, from the server (see “Removing the SAS riser-card and controller assembly” on page 129).

16-drive-capable server model:




Figure 140. SAS controller assembly removal

Tape-enabled server model:




Figure 141. SAS controller assembly removal

7. Pull the SAS controller horizontally out of the connector on the SAS riser-card.

Note: If you have installed the optional ServeRAID adapter advanced feature key, grasp the feature key and lift to remove it from connector on the ServeRAID adapter and keep it in future use.

8. If you are replacing the SAS controller with another supported SAS controller, continue with “Installing a ServeRAID SAS controller on the SAS riser-card.”

Installing a ServeRAID SAS controller on the SAS riser-card

About this task

Important: If you have installed a SAS expander card in a 16-drive-capable server, the SAS controller is installed in a PCI riser-card assembly and is installed and removed the same way as any other PCI adapter. Do not use the instructions in this topic; use the instructions in “Installing a PCI adapter” on page 53 and “Removing a PCI adapter” on page 58.

To install a SAS controller on the SAS riser-card, complete the following steps:

Procedure

1. Make sure that the server is turned off, all external cables and power cords are disconnected, and the cover has been removed.
2. If you are installing a new or replacement SAS controller, touch the static-protective package that contains the new SAS controller to any unpainted metal surface on the server. Then, remove the SAS controller from the package.

Note: If you have the optional ServeRAID adapter advanced feature key, install it first (see “Installing an optional ServeRAID adapter advanced feature key” on page 137).

3. If you are installing a new or replacement SAS controller that uses a battery, complete the following steps:
 - a. Remove the battery from the SAS controller package or the battery package.
 - b. Install the battery and connect the battery to the SAS controller as instructed in the documentation that comes with the SAS controller or the battery.
4. If the new SAS controller is a different physical size than the SAS controller that you removed, you might have to move the controller retention bracket (tape-enabled model servers only) to the correct location for the new SAS

controller. See “Moving the SAS controller retention bracket” on page 145; then, continue with the next step in this procedure.

5. Turn the SAS controller so that the connectors are facing up and the edge connectors are aligned correctly with the connector on the SAS riser-card.

16-drive-capable server model:




Figure 142. SAS controller installation

Tape-enabled server model:




Figure 143. SAS controller installation

6. Firmly press the SAS controller horizontally into the connector on the SAS riser-card.
7. (Tape-enabled model server only) Gently press the opposite edge of the SAS controller into the controller retention bracket.
8. Install the SAS riser-card and controller assembly (see “Installing the SAS riser-card and controller assembly” on page 130).

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Note:

1. When you restart the server for the first time after you install a SAS controller with a battery, the monitor screen remains blank while the controller initializes

the battery. This might take a few minutes, after which the startup process continues. This is a one-time occurrence.

Important: You must allow the initialization process to be completed. If you do not, the battery pack will not work, and the server might not start.

The battery comes partially charged, at 30% or less of capacity. Run the server for 4 to 6 hours to fully charge the controller battery. The LED just above the battery on the controller remains lit until the battery is fully charged.

Until the battery is fully charged, the controller firmware sets the controller cache to write-through mode; after the battery is fully charged, the controller firmware re-enables write-back mode.

2. When you restart the server, you are given the opportunity to import the existing RAID configuration to the new ServeRAID SAS controller.

Installing an optional ServeRAID adapter advanced feature key

About this task

To install an optional ServeRAID adapter advanced feature key, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Turn off the server and peripheral devices and disconnect all power cords and external cables (see “Turning off the server” on page 23).
3. Remove the cover (see “Removing the cover” on page 45).
4. Align the upgrade key with the connector on the ServeRAID adapter and push it into the connector until it is firmly seated.




Figure 144. ServeRAID adapter advanced feature key installation




Figure 145. ServeRAID adapter advanced feature key installation

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Installing a ServeRAID SAS controller battery on the remote battery tray

Use this information to install a ServeRAID SAS controller battery on the remote battery tray.

About this task

Note: For brevity, in this documentation the Intelligent Battery Backup Unit (iBBU) is often referred to as the *battery*.

When you install a ServeRAID SAS controller in a PCI riser-card assembly in the server, you must install the battery at a distance from the ServeRAID controller to avoid overheating. This section describes the process for installing a battery or batteries in the server.

To install a battery, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.

2. Turn off the server and peripheral devices and disconnect all power cords and external cables (see “Turning off the server” on page 23).
3. Remove the cover (see “Removing the cover” on page 45).
4. Remove the PCI riser-card assembly from the server and set it aside (see “Removing a PCI riser-card assembly” on page 46).
5. Remove the ServeRAID controller from the riser card (see “Removing a PCI adapter” on page 58).
6. If a battery and battery carrier are attached to the SAS controller, disconnect the battery carrier cable from the battery and remove the three screws that secure the battery carrier to the ServeRAID controller. Set the battery and battery carrier aside.

Note: The illustrations in this document might differ slightly from your hardware.




Figure 146. Battery removal

7. Install the interposer card on the interposer card connector on the ServeRAID controller:
 - a. Remove the interposer card and the loose screw from the bag.
 - b. Rotate the standoff so that it aligns with the hole in the ServeRAID controller, and position the interposer card connector over the ServeRAID controller connector.




Figure 147. Interposer card installation

- c. Press the interposer card down onto the interposer card connector so that the interposer card is secured.
- d. From the other side of the ServeRAID controller, insert and tighten the screw to secure the interposer card to the ServeRAID controller.
8. Connect one end of the remote battery cable to the interposer card.

Attention: To avoid damage to the hardware, make sure that you align the black dot on the cable connector with the black dot on the connector on the interposer card. *Do not force the remote battery cable into the connector.*




Figure 148. Connecting remote battery cable

9. Install the ServeRAID controller on the riser card (see “Installing a PCI adapter” on page 53).
10. Install the PCI riser-card assembly in the server (see “Installing a PCI riser-card assembly” on page 47).
11. Connect the remote battery cable to the battery carrier.
Attention: To avoid damage to the hardware, make sure that you align the black dot on the cable connector with the black dot on the connector on the interposer card. *Do not force the remote battery cable into the connector.*
12. Install the battery on the remote battery tray:
 - a. Connect the battery carrier cable to the battery, if it is not already connected.
 - b. On the remote battery tray, find the pattern of recessed rings that matches the posts on the battery and battery carrier.




Figure 149. Battery installation

- c. Press the posts into the rings and underneath the tabs on the remote battery tray.
 - d. Secure the battery to the tray with the battery retention clip.
13. Route the remote battery cable.

Attention: Make sure that the cable is not pinched and does not cover any connectors or obstruct any components on the system board.




Figure 150. Remote battery cable routing

- **For a battery that is installed in PCI assembly slot 1:** Route the remote battery cable from the ServeRAID controller down through the slot on the left side of the DIMM air baffle, through the notch on the left side of the DIMM air baffle, across to the notch in the microprocessor air baffle, and up to the battery on the remote battery tray.
 - **For a battery that is installed in PCI assembly slot 2:** Route the remote battery cable from the ServeRAID controller through the hole in the right side of the power supply (see the illustration detail).
14. To install another ServeRAID controller remote battery in the server, repeat steps 7 on page 140 through 12 on page 142.
 15. Install the server cover.
 16. Connect the power cords and all external cables, and turn on the server and peripheral devices.

Results

Note: The battery must recharge for at least 6 hours under normal operating conditions. To protect your data, the ServeRAID controller firmware changes the

write policy to write-through until the battery unit is sufficiently charged. When the battery unit is charged, the ServeRAID controller firmware changes the write policy to write-back.

Moving the SAS controller retention bracket

Use this information to move the SAS controller retention bracket.

About this task

Note: This procedure applies only to servers that have the following SAS riser-card.




Figure 151. SAS riser card

To move the SAS controller side retention bracket to a different position to accommodate the dimensions of the current SAS ServeRAID controller, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Make sure that the server and all peripheral devices are turned off and that the power cords and all external cables are disconnected.
3. Remove the SAS riser-card assembly from the server (see “Removing the SAS riser-card and controller assembly” on page 129).
4. Remove the ServeRAID controller from the SAS riser-card.




Figure 152. ServeRAID controller removal

5. Remove the retention bracket from the current location:
 - a. Pinch the bottoms of both bracket posts and push the posts up out of the SAS riser-card assembly.




Figure 153. Retention bracket removal

- b. Rotate the bracket to free the bracket tab from the slot on the SAS riser-card assembly.
6. Install the retention bracket in the new location on the SAS riser-card assembly:
 - a. Insert the bracket tab into the slot on the SAS riser-card assembly.




Figure 154. Retention bracket removal

- b. Rotate the bracket so that the bracket posts align with the holes in the SAS riser-card assembly.

- c. Press the posts through the holes in the SAS riser-card until they click into place.
- d. Install the SAS controller on the SAS riser-card (see “Installing a ServeRAID SAS controller on the SAS riser-card” on page 135).
- e. Install the riser-card assembly in the server (see “Installing the SAS riser-card and controller assembly” on page 130).
- f. Connect the power cords and all external cables, and turn on the server and peripheral devices.

Installing a USB hypervisor memory key

Hypervisor is a virtualization platform that enables multiple operating systems to run on a host computer at the same time. Support for hypervisor is available with the purchase and installation of an optional USB hypervisor memory key, with embedded hypervisor software.

About this task

To install the USB hypervisor memory key, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Turn off the server and peripheral devices and disconnect all power cords and external cables (see “Turning off the server” on page 23).
3. Remove the cover (see “Removing the cover” on page 45).
4. Locate the SAS riser-card assembly, which is near the left front corner of the server.
5. Push the blue locking collar on the USB hypervisor connector on the SAS riser-card toward the SAS riser-card (the unlocked position).




Figure 155. USB hypervisor memory key installation

6. Insert the hypervisor memory key into the USB hypervisor connector.

- Slide the blue lock on the USB hypervisor connector forward toward the hypervisor memory key as far as it will go, to secure the memory key in position.

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Note: You must configure the server to boot from the hypervisor USB drive. See Chapter 3, “Configuring the server,” on page 157 for information about enabling the embedded hypervisor.

Removing a USB hypervisor memory key

Use this information to remove a USB hypervisor memory key.

About this task

To remove the USB hypervisor memory key, complete the following steps:

Procedure

- Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
- Turn off the server and peripheral devices and disconnect all power cords and external cables (see “Turning off the server” on page 23).
- Remove the cover (see “Removing the cover” on page 45).
- Locate the SAS riser-card assembly, which is near the left front corner of the server.
- Push the blue locking collar on the USB hypervisor connector back toward the SAS riser-card to unlock it from the connector.




Figure 156. USB hypervisor memory key removal

- Pull the hypervisor memory key from the USB hypervisor connector.

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Note: You must configure the server not to look for the hypervisor USB drive. See Chapter 3, “Configuring the server,” on page 157 for information about disabling hypervisor support.

Installing the optional two-port Ethernet adapter

Use this information to install the optional two-port Ethernet adapter.

About this task

To install an Ethernet adapter, complete the following steps:

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Make sure that the server is turned off, all external cables and power cords are disconnected, and the cover has been removed. For more information, see “Turning off the server” on page 23 and “Removing the cover” on page 45.
3. Attach the rubber stopper on the chassis, along the edge of the system board, as shown in the following illustration.




Figure 157. Attaching rubber stopper

4. Remove the adapter filler panel on the rear of the chassis (if it has not been removed already).




Figure 158. Adapter filler panel removal

5. Install the two standoffs on the system board.
6. Insert the bottom tabs of the metal clip into the port openings from outside the chassis.




Figure 159. Bottom tabs installation

7. While you slightly press the top of the metal clip, rotate the metal clip toward the front of the server until the metal clip clicks into place. Make sure the metal clip is securely engaged on the chassis.

Attention: Pressing the top of the metal clip with excessive force may cause damage to the metal clip.

8. Touch the static-protective package that contains the new adapter to any unpainted metal surface on the server. Then, remove the adapter from the package.
9. Align the adapter with the adapter connector on the system board; then, tilt the adapter so that the port connectors on the adapter line up with the port openings on the chassis.




Figure 160. Adapter installation

10. Slide the port connectors on the adapter into the port openings on the chassis; then, press the adapter firmly until the two standoffs engage the adapter. Make sure the adapter is securely seated on the connector on the system board.

Make sure the port connectors on the adapter do not set on the rubber stopper. The following illustration shows the side view of the adapter in the server.




Figure 161. Adapter side view

Attention: Make sure the port connectors on the adapter are aligned properly with the chassis on the rear of the server. An incorrectly seated adapter might cause damage to the system board or the adapter.




Figure 162. Port connectors alignment

11. Slide the port connectors on the adapter into the port openings on the chassis; then, press the adapter firmly until the two standoffs engage the adapter. Make sure the adapter is securely seated on the connector on the system board.

Make sure the port connectors on the adapter do not set on the rubber stopper. The following illustration shows the side view of the adapter in the server.




Figure 163. Adapter side view

Attention: Make sure the port connectors on the adapter are aligned properly with the chassis on the rear of the server. An incorrectly seated adapter might cause damage to the system board or the adapter.




Figure 164. Port connectors alignment

12. Reinstall the PCI riser-card assembly in PCI riser connector 1 if you have removed it previously (see “Installing a PCI riser-card assembly” on page 47).

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation” on page 154.

Installing an optional DVD drive

Use this information to install an optional DVD drive.

About this task

For a list of supported optional optical disk drives for the server, see <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/>.

To install an optional DVD drive, complete the following steps.




Figure 165. DVD drive retention clip installation

Procedure

1. Read the safety information that begins on page “Safety” on page v and “Installation guidelines” on page 37.
2. Make sure that the server is turned off, all external cables and power cords are disconnected, and the cover has been removed. For more information, see “Turning off the server” on page 23 and “Removing the cover” on page 45.
3. Remove the optical drive filler panel if it is installed. Locate the blue release tab on the rear of the optical drive filler panel; then, while you press the tab, push the optical drive filler panel out of the drive bay. Save the optical drive filler panel for future use.




Figure 166. Optical drive filler panel removal

4. Attach the drive-retention clip to the side of the drive.
5. Slide the drive into the DVD drive bay until the drive clicks into place.

Results

If you have other devices to install or remove, do so now. Otherwise, go to “Completing the installation.”

Completing the installation

Use this information to complete the installation.

To complete the installation, complete the following steps:

1. If you removed the microprocessor 2 air baffle, replace the microprocessor 2 air baffle (see “Installing the microprocessor 2 air baffle” on page 49).
2. If you removed the DIMM air baffle, install it (see “Installing the DIMM air baffle” on page 51).
3. If you removed either of the PCI riser-card assemblies, replace the riser-card assemblies (see “Installing a PCI riser-card assembly” on page 47).
4. If you removed the server cover, replace it (see “Replacing the server cover” on page 155).
5. Install the server in a rack. See the *Rack Installation Instructions* that come with the server for complete rack installation and removal instructions.
6. To attach peripheral devices and connect the power cords, see “Connecting the external cables” on page 155.

Replacing the server cover

Use this information to replace the server cover.

About this task

To replace the server cover, complete the following steps:

Procedure

1. Make sure that all internal cables are correctly routed.
2. Place the cover-release latch in the open (up) position.




Figure 167. Cover-release latch

3. Insert the bottom tabs of the top cover into the matching slots in the server chassis.
4. Press down on the cover-release latch to slide the cover forward and lock the cover in place.
5. Slide the server into the rack.

Connecting the external cables

The following illustrations show the locations of the input and output connectors on the front and rear of the server.

Front view




Figure 168. Connectors front view

Rear view




Figure 169. Connectors rear view

See the documentation that comes with any external devices for additional cabling instructions. It might be easier for you to route cables before you connect the devices to the server.

If the server comes with an installed operating system, see the documentation that comes with the operating system for additional cabling instructions.

Updating the server configuration

Use this information to update the server configuration.

When you start the server for the first time after you add or remove an internal device, external SAS device, or USB keyboard or mouse, you might receive a message that the configuration has changed. After the POST fails three times, the Setup utility starts automatically so that you can save the new configuration settings. For more information, see Chapter 3, “Configuring the server,” on page 157.

Some optional devices have device drivers that you must install. See the documentation that comes with each optional device for information about installing device drivers.

The server comes with at least one multi-core microprocessor, which enables the server to operate as a symmetric multiprocessing (SMP) server. You might have to upgrade the operating system to support SMP. For more information, see “Using the ServerGuide Setup and Installation CD” on page 164 and the operating-system documentation.

If you have installed or removed a hard disk drive, see “Using the LSI Configuration Utility program” on page 172.

If you have installed a USB hypervisor memory key on the SAS riser-card, see the user's guide that comes with the hypervisor memory key. Hypervisor enables guest operating systems to function on the server.

For information about configuring the integrated Gigabit Ethernet controller, see “Configuring the Gigabit Ethernet controller” on page 172.

Chapter 3. Configuring the server

The following configuration programs come with the server:

- **Setup utility**

The Setup utility (formerly called the Configuration/Setup Utility program) is part of the IBM System x Server Firmware. Use it to change interrupt request (IRQ) settings, change the startup-device sequence, set the date and time, and set passwords. For information about using this program, see “Using the Setup utility” on page 158.

- **Boot Menu program**

The Boot Menu program is part of the IBM System x Server Firmware. Use it to override the startup sequence that is set in the Setup utility and temporarily assign a device to be first in the startup sequence.

- **IBM ServerGuide Setup and Installation CD**

The ServerGuide program provides software-setup tools and installation tools that are designed for the server. Use this CD during the installation of the server to configure basic hardware features, such as an integrated SAS controller with RAID capabilities, and to simplify the installation of your operating system. For information about obtaining and using this CD, see “Using the ServerGuide Setup and Installation CD” on page 164.

- **Integrated management module**

Use the integrated management module (IMM) for configuration, to update the firmware and sensor data record/field replaceable unit (SDR/FRU) data, and to remotely manage a network. For information about using the IMM, see “Using the integrated management module” on page 167.

- **VMware embedded USB hypervisor**

The VMware embedded USB hypervisor is available on the server models that come with an installed IBM USB Memory Key for VMware hypervisor. The USB memory key is installed in the USB connector on the SAS riser-card. Hypervisor is virtualization software that enables multiple operating systems to run on a host computer at the same time. For more information about using the embedded hypervisor, see “Using the USB memory key for VMware hypervisor” on page 168.

- **Remote presence capability and blue-screen capture**

The remote presence and blue-screen capture feature are integrated into the integrated management module (IMM). The virtual media key is required to enable these features. When the optional virtual media key is installed in the server, it activates the remote presence functions. Without the virtual media key, you will not be able to access the network remotely to mount or unmount drives or images on the client system. However, you will still be able to access the host graphical user interface through the Web interface without the virtual media key. You can order an optional IBM Virtual Media Key, if one did not come with your server. For more information about how to enable the remote presence function, see “Using the remote presence capability and blue-screen capture” on page 169.

- **Ethernet controller configuration**

For information about configuring the Ethernet controller, see “Configuring the Gigabit Ethernet controller” on page 172.

- **LSI Configuration Utility program**

Use the LSI Configuration Utility program to configure the integrated SAS/SATA controller with RAID capabilities and the devices that are attached to it. For information about using this program, see “Using the LSI Configuration Utility program” on page 172.

The following table lists the different server configurations and the applications that are available for configuring and managing RAID arrays.

Table 15. Server configuration and applications for configuring and managing RAID arrays

Server configuration	RAID array configuration (before operating system is installed)	RAID array management (after operating system is installed)
ServeRAID-BR10i adapter (LSI 1068E)	LSI Utility (Setup utility, press Ctrl+C), ServerGuide	MegaRAID Storage Manager (for monitoring storage only)
ServeRAID-BR10il v2 adapter (LSI 1064E)	LSI Utility (Setup utility, press Ctrl+C), ServerGuide	MegaRAID Storage Manager and IBM Director
ServeRAID-MR10i adapter (LSI 1078)	MegaRAID Storage Manager (MSM), MegaRAID BIOS Configuration Utility (press C to start), ServerGuide	MegaRAID Storage Manager (MSM)
ServeRAID-M5014 adapter (LSI SAS2108)	MegaRAID Storage Manager (MSM), MegaCLI (Command Line Interface), ServerGuide	MegaRAID Storage Manager and IBM Director
ServeRAID-M5015 adapter (LSI SAS2108)	MegaRAID Storage Manager (MSM), MegaCLI (Command Line Interface), ServerGuide	MegaRAID Storage Manager and IBM Director
ServeRAID-M1050 adapter (LSI SAS2008)	MegaRAID Storage Manager (MSM), MegaCLI (Command Line Interface), ServerGuide	MegaRAID Storage Manager and IBM Director

- **IBM Advanced Settings Utility (ASU) program**

Use this program as an alternative to the Setup utility for modifying UEFI settings and IMM settings. Use the ASU program online or out-of-band to modify UEFI settings from the command line without the need to restart the server to access the Setup utility. For more information about using this program, see “IBM Advanced Settings Utility program” on page 175.

Using the Setup utility

Use these instructions to start the Setup utility.

Use the Setup utility, formerly called the Configuration/Setup Utility program, to perform the following tasks:

- View configuration information
- View and change assignments for devices and I/O ports
- Set the date and time
- Set the startup characteristics of the server and the order of startup devices
- Set and change settings for advanced hardware features
- View, set, and change settings for power-management features
- View and clear error logs
- Resolve configuration conflicts

Starting the Setup utility

About this task

To start the Setup utility, complete the following steps:

Procedure

1. Turn on the server.

Note: Approximately 3 minutes after the server is connected to ac power, the power-control button becomes active.

2. When the prompt <F1> Setup is displayed, press F1. If you have set an administrator password, you must type the administrator password to access the full Setup utility menu. If you do not type the administrator password, a limited Setup utility menu is available.
3. Select the settings to view or change.

Setup utility menu choices

The following choices are on the Setup utility main menu. Depending on the version of the firmware, some menu choices might differ slightly from these descriptions.

- **System Information**

Select this choice to view information about the server. When you make changes through other choices in the Setup utility, some of those changes are reflected in the system information; you cannot change settings directly in the system information.

This choice is on the full Setup utility menu only.

- **System Summary**

Select this choice to view configuration information, including the ID, speed, and cache size of the microprocessors, machine type and model of the server, the serial number, the system UUID, and the amount of installed memory. When you make configuration changes through other choices in the Setup utility, the changes are reflected in the system summary; you cannot change settings directly in the system summary.

- **Product Data**

Select this choice to view the system-board identifier, the revision level or issue date of the firmware, the integrated management module and diagnostics code, and the version and date.

- **System Settings**

Select this choice to view or change the server component settings.

- **Processors**

Select this choice to view or change the processor settings.

- **Memory**

Select this choice to view or change the memory settings. To configure memory mirroring, select **System Settings** → **Memory**, and then select **Memory Channel Mode** → **Mirroring**.

- **Devices and I/O Ports**

Select this choice to view or change assignments for devices and input/output (I/O) ports. You can configure the serial ports; configure remote console redirection; enable or disable integrated Ethernet controllers, the SAS/SATA controller, SATA optical drive channels, and PCI slots; and video

controller. If you disable a device, it cannot be configured, and the operating system will not be able to detect it (this is equivalent to disconnecting the device).

- **Power**

Select this choice to view or change power capping to control consumption, processors, and performance states.

- **Operating Modes**

Select this choice to view or change the operating profile (for example, performance and power utilization).

- **Legacy Support**

Select this choice to view or set legacy support.

- **Force Legacy Video on Boot**

Select this choice to force INT video support, if the operating system does not support UEFI video output standards.

- **Rehook INT**

Select this choice to enable or disable devices from taking control of the boot process. The default is **Disable**.

- **Legacy Thunk Support**

Select this choice to enable or disable the UEFI to interact with PCI mass storage devices that are not UEFI-compliant.

- **Integrated Management Module**

Select this choice to view or change the settings for the integrated management module.

- **POST Watchdog Timer**

Select this choice to view or enable the POST watchdog timer.

- **POST Watchdog Timer Value**

Select this choice to view or set the POST loader watchdog timer value.

- **Reboot System on NMI**

Enable or disable restarting the system whenever a nonmaskable interrupt (NMI) occurs. **Disabled** is the default.

- **Commands on USB Interface Preference**

Select this choice to enable or disable the Ethernet over USB interface on IMM.

- **Network Configuration**

Select this choice to view the system management network interface port, the IMM MAC address, the current IMM IP address, and host name; define the static IMM IP address, subnet mask, and gateway address; specify whether to use the static IP address or have DHCP assign the IMM IP address; save the network changes; and reset the IMM.

- **Reset IMM to Defaults**

Select this choice to view or reset IMM to the default settings.

- **Reset IMM**

Select this choice to reset IMM.

- **Adapters and UEFI Drivers**

Select this choice to view information about the adapters and drivers in the server that are compliant with EFI 1.10 and UEFI 2.0.

- **Network**

Select this choice to view or configure the network options, such as the iSCSI, PXE, and network devices. There might be additional configuration choices for optional network devices that are compliant with UEFI 2.1 and later.

- **Storage**

Select this choice to view or configure the storage devices options. There might be additional configuration choices for optional storage devices that are compliant with UEFI 2.1 and later.

- **Video**

Select this choice to view or configure the video device options installed in the server. There might be additional configuration choices for optional video devices that are compliant with UEFI 2.1 and later.

- **Date and Time**

Select this choice to set the date and time in the server, in 24-hour format (*hour:minute:second*).

This choice is on the full Setup utility menu only.

- **Start Options**

Select this choice to view or change the start options, including the startup sequence, keyboard NumLock state, PXE boot option, and PCI device boot priority. Changes in the startup options take effect when you start the server.

The startup sequence specifies the order in which the server checks devices to find a boot record. The server starts from the first boot record that it finds. If the server has Wake on LAN hardware and software and the operating system supports Wake on LAN functions, you can specify a startup sequence for the Wake on LAN functions. For example, you can define a startup sequence that checks for a disc in the CD-RW/DVD drive, then checks the hard disk drive, and then checks a network adapter.

This choice is on the full Setup utility menu only.

- **Boot Manager**

Select this choice to view, add, or change the device boot priority, boot from a file, select a one-time boot, or reset the boot order to the default setting.

- **System Event Logs**

Select this choice to enter the System Event Manager, where you can view the error messages in the system-event logs. You can use the arrow keys to move between pages in the error log.

The system-event logs contain all event and error messages that have been generated during POST, by the systems-management interface handler, and by the system service processor. Run the diagnostic programs to get more information about error codes that occur. See the *Problem Determination and Service Guide* on the IBM Documentation CD for instructions for running the diagnostic programs.

Important: If the system-error LED on the front of the server is lit but there are no other error indications, clear the system-event log. Also, after you complete a repair or correct an error, clear the system-event log to turn off the system-error LED on the front of the server.

- **POST Event Viewer**

Select this choice to enter the POST event viewer to view the error messages in the POST event log.

- **System Event Log**

Select this choice to view the error messages in the system-event log.

- **Clear System Event Log**

Select this choice to clear the system-event log.

- **User Security**

Select this choice to set, change, or clear passwords. See “Passwords” for more information.

This choice is on the full and limited Setup utility menu.

- **Set Power-on Password**

Select this choice to set or change a power-on password. For more information, see “Power-on password” on page 163.

- **Clear Power-on Password**

Select this choice to clear a power-on password. For more information, see “Power-on password” on page 163.

- **Set Administrator Password**

Select this choice to set or change an administrator password. An administrator password is intended to be used by a system administrator; it limits access to the full Setup utility menu. If an administrator password is set, the full Setup utility menu is available only if you type the administrator password at the password prompt. For more information, see “Administrator password” on page 163.

- **Clear Administrator Password**

Select this choice to clear an administrator password. For more information, see “Administrator password” on page 163.

- **Save Settings**

Select this choice to save the changes that you have made in the settings.

- **Restore Settings**

Select this choice to cancel the changes that you have made in the settings and restore the previous settings.

- **Load Default Settings**

Select this choice to cancel the changes that you have made in the settings and restore the factory settings.

- **Exit Setup**

Select this choice to exit from the Setup utility. If you have not saved the changes that you have made in the settings, you are asked whether you want to save the changes or exit without saving them.

Passwords

From the **User Security** menu choice, you can set, change, and delete a power-on password and an administrator password. The **User Security** choice is on the full Setup utility menu only.

If you set only a power-on password, you must type the power-on password to complete the system startup and to have access to the full Setup utility menu.

An administrator password is intended to be used by a system administrator; it limits access to the full Setup utility menu. If you set only an administrator password, you do not have to type a password to complete the system startup, but you must type the administrator password to access the Setup utility menu.

If you set a power-on password for a user and an administrator password for a system administrator, you must type the power-on password to complete the system startup. A system administrator who types the administrator password has access to the full Setup utility menu; the system administrator can give the user

authority to set, change, and delete the power-on password. A user who types the power-on password has access to only the limited Setup utility menu; the user can set, change, and delete the power-on password, if the system administrator has given the user that authority.

Power-on password

If a power-on password is set, when you turn on the server, the system startup will not be completed until you type the power-on password. You can use any combination of between six and 20 printable ASCII characters for the password.

When a power-on password is set, you can enable the Unattended Start mode, in which the keyboard and mouse remain locked but the operating system can start. You can unlock the keyboard and mouse by typing the power-on password.

If you forget the power-on password, you can regain access to the server in any of the following ways:

- If an administrator password is set, type the administrator password at the password prompt. Start the Setup utility and reset the power-on password.
- Remove the battery from the server and then reinstall it. See the *Problem Determination and Service Guide* on the IBM Documentation CD for instructions for removing the battery.
- Change the position of the power-on password switch (enable switch 1 of the system board switch block (SW4) to bypass the power-on password check (see “System-board switches and jumpers” on page 29 for more information).

Attention: Before you change any switch settings or move any jumpers, turn off the server; then, disconnect all power cords and external cables. See the safety information that begins on page “Safety” on page v. Do not change settings or move jumpers on any system-board switch or jumper blocks that are not shown in this document.

The default for all of the switches on switch block (SW4) is Off.

While the server is turned off, move switch 1 of the switch block (SW4) to the On position to enable the power-on password override. You can then start the Setup utility and reset the power-on password. You do not have to return the switch to the previous position.

The power-on password override switch does not affect the administrator password.

Administrator password

If an administrator password is set, you must type the administrator password for access to the full Setup utility menu. You can use any combination of between six and 20 printable ASCII characters for the password.

Attention: If you set an administrator password and then forget it, there is no way to change, override, or remove it. You must replace the system board.

Using the Boot Selection Menu program

The Boot Selection Menu is used to temporarily redefine the first startup device without changing boot options or settings in the Setup utility.

About this task

To use the Boot Selection Menu program, complete the following steps:

Procedure

1. Turn off the server.
2. Restart the server.
3. Press F12 (**Select Boot Device**). If a bootable USB mass storage device is installed, a submenu item (**USB Key/Disk**) is displayed.
4. Use the Up Arrow and Down Arrow keys to select an item from the **Boot Selection Menu** and press Enter.

Results

The next time the server starts, it returns to the startup sequence that is set in the Setup utility.

Starting the backup server firmware

The system board contains a backup copy area for the server firmware. This is a secondary copy of server firmware that you update only during the process of updating server firmware. If the primary copy of the server firmware becomes damaged, use this backup copy.

About this task

To force the server to start from the backup copy, turn off the server; then, place the UEFI boot recovery J29 jumper in the backup position (pins 2 and 3).

Use the backup copy of the server firmware until the primary copy is restored. After the primary copy is restored, turn off the server; then, move the UEFI boot recovery J29 jumper back to the primary position (pins 1 and 2).

Using the ServerGuide Setup and Installation CD

The *ServerGuide Setup and Installation* CD contains a setup and installation program that is designed for your server. The ServerGuide program detects the server model and optional hardware devices that are installed and uses that information during setup to configure the hardware. The ServerGuide program simplifies operating-system installations by providing updated device drivers and, in some cases, installing them automatically.

You can download a free image of the *ServerGuide Setup and Installation* CD or purchase the CD from the ServerGuide fulfillment Web site at <http://www.ibm.com/systems/management/serverguide/sub.html>. To download the free image, click **IBM Service and Support Site**.

Note: Changes are made periodically to the IBM Web site. The actual procedure might vary slightly from what is described in this document.

The ServerGuide program has the following features:

- An easy-to-use interface
- Diskette-free setup, and configuration programs that are based on detected hardware
- ServeRAID Manager program, which configures your ServeRAID adapter or integrated SCSI controller with RAID capabilities
- Device drivers that are provided for the server model and detected hardware
- Operating-system partition size and file-system type that are selectable during setup

ServerGuide features

Features and functions can vary slightly with different versions of the ServerGuide program. To learn more about the version that you have, start the *ServerGuide Setup and Installation* CD and view the online overview. Not all features are supported on all server models.

The ServerGuide program requires a supported IBM server with an enabled startable (bootable) CD drive. In addition to the *ServerGuide Setup and Installation* CD, you must have your operating-system CD to install the operating system.

The ServerGuide program performs the following tasks:

- Sets system date and time
- Detects the RAID adapter or controller and runs the SAS RAID configuration program (with LSI chip sets for ServeRAID adapters only)
- Checks the microcode (firmware) levels of a ServeRAID adapter and determines whether a later level is available from the CD
- Detects installed optional hardware devices and provides updated device drivers for most adapters and devices
- Provides diskette-free installation for supported Windows operating systems
- Includes an online readme file with links to tips for hardware and operating-system installation

Setup and configuration overview

When you use the *ServerGuide Setup and Installation* CD, you do not need setup diskettes. You can use the CD to configure any supported IBM server model. The setup program provides a list of tasks that are required to set up your server model. On a server with a ServeRAID adapter or integrated SCSI controller with RAID capabilities, you can run the SCSI RAID configuration program to create logical drives.

Note: Features and functions can vary slightly with different versions of the ServerGuide program.

When you start the *ServerGuide Setup and Installation* CD, the program prompts you to complete the following tasks:

- Select your language.
- Select your keyboard layout and country.
- View the overview to learn about ServerGuide features.
- View the readme file to review installation tips for your operating system and adapter.
- Start the operating-system installation. You will need your operating-system CD.

Important: Before you install a legacy operating system (such as VMware) on a server with an LSI SAS controller, you must first complete the following steps:

1. Update the device driver for the LSI SAS controller to the latest level.
2. In the Setup utility, set **Legacy Only** as the first option in the boot sequence in the **Boot Manager** menu.
3. Using the LSI Configuration Utility program, select a boot drive.

For detailed information and instructions, go to <https://www.ibm.com/systems/support/supportsite.wss/docdisplay?lnocid=MIGR-5083225>.

Typical operating-system installation

The ServerGuide program can reduce the time it takes to install an operating system. It provides the device drivers that are required for your hardware and for the operating system that you are installing. This section describes a typical ServerGuide operating-system installation.

Note: Features and functions can vary slightly with different versions of the ServerGuide program.

1. After you have completed the setup process, the operating-system installation program starts. (You will need your operating-system CD to complete the installation.)
2. The ServerGuide program stores information about the server model, service processor, hard disk drive controllers, and network adapters. Then, the program checks the CD for newer device drivers. This information is stored and then passed to the operating-system installation program.
3. The ServerGuide program presents operating-system partition options that are based on your operating-system selection and the installed hard disk drives.
4. The ServerGuide program prompts you to insert your operating-system CD and restart the server. At this point, the installation program for the operating system takes control to complete the installation.

Installing your operating system without using ServerGuide

About this task

If you have already configured the server hardware and you are not using the ServerGuide program to install your operating system, complete the following steps to download the latest operating-system installation instructions from the IBM Web site.

Note: Changes are made periodically to the IBM Web site. The actual procedure might vary slightly from what is described in this document.

1. Go to <http://www.ibm.com/systems/support/>.
2. Under **Product support**, click **System x**.
3. From the menu on the left side of the page, click **System x support search**.
4. From the **Task** menu, select **Install**.
5. From the **Product family** menu, select **System x3650 M3**.
6. From the **Operating system** menu, select your operating system, and then click **Search** to display the available installation documents.

Using the integrated management module

The integrated management module (IMM) is a second generation of the functions that were formerly provided by the baseboard management controller hardware. It combines service processor functions, video controller, and (when an optional virtual media key is installed) remote presence function in a single chip.

The IMM supports the following basic systems-management features:

- Environmental monitor with fan speed control for temperature, voltages, fan failure, and power supply failure.
- Light path diagnostics LEDs to report errors that occur with fans, power supplies, microprocessor, hard disk drives, and system errors.
- DIMM error assistance. The Unified Extensible Firmware Interface (UEFI) disables a failing DIMM that is detected during POST, and the IMM lights the associated system-error LED and the failing DIMM error LED.
- System-event log.
- ROM-based IMM firmware flash updates.
- Auto Boot Failure Recovery.
- A virtual media key, which enables full systems-management support (remote video, remote keyboard/mouse, and remote storage).
- When one of the two microprocessors reports an internal error, the server disables the defective microprocessor and restarts with the one good microprocessor.
- NMI detection and reporting.
- Automatic Server Restart (ASR) when POST is not complete or the operating system hangs and the OS watchdog timer times out. The IMM might be configured to watch for the OS watchdog timer and restart the server after a timeout, if the ASR feature is enabled. Otherwise, the IMM allows the administrator to generate an NMI by pressing an NMI button on the information panel for an operating-system memory dump. ASR is supported by IPMI.
- Intelligent Platform Management Interface (IPMI) Specification V2.0 and Intelligent Platform Management Bus (IPMB) support.
- Invalid system configuration (CNFG) LED support.
- Serial redirect.
- Serial over LAN (SOL).
- Active Energy Manager.
- Query power-supply input power.
- PECI 2 support.
- Power/reset control (power-on, hard and soft shutdown, hard and soft reset, schedule power control).
- Alerts (in-band and out-of-band alerting, PET traps - IPMI style, SNMP, e-mail).
- Operating-system failure blue screen capture.
- Command-line interface.
- Configuration save and restore.
- PCI configuration data.
- Boot sequence manipulation.

The IMM also provides the following remote server management capabilities through the OSA SMBridge management utility program:

- **Command-line interface (IPMI Shell)**

The command-line interface provides direct access to server management functions through the IPMI 2.0 protocol. Use the command-line interface to issue commands to control the server power, view system information, and identify the server. You can also save one or more commands as a text file and run the file as a script.


- **Serial over LAN**

Establish a Serial over LAN (SOL) connection to manage servers from a remote location. You can remotely view and change the UEFI settings, restart the server, identify the server, and perform other management functions. Any standard Telnet client application can access the SOL connection.

Using the USB memory key for VMware hypervisor

The VMware hypervisor is available on server models that come with an installed IBM USB Memory Key for VMware Hypervisor. The USB memory key comes installed in the USB hypervisor connector on the SAS riser-card (see the following illustration). Hypervisor is virtualization software that enables multiple operating systems to run on a host computer at the same time. The USB memory key is required to activate the hypervisor functions.

About this task



To start using the embedded hypervisor functions, you must add the USB memory key to the startup sequence in the Setup utility.

To add the USB hypervisor memory key to the boot order, complete the following steps:

Procedure

1. Turn on the server.

Note: Approximately 3 minutes after the server is connected to ac power, the power-control button becomes active.

2. When the prompt <F1> Setup is displayed, press F1.
3. From the Setup utility main menu, select **Boot Manager**.
4. Select **Add Boot Option**; then, select **Hypervisor**. Press Enter, and then press Esc.
5. Select **Change Boot Order** and then select **Commit Changes**; then, press Enter.
6. Select **Save Settings** and then select **Exit Setup**.

Results

If the embedded hypervisor image becomes corrupt, you can use the *VMware Recovery* CD that comes with the server to recover the image. To recover the flash device image, complete the following steps:

1. Turn on the server.

Note: Approximately 3 minutes after the server is connected to ac power, the power-control button becomes active.

2. Insert the *VMware Recovery* CD into the CD or DVD drive.
3. Follow the instructions on the screen.

For additional information and instructions, see the *VMware ESXi Server 3i Embedded Setup Guide* at http://www.vmware.com/pdf/vi3_35/esx_3i_e/r35/vi3_35_25_3i_setup.pdf.

Using the remote presence capability and blue-screen capture

The remote presence and blue-screen capture features are integrated functions of the integrated management module (IMM). When an optional virtual media key is installed in the server, it activates full systems-management functions. The virtual media key is required to enable the integrated remote presence and blue-screen capture features. Without the virtual media key, you cannot remotely mount or unmount drives or images on the client system. However, you still can access the Web interface without the key.

After the virtual media key is installed in the server, it is authenticated to determine whether it is valid. If the key is not valid, you receive a message from the Web interface (when you attempt to start the remote presence feature) indicating that the hardware key is required to use the remote presence feature.

The virtual media key has an LED. When this LED is lit and green, it indicates that the key is installed and functioning correctly.

The remote presence feature provides the following functions:

- Remotely viewing video with graphics resolutions up to 1600 x 1200 at 75 Hz, regardless of the system state
- Remotely accessing the server, using the keyboard and mouse from a remote client
- Mapping the CD or DVD drive, diskette drive, and USB flash drive on a remote client, and mapping ISO and diskette image files as virtual drives that are available for use by the server
- Uploading a diskette image to the IMM memory and mapping it to the server as a virtual drive

The blue-screen capture feature captures the video display contents before the IMM restarts the server when the IMM detects an operating-system hang condition. A system administrator can use the blue-screen capture to assist in determining the cause of the hang condition.

Enabling the remote presence feature

Use this information to enable the remote presence feature.

About this task

To enable the remote presence feature, complete the following steps:

Procedure

1. Install the virtual media key into the dedicated slot on the system board (see Replacing an IBM virtual media key).
2. Turn on the server.

Note: Approximately 3 minutes after the server is connected to ac power, the power-control button becomes active.

Obtaining the IP address for the Web interface access

To access the Web interface and use the remote presence feature, you need the IP address for the IMM. You can obtain the IMM IP address through the Setup utility.

About this task

To locate the IP address, complete the following steps:

Procedure

1. Turn on the server.

Note: Approximately 3 minutes after the server is connected to ac power, the power-control button becomes active.

2. When the prompt <F1> Setup is displayed, press F1. If you have set both a power-on password and an administrator password, you must type the administrator password to access the full Setup utility menu.
3. From the Setup utility main menu, select **System Settings**.
4. On the next screen, select **Integrated Management Module**.
5. On the next screen, select **Network Configuration**.
6. Find the IP address and write it down.
7. Exit from the Setup utility.

Logging on to the Web interface

Use this information to log on to the web interface.

About this task

To log on to the Web interface to use the remote presence functions, complete the following steps:

Procedure

1. Open a Web browser on a computer that connects to the server and in the **address** or **URL** field, type the IP address or host name of the IMM to which you want to connect.

Note:

- a. If you are logging in to the IMM for the first time after installation, the IMM defaults to DHCP. If a DHCP host is not available, the IMM uses the default static IP address 192.168.70.125.
- b. You can obtain the DHCP-assigned IP address or the static IP address from the server UEFI or from your network administrator.

The Login page is displayed.

2. Type the user name and password. If you are using the IMM for the first time, you can obtain the user name and password from your system administrator. All login attempts are documented in the event log. A welcome page opens in the browser.

Note: The IMM is set initially with a user name of USERID and password of PASSWORD (passw0rd with a zero, not the letter O). You have read/write access. For enhanced security, change this default password during the initial configuration.

3. On the Welcome page, type a timeout value (in minutes) in the field that is provided. The IMM will log you off the Web interface if your browser is inactive for the number of minutes that you entered for the timeout value.
4. Click **Continue** to start the session. The browser opens the System Status page, which displays the server status and the server health summary.

Enabling the Broadcom Gigabit Ethernet Utility program

The Broadcom Gigabit Ethernet Utility program is part of the server firmware. You can use it to configure the network as a startable device, and you can customize where the network startup option appears in the startup sequence. Enable and disable the Broadcom Gigabit Ethernet Utility program from the Setup utility.

Configuring the Gigabit Ethernet controller

The Ethernet controllers are integrated on the system board. They provide an interface for connecting to a 10 Mbps, 100 Mbps, or 1 Gbps network and provide full-duplex (FDX) capability, which enables simultaneous transmission and reception of data on the network. If the Ethernet ports in the server support auto-negotiation, the controllers detect the data-transfer rate (10BASE-T, 100BASE-TX, or 1000BASE-T) and duplex mode (full-duplex or half-duplex) of the network and automatically operate at that rate and mode.

About this task

You do not have to set any jumpers or configure the controllers. However, you must install a device driver to enable the operating system to address the controllers. To find updated information about configuring the controllers, complete the following steps.

Note: Changes are made periodically to the IBM Web site. The actual procedure might vary slightly from what is described in this document.

Procedure

1. Go to <http://www.ibm.com/systems/support/>.
2. Under **Product support**, click **System x**.
3. Under **Popular links**, click **Software and device drivers**.
4. From the **Product family** menu, select **System x3650 M3** and click **Go**.

Using the LSI Configuration Utility program

Use the LSI Configuration Utility program to configure and manage redundant array of independent disks (RAID) arrays.

Be sure to use this program as described in this document.

- Use the LSI Configuration Utility program to perform the following tasks:
 - Perform a low-level format on a hard disk drive
 - Create an array of hard disk drives with or without a hot-spare drive
 - Set protocol parameters on hard disk drives

The integrated SAS/SATA controller with RAID capabilities supports RAID arrays. You can use the LSI Configuration Utility program to configure RAID 1 (IM), RAID 1E (IME), and RAID 0 (IS) for a single pair of attached devices. If you install a different type of RAID adapter, follow the instructions in the documentation that comes with the adapter to view or change settings for attached devices.

In addition, you can download an LSI command-line configuration program from <http://www.ibm.com/systems/support/>.

When you are using the LSI Configuration Utility program to configure and manage arrays, consider the following information:

- The integrated SAS/SATA controller with RAID capabilities supports the following features:
 - Integrated Mirroring (IM) with hot-spare support (also known as RAID 1)
Use this option to create an integrated array of two disks plus up to two optional hot spares. All data on the primary disk can be migrated.

- Integrated Mirroring Enhanced (IME) with hot-spare support (also known as RAID 1E)
Use this option to create an integrated mirror enhanced array of three to eight disks, including up to two optional hot spares. All data on the array disks will be deleted.
- Integrated Striping (IS) (also known as RAID 0)
Use this option to create an integrated striping array of two to eight disks. All data on the array disks will be deleted.
- Hard disk drive capacities affect how you create arrays. The drives in an array can have different capacities, but the RAID controller treats them as if they all have the capacity of the smallest hard disk drive.
- If you use an integrated SAS/SATA controller with RAID capabilities to configure a RAID 1 (mirrored) array after you have installed the operating system, you will lose access to any data or applications that were previously stored on the secondary drive of the mirrored pair.
- If you install a different type of RAID controller, see the documentation that comes with the controller for information about viewing and changing settings for attached devices.

Starting the LSI Configuration Utility program

Use this information to start the LSI Configuration Utility program.

About this task

To start the LSI Configuration Utility program, complete the following steps:

Procedure

1. Turn on the server.

Note: Approximately 3 minutes after the server is connected to ac power, the power-control button becomes active.

2. When the prompt <F1> Setup is displayed, press F1. If you have set an administrator password, you must type the administrator password to access the full Setup utility menu. If you do not type the administrator password, a limited Setup utility menu is available.
3. Select **System Settings → Adapters and UEFI drivers**.
4. Select **Please refresh this page first** and press Enter.
5. Select the device driver that is applicable for the SAS controller in the server. For example, **LSI Logic Fusion MPT SAS Driver**.
6. To perform storage-management tasks, see the SAS controller documentation, which you can download from the Disk controller and RAID software matrix:
 - a. Go to <http://www.ibm.com/systems/support/>.
 - b. Under **Product support**, click **System x**.
 - c. Under **Popular links**, click **Storage Support Matrix**.

Results

When you have finished changing settings, press Esc to exit from the program; select **Save** to save the settings that you have changed.

Formatting a hard disk drive

Low-level formatting removes all data from the hard disk. If there is data on the disk that you want to save, back up the hard disk before you perform this procedure.

About this task

Note: Before you format a hard disk, make sure that the disk is not part of a mirrored pair.

To format a drive, complete the following steps:

1. From the list of adapters, select the controller (channel) for the drive that you want to format and press Enter.
2. Select **SAS Topology** and press Enter.
3. Select **Direct Attach Devices** and press Enter.
4. To highlight the drive that you want to format, use the Up Arrow and Down Arrow keys. To scroll left and right, use the Left Arrow and Right Arrow keys or the End key. Press Alt+D.
5. To start the low-level formatting operation, select **Format** and press Enter.

Creating a RAID array of hard disk drives

Use this information to create a RAID array of hard disk drives.

About this task

To create a RAID array of hard disk drives, complete the following steps:

1. From the list of adapters, select the controller (channel) for which you want to create an array.
2. Select **RAID Properties**.
3. Select the type of array that you want to create.
4. In the RAID Disk column, use the Spacebar or Minus (-) key to select **[Yes]** (select) or **[No]** (deselect) to select or deselect a drive from a RAID disk.
5. Continue to select drives, using the Spacebar or Minus (-) key, until you have selected all the drives for your array.
6. Press C to create the disk array.
7. Select **Save changes then exit this menu** to create the array.
8. Exit the Setup utility.

IBM Advanced Settings Utility program

The IBM Advanced Settings Utility (ASU) program is an alternative to the Setup utility for modifying UEFI settings. Use the ASU program online or out-of-band to modify UEFI settings from the command line without the need to restart the server to access the Setup utility.

You can also use the ASU program to configure the optional remote presence features or other IMM settings. The remote presence features provide enhanced systems-management capabilities.

In addition, the ASU program provides limited settings for configuring the IPMI function in the IMM through the command-line interface.

Use the command-line interface to issue setup commands. You can save any of the settings as a file and run the file as a script. The ASU program supports scripting environments through a batch-processing mode.

For more information and to download the ASU program, go to <http://www.ibm.com/systems/support/>.

Updating IBM Systems Director

If you plan to use IBM Systems Director to manage the server, you must check for the latest applicable IBM Systems Director updates and interim fixes.

About this task

Note: Changes are made periodically to the IBM Web site. The actual procedure might vary slightly from what is described in this document.

To locate and install a newer version of IBM Systems Director, complete the following steps:

Procedure

1. Check for the latest version of IBM Systems Director:
 - a. Go to <http://www.ibm.com/systems/management/director/downloads.html>.
 - b. If a newer version of IBM Systems Director than what comes with the server is shown in the drop-down list, follow the instructions on the Web page to download the latest version.
2. Install the IBM Systems Director program.

Results

If your management server is connected to the Internet, to locate and install updates and interim fixes, complete the following steps:

1. Make sure that you have run the Discovery and Inventory collection tasks.
2. On the Welcome page of the IBM Systems Director Web interface, click **View updates**.
3. Click **Check for updates**. The available updates are displayed in a table.
4. Select the updates that you want to install, and click **Install** to start the installation wizard.

If your management server is not connected to the Internet, to locate and install updates and interim fixes, complete the following steps:

1. Make sure that you have run the Discovery and Inventory collection tasks.
2. On a system that is connected to the Internet, go to <http://www.ibm.com/support/fixcentral/>.
3. From the **Product family** list, select **IBM Systems Director**.
4. From the **Product** list, select **IBM Systems Director**.
5. From the **Installed version** list, select the latest version, and click **Continue**.
6. Download the available updates.
7. Copy the downloaded files to the management server.
8. On the management server, on the Welcome page of the IBM Systems Director Web interface, click the **Manage** tab, and click **Update Manager**.
9. Click **Import updates** and specify the location of the downloaded files that you copied to the management server.
10. Return to the Welcome page of the Web interface, and click **View updates**.
11. Select the updates that you want to install, and click **Install** to start the installation wizard.

Appendix A. Getting help and technical assistance

If you need help, service, or technical assistance or just want more information about IBM products, you will find a wide variety of sources available from IBM to assist you.

Use this information to obtain additional information about IBM and IBM products, determine what to do if you experience a problem with your IBM system or optional device, and determine whom to call for service, if it is necessary.

Before you call

Before you call, make sure that you have taken these steps to try to solve the problem yourself.

If you believe that you require IBM to perform warranty service on your IBM product, the IBM service technicians will be able to assist you more efficiently if you prepare before you call.

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Check for updated software, firmware, and operating-system device drivers for your IBM product. The IBM Warranty terms and conditions state that you, the owner of the IBM product, are responsible for maintaining and updating all software and firmware for the product (unless it is covered by an additional maintenance contract). Your IBM service technician will request that you upgrade your software and firmware if the problem has a documented solution within a software upgrade.
- If you have installed new hardware or software in your environment, check <http://www.ibm.com/systems/info/x86servers/serverproven/compat/us/> to make sure that the hardware and software is supported by your IBM product.
- Go to <http://www.ibm.com/supportportal> to check for information to help you solve the problem.
- Gather the following information to provide to IBM Support. This data will help IBM Support quickly provide a solution to your problem and ensure that you receive the level of service for which you might have contracted.
 - Hardware and Software Maintenance agreement contract numbers, if applicable
 - Machine type number (IBM 4-digit machine identifier)
 - Model number
 - Serial number
 - Current system UEFI and firmware levels
 - Other pertinent information such as error messages and logs
- Go to http://www.ibm.com/support/entry/portal/Open_service_request to submit an Electronic Service Request. Submitting an Electronic Service Request will start the process of determining a solution to your problem by making the pertinent information available to IBM Support quickly and efficiently. IBM service technicians can start working on your solution as soon as you have completed and submitted an Electronic Service Request.

You can solve many problems without outside assistance by following the troubleshooting procedures that IBM provides in the online help or in the documentation that is provided with your IBM product. The documentation that comes with IBM systems also describes the diagnostic tests that you can perform. Most systems, operating systems, and programs come with documentation that contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the operating system or program.

Using the documentation

Information about your IBM system and preinstalled software, if any, or optional device is available in the documentation that comes with the product. That documentation can include printed documents, online documents, readme files, and help files.

See the troubleshooting information in your system documentation for instructions for using the diagnostic programs. The troubleshooting information or the diagnostic programs might tell you that you need additional or updated device drivers or other software. IBM maintains pages on the World Wide Web where you can get the latest technical information and download device drivers and updates. To access these pages, go to <http://www.ibm.com/supportportal>.

Getting help and information from the World Wide Web

Up-to-date information about IBM products and support is available on the World Wide Web.

On the World Wide Web, up-to-date information about IBM systems, optional devices, services, and support is available at <http://www.ibm.com/supportportal>. IBM System x information is at <http://www.ibm.com/systems/x/>. IBM BladeCenter information is at <http://www.ibm.com/systems/bladecenter>. IBM IntelliStation information is at <http://www.ibm.com/systems/intellistation>.

How to send DSA data to IBM

Use the IBM Enhanced Customer Data Repository to send diagnostic data to IBM.

Before you send diagnostic data to IBM, read the terms of use at <http://www.ibm.com/de/support/ecurep/terms.html>.

You can use any of the following methods to send diagnostic data to IBM:

- **Standard upload:** http://www.ibm.com/de/support/ecurep/send_http.html
- **Standard upload with the system serial number:** http://www.ecurep.ibm.com/app/upload_hw
- **Secure upload:** http://www.ibm.com/de/support/ecurep/send_http.html#secure
- **Secure upload with the system serial number:** https://www.ecurep.ibm.com/app/upload_hw

Creating a personalized support web page

You can create a personalized support web page by identifying IBM products that are of interest to you.

To create a personalized support web page, go to <http://www.ibm.com/support/mynotifications>. From this personalized page, you can subscribe to weekly email notifications about new technical documents, search for information and downloads, and access various administrative services.

Software service and support

Through IBM Support Line, you can get telephone assistance, for a fee, with usage, configuration, and software problems with your IBM products.

For more information about Support Line and other IBM services, see <http://www.ibm.com/services> or see <http://www.ibm.com/planetwide> for support telephone numbers. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

Hardware service and support

You can receive hardware service through your IBM reseller or IBM Services.

To locate a reseller authorized by IBM to provide warranty service, go to <http://www.ibm.com/partnerworld/> and click **Business Partner Locator**. For IBM support telephone numbers, see <http://www.ibm.com/planetwide>. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

In the U.S. and Canada, hardware service and support is available 24 hours a day, 7 days a week. In the U.K., these services are available Monday through Friday, from 9 a.m. to 6 p.m.

IBM Taiwan product service

Use this information to contact IBM Taiwan product service.

台灣 IBM 產品服務聯絡方式：
台灣國際商業機器股份有限公司
台北市松仁路 7 號 3 樓
電話：0800-016-888

IBM Taiwan product service contact information:

IBM Taiwan Corporation
3F, No 7, Song Ren Rd.
Taipei, Taiwan
Telephone: 0800-016-888

Appendix B. Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing
IBM Corporation
North Castle Drive
Armonk, NY 10504-1785
U.S.A.

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product, and use of those websites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Trademarks

IBM, the IBM logo, and ibm.com are trademarks of International Business Machines Corp., registered in many jurisdictions worldwide. Other product and service names might be trademarks of IBM or other companies.

A current list of IBM trademarks is available on the web at <http://www.ibm.com/legal/us/en/copytrade.shtml>.

Adobe and PostScript are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Cell Broadband Engine is a trademark of Sony Computer Entertainment, Inc., in the United States, other countries, or both and is used under license therefrom.

Intel, Intel Xeon, Itanium, and Pentium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Java and all Java-based trademarks and logos are trademarks or registered trademarks of Oracle and/or its affiliates.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Important notes

Processor speed indicates the internal clock speed of the microprocessor; other factors also affect application performance.

CD or DVD drive speed is the variable read rate. Actual speeds vary and are often less than the possible maximum.

When referring to processor storage, real and virtual storage, or channel volume, KB stands for 1024 bytes, MB stands for 1,048,576 bytes, and GB stands for 1,073,741,824 bytes.

When referring to hard disk drive capacity or communications volume, MB stands for 1,000,000 bytes, and GB stands for 1,000,000,000 bytes. Total user-accessible capacity can vary depending on operating environments.

Maximum internal hard disk drive capacities assume the replacement of any standard hard disk drives and population of all hard disk drive bays with the largest currently supported drives that are available from IBM.

Maximum memory might require replacement of the standard memory with an optional memory module.

Each solid-state memory cell has an intrinsic, finite number of write cycles that the cell can incur. Therefore, a solid-state device has a maximum number of write cycles that it can be subjected to, expressed as total bytes written (TBW). A

device that has exceeded this limit might fail to respond to system-generated commands or might be incapable of being written to. IBM is not responsible for replacement of a device that has exceeded its maximum guaranteed number of program/erase cycles, as documented in the Official Published Specifications for the device.

IBM makes no representation or warranties regarding non-IBM products and services that are ServerProven, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. These products are offered and warranted solely by third parties.

IBM makes no representations or warranties with respect to non-IBM products. Support (if any) for the non-IBM products is provided by the third party, not IBM.

Some software might differ from its retail version (if available) and might not include user manuals or all program functionality.

Particulate contamination

Attention: Airborne particulates (including metal flakes or particles) and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the device that is described in this document.

Risks that are posed by the presence of excessive particulate levels or concentrations of harmful gases include damage that might cause the device to malfunction or cease functioning altogether. This specification sets forth limits for particulates and gases that are intended to avoid such damage. The limits must not be viewed or used as definitive limits, because numerous other factors, such as temperature or moisture content of the air, can influence the impact of particulates or environmental corrosives and gaseous contaminant transfer. In the absence of specific limits that are set forth in this document, you must implement practices that maintain particulate and gas levels that are consistent with the protection of human health and safety. If IBM determines that the levels of particulates or gases in your environment have caused damage to the device, IBM may condition provision of repair or replacement of devices or parts on implementation of appropriate remedial measures to mitigate such environmental contamination. Implementation of such remedial measures is a customer responsibility.

Table 16. Limits for particulates and gases

Contaminant	Limits
Particulate	<ul style="list-style-type: none">• The room air must be continuously filtered with 40% atmospheric dust spot efficiency (MERV 9) according to ASHRAE Standard 52.2¹.• Air that enters a data center must be filtered to 99.97% efficiency or greater, using high-efficiency particulate air (HEPA) filters that meet MIL-STD-282.• The deliquescent relative humidity of the particulate contamination must be more than 60%².• The room must be free of conductive contamination such as zinc whiskers.
Gaseous	<ul style="list-style-type: none">• Copper: Class G1 as per ANSI/ISA 71.04-1985³• Silver: Corrosion rate of less than 300 Å in 30 days

Table 16. Limits for particulates and gases (continued)

Contaminant	Limits
	<p>¹ ASHRAE 52.2-2008 - <i>Method of Testing General Ventilation Air-Cleaning Devices for Removal Efficiency by Particle Size</i>. Atlanta: American Society of Heating, Refrigerating and Air-Conditioning Engineers, Inc.</p> <p>² The deliquescent relative humidity of particulate contamination is the relative humidity at which the dust absorbs enough water to become wet and promote ionic conduction.</p> <p>³ ANSI/ISA-71.04-1985. <i>Environmental conditions for process measurement and control systems: Airborne contaminants</i>. Instrument Society of America, Research Triangle Park, North Carolina, U.S.A.</p>

Documentation format

The publications for this product are in Adobe Portable Document Format (PDF) and should be compliant with accessibility standards. If you experience difficulties when you use the PDF files and want to request a web-based format or accessible PDF document for a publication, direct your mail to the following address:

*Information Development
IBM Corporation
205/A015
3039 E. Cornwallis Road
P.O. Box 12195
Research Triangle Park, North Carolina 27709-2195
U.S.A.*

In the request, be sure to include the publication part number and title.

When you send information to IBM, you grant IBM a nonexclusive right to use or distribute the information in any way it believes appropriate without incurring any obligation to you.

Telecommunication regulatory statement

This product may not be certified in your country for connection by any means whatsoever to interfaces of public telecommunications networks. Further certification may be required by law prior to making any such connection. Contact an IBM representative or reseller for any questions.

Electronic emission notices

When you attach a monitor to the equipment, you must use the designated monitor cable and any interference suppression devices that are supplied with the monitor.

Federal Communications Commission (FCC) statement

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that might cause undesired operation.

Industry Canada Class A emission compliance statement

This Class A digital apparatus complies with Canadian ICES-003.

Avis de conformité à la réglementation d'Industrie Canada

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Australia and New Zealand Class A statement

Attention: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

European Union EMC Directive conformance statement

This product is in conformity with the protection requirements of EU Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a nonrecommended modification of the product, including the fitting of non-IBM option cards.

Attention: This is an EN 55022 Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Responsible manufacturer:

International Business Machines Corp.
New Orchard Road
Armonk, New York 10504
914-499-1900

European Community contact:

IBM Deutschland GmbH
Technical Regulations, Department M372
IBM-Allee 1, 71139 Ehningen, Germany
Telephone: +49 7032 15 2941
Email: lugi@de.ibm.com

Germany Class A statement

Deutschsprachiger EU Hinweis: Hinweis für Geräte der Klasse A EU-Richtlinie zur Elektromagnetischen Verträglichkeit

Dieses Produkt entspricht den Schutzanforderungen der EU-Richtlinie 2004/108/EG zur Angleichung der Rechtsvorschriften über die elektromagnetische Verträglichkeit in den EU-Mitgliedsstaaten und hält die Grenzwerte der EN 55022 Klasse A ein.

Um dieses sicherzustellen, sind die Geräte wie in den Handbüchern beschrieben zu installieren und zu betreiben. Des Weiteren dürfen auch nur von der IBM empfohlene Kabel angeschlossen werden. IBM übernimmt keine Verantwortung für die Einhaltung der Schutzanforderungen, wenn das Produkt ohne Zustimmung der IBM verändert bzw. wenn Erweiterungskomponenten von Fremdherstellern ohne Empfehlung der IBM gesteckt/eingebaut werden.

EN 55022 Klasse A Geräte müssen mit folgendem Warnhinweis versehen werden:

Warnung: Dieses ist eine Einrichtung der Klasse A. Diese Einrichtung kann im Wohnbereich Funk-Störungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen zu ergreifen und dafür aufzukommen.

Deutschland: Einhaltung des Gesetzes über die elektromagnetische Verträglichkeit von Geräten

Dieses Produkt entspricht dem Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG). Dies ist die Umsetzung der EU-Richtlinie 2004/108/EG in der Bundesrepublik Deutschland.

Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG) (bzw. der EMC EG Richtlinie 2004/108/EG) für Geräte der Klasse A

Dieses Gerät ist berechtigt, in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen.

Verantwortlich für die Einhaltung der EMV Vorschriften ist der Hersteller:

International Business Machines Corp.
New Orchard Road
Armonk, New York 10504
914-499-1900

Der verantwortliche Ansprechpartner des Herstellers in der EU ist:

IBM Deutschland GmbH
Technical Regulations, Abteilung M372
IBM-Allee 1, 71139 Ehningen, Germany
Telephone: +49 7032 15 2941
Email: lugi@de.ibm.com

Generelle Informationen:

Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55022 Klasse A.

Japan VCCI Class A statement

この装置は、クラス A 情報技術装置です。この装置を家庭環境で使用する
と電波妨害を引き起こすことがあります。この場合には使用者が適切な対策
を講ずるよう要求されることがあります。 VCCI-A

This is a Class A product based on the standard of the Voluntary Control Council for Interference (VCCI). If this equipment is used in a domestic environment, radio interference may occur, in which case the user may be required to take corrective actions.

Japan Electronics and Information Technology Industries Association (JEITA) statement

高調波ガイドライン準用品

Japan Electronics and Information Technology Industries Association (JEITA)
Confirmed Harmonics Guidelines with Modifications (products greater than 20 A per phase)

Korea Communications Commission (KCC) statement

이 기기는 업무용(A급)으로 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

This is electromagnetic wave compatibility equipment for business (Type A). Sellers and users need to pay attention to it. This is for any areas other than home.

Russia Electromagnetic Interference (EMI) Class A statement

ВНИМАНИЕ! Настоящее изделие относится к классу А. В жилых помещениях оно может создавать радиопомехи, для снижения которых необходимы дополнительные меры

People's Republic of China Class A electronic emission statement

声 明
此为 A 级产品。在生活环境中，该产品可能会造成无线电干扰。在这种情况下，可能需要用户对其干扰采取切实可行的措施。

Taiwan Class A compliance statement

警告使用者：
這是甲類的資訊產品，在
居住的環境中使用時，可
能會造成射頻干擾，在這
種情況下，使用者會被要
求採取某些適當的對策。

Index

Numerics

- 4 Pac HDD upgrade option, installing 65
- 8 Pac HDD for 2 RAID Kit with 2 M5015 adapters option, installing 86
- 8 Pac HDD option, installing 72

A

- ac power LED 18
- accessible documentation 184
- acoustical noise emissions 6
- Active Energy Manager 10
- Active Memory 10
- Active Memory Manager 10
- adapter
 - installing 53
 - PCI bus, identification 53
 - removing 58
 - requirements 53
 - ServeRAID SAS
 - installing 135
 - removing 134
 - slot types 53
- adapter bracket (full-length)
 - installing 52
 - storing 52
- administrator password 159
- Advanced Settings Utility (ASU)
 - program, overview 175
- air baffle
 - DIMM
 - installing 51
 - removing 50
 - microprocessor 2
 - installing 49
 - removing 48
- assistance, getting 177
- attention notices 6
- Australia Class A statement 185

B

- battery
 - connector 28
 - installing remote 139
- before you install a legacy operating system 165
- blue-screen capture feature, overview 169
- boot precedence, default 53
- boot selection menu program, using 164
- Broadcom 171
- Broadcom Gigabit Ethernet Utility program 171

C

- cable connectors 28
- cabling 104
 - external routing 155
 - internal routing 40
 - system-board external connectors 29
 - system-board internal connectors 28
- Canada Class A electronic emission statement 185
- caution statements 6
- CD/DVD drive activity LED 15
- China Class A electronic emission statement 188
- Class A electronic emission notice 185
- components, server 26
- configuration
 - updating server 156, 157
 - with ServerGuide 165
- configuration cable 104
- configuration cable, removing 104
- configuration programs
 - LSI Configuration Utility 157
- connectors
 - battery 28
 - cable 28
 - DIMMs 28
 - external cable routing 155
 - external port 29
 - fans 28
 - for options on the system board 35
 - front 155
 - hard disk drive 35
 - internal 28
 - internal cable routing 40
 - memory 28
 - microprocessor 28
 - PCI 28
 - PCI riser-card adapter 36
 - port 29
 - rear 155
 - SAS riser-card 35
 - system board 28
 - tape drive 35
- contamination, particulate and gaseous 6, 183
- controller, configuring Ethernet 172
- controls and LEDs
 - front view 15
 - on light path diagnostics panel 17
 - operator information panel 16
 - rear view 18
- convert
 - a 16 bay system to a 8 bay + tape system 101
- cooling 6, 10
- cover
 - removing 45
 - replacing 155
- creating a personalized support web page 179
- creating, RAID array 174

- custom support web page 179

D

- danger statements 6
- dc power supply LED errors 20
- device drivers 15
- diagnostics panel, controls and LEDs 17
- diagnostics program, DSA preboot 10
- DIMM air baffle
 - installing 51
 - removing 50
- DIMM installation sequence
 - for memory mirroring 121
- DIMMs
 - installation sequence for memory mirroring 119
 - installing 121
 - order of installation 118
 - types supported 115
- documentation
 - format 184
 - using 178
- documentation CD 3
- documentation, related 5
- drive, hot-swap
 - installing 61
 - removing 62
- drive, installing simple-swap 63
- drive, installing tape 104
- DSA, sending data to IBM 178
- DVD drive
 - installing 153
- Dynamic System Analysis (DSA) Preboot diagnostics program 10

E

- electrical input 6
- electronic emission Class A notice 185
- electrostatic-discharge wrist strap, using 40
- embedded hypervisor, using 168
- EMC brackets
 - installing 102
- enclosure manager heartbeat LED 34
- environment 6
- errors
 - dc power supply LEDs 20
- Ethernet
 - systems-management connector 18
- Ethernet activity LED 16, 18
- Ethernet adapter, installing 149
- Ethernet connector 18
- Ethernet controller, configuring 172
- Ethernet-link LED 18
- Ethernet-link status LED 16
- European Union EMC Directive conformance statement 186
- external cable routing 155

F

- fan
 - installing 128
 - removing 127
 - requirements 128
- fans 10
- FCC Class A notice 185
- features 6
 - and specifications 6
 - IMM 167
 - RAS 13
 - remote presence 169
 - ServerGuide 165
- filler panel
 - 4-drive 65, 72, 86
 - hard-disk drive bay 61
- firmware updates 1, 164
- firmware, UEFI-compliant 10
- formatting a hard disk drive 174

G

- gaseous contamination 6, 183
- Germany Class A statement 186
- gigabit Ethernet controller,
 - configuring 172
- grease, thermal 114

H

- hard disk drive
 - formatting 174
 - installing 61, 63
 - removing 62, 64
- hard disk drive backplane
 - cabling 104
- hard disk drive backplane,
 - removing 101
- Hardware and software requirements 4
- hardware service and support telephone numbers 179
- heat output 6
- help
 - from the World Wide Web 178
 - from World Wide Web 178
 - sending diagnostic data to IBM 178
 - sources of 177
- hot-swap
 - drive
 - installing 61
 - removing 62
 - fan
 - installing 128
 - removing 127
- humidity 6
- hypervisor memory key
 - installing 147
 - removing 148
 - using 168

I

- IBM Advanced Settings Utility program,
 - overview 175
- IBM Director 10

- IBM Systems Director
 - overview 14
 - server feature 10
 - updating 175
- IBM Taiwan product service 179
- IBM Virtual Media Key, installing 60
- IBM X-Architecture technology 10
- IMM
 - overview 10
 - using 167
- IMM heartbeat LED 34
- important notices 6, 182
- IN OK LED 21
- IN OK power LED 18
- information center 178
- information LED 16
- install
 - optional tape drive 100
- installation guidelines 37
- installing
 - a hot-swap power supply 123
 - air baffle (DIMM) 51
 - air baffle (microprocessor 2) 48, 49
 - DIMM 121
 - DVD drive 153
 - EMC brackets 102
 - Ethernet adapter 149
 - full-length adapter bracket 52
 - hard disk drive 61
 - IBM Virtual Media Key 60
 - memory module 121
 - microprocessor 108
 - microprocessor 2 air baffle 48, 49
 - PCI adapter 53
 - RAID controller 135
 - SAS controller 135
 - SAS hard disk drive backplane 104
 - SAS riser-card and controller assembly 130
 - SAS/SATA 4 Pac HDD upgrade option 65
 - SAS/SATA 8 Pac HDD for 2 RAID Kit with 2 M5015 adapters option 86
 - SAS/SATA 8 Pac HDD option 72
 - ServeRAID adapter advanced feature key 137
 - ServeRAID SAS controller 104
 - simple-swap drive 63
 - simple-swap hard disk drive 63
 - tape drive 104
 - USB hypervisor memory key 147
- integrated management module,
 - about 10
- internal cable routing 40
- IP address, obtaining for Web interface 170

J

- Japan Class A electronic emission statement 187
- Japan Electronics and Information Technology Industries Association statement 188
- JEITA statement 188
- jumpers, description
 - for system board 29

K

- Korea Class A electronic emission statement 188

L

- LED errors
 - dc power supply 20
- LEDs 15
 - ac power 18
 - enclosure manager heartbeat 34
 - Ethernet activity 16, 18
 - Ethernet icon LED 16
 - Ethernet link 18
 - Ethernet-link status 16
 - IMM heartbeat 34
 - IN OK power 18
 - information 16
- LEDs
 - Ethernet icon 16
- locator 16, 18
- OUT OK power 18
- power-on 16, 18
- power-supply 20
- power-supply detected problems 20
- riser-card assembly 37
- system board 33
- system error 16
- system pulse 34
- system-error 18

LEDs and controls

- front view 15
- on light path diagnostics panel 17
- operator information panel 16
- rear view 18

legacy operating system requirement 165

Licenses and Attributions Documents 5

light path diagnostics panel

- accessing 17

Linux license agreement 5

locator LED 16, 18

LSI Configuration Utility

- overview 172
- starting 173

M

- management module, integrated 10
- management, systems 10
- memory 10
 - two-DIMM-per-channel (2DPC) 115
- memory mirroring
 - description 119
 - DIMM population sequence 119, 121
- memory module
 - installing 121
 - specifications 6
- memory online-spare
 - description 121
- memory support 10
- menu choices in Setup utility 159
- microprocessor
 - heat sink 108
 - installing 108
 - specifications 6

- microprocessor 2 air baffle
 - installing 49
 - removing 48
- mirroring mode 119

N

- New Zealand Class A statement 185
- NMI button 17
- notes 6
- notes, important 182
- notices 181
 - electronic emission 185
 - FCC, Class A 185
- notices and statements 6

O

- obtaining IP address for Web interface 170
- online documentation 1, 5
- online-spare mode 121
- operating system 25
- operating system installation
 - with ServerGuide 166
 - without ServerGuide 166
- operator information panel
 - CD/DVD-eject button 15
- optional device connectors
 - on the system board 35
- OUT OK LED 21
- OUT OK power LED 18

P

- particulate contamination 6, 183
- password
 - administrator 163
 - power-on 163
- password, power-on
 - switch on system board 163
- PCI
 - expansion slots 6
- PCI adapter
 - installing 53
 - removing 58
- PCI riser-card assembly
 - installing 47
 - removing 46, 47
- People's Republic of China Class A
 - electronic emission statement 188
- port connectors 29
- power
 - supply 6
- power supply
 - installing 123
- power-control button 16
- power-cord connector 18
- power-on LED
 - front 16
 - rear 18
- power-on password
 - setting 159
- power-on password override switch 29
- power-supply LEDs 20

- power-supply LEDs and detected problems 20
- PowerExecutive 10
- product service, IBM Taiwan 179
- publications 5

R

- RAID array, creating 174
- RAID controller
 - installing 135
 - removing 134
- RAS features 13
- redundant
 - cooling 10
- remind button 17
- remote battery, installing 139
- remote presence feature
 - enabling 170
 - functions 10
 - using 169
- removing
 - configuration cable 104
 - cover 45
 - DIMM air baffle 50
 - hard disk drive 62, 64
 - PCI adapter 58
 - RAID controller 134
 - SAS controller 134
 - SAS hard disk drive backplane 101
 - SAS riser-card and controller assembly 129
 - ServeRAID SAS controller 104
 - USB hypervisor memory key 148
- replacing
 - SAS hard disk drive backplane 104
 - ServeRAID SAS controller 104
 - simple-swap hard disk drive 63
- replacing cover 155
- reset button 17
- retention bracket (tape-enabled SAS riser-card), moving 145
- riser-card assembly
 - installing 47
 - LEDs 37
 - location 58
 - removing 46, 47
- Russia Class A electronic emission statement 188

S

- safety v
- safety statements v, vii
- SAS connector, internal 28
- SAS controller
 - installing 135
 - moving retention bracket (tape-enabled SAS riser-card) 145
 - removing 134
- SAS controller battery, installing remote 139
- SAS hard disk drive backplane
 - installing 104
- SAS riser-card
 - cabling 104

- SAS riser-card and controller assembly
 - installing 130
 - removing 129
- SAS/SATA 4 Pac HDD upgrade option, installing 65
- SAS/SATA 8 Pac HDD for 2 RAID Kit with 2 M5015 adapters option, installing 86
- SAS/SATA 8 Pac HDD option, installing 72
- sending diagnostic data to IBM 178
- serial connector 18
- server configuration, updating 156, 157
- Server controls 15
- Server controls, LEDs, and power 15
- server firmware, starting backup 164
- server firmware, UEFI-compliant 10
- server power and IMM 23
- ServeRAID adapter advanced feature key
 - installing 137
- ServeRAID SAS controller
 - installing 104
 - removing 104
- ServeRAID support 10
- ServerGuide
 - downloading CD 10
 - features 165
 - using 164
 - using to install operating system 166
- ServerProven 25, 123
- service and support
 - before you call 177
 - hardware 179
 - software 179
- setup and configuration with ServerGuide 165
- Setup utility
 - menu choices 159
 - starting 159
 - using 158
- simple-swap
 - hard disk drive 64
- size 6
- software service and support telephone numbers 179
- specifications 6
- starting
 - backup server firmware 164
 - LSI Configuration Utility 173
 - Setup utility 159
- statements and notices 6
- static-sensitive devices, handling 40
- storing full-length adapter bracket 52
- support web page, custom 179
- switch
 - functions 29
 - power-on password override 29
 - system board location 29
- switch block
 - system board 29
- system board
 - connectors 28
 - external port 29
 - internal 28
 - LEDs 33
 - power-on password switch 163
 - switch block 29

- system board optional devices
 - connectors 35
- system pulse LEDs 34
- system reliability guidelines 39
- system-error LED
 - front 16
 - rear 18
- system-locator LED 16, 18
- Systems Director, updating 175
- systems management 10, 14

T

- Taiwan Class A electronic emission statement 189
- tape drive, installing 104
- telecommunication regulatory statement 184
- telephone numbers 179
- temperature 6
- thermal grease 114
- trademarks 182
- turning off the server 23
- turning on the server 23
- two-DIMM-per-channel (2DPC) requirements 115

U

- United States FCC Class A notice 185
- UpdateXpress 15
- updating
 - IBM Systems Director 175
 - server configuration 156, 157
- USB connector 15, 18
- USB hypervisor memory key
 - installing 147
 - removing 148
 - using 168
- using
 - boot selection menu program 164
 - embedded hypervisor 168
 - LSI Configuration Utility 172
 - remote presence feature 169
 - ServerGuide 164
 - Setup utility 158

V

- video connector
 - front 15
 - rear 18
- virtual media key, installing 60

W

- Web interface
 - logging on to 171
 - obtaining IP address 170
- web site
 - ServerGuide 164
- weight 6



Part Number: 00KC218

Printed in USA

(1P) P/N: 00KC218

