



XClarity Controller with Intel Xeon SP (1st, 2nd Gen) User Guide



Note: Before using this information, read the general information in [Appendix B “Notices”](#) on page 203.

Fifteenth Edition (May 2021)

© Copyright Lenovo 2017, 2022.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration (GSA) contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Contents

Contents i

Chapter 1. Introduction 1

XClarity Controller Standard, Advanced, and Enterprise Level features	2
XClarity Controller Standard Level features	2
XClarity Controller Advanced Level features	5
XClarity Controller Enterprise Level features	5
Upgrading XClarity Controller	6
Web browser and operating-system requirements	6
Multiple language support.	7
MIBs Introduction	7
Notices used in this document	8

Chapter 2. Opening and Using the XClarity Controller Web Interface 9

Accessing the XClarity Controller web interface	9
Setting up the XClarity Controller network connection through the XClarity Provisioning Manager.	10
Logging in to the XClarity Controller	12
Description of XClarity Controller functions on web interface.	13

Chapter 3. Configuring the XClarity Controller 17

Configuring user accounts/LDAP	17
User authentication method	17
Creating a new user account	18
Deleting a user account	20
Using hashed passwords for authentication	20
Configuring global login settings	22
Configuring LDAP	24
Configuring network protocols	29
Configuring the Ethernet settings	29
Configuring DNS	31
Configuring DDNS	31
Configuring Ethernet over USB	32
Configuring SNMP	32
Enabling or Disabling IPMI Network Access	33
Configuring Network Settings with IPMI commands	33
Service Enablement and Port Assignment.	33
Configuring Access Restriction	34
Configuring Front Panel USB Port to Management	35
Configuring security settings.	36

SSL overview	36
SSL certificate handling	37
SSL certificate management	37
Configuring the Secure Shell server	38
IPMI over Keyboard Controller Style (KCS) Access	38
Prevent System Firmware Down-Level	39
Assert Physical Presence	39
Configuring the Security Key Management (SKM)	39
Extended Audit Log	43
Cryptography Setting.	43
Backing up and Restoring the BMC configuration	45
Backing up the BMC configuration	45
Restoring the BMC configuration	46
Resetting the BMC to Factory Default	46
Restarting the XClarity Controller	46

Chapter 4. Monitoring the server status. 47

Viewing the Health Summary/Active System Events	47
Viewing the System Information	48
Viewing the System Utilization	50
Viewing Event Logs	51
Viewing Audit Logs	51
Viewing the Maintenance History	52
Configuring Alert Recipients	52
Capturing the latest OS failure screen data	54

Chapter 5. Configuring the Server . . . 55

Viewing the adapter information and configuration settings	55
Configuring system boot mode and order.	55
Configuring one-time boot	56
Managing the server power	57
Configuring the power redundancy	57
Configuring the power capping policy	57
Configuring the power restore policy	58
Power actions.	58
Managing and monitoring power consumption with IPMI commands	59
Remote Console Functionality	61
Enabling the remote console functionality.	62
Remote power control	62
Remote console capture screen	63
Remote console keyboard support	63

Remote console mouse support	64
Screen Video Record/Replay	64
Remote console screen modes	65
Media mount methods	65
Remote disk using Java client	69
Media mount error issues	73
Exiting the remote console session	75
Downloading service data	75
Server Properties	75
Setting Location and Contact	75
Setting server timeouts	76
Trespass message	76
Setting the XClarity Controller date and time	77

Chapter 6. Configuring the Storage. 79

RAID Detail	79
RAID Setup	79
Viewing and configuring the virtual drives	79
Viewing and configuring the storage inventory.	80

Chapter 7. Updating Server Firmware 83

Overview	83
System, Adapter and PSU Firmware Update	83

Chapter 8. License Management 85

Installing an activation key.	85
Removing an activation key	85
Exporting an activation key	86

Chapter 9. Lenovo XClarity Controller Redfish REST API 87

Chapter 10. Command-line interface 89

Accessing the command-line interface	89
Logging in to the command-line session	89
Configuring serial-to-SSH redirection	89
Command syntax	90
Features and limitations	90
Alphabetical command listing	91
Utility commands	93
exit command.	93
help command	93
history command	93
Monitor commands	94
clearlog command	94
fans command	95
ffdc command	95

hreport command	96
mhlog command	97
led command	97
readlog command	99
syshealth command	100
temps command	101
volts command	101
vpd command	102
Server power and restart control commands	102
power command	102
reset command	104
fuelg command	105
pxeboot command.	106
Serial redirect command	107
console command	107
Configuration commands	107
accseccfg command	107
alertcfg command	108
asu command.	109
backup command	112
dhcpcfg command	113
dns command	114
encaps command	115
ethtbody command	116
firewall command	117
gprofile command	118
hashpw command	118
ifconfig command	119
keycfg command	122
ldap command	123
ntp command	125
portcfg command	126
portcontrol command.	127
ports command	128
rdmount command.	129
restore command	130
restoredefaults command	130
roles command	131
seccfg command	132
set command	132
smtp command	133
snmp command	133
snmpalerts command	135
srcfg command	137
sshcfg command	138
ssl command	139
sslcfg command.	140
storekeycfg command	143
syncrep command	144
thermal command	145

timeouts command	146	IPMI Commands with OEM Parameters	174
tls command	147	Get / Set LAN Configuration Parameters	174
trespass command.	147	OEM IPMI Commands	185
uefipw command	148	Chapter 12. Edge servers195
usbeth command	149	System Lockdown Mode	195
usbfw command	149	SED Authentication Key (AK) Manager	196
users command	149	Edge Networking	196
IMM control commands	154	Appendix A. Getting help and	technical assistance
alertentries command	154	Before you call	199
batch command	156	Collecting service data	200
clearcfg command	157	Contacting Support	201
clock command	157	Appendix B. Notices.203
identify command	158	Trademarks	204
info command	158	Important notes.	204
spreset command	159	Particulate contamination	204
Agent-less commands	159	Telecommunication regulatory statement.	205
storage command	159	Electronic emission notices	205
adapter command	168	Taiwan BSMI RoHS declaration.	206
m2raid command	170	Taiwan import and export contact information	206
Support commands	171	Index209
dbgshimm command.	171		
Chapter 11. IPMI interface173		
Managing the XClarity Controller with IPMI	173		
Using IPMItool	173		

Chapter 1. Introduction

The Lenovo XClarity Controller (XCC) is the next generation management controller that replaces the baseboard management controller (BMC) for Lenovo ThinkSystem servers.

It is the follow-on to the Integrated Management Module II (IMM2) service processor that consolidates the service processor functionality, Super I/O, video controller, and remote presence capabilities into a single chip on the server system board. It provides features such as the following:

- Choice of a dedicated or shared Ethernet connection for systems management
- Support for HTML5
- Support for access via XClarity Mobile
- XClarity Provisioning Manager
- Remote configuration using XClarity Essentials or XClarity Controller CLI.
- Capability for applications and tools to access the XClarity Controller either locally or remotely
- Enhanced remote-presence capabilities.
- REST API (Redfish schema) support for additional web-related services and software applications.

Note: The XClarity Controller currently supports Redfish Scalable Platforms Management API Specification 1.15.0 and schema 2021.4

Notes:

- In the XClarity Controller web interface, BMC is used in referring to the XCC.
- A dedicated systems-management network port may not be available on some ThinkSystem servers; for these servers access to the XClarity Controller is only available through a network port that is shared with the server operating system.
- For Flex servers, the Chassis Management Module (CMM) is the primary management module for systems-management functions. Access to the XClarity Controller is available through the network port on the CMM.

This document explains how to use the functions of the XClarity Controller in a ThinkSystem server. The XClarity Controller works with the XClarity Provisioning Manager and UEFI to provide systems-management capability for ThinkSystem servers.

To check for firmware updates, complete the following steps.

Note: The first time you access the Support Portal, you must choose the product category, product family, and model numbers for your server. The next time you access the Support Portal, the products you selected initially are preloaded by the website, and only the links for your products are displayed. To change or add to your product list, click the **Manage my product lists** link. Changes are made periodically to the website. Procedures for locating firmware and documentation might vary slightly from what is described in this document.

1. Go to <http://datacentersupport.lenovo.com>.
2. Under **Support**, select **Data Center**.
3. When the content is loaded, select **Servers**.
4. Under **Select Series**, first select the particular server hardware series, then under **Select SubSeries**, select the particular server product subseries, and finally, under **Select Machine Type** select the particular machine type.

XClarity Controller Standard, Advanced, and Enterprise Level features

With the XClarity Controller, Standard, Advanced, and Enterprise levels of XClarity Controller functionality are offered. See the documentation for your server for more information about the level of XClarity Controller installed in your server. All levels provide the following:

- Around-the-clock remote access and management of your server
- Remote management independent of the status of the managed server
- Remote control of hardware and operating systems

Note: Some features might not apply to Flex system servers.

The following is a list of XClarity Controller standard level features:

XClarity Controller Standard Level features

The following is a list of XClarity Controller Standard Level features:

Industry Standard Management Interfaces

- IPMI 2.0 Interface
- Redfish
- CIM-XML
- DCMI 1.5
- SNMPv3
- SNMPv1 (Traps Only) requires minimum v2.10 or v2.12 XCC Firmware updates depending on server type. See XCC Firmware update Change file for details.

Other Management Interfaces

- Web
- Legacy CLI
- Front Panel USB - virtual operator panel via mobile device

Power / Reset Control

- Power On
- Hard/Soft Shutdown
- Scheduled Power Control
- System Reset
- Boot Order Control

Event Logs

- IPMI SEL
- Human Readable Log
- Audit Log

Environmental Monitoring

- Agent Free Monitoring
- Sensor Monitoring

- Fan Control
- LED Control
- Chipset Errors (Caterr, IERR, etc...)
- System Health Indication
- OOB Performance Monitoring for I/O adapters
- Inventory Display and Export

RAS

- Virtual NMI
- Automatic Firmware Recovery
- Automated promotion of backup firmware
- POST Watchdog
- OS Loader Watchdog
- Blue Screen Capture (OS Failure)
- Embedded Diagnostic Tools

Network Configuration

- IPv4
- IPv6
- IP Address, Subnet Mask, Gateway
- IP Address Assignment Modes
- Host name
- Programmable MAC address
- Dual MAC Selection (if supported by server hardware)
- Network Port Reassignments
- VLAN Tagging

Network Protocols

- DHCP
- DNS
- DDNS
- HTTP/HTTPS
- SNMPv3
- SNMPv1 (Traps only)
- SSL
- SSH
- SMTP
- LDAP client
- NTP
- SLP
- SSDP

Alerts

- PET Traps
- CIM Indication
- SNMP TRAPs
- E-mail
- Redfish events

Serial Redirection

- IPMI SOL
- Serial port configuration

Security

- XClarity Controller Core Root of Trust for Measurement (CRTM)
- Digitally signed firmware updates
- Role Based Access Control (RBAC)
- Local User Accounts
- LDAP/AD User Accounts
- Secure Rollback of Firmware
- Chassis intrusion detection (only available on some server models)
- XCC remote assertion of UEFI TPM Physical Presence
- Audit logging of configuration changes and server actions
- Public-key (PK) Authentication
- System Retire/Repurpose

Remote Presence

- Remote Disk on Card (RDOC): Virtual Media mounting of remote ISO/IMG files via CIFS, NFS, HTTP, HTTPS, FTP, SFTP, and LOCAL

Power Management

- Real time Power Meter

License Management

- Activation Key Validation and Repository

Deployment & Configuration

- Remote Configuration
- Deployment & Configuration Tools and Driver Packs using the embedded XClarity Provisioning Manager
- Configuration Backup and Restore

Firmware Updates

- Agent Free Update
- Remote Update

XClarity Controller Advanced Level features

The following is a list of XClarity Controller Advanced Level features:

All of the XClarity Controller Standard Level features plus:

Alerts

- Syslog

Remote Presence

- Remote KVM

Serial Redirection

- Serial Redirection via SSH

Security

- Security Key Lifecycle Manager (SKLM)
- IP address blocking

Power Management

- Real time Power Graphics
- Historical Power Counters
- Temperature Graphics

Deployment & Configuration

- Remote OS Deployment using the embedded XClarity Provisioning Manager with the XClarity Controller Remote KVM feature

XClarity Controller Enterprise Level features

The following is a list of XClarity Controller Enterprise Level features:

All of the XClarity Controller Standard and Advanced Level features plus:

RAS

- Boot Capture

Remote Presence

- Quality/Bandwidth Control
- Virtual Console Collaboration (six users)
- Virtual Console Chat
- Virtual Media
 - Mounting of remote ISO/IMG files via remote console
 - Mounting file from Network: - Mount an ISO or IMG image file from a file server (HTTPS, CIFS, NFS) to the host as a DVD or USB drive

Power Management

- Power Capping

- OOB Performance Monitoring - System Performance metrics

Deployment & Configuration

- Remote Deployment using Lenovo XClarity Administrator. When using the Lenovo XClarity Administrator for operating system deployment, see https://pubs.lenovo.com/lxca/supported_operating_system_images for details on the supported operating systems.

Upgrading XClarity Controller

If your server came with the Standard or Advanced level of the XClarity Controller firmware functionality, you might be able to upgrade the XClarity Controller functionality in your server. For more information about available upgrade levels and how to order, see [Chapter 8 “License Management” on page 85](#).

Web browser and operating-system requirements

Use the information in this topic to view the list of supported browsers, cipher suites and operating systems for your server.

The XClarity Controller web interface requires one of the following web browsers:

- Chrome 64.0 or above (64.0 or above for Remote Console)
- Firefox ESR 78.0 or above
- Microsoft Edge 79.0 or above
- Safari 12.0 or above (iOS 7 or later and OS X)

Note: Support for the remote console feature is not available through the browser on mobile device operating systems.

The browsers listed above match those currently supported by the XClarity Controller firmware. The XClarity Controller firmware may be enhanced periodically to include support for other browsers.

Depending upon the version of the firmware in the XClarity Controller, web browser support can vary from the browsers listed in this section. To see the list of supported browsers for the firmware that is currently on the XClarity Controller, click the **Supported Browsers** menu list from the XClarity Controller login page.

For increased security, only high strength ciphers are now supported when using HTTPS. When using HTTPS, the combination of your client operating system and browser must support one of the following cipher suites:

- ECDHE-ECDSA-AES256-GCM-SHA384
- ECDHE-ECDSA-AES256-SHA384
- ECDHE-ECDSA-AES256-SHA
- ECDHE-ECDSA-AES128-GCM-SHA256
- ECDHE-ECDSA-AES128-SHA256
- ECDHE-ECDSA-AES128-SHA
- ECDHE-RSA-AES256-GCM-SHA384
- ECDHE-RSA-AES256-SHA384
- ECDHE-RSA-AES128-GCM-SHA256
- ECDHE-RSA-AES128-SHA256

Your internet browser's cache stores information about web pages that you visit so that they will load more quickly in the future. After a flash update of the XClarity Controller firmware, your browser may continue to use information from its cache instead of retrieving it from the XClarity Controller. After updating the XClarity Controller firmware, it is recommended that you clear the browser cache to ensure that web pages served by the XClarity Controller are displayed correctly.

Multiple language support

Use the information in this topic to view the list of languages supported by the XClarity Controller.

By default, the chosen language for the XClarity Controller web interface is English. The interface is capable of displaying multiple languages. These include the following:

- French
- German
- Italian
- Japanese
- Korean
- Portuguese (Brazil)
- Russian
- Simplified Chinese
- Spanish (international)
- Traditional Chinese

To choose the language of your preference, click the arrow beside the currently selected language. A drop-down menu will appear to let you choose your preferred language.

Text strings that are generated by the XClarity Controller firmware are displayed in the language dictated by the browser. If the browser specifies a language other than one of the translated languages listed above, the text is displayed in English. In addition, any text string that is displayed by the XClarity Controller firmware, but is not generated by the XClarity Controller (for example messages generated by UEFI, PCIe adapters, etc...) are displayed in English.

The input of language-specific text other than English, such as the **Trespass message** is currently not supported. Only text typed in English is supported.

MIBs Introduction

Use the information in this topic to access Management Information Base.

The SNMP MIBs can be downloaded from the <https://support.lenovo.com/> (Search by machine type on the portal). It includes the following four MIBs.

- The **SMI MIB** describes the Structure of Management Information for the Lenovo Data Center Group.
- The **Product MIB** describes the object identifier for Lenovo Products.
- The **XCC MIB** provides the inventory and monitoring information for Lenovo XClarity Controller.
- The **XCC Alert MIB** defines traps for alert conditions detected by Lenovo XClarity Controller.

Note: The import order for the four MIBs is **SMI MIB** → **Product MIB** → **XCC MIB** → **XCC Alert MIB**.

Notices used in this document

Use this information to understand the notices that are used in this document.

The following notices are used in the documentation:

- **Note:** These notices provide important tips, guidance, or advice.
- **Important:** These notices provide information or advice that might help you avoid inconvenient or problem situations.
- **Attention:** These notices indicate potential damage to programs, devices, or data. An attention notice is placed just before the instruction or situation in which damage might occur.

Chapter 2. Opening and Using the XClarity Controller Web Interface

This topic describes the login procedures and the actions that you can perform from the XClarity Controller web interface.

The XClarity Controller combines service processor functions, a video controller, and remote presence function in a single chip. You must first log in using the XClarity Controller web interface to access the XClarity Controller remotely. This chapter describes the login procedures and the actions that you can perform from the XClarity Controller web interface.

Accessing the XClarity Controller web interface

The information in this topic explains how to access the XClarity Controller web interface.

The XClarity Controller supports static and Dynamic Host Configuration Protocol (DHCP) IPv4 addressing. The default static IPv4 address assigned to the XClarity Controller is 192.168.70.125. The XClarity Controller is initially configured to attempt to obtain an address from a DHCP server, and if it cannot, it uses the static IPv4 address.

The XClarity Controller also supports IPv6, but it does not have a fixed static IPv6 IP address by default. For initial access to the XClarity Controller in an IPv6 environment, you can either use the IPv4 IP address or the IPv6 link-local address. The XClarity Controller generates a unique link-local IPv6 address, using the IEEE 802 MAC address by inserting two octets, with hexadecimal values of 0xFF and 0xFE in the middle of the 48-bit MAC as described in RFC4291 and flipping the 2nd bit from the right in the first octet of the MAC address. For example if the MAC address is 08-94-ef-2f-28-af, the link-local address would be as follows:

```
fe80::0a94:eff:fe2f:28af
```

When you access the XClarity Controller, the following IPv6 conditions are set as default:

- Automatic IPv6 address configuration is enabled.
- IPv6 static IP address configuration is disabled.
- DHCPv6 is enabled.
- Stateless auto-configuration is enabled.

The XClarity Controller provides the choice of using a **dedicated** systems-management network connection (if applicable) or one that is **shared** with the server. The default connection for rack-mounted and tower servers is to use the **dedicated** systems-management network connector.

The dedicated systems-management network connection on most servers is provided using a separate 1Gbit network interface controller. However, on some systems the dedicated systems-management network connection may be provided using the Network Controller Sideband Interface (NCSI) to one of the network ports of a multi-port network interface controller. In this case, the dedicated systems-management network connection is limited to the 10/100 speed of the sideband interface. For information and any limitations on the implementation of the management port on your system, see your system documentation.

Note: A **dedicated** systems-management network port might not be available on your server. If your hardware does not have a **dedicated** network port, the **shared** setting is the only XClarity Controller setting available.


Setting up the XClarity Controller network connection through the XClarity Provisioning Manager

Use the information in this topic to set up an XClarity Controller network connection through the XClarity Provisioning Manager.

After you start the server, you can use the XClarity Provisioning Manager to configure the XClarity Controller network connection. The server with the XClarity Controller must be connected to a DHCP server, or the server network must be configured to use the XClarity Controller static IP address. To set up the XClarity Controller network connection through the Setup utility, complete the following steps:

Step 1. Turn on the server. The ThinkSystem welcome screen is displayed.

Note: It may take up to 40 seconds after the server is connected to AC power for the power-control button to become active.




Step 2. When the prompt <F1> System Setup is displayed, press F1. If you have set both a power-on password and an administrator password, you must type the administrator password to access the XClarity Provisioning Manager.

Step 3. From the XClarity Provisioning Manager main menu, select **UEFI Setup**.

Step 4. On the next screen, select **BMC Settings**; then, click **Network Settings**.

Step 5. There are three XClarity Controller network connection choices in the **DHCP Control** field:

- Static IP
- DHCP Enabled
- DHCP with Fallback



- Step 6. Select one of the network connection choices.
- Step 7. If you choose to use a static IP address, you must specify the IP address, the subnet mask, and the default gateway.
- Step 8. You can also use the Lenovo XClarity Controller Manager to select a dedicated network connection (if your server has a dedicated network port) or a shared XClarity Controller network connection.

Notes:

- A dedicated systems-management network port might not be available on your server. If your hardware does not have a dedicated network port, the **shared** setting is the only XClarity Controller setting available. On the **Network Configuration** screen, select **Dedicated** (if applicable) or **Shared** in the **Network Interface Port** field.
- To find the locations of the Ethernet connectors on your server that are used by the XClarity Controller, see the documentation that came with your server.

- Step 9. Click **Save**.
- Step 10. Exit from the XClarity Provisioning Manager.

Notes:

- You must wait approximately 1 minute for changes to take effect before the server firmware is functional again.
- You can also configure the XClarity Controller network connection through the XClarity Controller web interface or command-line interface (CLI). In the XClarity Controller web interface, network connections can be configured by clicking **BMC Configuration** from the left navigation panel, and then selecting **Network**. In the XClarity Controller CLI, network connections are configured using several commands that depend on the configuration of your installation.

Logging in to the XClarity Controller

Use the information in this topic to access the XClarity Controller through the XClarity Controller web interface.


Important: The XClarity Controller is set initially with a user name of USERID and password of PASSWORD (with a zero, not the letter O). This default user setting has Supervisor access. Change this user name and password during your initial configuration for enhanced security. After making the change, you are unable to set PASSWORD as the login password again.



Note: In a Flex System, the XClarity Controller user accounts can be managed by a Flex System Chassis Management Module (CMM) and might be different than the USERID/PASSWORD combination described above.


To access the XClarity Controller through the XClarity Controller web interface, complete the following steps:

- Step 1. Open a web browser. In the address or URL field, type the IP address or host name of the XClarity Controller to which you want to connect.
- Step 2. Select the desired language from the language drop-down list.

The Login window is shown in the following illustration.



- Step 3. Type your user name and password in the XClarity Controller Login window. If you are using the XClarity Controller for the first time, you can obtain your user name and password from your system administrator. All login attempts are documented in the event log. Depending on how your system administrator configured the user ID, you might need to enter a new password after logging in.
- Step 4. Click **Login** to start the session. The browser opens the XClarity Controller home page, as shown in the following illustration. The home page displays information about the system that the XClarity Controller manages plus icons indicating how many critical errors  and how many warnings  are currently present in the system.



The home page is essentially divided into two sections. The first section is the left navigation panel, which is a set of topics that allow you to perform the following actions:

- Monitor the server status
- Configure the server
- Configure the XClarity Controller or BMC
- Update the firmware

The second section is the graphical information provided to the right of the navigation panel. The modular format gives you a quick view of the server status and some quick actions that can be performed.

Description of XClarity Controller functions on web interface

The following is a table that describes the XClarity Controller functions in the left navigation panel.

Note: When navigating the web interface, you can also click the question mark icon for online help.

Table 1. XClarity Controller functions

Three column table containing descriptions of the actions that you can perform from the XClarity Controller web interface.

Tab	Selection	Description
Home	Health Summary/Active System Events	Shows the current status of the major hardware components in the system.
	System Information and Settings	Provides a summary of common system information.
	Quick Actions	Provides a quick link to control the server power and location LED, and a button to download the service data.
	Power Utilization/System Utilization/Temperature	Provides a quick overview of the current power utilization, system utilization and overall server temperature.

Table 1. XClarity Controller functions (continued)

Tab	Selection	Description
	Remote Console Preview	Control the server at the operating system level. You can view and operate the server console from your computer. The remote console section in the XClarity Controller home page displays a screen image with a Launch button. The right tool bar includes the following quick actions: <ul style="list-style-type: none"> • Capture Screen • Settings • Recorded Videos • Latest Failure Screen
Events	Event Log	Provides a historical list of all hardware and management events.
	Audit Log	Provides a historical record of user actions, such as logging in to the Lenovo XClarity Controller, creating a new user, and changing a user password. You can use the audit log to track and document authentication and controls in IT systems.
	Maintenance History	Displays all the firmware update, configuration and hardware replacement history.
	Alert Recipients	Manage who will be notified of system events. It allows you to configure each recipient, and manage settings that apply to all event recipients. You can also generate a test event to verify the notification configuration settings.
Inventory		Displays all the components in the system, along with their status and key information. You can click on a device to display additional information. Note: Refer to SMM2 web interface for more details of solution power status.
Utilization		Displays ambient/component temperature, power utilization, voltage levels, system subsystem utilization and fan speed information of the server and its components in either graphic or tabular formats.
Storage	Detail	Displays the storage devices' physical structure and storage configuration.
	RAID Setup	View or modify current RAID configuration, including the information of virtual disks and physical storage devices.
Remote Console		Provides access to remote console functionality. You can use the virtual media feature to mount ISO or IMG files that are located on your system or on a network location that can be accessed by the BMC using CIFS, NFS, HTTPS, or SFTP. The mounted disk appears as a USB disk drive that is attached to the server.
Firmware Update		<ul style="list-style-type: none"> • Displays firmware levels. • Update the XClarity Controller firmware and server firmware.
Server Configuration	Adapters	Displays information of the network adapters installed and the settings that can be configured via the XClarity Controller.

Table 1. XClarity Controller functions (continued)

Tab	Selection	Description
	Boot Options	<ul style="list-style-type: none"> • Select the boot device for one-time boot during next server restart. • Change boot mode and boot order settings.
	Power Policy	<ul style="list-style-type: none"> • Configure the power redundancy during the event of a power supply failure. • Configure power capping policy. • Configure power restore policy. <p>Note: Refer to SMM2 web interface for more details of solution power status.</p>
	Server Properties	<ul style="list-style-type: none"> • Monitor various properties, status conditions, and settings for your server. • Manage server start timeouts to detect and recover from server hang. • Create Trespass Message. A Trespass Message is a message that you can create for users to see when they log in to the XClarity Controller.
BMC Configuration	Backup and Restore	Reset the configuration of the XClarity Controller to factory defaults, backup current configuration or restore configuration from a file.
	License	Manage activation keys for optional XClarity Controller features.
	Network	Configure networking properties, status, and settings for the XClarity Controller.
	Security	Configure security properties, status, and settings for the XClarity Controller.
	User/LDAP	<ul style="list-style-type: none"> • Configure the XClarity Controller login profiles and global login settings. • View user accounts that are currently logged in to the XClarity Controller. • The LDAP tab configures user authentication for use with one or more LDAP servers. It also allows you to enable or disable LDAP security and manage its certificates.

Chapter 3. Configuring the XClarity Controller

Use the information in this chapter to understand the options available for XClarity Controller configurations.

When configuring the XClarity Controller, the following key options are available:

- Backup and Restore
- License
- Network
- Security
- User/LDAP
- Call Home

Configuring user accounts/LDAP

Use the information in this topic to understand how user accounts are managed.

Click **User/LDAP** under **BMC Configuration** to create, modify, and view user accounts, and to configure LDAP settings.

The **Local User** tab shows the user accounts that are configured in the XClarity Controller, and which are currently logged in to the XClarity Controller.

The **LDAP** tab shows the LDAP configuration for accessing user accounts that are kept on an LDAP server.

User authentication method

Use the information in this topic to understand the modes that the XClarity Controller can use to authenticate login attempts.

Click **Allow logons from** to select how user login attempts are authenticated. You can select one of the following authentication methods:

- **Local only:** Users are authenticated by a search of the local user account configured in the XClarity Controller. If there is no match of the user ID and password, access is denied.
- **LDAP only:** The XClarity Controller attempts to authenticate the user with credentials kept on an LDAP server. The local user accounts in the XClarity Controller **are not** searched with this authentication method.
- **Local first, then LDAP:** Local authentication is attempted first. If local authentication fails; then, LDAP authentication is attempted.
- **LDAP first, then local user:** LDAP authentication is attempted first. If LDAP authentication fails; then, local authentication is attempted.

Notes:

- Only locally administered accounts are shared with the IPMI and SNMP interfaces. These interfaces do not support LDAP authentication.
- IPMI and SNMP users can login using the locally administered accounts when the **Allow logons from** field is set to **LDAP only**.

Creating a new user account

Use the information in this topic to create a new local user.

Create user

Click **Create** to create a new user account.

Complete the following fields: **User name**, **Password**, **Confirm Password**, and **Authority Level**. For further details on the authority level, see the following section.

User authority level

The following user authority levels are available:

Supervisor

The Supervisor user authority level has no restrictions.

Read only

The Read only user authority level has read-only access and cannot perform actions such as file transfers, power and restart actions, or remote presence functions.

Custom

The Custom user authority level allows a more customized profile for user authority with settings for the actions that the user is allowed to perform.

Select one or more of the following Custom user authority levels:

Adapter Configuration - Networking & Security

A user can modify configuration parameters on the Security, Network, and Serial Port pages.

User Account Management

A user can add, modify, or delete users, and change the global login settings.

Remote Console Access

A user can access the remote console.

Remote Console and Remote Disk Access

A user can access the remote console and the virtual media feature.

Remote Server Power/Restart

A user can perform power-on and restart functions for the server.

Adapter Configuration - Basic

A user can modify configuration parameters on the Server Properties and Events pages.

Ability to Clear Event Logs

A user can clear the event logs. Anyone can look at the event logs; but, this authority level is required to clear the logs.

Adapter Configuration - Advanced (Firmware Update, Restart BMC, Restore Configuration)

A user has no restrictions when configuring the XClarity Controller. In addition, the user is said to have administrative access to the XClarity Controller. Administrative access includes the following advanced functions: firmware updates, PXE network boot, restoring XClarity Controller factory defaults, modifying and restoring XClarity Controller settings from a configuration file, and restarting and resetting the XClarity Controller.

When a user sets the authority level of an XClarity Controller login ID, the resulting IPMI privilege level of the corresponding IPMI User ID is set according to the following priorities:

- If a user sets the XClarity Controller login ID authority level to **Supervisor**, the IPMI privilege level is set to Administrator.
- If a user sets the XClarity Controller login ID authority level to **Read Only**, the IPMI privilege level is set to User.
- If a user sets the XClarity Controller login ID authority level to any of the following types of access, the IPMI privilege level is set to Administrator:
 - User Account Management Access
 - Remote Console Access
 - Remote Console and Remote Disk Access
 - Adapter Configuration - Networking & Security
 - Adapter Configuration - Advanced
- If a user sets the XClarity Controller login ID authority level to **Remote Server Power/Restart Access** or **Ability to Clear Event Logs**, the IPMI privilege level is set to Operator.
- If a user sets the XClarity Controller login ID authority level to **Adapter Configuration - Basic**, the IPMI privilege level is set to User.

SNMPv3 Settings

To enable SNMPv3 access for a user, select the check box next to the **SNMPv3 Settings**. The following user access options are explained:

Access type

Only **GET** operations are supported. The XClarity Controller does not support SNMPv3 **SET** operations. SNMP3 can only perform query operations.

Address for traps

Specify the trap destination for the user. This can be an IP address or hostname. Using traps, the SNMP agent notifies the management station about events, (for example, when a processor temperature exceeds the limit).

Authentication protocol

Only **HMAC-SHA** is supported as the authentication protocol. This algorithm is used by the SNMPv3 security model for authentication.

Privacy protocol

The data transfer between the SNMP client and the agent can be protected using encryption. The supported methods are **CBC-DES** and **AES**.

Notes: Even if repetitive strings of a password is used by an SNMPv3 user, access will still be allowed to the XClarity Controller. Two examples are shown for your reference.

- If the password is set to **"11111111"** (eight-digit number containing eight 1's), the user can still access the XClarity Controller if the password is accidentally inputted with more than eight 1's. For example, if the password is inputted as **"1111111111"** (ten-digit number containing ten 1's), access will still be granted. The repetitive string will be considered having the same key.
- If the password is set to **"bertbert"**, the user can still access the XClarity Controller if the password is accidentally inputted as **"bertbertbert"**. Both passwords are considered to have the same key.

For further details, refer to page 72 in the Internet Standard of RFC 3414 document (<https://tools.ietf.org/html/rfc3414>).

SSH Key

The XClarity Controller supports SSH Public Key Authentication (RSA key type). To add a SSH key to the local user account, select the check box next to the **SSH Key**. The following two options are provided:

Select key file

Select the SSH key file to be imported into the XClarity Controller from your server.

Enter key into a text field

Paste or type the data from your SSH key into the text field.

Notes:

- Some of Lenovo's tools may create a temporary user account for accessing the XClarity Controller when the tool is run on the server operating system. This temporary account is not viewable and does not use any of the 12 local user account positions. The account is created with a random user name (for example, "20luN4SB") and password. The account can only be used to access the XClarity Controller on the internal Ethernet over USB interface, and only for the CIM-XML and SFTP interfaces. The creation and removal of this temporary account is recorded in the audit log as well as any actions performed by the tool with these credentials.
- For the SNMPv3 Engine ID, the XClarity Controller uses a HEX string to denote the ID. This HEX string is converted from the default XClarity Controller host name. See the example below:

The host name "XCC-7X06-S4AHJ300" is first converted into ASCII format: 88 67 67 45 55 88 48 54 45 83 52 65 72 74 51 48 48

The HEX string is built using the ASCII format (ignore the spaces in between): 58 43 43 2d 37 58 30 36 2d 53 34 41 48 4a 33 30 30

Deleting a user account

Use the information in this topic to remove a local user account.

To delete a local user account, click the trash can icon on the row of the account that you wish to remove. If you are authorized, you can remove your own account or the account of other users, even if they are currently logged in, unless it is the only account remaining with User Account Management privileges. Sessions that are already in progress when user accounts are deleted will not be automatically terminated.

Using hashed passwords for authentication

Use the information in this topic to understand how to use hashed passwords for authentication.

Aside from the use of passwords and LDAP/AD user accounts, the XClarity Controller also supports third-party hashed passwords for authentication. The special password uses a one-way hash (SHA256) format and is supported by the XClarity Controller web, OneCLI, and CLI interfaces. However, please note that authentication of XCC SNMP, IPMI and CIM interfaces do not support third-party hashed passwords. Only the OneCLI tool and XCC CLI interface can create a new account with a hashed password or perform a hashed password update. The XClarity Controller also allows the OneCLI tool and XClarity Controller CLI interface to retrieve the hashed password if the capability of reading hashed password is enabled.

Setting hashed password via XClarity Controller web

Click **Security** under **BMC Configuration**, and scroll to the **Security Password Manager** section to enable or disable the **Third-party Password** function. If enabled, a third-party hashed password is employed for log-in authentication. Retrieval of the third-party hashed password from the XClarity Controller can also be enabled or disabled.

Note: By default, the **Third-party Password** and **Allow Third-party Password Retrieval** functions are disabled.

To check if the user password is **Native** or a **Third-party Password**, click **User/LDAP** under **BMC Configuration** for details. The information will be under the **Advanced Attribute** column.

Notes:

- Users will not be able to change a password if it is a third-party password, and the **Password** and **Confirm password** fields will be greyed out.
- If the third-party password has expired, a warning message will be shown during the user login process.

Setting hashed password via OneCLI function

- Enabling feature

```
$ sudo OneCli config set IMM.ThirdPartyPassword Enabled
```

- Creating hashed password (No Salt). The following shows an example logging to the XClarity Controller using the **password123** password.

```
$ pwhash = `echo -n password123 | openssl dgst -sha256 | awk '{print $NF}``
```

```
$ echo $pwhash 5e884898da28047151d0e56f8dc6292773603d0d6aabbdd62a11ef721d1542d8
```

```
$ sudo OneCli config set IMM.Loginid.2 admin
```

```
$ sudo OneCli config set IMM.SHA256Password.2 $pwhash
```

```
$ sudo OneCli config set IMM.SHA256PasswordSalt.2 ""
```

- Creating user with hashed password (With Salt). The following shows an example logging to the XClarity Controller using the **password123** password. Salt=abc.

```
$ pwhash = `echo -n password123abc | openssl dgst -sha256 | awk '{print $NF}``
```

```
$ echo $pwhash 292bcbc41bb078cf5bd258db60b63a4b337c8c954409442cfad7148bc6428fee
```

```
$ sudo OneCli config set IMM.Loginid.3 Admin
```

```
$ sudo OneCli config set IMM.SHA256Password.3 $pwhash
```

```
$ sudo OneCli config set IMM.SHA256PasswordSalt.3 'abc'
```

- Retrieving the hashed password and salt.

```
$ sudo OneCli config set IMM.ThirdPartyPasswordReadable Enabled
```

```
$ sudo OneCli config show IMM.SHA256Password.3
```

```
$ sudo OneCli config show IMM.SHA256PasswordSalt.3
```

- Deleting the hashed password and salt.

```
$ sudo OneCli config set IMM.SHA256Password.3 ""
```

```
$ sudo OneCli config set IMM.SHA256PasswordSalt.3 ""
```

- Setting the hashed password to an existing account.

```
$ sudo OneCli config set IMM.Loginid.2 admin
```

```
$ sudo OneCli config set IMM.Password.2 PasswOrd123abc
```

```
$ sudo OneCli config set IMM.SHA256Password.2 $pwhash
```

```
$ sudo OneCli config set IMM.SHA256PasswordSalt.2 ""
```

Note: While the hashed password is being set, this password will immediately take effect. The original standard password will no longer be effective. In this example, the original standard password **Passw0rd123abc** cannot be used anymore until the hashed password is deleted.

Setting hashed password via CLI function

- Enabling feature

```
> hashpw -sw enabled
```

- Creating hashed password (No Salt). The following shows an example logging to the XClarity Controller using the **password123** password.

```
$ pwhash = `echo -n password123 | openssl dgst -sha256 | awk '{print $NF}``
```

```
5e884898da28047151d0e56f8dc6292773603d0d6aabbdd62a11ef721d1542d8
```

```
> users -2 -n admin -shp 5e884898da28047151d0e56f8dc6292773603d0d6aabbdd62a11ef721d1542d8 -a super
```

- Creating user with hashed password (With Salt). The following shows an example logging to the XClarity Controller using the **password123** password. Salt=abc.

```
$ pwhash = `echo -n password123abc | openssl dgst -sha256 | awk '{print $NF}``
```

```
$ echo $pwhash 292bcbcb41bb078cf5bd258db60b63a4b337c8c954409442cfad7148bc6428fee
```

```
> users -3 -n Admin -shp 292bcbcb41bb078cf5bd258db60b63a4b337c8c954409442cfad7148bc6428fee -ssalt 'abc' -a super
```

- Retrieving the hashed password and salt.

```
> hashpw -re enabled
```

```
> users -3 -ghp -gsalt
```

- Deleting the hashed password and salt.

```
> users -3 -shp "" -ssalt ""
```

- Setting the hashed password to an existing account.

```
> users -2 -n admin -p Passw0rd123abc -shp 5e884898da28047151d0e56f8dc6292773603d0d6aabbdd62a11ef721d1542d8 -a super
```

Note: While the hashed password is being set, this password will immediately take effect. The original standard password will no longer be effective. In this example, the original standard password **Passw0rd123abc** cannot be used anymore until the hashed password is deleted.

After the hashed password has been set up, remember you do not use this to login to the XClarity Controller. When logging in, you will need to use the plaintext password. In the example shown below, the plaintext password is “password123”.

```
$ pwhash = `echo -n password123 | openssl dgst -sha256 | awk '{print $NF}``
```

```
5e884898da28047151d0e56f8dc6292773603d0d6aabbdd62a11ef721d1542d8
```

```
> users -2 -n admin -shp 5e884898da28047151d0e56f8dc6292773603d0d6aabbdd62a11ef721d1542d8 -a super
```

Configuring global login settings

Use the information in this topic to configure login and password policy settings that apply to all users.

Web inactivity session timeout

Use the information in this topic to set the web inactivity session timeout option.

In the **Web inactivity session timeout** field, you can specify how long, in minutes, the XClarity Controller waits before it disconnects an inactive web session. The maximum wait time is 1,440 minutes. If set to 0, the web session never expires.

The XClarity Controller firmware supports up to six simultaneous web sessions. To free up sessions for use by others, it is recommended that you log out of the web session when you are finished rather than relying on the inactivity timeout to automatically close your session.

Note: If you leave the browser open on an XClarity Controller web page that automatically refreshes, your web session will not automatically close due to inactivity.

Account security policy settings

Use this information to understand and set the account security policy for your server.

Notes: In a Flex System, the account security policy settings are managed by the Flex System Chassis Management Module (CMM) and cannot be modified through the XCC. When the CMM is used to configure the account security policy, make note of the following:

- Unlike the XCC, the CMM does not have the **Password expiration warning period (days)** setting. When the **Password expiration period** is configured to be longer than 5 days in the CMM, the XCC will set the password expiration warning period to be 5 days. Conversely, if the setting is shorter than 5 days, the password expiration warning period will be the same as the value inputted in the **Password expiration period**.
- For the **Maximum number of login failures (times)** setting, the range set forth in the CMM is 0-100 times. However, the range defined in the XCC is 0-10 times. Thus, when the user selects a value that exceeds 10 times in the CMM, the XCC will still set the maximum number of login failures as 10 times.
- For the **Minimum password change interval (hours)** setting, the range set forth in the CMM is 0-1440 hours. However, the range defined in the XCC is 0-240 hours. Thus, when the user selects a value that exceeds 240 hours in the CMM, the XCC will still set the minimum password change interval to be 240 hours.

The following information is a description of the fields for the security settings.

Force to change password on first access

After setting up a new user with a default password, selection of this check box will force that user to change their password the first time that the user logs in. The default value for this field is to have the check box enabled.

Force default account password must be changed on next login

A manufacturing option is provided to reset the default USERID profile after the first successful login. When this check box is enabled, the default password must be changed before the account can be used. The new password is subject to all active password enforcement rules. The default value for this field is to have the check box enabled.

Complex password required

The option box is checked by default and the complex password must adhere to the following rules:

- Only contain the following characters (no white-space characters allowed): A-Z, a-z, 0-9, ~`!@#\$%^&*()-+={}[]|:;'"<>,?/_
- Must contain at least one letter
- Must contain at least one number

- Must contain at least two of the following combinations:
 - At least one upper-case letter.
 - At least one lower-case letter.
 - At least one special character.
- No other characters (in particular, spaces or white-space characters) are allowed
- Passwords may have no more than two consecutive instances of the same character (i.e., “aaa”).
- The password cannot be literary same as the user name, simply repeating the user name one or more times, or a reverse character order of the user name.
- Passwords must be a minimum of 8 and a maximum of 32 characters long

If the option box is not checked, the number specified in the minimum password length can be set as 0–32 characters. The account password may be blank if minimum password length is set as 0.

Password expiration period (days)

This field contains the maximum password age that is permitted before the password must be changed.

Password expiration warning period (days)

This field contains the number of days a user is warned before their password expires.

Minimum password length

This field contains the minimum length of the password.

Minimum password reuse cycle

This field contains the number of previous passwords that cannot be reused. Up to ten previous passwords can be compared. Select 0 to allow the reuse of all previous passwords.

Minimum password change interval (hours)

This field contains how long a user must wait between password changes.

Maximum number of login failures (times)

This field contains the number of failed login attempts that are allowed before the user is locked out for a period of time.

Lockout period after maximum login failures (minutes)

This field specifies how long (in minutes), the XClarity Controller subsystem will disable remote login attempts after the maximum number of login failures has been reached.

Configuring LDAP

Use the information in this topic to view or change XClarity Controller LDAP settings.

LDAP support includes:

- Support for LDAP protocol version 3 (RFC-2251)
- Support for the standard LDAP client APIs (RFC-1823)
- Support for the standard LDAP search filter syntax (RFC-2254)
- Support for Lightweight Directory Access Protocol (v3) Extension for Transport Layer Security (RFC-2830)

The LDAP implementation supports the following LDAP servers:

- Microsoft Active Directory (Windows 2003, Windows 2008, Windows 2012, Windows 2016, Windows 2019)
- Microsoft Active Directory Application Mode (Windows 2003 Server)

- Microsoft Lightweight Directory Service (Windows 2008, Windows 2012)
- Novell eDirectory Server, version 8.7, 8.8 and 9.4
- OpenLDAP Server 2.1, 2.2, 2.3 and 2.4

Click the **LDAP** tab to view or modify XClarity Controller LDAP settings.

The XClarity Controller can remotely authenticate a user's access through a central LDAP server instead of, or in addition to the local user accounts that are stored in the XClarity Controller itself. Privileges can be designated for each user account using the IBMRBSPermissions string. You can also use the LDAP server to assign users to groups and perform group authentication, in addition to the normal user (password check) authentication. For example, an XClarity Controller can be associated with one or more groups, the user will pass group authentication only if the user belongs to at least one group that is associated with the XClarity Controller.

To configure an LDAP server, complete the following steps:

1. Under **LDAP Server Information**, the following options are available from the item list:
 - **Use LDAP server for Authentication only (with local authorization):** This selection directs the XClarity Controller to use the credentials only to authenticate to the LDAP server and to retrieve group membership information. The group names and privileges can be configured in the Active Directory Settings section.
 - **Use LDAP server for Authentication and Authorization:** This selection directs the XClarity Controller to use the credentials both to authenticate to the LDAP server and to identify a user's permission.

Note: The LDAP servers to be used for authentication can either be configured manually or discovered dynamically via DNS SRV records.

- **Use Pre-Configured Servers:** You can configure up to four LDAP servers by entering each server's IP address or host name if DNS is enabled. The port number for each server is optional. If this field is left blank, the default value of 389 is used for non-secured LDAP connections. For secured connections, the default port value is 636. You must configure at least one LDAP server.
- **Use DNS to Find Servers:** You can choose to discover the LDAP server(s) dynamically. The mechanisms described in RFC2782 (A DNS RR for specifying the location of services) are used to locate the LDAP server(s). This is known as DNS SRV. You need to specify a fully qualified domain name (FQDN) to be used as the domain name in the DNS SRV request.
 - **AD Forest:** In an environment with universal groups in cross domains, the forest name (set of domains) must be configured to discover the required Global Catalogs (GC). In an environment where cross-domain group membership does not apply, this field can be left blank.
 - **AD Domain:** You will need to specify a fully qualified domain name (FQDN) to be used as the domain name in the DNS SRV request.

If you wish to enable secure LDAP, click the **Enable Secure LDAP** check box. In order to support secure LDAP, a valid SSL certificate must be in place and at least one SSL client trusted certificate must be imported into the XClarity Controller. Your LDAP server must support Transport Layer Security (TLS) version 1.2 to be compatible with the XClarity Controller secure LDAP client. For more information about certificate handling, see [“SSL certificate handling” on page 37](#).

2. Fill in information under **Additional Parameters**. Below are explanations of the parameters.

Binding method

Before you can search or query the LDAP server, you must send a bind request. This field controls how this initial bind to the LDAP server is performed. The following bind methods are available:

- **No Credentials Required**

Use this method to bind without a Distinguished Name (DN) or password. This method is strongly discouraged because most servers are configured to not allow search requests on specific user records.

- **Use Configured Credentials**

Use this method to bind with the configured client DN and password.

- **Use Login Credentials**

Use this method to bind with the credentials that are supplied during the login process. The user ID can be provided through a DN, a partial DN, a fully qualified domain name, or through a user ID that matches the UID Search Attribute that is configured on the XClarity Controller. If the credentials that are presented resemble a partial DN (e.g. cn=joe), this partial DN will be prepended to the configured Root DN in an attempt to create a DN that matches the user's record. If the bind attempt fails, a final attempt will be made to bind by prepending cn= to the login credential, and prepending the resulting string to the configured Root DN.

If the initial bind is successful, a search is performed to find an entry on the LDAP server that belongs to the user who is logging in. If necessary, a second attempt to bind is made, this time with the DN that is retrieved from the user's LDAP record and the password that was entered during the login process. If the second attempt to bind fails, the user is denied access. The second bind is performed only when the **No Credentials Required** or **Use Configured Credentials** binding methods are used.

Root Distinguished Name (DN)

This is the distinguished name (DN) of the root entry of the directory tree on the LDAP server (for example, dn=mycompany,dc=com). This DN is used as the base object for all search requests.

UID Search Attribute

When the binding method is set to **No Credentials Required** or **Use Configured Credentials**, the initial bind to the LDAP server is followed by a search request that retrieves specific information about the user, including the user's DN, login permissions, and group membership. This search request must specify the attribute name that represents the user IDs on that server. This attribute name is configured in this field. On Active Directory servers, the attribute name is usually **sAMAccountName**. On Novell eDirectory and OpenLDAP servers, the attribute name is **uid**. If this field is left blank, the default is **uid**.

Group Filter

The **Group Filter** field is used for group authentication. Group authentication is attempted after the user's credentials are successfully verified. If group authentication fails, the user's attempt to log on is denied. When the group filter is configured, it is used to specify to which groups the XClarity Controller belongs. This means that to succeed the user must belong to at least one of the groups that are configured for group authentication. If the **Group Filter** field is left blank, group authentication automatically succeeds. If the group filter is configured, an attempt is made to match at least one group in the list to a group that the user belongs to. If there is no match, the user fails authentication and is denied access. If there is at least one match, group authentication is successful.

The comparisons are case sensitive. The filter is limited to 511 characters and can consist of one or more group names. The colon (:) character must be used to delimit multiple group names. Leading and trailing spaces are ignored, but any other space is treated as part of the group name.

Note: The wildcard character (*) is no longer treated as a wildcard. The wildcard concept has been discontinued to prevent security exposures. A group name can be specified as a full DN or by using only the **cn** portion. For example, a group with a DN of cn=adminGroup, dc=mycompany, dc=com can be specified using the actual DN or with adminGroup.

Nested group membership is supported only in Active Directory environments. For example, if a user is a member of GroupA and GroupB, and GroupA is also a member of GroupC, the user is said

to be a member of GroupC also. Nested searches stop if 128 groups have been searched. Groups in one level are searched before groups in a lower level. Loops are not detected.

Group Search Attribute

In an Active Directory or Novell eDirectory environment, the **Group Search Attribute** field specifies the attribute name that is used to identify the groups to which a user belongs. In an Active Directory environment, the attribute name is **memberOf**. In an eDirectory environment, the attribute name is **groupMembership**. In an OpenLDAP server environment, users are usually assigned to groups whose objectClass equals PosixGroup. In that context, this field specifies the attribute name that is used to identify the members of a particular PosixGroup. This attribute name is **memberUid**. If this field is left blank, the attribute name in the filter defaults to **memberOf**.

Login Permission Attribute

When a user is authenticated through an LDAP server successfully, the login permissions for the user must be retrieved. To retrieve the login permissions, the search filter that is sent to the server must specify the attribute name that is associated with login permissions. The **Login Permission Attribute** field specifies the attribute name. If using LDAP server for Authentication and Authorization, but this field is left blank, the user will be refused access.

The attribute value that is returned by the LDAP server searches for the keyword string **IBMRBSPermissions=**. This keyword string must be immediately followed by a bit string that is entered as 12 consecutive 0s or 1s. Each bit represents a set of functions. The bits are numbered according to their positions. The left-most bit is bit position 0, and the right-most bit is bit position 11. A value of 1 at a bit position enables the function that is associated with that bit position. A value of 0 at a bit position disables the function that is associated with that bit position.

The string **IBMRBSPermissions=010000000000** is a valid example. The **IBMRBSPermissions=** keyword is used to allow it to be placed anywhere in this field. This enables the LDAP administrator to reuse an existing attribute; therefore, preventing an extension to the LDAP schema. This also enables the attribute to be used for its original purpose. You can add the keyword string anywhere in this field. The attribute that you use can allow for a free-formatted string. When the attribute is retrieved successfully, the value that is returned by the LDAP server is interpreted according to the information in the following table.

Table 2. Permission bits

Three column table containing bit position explanations.

Bit position	Function	Explanation
0	Deny Always	A user will always fail authentication. This function can be used to block a particular user or users associated with a particular group.
1	Supervisor Access	A user is given administrator privileges. The user has read/write access to every function. If you set this bit, you do not have to individually set the other bits.
2	Read Only Access	A user has read-only access, and cannot perform any maintenance procedures (for example, restart, remote actions, or firmware updates) or make modifications (for example, the save, clear, or restore functions). Bit position 2 and all other bits are mutually exclusive, with bit position 2 having the lowest precedence. When any other bit is set, this bit will be ignored.
3	Networking and Security	A user can modify the Security, Network Protocols, Network Interface, Port Assignments, and Serial Port configurations.
4	User Account Management	A user can add, modify, or delete users and change the Global Login Settings in the Login Profiles window.

Table 2. Permission bits (continued)

Bit position	Function	Explanation
5	Remote Console Access	A user can access the remote server console.
6	Remote Console and Remote Disk Access	A user can access the remote server console and the remote disk functions for the remote server.
7	Remote Server Power/ Restart Access	A user can access the power on and restart functions for the remote server.
8	Basic Adapter Configuration	A user can modify configuration parameters in the System Settings and Alerts windows.
9	Ability to Clear Event Logs	A user can clear the event logs. Note: All users can view the event logs; but, to clear the event logs the user is required to have this level of permission.
10	Advanced Adapter Configuration	A user has no restrictions when configuring the XClarity Controller. In addition the user has administrative access to the XClarity Controller. The user can perform the following advanced functions: firmware upgrades, PXE network boot, restore XClarity Controller factory defaults, modify and restore adapter configuration from a configuration file, and restart/reset the XClarity Controller.
11	Reserved	This bit position is reserved for future use. If none of the bits are set, the user has read-only authority. Priority is given to login permissions that are retrieved directly from the user record. If the login permission attribute is not in the user's record, an attempt is made to retrieve the permissions from the groups to which the user belongs. This is performed as part of the group authentication phase. The user is assigned the inclusive OR of all the bits for all groups. The Read Only Access bit (position 2) is set only if all other bits are set to zero. If the Deny Always bit (position 0) is set for any of the groups, the user is refused access. The Deny Always bit (position 0) always has precedence over all other bits.

If none of the bits are set, the default will be set to **Read Only** for the user.

Note that priority is given to login permissions retrieved directly from the user record. If the user does not have the login permission attribute in its record, an attempt will be made to retrieve the permissions from the group(s) that the user belongs to, and, if configured, that match the group filter. In this case the user will be assigned the inclusive OR of all the bits for all of the groups. Similarly, the **Read Only Access** bit will only be set if all the other bits are zero. Moreover, note that if the **Deny Always** bit is set for any of the groups, the user will be refused access. The **Deny Always** bit always has precedence over every other bit.

Note: If you give a user the ability to modify basic, networking, and/or security related adapter configuration parameters, you should consider giving this same user the ability to restart the XClarity Controller (bit position 10). Otherwise, without this ability, a user might be able to change parameters (for example, IP address of the adapter), but will not be able to have them take effect.

- Choose whether or not to **Enable enhanced role-based security for Active Directory Users** under **Active Directory Settings** (if **Use LDAP server for Authentication and Authorization** mode is used), or configure the **Groups for Local Authorization** (if **Use LDAP server for Authentication only (with local authorization)** mode is used).
 - Enable enhanced role-based security for Active Directory Users**

If enhanced role-based security setting is enabled, a free-formatted server name must be configured to act as the target name for this particular XClarity Controller. The target name can be associated with one or more roles on the Active Directory server through a Role Based Security (RBS) Snap-In. This is accomplished by creating managed targets, giving them specific names, and then associating them to the appropriate roles. If a name is configured in this field, it provides the ability to define specific roles for users and XClarity Controllers (targets) who are members of the same role. When a user logs in to the XClarity Controller and is authenticated via Active Directory, the roles that the user is a member of are retrieved from the directory. The permissions that are assigned to the user are extracted from the roles that also have as a member a target that matches the server name that is configured here, or a target that matches any XClarity Controller. Multiple XClarity Controllers can share the same target name. This could be used to group multiple XClarity Controllers together and assign them to the same role (or roles) by using a single managed target. Conversely each XClarity Controller can be given a unique name.

- **Groups for Local Authorization**

Group Names are configured to provide local authorization specifications for groups of users. Each group name can be assigned permissions (Roles) that are the same as described in the table above. The LDAP server associates users with a group name. When the user logs in he is assigned the permissions that are associated with the group to which the user belongs. Additional groups can be configured by clicking the “+” icon or deleted by clicking the “x” icon.

Configuring network protocols

Use the information in this topic to view or establish network settings for the XClarity Controller.

Configuring the Ethernet settings

Use the information in this topic to view or change how the XClarity Controller communicates by way of an Ethernet connection.

The XClarity Controller uses two network controllers. One network controller is connected to the dedicated management port and the other network controller is connected to the shared port. Each of the network controllers is assigned its own burned in MAC address. If DHCP is being used to assign an IP address to the XClarity Controller, when a user switches between network ports or when a failover from the dedicated network port to the shared network port occurs, a different IP address may be assigned to the XClarity Controller by the DHCP server. It is recommended that when using DHCP, users should use the host name to access the XClarity Controller rather than relying on an IP address. Even if the XClarity Controller network ports are not changed, the DHCP server could possibly assign a different IP address to the XClarity Controller when the DHCP lease expires, or when the XClarity Controller reboots. If a user needs to access the XClarity Controller using an IP address that will not change, the XClarity Controller should be configured for a static IP address rather than DHCP.

Click **Network** under **BMC Configuration** to modify XClarity Controller Ethernet settings.

Configuring the XClarity Controller Host Name

The default XClarity Controller host name is generated using a combination of the string “XCC-“ followed by the server machine type and server serial number (for example. “XCC-7X03-1234567890”). You can change the XClarity Controller host name by entering up to a maximum of 63 characters in this field. The host name must not include a period (.) and can contain only alphabet, numeric, hyphen and underscore characters.

Ethernet Ports

This setting controls the enablement of Ethernet ports used by management controller, including the shared and dedicated ports.

Once **disabled**, all Ethernet ports will not be assigned any IPv4 or IPv6 addresses, and prevents any further changes to any Ethernet configurations.

Note: This setting does not affect the USB LAN interface or the USB management port at the front of the server. Those interfaces have their own dedicated enablement settings.

Configuring IPv4 network settings

To use an IPv4 Ethernet connection, complete the following steps:

1. Enable the **IPv4** option.

Note: Disabling the Ethernet interface prevents access to the XClarity Controller from the external network.

2. From the **Method** field, select one of the following options:

- **Obtain IP from DHCP:** The XClarity Controller will obtain its IPv4 address from a DHCP server.
- **Use static IP address:** The XClarity Controller will use the user specified value for its IPv4 address.
- **First DHCP, then static IP address:** The XClarity Controller will attempt to obtain its IPv4 address from a DHCP server, but if that attempt fails, the XClarity Controller will use user specified value for its IPv4 address.

3. In the **Static address** field, type the IP address that you want to assign to the XClarity Controller.

Note: The IP address must contain four integers from 0 to 255 with no spaces and separated by periods. This field will not be configurable if the method is set to **Obtain IP from DHCP**.

4. In the **Network mask** field, type the subnet mask that is used by the XClarity Controller.

Note: The subnet mask must contain four integers from 0 to 255 with no spaces or consecutive periods and separated by periods. The default setting is 255.255.255.0. This field will not be configurable if the method is set to **Obtain IP from DHCP**.

5. In the **Default Gateway** field, type your network gateway router.

Note: The gateway address must contain four integers from 0 to 255 with no spaces or consecutive periods and separated by periods. This field will not be configurable if the method is set to **Obtain IP from DHCP**.

Configuring advanced Ethernet settings

Click the **Advanced Ethernet** tab to set additional Ethernet settings.

Note: In a Flex System, the VLAN settings are managed by a Flex System CMM and cannot be modified on the XClarity Controller.

To enable Virtual LAN (VLAN) tagging select the **Enable VLAN** check box. When VLAN is enabled and a VLAN ID is configured, the XClarity Controller only accepts packets with the specified VLAN IDs. The VLAN IDs can be configured with numeric values between 1 and 4094.

From the **MAC selection** list choose one of the following selections:

- Use burned in MAC address

The Burned-in MAC address option is a unique physical address that is assigned to this XClarity Controller by the manufacturer. The address is a read-only field.

- Use custom MAC address

If a value is specified, the locally administered address overrides the burned-in MAC address. The locally administered address must be a hexadecimal value from 000000000000 through FFFFFFFF. This value

must be in the form **xx:xx:xx:xx:xx:xx** where **x** is a hexadecimal number from 0 to 9 or “a” through “f”. The XClarity Controller does not support the use of a multicast address. The first byte of a multicast address is an odd number (the least significant bit is set to 1); therefore, the first byte must be an even number.

In the **Maximum transmission unit** field, specify the maximum transmission unit of a packet (in bytes) for your network interface. The maximum transmission unit range is from 60 to 1500. The default value for this field is 1500.

To use an IPv6 Ethernet connection, complete the following steps:

Configuring IPv6 network settings

1. Enable the **IPv6** option.
2. Assign an IPv6 address to the interface using one of the following assignment methods:
 - Use stateless address autoconfiguration
 - Use stateful address configuration (DHCPv6)
 - Use statically assigned IP address

Notes: When the **Use statically assigned IP address** is chosen, you will be asked to type the following information:

- IPv6 Address
- Prefix length
- Gateway

Configuring DNS

Use the information in this topic to view or change XClarity Controller Domain Name System (DNS) settings.

Note: In a Flex System, DNS settings cannot be modified on the XClarity Controller. DNS settings are managed by the CMM.

Click **Network** under **BMC Configuration** to view or modify XClarity Controller DNS settings.

If you click the **Use additional DNS address servers** check box, specify the IP addresses of up to three Domain Name System servers on your network. Each IP address must contain integers from 0 to 255, separated by periods. These DNS server addresses are added to the top of the search list, so a host name lookup is done on these servers before one that is automatically assigned by a DHCP server.

Configuring DDNS

Use the information in this topic to enable or disable Dynamic Domain Name System (DDNS) protocol on the XClarity Controller.

Click **Network** under **BMC Configuration** to view or modify XClarity Controller DDNS settings.

Click the **Enable DDNS** check box, to enable DDNS. When DDNS is enabled, the XClarity Controller notifies a domain name server to change in real time, the active domain name server configuration of the XClarity Controller configured host names, addresses or other information that is stored in the domain name server.

Choose an option from the item list to decide how you want the domain name of the XClarity Controller to be selected.

- **Use custom domain name:** You can specify the domain name to which the XClarity Controller belongs.

- **Use domain name obtained from the DHCP server:** The domain name to which the XClarity Controller belongs is specified by the DHCP server.

Configuring Ethernet over USB

Use the information in this topic to control the Ethernet over USB interface used for in-band communication between the server and the XClarity Controller.

Click **Network** under **BMC Configuration** to view or modify the XClarity Controller Ethernet over USB settings.

The Ethernet over USB is used for in-band communications to the XClarity Controller. Click the check box to enable or disable the Ethernet over USB interface.

Important: If you disable the Ethernet over USB, you cannot perform an in-band update of the XClarity Controller firmware or server firmware using the Linux or Windows flash utilities.

Select the method that The XClarity Controller uses to assign addresses to the endpoints of the Ethernet over USB interface.

- **Use IPv6 link-local address for Ethernet over USB:** This method uses IPv6 addresses based off the MAC address that have been allocated to the endpoints of the Ethernet over USB interface. Normally, the IPv6 link local address is generated using the MAC address (RFC 4862) but Windows 2008 and newer 2016 operating systems do not support a static link local IPv6 address on the host end of the interface. Instead the default Windows behavior regenerates random link local addresses while running. If the XClarity Controller Ethernet over USB interface is configured to use the IPv6 link local address mode, various functions that make use of this interface will not work because the XClarity Controller does not know what address Windows has assigned to the interface. If the server is running Windows use one of the other Ethernet over USB address configuration methods, or disable the default Windows behavior by using this command: **netsh interface ipv6 set global randomizeidentifiers=disabled**
- **Use IPv4 link-local address for Ethernet over USB:** An IP address in the 169.254.0.0/16 range is assigned to the XClarity Controller and server side of the network.
- **Configure IPv4 setting for Ethernet over USB:** With this method, it specifies the IP addresses and network mask that are assigned to the XClarity Controller and the server side of the Ethernet over USB interface.

Notes:

1. The OS IP configuration settings is not used to set the OS IP address of Ethernet Over USB interface, but is used to notify BMC that OS IP address of Ethernet over USB has changed.
2. Before you configure three IP settings for Ethernet over USB, you need to manually configure the OS IP address of Ethernet over USB interface in your local operating system.

Mapping of external Ethernet port numbers to Ethernet over USB port numbers is controlled by clicking the **Enable external Ethernet to Ethernet over USB port forwarding** checkbox and completing the mapping information for ports you wish to have forwarded from the management network interface to the server.

Configuring SNMP

Use the information in this topic to configure SNMP agents.

Complete the following steps to configure the XClarity Controller SNMP alert settings.

1. Click **Network** under **BMC Configuration**.
2. Check the corresponding check box to enable the **SNMPv1 Trap**, **SNMPv2 Trap** and/or **SNMPv3 Trap**.
3. If enabling the **SNMPv1 Trap** or **SNMPv2 Trap**, complete the following fields:

- a. In the **Community Name** field, enter the community name; Name cannot be empty.
 - b. In the **Host** field, enter host address.
4. If enabling the **SNMPv3 Trap**, complete the following fields:
 - a. In the **Engine ID** field, enter the engine ID. Engine ID cannot be empty.
 - b. In the **Trap Receiver Port** field, enter the port number. Default port number is 162.
 5. If enabling the SNMP Traps, select the following event types you wish to be alerted:
 - **Critical**
 - **Attention**
 - **System**

Note: Click on each major category to further select their sub-category event types you wish to be alerted.

Enabling or Disabling IPMI Network Access

Use the information in this topic to control IPMI network access to the XClarity Controller.

Click **Network** under **BMC Configuration** to view or modify XClarity Controller IPMI settings. Complete the following fields to view or modify IPMI settings:

IPMI over LAN Access

Click the switch to enable or disable IPMI network access to the XClarity Controller.

Important:

- If you are not using any tools or applications that access the XClarity Controller through the network using the IPMI protocol, it is highly recommended that you disable IPMI network access for improved security.
- IPMI over LAN access to the XClarity Controller is disabled by default.

Configuring Network Settings with IPMI commands

Use the information in this topic to configure the network settings using IPMI commands.

Because each BMC network setting is configured using separate IPMI requests and in no particular order, the BMC does not have the complete view of all of the network settings until the BMC is restarted to apply the pending network changes. The request to change a network setting may succeed at the time that the request is made, but later be determined to be invalid when additional changes are requested. If the pending network settings are incompatible when the BMC is restarted, the new settings will not be applied. After restarting the BMC, you should attempt to access the BMC using the new settings to ensure that they have been applied as expected.

Service Enablement and Port Assignment

Use the information in this topic to view or change the port numbers used by some services on the XClarity Controller.

Click **Network** under **BMC Configuration** to view or modify XClarity Controller port assignments. Complete the following fields to view or modify port assignments:

Web

The port number is 80. This field is not user-configurable.

Web over HTTPS

In this field specify the port number for Web Over HTTPS. The default value is 443.

REST over HTTPS

The port number will automatically change to the one specified in the Web over HTTPS field. This field is not user-configurable.

CIM over HTTP

In this field specify the port number for CIM over HTTP. The default value is 5989.

Note: CIM is disabled by default.

Remote Presence

In this field specify the port number for Remote Presence. The default value is 3900.

IPMI over LAN

The port number is 623. This field is not user-configurable.

Note: IPMI is disabled by default.

SFTP

In this field specify the port number that is used for the SSH File Transfer Protocol (SFTP). The port number is 115. This field is not user-configurable.

Note: IMM.SFTPPortControl=open is required for OneCLI in-band updates.

SLP

In this field specify the port number that is used for the SLP. The port number is 427. This field is not user-configurable.

Notes: There are two service types that XClarity Controller reports:

- service: management-hardware.Lenovo:lenovo-xclarity-controller
- service: wbem

SSDP

The port number is 1900. This field is not user-configurable.

SSH

In this field specify the port number that is configured to access the command line interface through the SSH protocol. The default value is 22.

SNMP Agent

In this field specify the port number for the SNMP agent that runs on the XClarity Controller. The default value is 161. Valid port number values are from 1 to 65535.

SNMP Traps

In this field specify the port number that is used for SNMP traps. The default value is 162. Valid port number values are from 1 to 65535.

Configuring Access Restriction

Use the information in this topic to view or change the settings that block access from IP addresses or MAC addresses to the XClarity Controller.

Click **Network** under **BMC Configuration** to view or modify XClarity Controller access control settings.

Block List and Time Restriction

These options allow you to block specific IP/Mac addresses for specific period of time.

- **List of Blocked IP Addresses**

- You can enter up to three IPv4 addresses or ranges and three IPv6 addresses or ranges separated by commas, which are not allowed to access the XClarity Controller. Refer to the IPv4 examples below:
- Single IPv4 address sample: 192.168.1.1
- Supernet IPv4 address sample: 192.168.1.0/24
- IPv4 range sample: 192.168.1.1–192.168.1.5

- **List of Blocked MAC address**

- You can enter up to three MAC addresses separated by commas, which are not allowed to access the XClarity Controller. For example: 11:22:33:44:55:66.

- **Restricted Access (one time)**

- You can schedule a one-time time interval during which the XClarity Controller cannot be accessed. For the time interval that you specify:
- The beginning date and time must be later than the current XCC time.
- The ending date and time must be later than the beginning date and time.

- **Restricted Access (daily)**

- You can schedule one or more daily time intervals during which the XClarity Controller cannot be accessed. For each time interval that you specify:
- The ending date and time must be later than the beginning date and time.

Externally Triggered Block List

These options allow you to setup automatic blocking of specific IP addresses (IPv4 and IPv6) from which client successively attempted to log in to XClarity Controller with different incorrect username or password.

Automatic blocking will dynamically determines when excessive login failures occur from a particular IP address and blocks that address from accessing XClarity Controller for a predetermined amount of time.

- **Maximum number of login failures from a particular IP**

- The maximum number of times indicates the number of login failures allowed for a user with an incorrect password from a specific IP address before it becomes locked-out.
- If set to 0, IP address will never be locked due to login failures.
- The failed login counter for the specific IP address will be reset to zero after successful login from that IP address.

- **Lockout period for blocking an IP**

- The minimum amount of time (in minutes) that must pass before a user can attempt to log back in again from a locked IP address.
- If set to 0, access from the locked IP address remains blocked-out until the administrator explicitly unlocks it.

- **Block List**

- The table Block List displays all locked IP addresses. You can unlock one or all IP addresses from the Block List.

Configuring Front Panel USB Port to Management

Use the information in this topic to configure the XClarity Controller Front Panel USB Port to Management.

On some servers the front panel USB port can be switched to attach either to the server or to the XClarity Controller. Connection to the XClarity Controller is primarily intended for use with a mobile device running the Lenovo XClarity Mobile app. When a USB cable is connected between the mobile device and the server's front panel, an Ethernet over USB connection will be established between the mobile app running on the device and the XClarity Controller.

Click **Network** under **BMC Configuration** to view or modify XClarity Controller front panel USB port to management settings.

There are four types of settings that you can choose from:

Host Only Mode

The front panel USB port is always connected only to the server.

BMC Only Mode

The front panel USB port is always connected only to the XClarity Controller.

Shared Mode: owned by BMC

The front panel USB port is shared by both the server and the XClarity Controller, but the port is switched to the XClarity Controller.

Shared Mode: owned by Host

The front panel USB port is shared by both the server and the XClarity Controller, but the port is switched to the host.

For additional information about the Mobile app, see the following site:

https://pubs.lenovo.com/lxca/lxca_usemobileapp.html

Notes:

- If the front panel USB port is configured for Shared Mode, the port is connected to the XClarity Controller when there is no power, and is connected to the server when there is power. When there is power, the control of the front panel USB port can be switched back and forth between the server and the XClarity Controller. In shared mode, the port can also be switched between the host and the XClarity Controller by pressing and holding the front panel Identification button (for compute nodes it may be the USB management button) for more than 3 seconds.
- When configured in Shared Mode and the USB port is currently connected to the server, the XClarity Controller can support a request to switch the front panel USB port back to the XClarity Controller. When this request is executed, the front panel USB port will remain connected to the XClarity Controller until there is no USB activity to the XClarity Controller for the period specified by the inactivity timeout.

Configuring security settings

Use the information in this topic to configure security protocols.

Note: The default minimum TLS version setting is TLS 1.2, but you can configure the XClarity Controller to use other TLS versions if needed by your browser or management applications. For more information, see [“tls command” on page 147](#).

Click **Security** under **BMC Configuration** to access and configure security properties, status, and settings for your XClarity Controller.

SSL overview

This topic is an overview of the SSL security protocol.

SSL is a security protocol that provides communication privacy. SSL enables client/server applications to communicate in a way that prevents eavesdropping, tampering, and message forgery. You can configure the XClarity Controller to use SSL support for different types of connections, such as secure web server (HTTPS), secure LDAP connection (LDAPS), CIM over HTTPS, and SSH server, and to manage the certificates that are required for SSL.

SSL certificate handling

This topic provides information about the administration of certificates that can be used with the SSL security protocol.

You can use SSL with a self-signed certificate or with a certificate that is signed by a third-party certificate authority. Using a self-signed certificate is the simplest method for using SSL; but, it does create a small security risk. The risk arises because the SSL client has no way of validating the identity of the SSL server for the first connection that is attempted between the client and server. For example, it is possible that a third party might impersonate the XClarity Controller web server and intercept data that is flowing between the actual XClarity Controller web server and the user's web browser. If, at the time of the initial connection between the browser and the XClarity Controller, the self-signed certificate is imported into the certificate store of the browser, all future communications will be secure for that browser (assuming that the initial connection was not compromised by an attack).

For more complete security, you can use a certificate that is signed by a certificate authority (CA). To obtain a signed certificate, you will need to select **Generate Certificate Signing Request (CSR)**. Select **Download Certificate Signing Request (CSR)** and send the Certificate-Signing Request (CSR) to a CA to obtain a signed certificate. When the signed certificate is received, select **Import Signed Certificate** to import it into the XClarity Controller.

The function of the CA is to verify the identity of the XClarity Controller. A certificate contains digital signatures for the CA and the XClarity Controller. If a well-known CA issues the certificate or if the certificate of the CA has already been imported into the web browser, the browser can validate the certificate and positively identify the XClarity Controller web server.

The XClarity Controller requires a certificate for use with HTTPS Server, CIM over HTTPS, and the secure LDAP client. In addition the secure LDAP client also requires one or more trusted certificates to be imported. The trusted certificate is used by the secure LDAP client to positively identify the LDAP server. The trusted certificate is the certificate of the CA that signed the certificate of the LDAP server. If the LDAP server uses self-signed certificates, the trusted certificate can be the certificate of the LDAP server itself. Additional trusted certificates must be imported if more than one LDAP server is used in your configuration.

SSL certificate management

This topic provides information about some of the actions that can be selected for certificate management with the SSL security protocol.

Click **Security** under **BMC Configuration** to configure the SSL certificate management.

When managing XClarity Controller certificates, you are presented with the following actions:

Download Signed Certificate

Use this link to download a copy of the currently installed certificate. The certificate can be downloaded in either PEM or DER format. The contents of the certificate can be viewed using a third-party tool such as OpenSSL (www.openssl.org). An example of the command line for viewing the contents of the certificate using OpenSSL would look something like the following:

```
openssl x509 -in cert.der -inform DER -text
```

Download Certificate Signing Request (CSR)

Use this link to download a copy of the certificate signing request. The CSR can be downloaded in either PEM or DER format.

Generate Signed Certificate

Generate a self-signed certificate. After the operation is completed, SSL may be enabled using the new certificate.

Note: When performing the **Generate Signed Certificate** action, a Generate self-signed certificate for HTTPS window opens. You will be prompted to complete the required and optional fields. You **must** complete the required fields. Once you have entered your information, click **Generate** to complete the task.

Generate Certificate Signing Request (CSR)

Generate a certificate signing request (CSR). After the operation is completed, the CSR file may be downloaded and sent to a certificate authority (CA) for signing.

Note: When performing the **Generate Certificate Signing Request (CSR)** action, a Generate Certificate Signing Request for HTTPS window opens. You will be prompted to complete the required and optional fields. You **must** complete the required fields. Once you have entered your information, click **Generate** to complete the task.

Import a Signed Certificate

Use this to import a signed certificate. To obtain a signed certificate, a certificate signing request (CSR) must first be generated and sent to a certificate authority (CA).

Configuring the Secure Shell server

Use the information in this topic to understand and enable the SSH security protocol.

Click **Network** under **BMC Configuration** to configure the Secure Shell server.

To use the SSH protocol, a key needs to be generated first to enable the SSH server.

Notes:

- No certificate management is required to use this option.
- The XClarity Controller will initially create a SSH server key. If you wish to generate a new SSH server key, click **Network** under **BMC Configuration**; then, click **Regenerate key**.
- After you complete the action, you must restart the XClarity Controller for your changes to take effect.

IPMI over Keyboard Controller Style (KCS) Access

Use the information in this topic to control IPMI over Keyboard Controller Style (KCS) access to the XClarity Controller.

The XClarity Controller provides an IPMI interface via the KCS channel that does not require authentication.

Click **Security** under **BMC Configuration** to enable or disable IPMI over KCS access.

Note: After you change the settings, you must restart the XClarity Controller for your changes to take effect.

Important: If you are not running any tools or applications on the server that access the XClarity Controller through the IPMI protocol, it is highly recommended that you disable the IPMI KCS access for improved security. XClarity Essentials does use the IPMI over KCS interface to the XClarity Controller. If you disabled

the IPMI over KCS interface, re-enable it prior to running XClarity Essentials on the server. Then disable the interface after you have finished.

Prevent System Firmware Down-Level

Use the information in this topic to prevent system firmware from being changed to older firmware levels.

This feature allows you to decide whether or not to allow the system firmware to return to an older firmware level.

Click **Network** under **BMC Configuration** to prevent system firmware down-level

To enable or disable this feature, click **Network** under **BMC Configuration**. Any changes that are made will take effect immediately without the XClarity Controller requiring a restart.

Assert Physical Presence

Use the information in this topic to assert and de-assert Physical Presence from the XClarity Controller web page without being physically present at the server.

This feature is only available if the **Physical Presence Policy** is enabled through UEFI. Once enabled, you can access the physical presence feature by clicking **Security** under **BMC Configuration**.

Configuring the Security Key Management (SKM)

Use the information in this topic to create and manage security keys.

This feature uses centralized Key Management server to provide keys that unlock storage hardware, to gain access to data stored on SEDs in a ThinkSystem server. The Key Management server includes SKLM - IBM SED Key Management server, and KMIP - Thales/Gemalto SED Key Management servers (KeySecure and CipherTrust).

The XClarity Controller uses the network to retrieve keys from the Key Management server, the Key Management server must be accessible to the XClarity Controller. The XClarity Controller provides the communication channel between the Key Management server and the requesting ThinkSystem server. The XClarity Controller firmware attempts to connect with each configured Key Management server, stopping when a successful connection is established.

The XClarity Controller establishes communication with the Key Management server if the following conditions are met:

- One or more Key Management server host name/IP addresses are configured in the XClarity Controller.
- Two certificates (client and server) for communication with the Key Management server are installed in the XClarity Controller.

Note: Configure at least two (a primary and a secondary) Key Management servers with the same protocol for your device. If the primary Key Management server does not respond to the connection attempt from the XClarity Controller; connection attempts are initiated with the additional Key Management servers until a successful connection is established.

A Transport Layer Security (TLS) connection must be established between the XClarity Controller and the Key Management server. The XClarity Controller authenticates the Key Management server by comparing the server certificate submitted by the Key Management server, with the Key management server certificate previously imported into the XClarity Controller's trust store. The Key Management server authenticates each XClarity Controller that communicates with it and checks to verify that the XClarity Controller is permitted to access the Key Management server. This authentication is accomplished by comparing the client certificate

that the XClarity Controller submits, with a list of trusted certificates that are stored on the Key Management server.

At least one Key Management server will be connected, and the device group is considered optional. The Key Management server certificate will need to be imported, while the client certificate needs to be specified. By default, the HTTPS certificate is used. If you wish to replace it, you can generate a new one.

Note: To connect the KMIP server(KeySecure and CipherTrust), must generate a certificate signing request (CSR), and its common name must be matched with the user name defined in the KMIP server, then import a certificate that has been signed by the Certificate Authority (CA) trusted by the KMIP server for the CSR.

Configuring the Key Management servers

Use the information in this topic to create the host name or IP address and associated port information for the Key Management server.

The Key Management Server(s) configure section consists of the following fields:

Host Name or IP address

Type the host name (if DNS is enabled and configured) or the IP address of the Key Management server in this field. Up to four servers can be added.

Port

Type the port number for the Key Management server in this field. If this field is left blank, the default value of 5696 is used. Valid port number values are 1 to 65535.

Configuring the device group

Use the information in this topic to configure the device group used in the SKLM server.

In the SKLM server, a device group allows users to manage the self-encrypting drive (SED) keys on multiple servers as a group. A device group with the same name must also be created on the SKLM server.

The Device Group section contains the following field:

Device Group

A device group allows users to manage the keys for SEDs on multiple servers as a group. A device group with the same name must also be created on the SKLM server. The default value for this field is IBM_SYSTEM_X_SED.

Establishing certificate management

This topic provides information about client and server certificate management.

Client and server certificates are used to authenticate the communication between the SKLM server and the XClarity Controller located in the ThinkSystem server. Client and server certificate management are discussed in this section.

Client Certificate Management

This topic provides information about client certificate management.

Client certificates are classified as one of the following:

- An XClarity Controller self-assigned certificate.
- A certificate generated from an XClarity Controller certificate signing request (CSR) and signed (externally) by a third party CA.

A client certificate is required for communication with the SKLM server. The client certificate contains digital signatures for the CA and the XClarity Controller.

Notes:

- Certificates are preserved across firmware updates.
- If a client certificate is not created for communication with the SKLM server, the XClarity Controller HTTPS server certificate is used.
- The function of the CA is to verify the identity of the XClarity Controller.

To create a client certificate, click the plus icon () and select one of the following items:

- Generate a New Key and a Self-Signed Certificate
- Generate a New Key and a Certificate Signing Request (CSR)

The **Generate a New Key and a Self-Signed Certificate** action item generates a new encryption key and a self-signed certificate. In the Generate New Key and Self-Signed Certificate window, type or select the information in the required fields and any optional fields that apply to your configuration, (see the following table). Click **OK** to generate your encryption key and certificate. A progress window displays while the self-signed certificate is being generated. A confirmation window is displayed when the certificate is successfully installed.

Note: The new encryption key and certificate replace any existing key and certificate.

Table 3. Generate a New Key and a Self-Signed Certificate

Two column table with headers documenting the required and optional fields for the Generate a new key and a self-signed certificate action. The bottom row spans across both columns.

Field	Description
Country ¹	From the list item, select the country where the BMC physically resides.
State or Providence ¹	Type the state or providence where the BMC physically resides.
City or Locality ¹	Type the city or locality where the BMC physically resides.
Organization Name ¹	Type the company or organization name that owns the BMC.
BMC Host Name ¹	Type the BMC host name that appears in the web address bar.
Contact Person	Type the name of the contact person that is responsible for the BMC.
Email address	Type the email address of the contact person responsible for the BMC.
Organization Unit	Type the unit within the company that owns the BMC.
Surname	Type the surname of the person responsible for the BMC. This field can contain a maximum of 60 characters.
Given Name	Type the given name of the person responsible for the BMC. This field can contain a maximum of 60 characters.
Initials	Type the initials of the person responsible for the BMC. This field can contain a maximum of 20 characters.
DN Qualifier	Type the Distinguished Name Qualifier for the BMC. This field can contain a maximum of 60 characters.
1. This is a required field.	

After the client certificate has been generated you can download the certificate to storage on your XClarity Controller by selecting the **Download Certificate** action item.

The **Generate a New Key and a Certificate Signing Request (CSR)** action item generates a new encryption key and a CSR. In the Generate a New Key and a Certificate Signing Request window, type or select the information in the required fields and any optional fields that apply to your configuration, (see the following table). Click **OK** to generate your new encryption key and CSR.

A progress window displays while the CSR is being generated and a confirmation window is displayed upon successful completion. After generation of the CSR, you must send the CSR to a CA for digital signing. Select the **Download Certificate Signing Request (CSR)** action item and click **OK** to save the CSR to your server. You can then submit the CSR to your CA for signing.

Table 4. Generate a New Key and a Certificate Signing Request

Two column table with headers documenting the required and optional fields for the Generate a new key and certificate signing request action. The bottom row spans across both columns.

Field	Description
Country ¹	From the list item, select the country where the BMC physically resides.
State or Providence ¹	Type the state or providence where the BMC physically resides.
City or Locality ¹	Type the city or locality where the BMC physically resides.
Organization Name ¹	Type the company or organization name that owns the BMC.
BMC Host Name ¹	Type the BMC host name that appears in the web address bar.
Contact Person	Type the name of the contact person that is responsible for the BMC.
Email address	Type the email address of the contact person responsible for the BMC.
Organization Unit	Type the unit within the company that owns the BMC.
Surname	Type the surname of the person responsible for the BMC. This field can contain a maximum of 60 characters.
Given Name	Type the given name of the person responsible for the BMC. This field can contain a maximum of 60 characters.
Initials	Type the initials of the person responsible for the BMC. This field can contain a maximum of 20 characters.
DN Qualifier	Type the Distinguished Name Qualifier for the BMC. This field can contain a maximum of 60 characters.
Challenge Password	Type the password to the CSR. This field can contain a maximum of 30 characters.
Unstructured Name	Type additional information, such as an unstructured name that is assigned to the BMC. This field can contain a maximum of 60 characters.
1. This is a required field.	

The CSR is digitally signed by the CA using the user's certificate processing tool, such as the **OpenSSL** or **Certutil** command line tool. All client certificates that are signed using the user's certificate processing tool have the same **base** certificate. This **base** certificate must also be imported to the SKLM server so that all servers digitally signed by the user are accepted by the SKLM server.

After the certificate has been signed by the CA you must import it into the BMC. Select the **Import a Signed Certificate** action item and select the file to upload as the client certificate; then, click **OK**. A progress window displays while the CA-signed certificate is being uploaded. A Certificate Upload window is displayed if the upload process is successful. A Certificate Upload Error window is displayed if the upload process is not successful.

Notes:

- For increased security, use a certificate that is digitally signed by a CA.
- The certificate that is imported into the XClarity Controller must correspond to the CSR that was previously generated.

After a CA-signed certificate is imported into the BMC, select the **Download Certificate** action item. When you select this action item, the CA-signed certificate is downloaded from the XClarity Controller to store on your system.

Server certificate management

This topic provides information about server certificate management.

The server certificate is generated in the SKLM server and must be imported into the XClarity Controller before the secure drive access functionality will work. To import the certificate that authenticates the SKLM server to the BMC, click **Import a Certificate** from the Server Certificate Status section of the Drive Access page. A progress indicator is displayed as the file is transferred to storage on the XClarity Controller.

After the server certificate is successfully transferred to the XClarity Controller, the Server Certificate Status area displays the following content: A server certificate is installed.

If you want to remove a trusted certificate, click the corresponding **Remove** button.

Extended Audit Log

Use the information in this topic to control extended audit log.

This feature allows you to decide whether or not to include the log entries of IPMI set command (raw data) from LAN and KCS channels into the audit log.

Click **Security** under **BMC Configuration** on XCC web to enable/disable extended audit log.

Note: If the IPMI set command is from LAN channel, user name and source IP address will be included in the log message. And all IPMI commands with sensitive security information (e.g. password) are excluded.

Cryptography Setting

Use the information in this topic to understand different cryptography settings.

High Security Mode

- Only support modern and strong ciphers.
- NIST Compliant.
- PFS-compliant (Perfect Forward Secrecy).

Compatibility Mode

- Supports a wide range of cipher suits for maximum compatibility.
- Non-PFS and Non-NIST compliant.

NIST Compliant Mode

- Supports a wide range of cipher suits for maximum compatibility.
- NIST compliant.
- PFS compliant.

TLS Version Support

- TLS 1.0 and higher
- TLS 1.1 and higher
- TLS 1.2 and higher
- TLS 1.3

The TLS Cryptography Setting is to restrict the supported TLS cipher suites against BMC services.

Please refer to the following table for different setting TLS Cipher suites are supported

TLS Cipher Configuration	TLS Version	TLS cipher suites
High Security Mode	TLS 1.3	<ul style="list-style-type: none">• TLS_AES_256_GCM_SHA384
High Security Mode	TLS 1.2	<ul style="list-style-type: none">• TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384• TLS_DHE_RSA_WITH_AES_256_GCM_SHA384• TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA384
NIST Compliant Mode	TLS 1.3	<ul style="list-style-type: none">• TLS_AES_256_GCM_SHA384• TLS_AES_128_GCM_SHA256• TLS_AES_128_CCM_8_SHA256• TLS_AES_128_CCM_SHA256
NIST Compliant Mode	TLS 1.2	<ul style="list-style-type: none">• TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384• TLS_DHE_RSA_WITH_AES_256_GCM_SHA384• TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA384• TLS_ECDHE_RSA_WITH_AES_128_GCM_SHA256• TLS_DHE_RSA_WITH_AES_128_GCM_SHA256• TLS_ECDHE_ECDSA_WITH_AES_128_GCM_SHA256
Compatibility Mode	TLS 1.3	<ul style="list-style-type: none">• TLS_AES_256_GCM_SHA384• TLS_AES_128_GCM_SHA256• TLS_CHACHA20_POLY1305_SHA256• TLS_AES_128_CCM_8_SHA256• TLS_AES_128_CCM_SHA256

TLS Cipher Configuration	TLS Version	TLS cipher suites
Compatibility Mode	TLS 1.2	<ul style="list-style-type: none"> • TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384 • TLS_DHE_RSA_WITH_AES_256_GCM_SHA384 • TLS_ECDHE_RSA_WITH_AES_128_GCM_SHA256 • TLS_ECDHE_RSA_WITH_CHACHA20_POLY1305_SHA256 • TLS_ECDHE_ECDSA_WITH_CHACHA20_POLY1305_SHA256 • TLS_DHE_RSA_WITH_AES_256_GCM_SHA384
Compatibility Mode	TLS 1.1 TLS 1.0	<ul style="list-style-type: none"> • TLS_RSA_WITH_AES_256_CBC_SHA256 • TLS_RSA_WITH_AES_128_CBC_SHA256 • TLS_RSA_WITH_AES_128_CBC_SHA • TLS_ECDHE_RSA_WITH_AES_256_CBC_SHA • TLS_ECDHE_RSA_WITH_AES_128_CBC_SHA

Backing up and Restoring the BMC configuration

The information in this topic describes how to restore or modify the BMC configuration.

Select **Backup and Restore** under **BMC Configuration** to perform the following actions:

- View management controller configuration summary
- Backup or restore the management controller configuration
- View backup or restore status
- Reset the management controller configuration to its factory default settings
- Access the management controller initial setup wizard

Backing up the BMC configuration

The information in this topic describes how to back up the BMC configuration.

Select **Backup and Restore** under **BMC Configuration**. At the very top is the **Backup BMC configuration** section.

If a backup was previously made, you will see the details in the **Last backup** field.

To backup the current BMC configuration, follow the steps shown below:

1. Specify the password for the BMC backup file.
2. Select if you wish to encrypt the whole file or only sensitive data.
3. Begin the backup process by clicking **Start Backup**. During the process, you are not allowed to perform any restore/reset actions.
4. When the process is completed, a button will appear to let you download the and save the file.

Note: When the user sets up a new XClarity Controller user/password and performs a backup of the configuration, the default account/password (USERID/PASSWORD) is included as well. Subsequently deleting the default account/password from the backup will result in the system showing a message notifying the user that there is a failure in restoring the XClarity Controller account/password. Users can ignore this message.

Restoring the BMC configuration

The information in this topic describes how to restore the BMC configuration.

Select **Backup and Restore** under **BMC Configuration**. Located below **Backup BMC Configuration** is the **Restore BMC from Configuration File** section.

To restore the BMC to a previously saved configuration, follow the steps shown below:

1. Browse to select the backup file and input the password when prompted.
2. Verify the file by clicking **View content** to view the details.
3. After verifying the content, click **Start Restore**.

Resetting the BMC to Factory Default

The information in this topic describes how to reset the BMC to the factory default settings.

Select **Backup and Restore** under **BMC Configuration**. Located below **Restore BMC from Configuration File** is the **Reset BMC to factory default** section.

To reset the BMC to factory defaults, follow the steps shown below:

1. Click **Start to Reset BMC to Factory Defaults**.

Notes:

- Only users with Supervisor user authority level can perform this action.
- The Ethernet connection is temporarily disconnected. You must log in the XClarity Controller web interface again after the reset operation is completed.
- Once you click **Start to Reset BMC to Factory Defaults**, all previous configuration changes will be lost. If you wish to enable LDAP when restoring the BMC configuration, you will need to first import a trusted security certificate before doing so.
- After the process is completed, the XClarity Controller will be restarted. If this is a local server, your TCP/IP connection will be lost and you may need to reconfigure the network interface to restore connectivity.
- Resetting the BMC to Factory Default is not affecting UEFI settings.

Restarting the XClarity Controller

The information in this topic explains how to restart your XClarity Controller.

For details on how to restart the XClarity Controller, see [“Power actions” on page 58](#)

Chapter 4. Monitoring the server status

Use the information in this topic to understand how to view and monitor information for the server that you are accessing.

Once you log into the XClarity Controller, a system status page will be displayed. From this page, you can view the server hardware status, event and audit logs, system status, maintenance history and alert recipients.

Viewing the Health Summary/Active System Events

Use the information in this topic to understand how to view the Health Summary/Active System Events.


When you access the XClarity Controller homepage, the **Health Summary** is shown by default. A graphical representation is given, which shows the number of hardware components that have been installed and their respective health status. The hardware components that are being monitored include the following:

- Processor (CPU)
- Memory
- Local Storage
- PCI Adapters
- Power Supply
- Fan
- System Board
- Others


Note: **Local Storage** may show "not available" on the Status Icon on systems with a simple swap back-plane configuration.

Health Summary

Active System Events (2)



If any of the hardware components is not operating normally, it will be marked by a critical or warning icon. A critical condition is indicated by a red circle icon, while a warning condition is indicated by a yellow triangle icon. By hovering the mouse icon over the critical or warning sign, up to three currently active events for that component will be shown.



To view the other events, click the **Active System Events** tab. A window will appear showing the events that are currently active in the system. Click **View all event logs** to view the entire event history.

If the hardware component is marked by a green check mark, it is operating normally, and there are no active events.

The text underneath the hardware component states the number of components installed. If you click the text, you will be directed to the **Inventory** page.

Viewing the System Information

This topic explains how to obtain a summary of common server information.

The **System Information and Settings** pane located to the left of the home page provides a summary of common server information, which includes the following:

- Machine name, power and operating system state

- Machine Type-Model
- Serial number
- System name
- Front USB ownership
- BMC license
- BMC IP address
- BMC host name
- UEFI version
- BMC version
- LXPM version
- Location

The server can be in one of the system states listed in the following table.

Table 5. System state descriptions

Two column table with headers documenting the system states of the server.

State	Description
System power off/State unknown	The server is powered off.
System on/starting UEFI	The server is powered on; but, UEFI is not running.
System running in UEFI	The server is powered on and UEFI is running.
System stopped in UEFI	The server is powered on; UEFI has detected a problem and has stopped running.
Booting operating system or in unsupported operating system	The server might be in this state for one of the following reasons: <ul style="list-style-type: none"> • The operating system loader has started; but, the operating system is not running • The BMC Ethernet over USB interface is disabled. • The operating system does not have the drivers loaded that support the Ethernet over USB interface.
Operating system booted	The server operating system is running.
Suspend to RAM	The server has been placed in standby or sleep state.
System running in memory test	The server is powered on and running memory diagnostic tools.
System running in Setup	The server is powered on and the system has booted into UEFI F1 setup menu or LXPM menu.
System running in LXPM maintenance mode	The server is powered on and the system has booted into the LXPM maintenance mode under which users can't navigate through the LXPM menu.

If you wish to change the system name, click the pencil icon. Type the system name you wish to use; then, click the green check mark.

If you wish to change the front USB ownership, click the pencil icon and select the **Front USB Ownership** mode that you wish from the drop-down menu. Then, click the green check mark.

If your server has a license other than the XClarity Controller Enterprise license, you may be able to purchase a license upgrade to enable enhanced features. To install the upgrade license after you have obtained an upgrade license, click the upward-pointing arrow icon.

BMC License



To add, delete or export a license, click the rightward-pointing arrow icon.

BMC License

Lenovo XClarity Controller Enterprise Upgrade



To change the relevant settings for the BMC IP address, BMC host name, UEFI version, BMC version and location items, click the right-ward pointing arrow.

- For the IP address and host name, you will be led to the **Ethernet Configuration** section under **Network**.
- For the UEFI and BMC version items, you will be led to the **Firmware Update** page.
- For the location item, you will be led to the **Server Properties** section on the **Server Configuration** page.

BMC IP Address	10.243.1.28	→
BMC Hostname	XCC-7X03-1234567890	→
BMC Version	V1.00 (Build ID: CDI303V)	→
UEFI Version	V1.00 (Build ID: TEE103J)	→
LXPM Version	V2.00 (Build ID: PDL105C)	→
Location	1, Room 222, Rack B52, Lowest unit 0	→



Viewing the System Utilization

By clicking **Utilization** in the left pane, a summary of common server utilization information is provided.

System utilization is a composite metric based on the real-time utilization of processor, memory, and I/O subsystems. The utilization data are all coming from the ME(Node manager) side, which includes the following:

- **CPU Utilization**
 - Aggregated C-State Residency
 - Measured time in C0 as a percentage of the used and max C0 residency (per second).
- **Memory Utilization**
 - Aggregated R/W volume of all Memory Channels.
 - Measured bandwidth calculated as a percentage of the used and max memory bandwidth available (per second).
- **I/O Utilization**
 - Aggregated R/W volume of Root Ports in the PCIe* Bus.
 - Measured bandwidth calculated as a percentage of the used and max I/O bandwidth available (per second).

Viewing Event Logs

The **Event Log** provides a historical list of all hardware and management events.

Select the **Event Log** tab in **Events** to display the **Event Log** page. All events in the log are time stamped, using the XClarity Controller date and time settings. Some events also generate alerts when they occur, if they are configured to do so in **Alert Recipients**. You can sort and filter events in the event log.

The following is a description of the actions that can be performed in the **Event Log** page.

- **Customize table:** Select this action item to choose the type of information you wish to display in the table. A sequence number can be displayed to assist in determining the order of events when more than one event has the same timestamp.

Note: Some sequence numbers are used by internal BMC processes, so it is normal that there may be gaps in the sequence numbers when the events are sorted by sequence number.

- **Clear logs:** Select this action item to delete the event logs.
- **Refresh:** Select this action item to update the display with any event log entries that may have occurred since the page was last displayed.
- **Type:** Select which event types to show. The event types include the following:



Shows Error entries in the log



Shows Warning entries in the log



Shows Informational entries in the log

Click each icon to turn off or on the types of errors to be displayed. Clicking the icon successively will toggle between showing and not showing the events. A blue box surrounding the icon indicates that type of event will be displayed.

- **Source type filter:** Select an item from the drop-down menu to display only the type of event log entries that you wish to be shown.
- **Time filter:** Select this action item to specify the interval of the events that you want to show.
- **Search:** To search for specific types of events or keywords, click the magnifying glass icon, and type a word to search for in the **Search** box. Note that the input is case-sensitive.

Note: The maximum number of event log records is 1024. When the event logs are full, the new log entry will automatically overwrite the oldest one.

Viewing Audit Logs

The **Audit Log** provides a historical record of user actions, such as logging in to the XClarity Controller, creating a new user, and changing a user password.

You can use the audit log to track and document authentication, changes, and system actions.

Both the event log and the audit log support similar maintenance and viewing actions. To see the description of the display and filtering actions that can be performed on the Audit Log page, see [“Viewing Event Logs” on page 51](#).

Notes:

- After running Lenovo’s tools on your server operating system, the Audit Log may contain records showing actions performed by a username (for example user “20luN4SB”) that you may not recognize. When some of the tools are run on the server operating system, they may create a temporary user account for accessing the XClarity Controller. The account is created with a random username and password and can only be used to access the XClarity Controller on the internal Ethernet over USB interface. The account can only be used to access the XClarity Controller CIM-XML and SFTP interfaces. The creation and removal of this temporary account is recorded in the audit log as well any actions performed by the tool with these credentials.
- The maximum number of audit log records is 1024. When the audit logs are full, the new log entry will automatically overwrite the oldest one.

Viewing the Maintenance History

The **Maintenance History** page includes information about the firmware update, configuration and hardware replacement history.

The contents of the maintenance history can be filtered to display certain types of events or certain intervals of time.

Note: The maximum number of maintenance history records is 250. When the maintenance history logs are full, the new log entry will automatically overwrite the oldest one.

Configuring Alert Recipients

To add and modify email and syslog notifications or SNMP TRAP recipients, use the information in this topic.

The following is a description of the actions that can be performed in the **Alert Recipients** tab.

The following actions items can be performed in the **Email/Syslog** recipients section.

- **Create:** Select this action item to create additional new Email recipients and Syslog recipients. Up to 12 Email and Syslog recipients can be configured.
 - **Create Email Recipient:** Select this action item to create an Email recipient.
 - Enter the name and email address of the recipient.
 - Select to enable or disable the event notification. If disable is selected, the account will remain configured, but no emails will be sent.
 - Select the types of events that the recipient will be notified of. If you click the drop-down next to the Critical, Attention, or System category labels you can select or deselect notifications for specific components in the category.
 - You can choose whether or not to have the event log contents included in the email alert.
 - The index specifies which of the 12 recipient slots is assigned.
 - You can configure the email server to which the events will be forwarded here or by clicking the SMTP Server action at the top of the section. See SMTP Server below for configuration details.
 - **Create Syslog Recipient:** Select this action item to create syslog recipients.
 - Enter the name and IP address or host name of the Syslog server.

- Select to enable or disable the event notification. If disable is selected, the account will remain configured but no emails will be sent.
- The index specifies which of the 12 recipient slots is assigned.
- Select the types of events that will be sent to the Syslog server. If you click the drop-down menu next to the Critical, Attention, or System category labels you can select or deselect notifications for specific components in the category.
- **SMTP Server:** Select this action item to configure the relevant settings for the SMTP Email server. Only one email server can be configured. The same email configuration is used when sending alerts to all of the configured email recipients. The BMC automatically switch from an secure connection to an encrypted connection for mail transfer using the STARTTLS command uniformly via port 587, if the target mail server supports it.
 - Enter the host name or IP address and network port number of the Email server.
 - If the Email server requires authentication, select the **Require Authentication** check box and enter the username and password. Select the type of authentication that is required by the Email server, either a challenge-response method (**CRAM-MD5**) or simple credentials (**LOGIN**).
 - Some networks may block outgoing emails if the reverse path value is not as expected. By default, the XClarity Controller will use alertmgr@domain, where the domain is the Domain name as specified in the DDNS section of the XClarity Controller network web page. You can specify your own sender information in place of the default.
 - You can test the connection to the Email server to ensure that the email settings have been configured correctly. The XClarity Controller will display a message indicating whether or not the connection is successful.
- **Retry and Delay:** Select this action item to configure the relevant settings for the retry and delay options.
 - The retry limit specifies the number of times that the XClarity Controller will attempt to send an alert if the initial attempt did not succeed.
 - The delay between entries specifies the amount of time that the XClarity Controller will wait after sending an alert to one recipient before sending an alert to the next recipient.
 - The delay between attempts specifies the amount of time that the XClarity Controller will wait after a failed attempt before retrying to send the alert.
- **Protocol:** Select this action item to configure the relevant settings for connection protocol.
 - You can choose between **TCP Protocol** or **UDP Protocol**, please note that this setting will apply to all syslog recipients.
- If Email or Syslog Recipients have been created, they will be listed in this section.
 - To edit the settings for an Email or Syslog Recipient click the pencil icon below the action header on the row next of the recipient that you wish to configure.
 - To delete an Email or Syslog Recipient click the trash can icon.
 - To send a test alert to an Email or Syslog Recipient, click the paper airplane icon.

The following actions can be performed in the **SNMPv3** user segment.

- **Create:** Select this action item to create SNMPv3 TRAP recipients.
 - Select the user account that is to be associated with the SNMPv3 TRAPs. The user account must be one of the twelve local user accounts.
 - Specify the host name or IP address of the SNMPv3 manager that will receive the SNMPv3 TRAPs.
 - The XClarity Controller uses the HMAC-SHA hash algorithm to authenticate with the SNMPv3 manager. This is the only algorithm supported.
 - The privacy password is used with the privacy protocol to encrypt the SNMP data.

- The **SNMPv3 global setting** applies to all SNMPv3 TRAP recipients. These settings can be configured while creating an SNMPv3 TRAP recipient or by clicking the SNMPv3 Settings action at the top of the **SNMPv3** user segment.
 - Select to enable or disable SNMPv3 TRAPs. If disabled, the settings will remain configured but no SNMPv3 TRAPs will be sent.
 - The BMC Contact and Location information is required and is configured on the Server Properties web page. See [“Setting Location and Contact” on page 75](#) for more information.
 - Select the types of events that will be cause TRAPs to be sent to the SNMPv3 manager. If you click the drop-down menu next to the Critical, Attention, or System category labels you can select or deselect notifications for specific components in the category.

Note: Data transfer between the SNMP client and the agent can be protected using encryption. The supported methods for **privacy protocol** are CBC-DES and AES.

- If SNMPv3 TRAP recipients have been created, they will be listed in this section.
 - To edit the settings for a SNMPv3 recipient, click the pencil icon below the action header on the row next of the recipient that you wish to configure.
 - To delete a SNMPv3 recipient, click the trash can icon.

Capturing the latest OS failure screen data

Use the information in this topic to capture and view an operating system failure screen.

The operating system screen is automatically captured when the OS Watchdog timeout occurs. If an event occurs that causes the OS to stop running, the OS Watchdog feature is triggered and the screen contents are captured. The XClarity Controller stores only one screen capture. When the OS Watchdog timeout occurs, a new screen capture overwrites the previous screen capture. The OS Watchdog feature must be enabled to capture the OS failure screen. To set the OS Watchdog Time, see [“Setting server timeouts” on page 76](#) for more information. The OS failure screen capture feature is available only with the XClarity Controller Advanced or Enterprise Level of functionality. See the documentation for your server for information about the level of XClarity Controller functionality that is installed in your server.

Click the **Latest Failure Screen** action in the **Remote Console** section of the XClarity Controller home page to view an image of the operating system display that was captured when the OS Watchdog timeout occurred. The capture can also be viewed by clicking **Service**, then **Latest Failure Screen** in the **Quick Action** section of the home page. If the system has not experienced an OS Watchdog timeout and captured the OS screen, a message indicating that the failure screen has not been created is displayed.

Chapter 5. Configuring the Server

Use the information in this chapter to understand the options available for server configurations.

When configuring the server, the following options are available:

- Adapters
- Boot options
- Power policy
- Server properties
- Chassis

Note: This item is only available on D3 V2 Chassis compatible nodes.

Viewing the adapter information and configuration settings

Use the information in this topic to view information about the adapters installed in the server.

Click **Adapters** under **Server Configuration** to view information about the adapters installed in the server.

Notes:

- If the adapter does not support status monitoring, it will not be visible for monitoring or configuration. For inventory related information of all the installed PCI adapters, refer to the **Inventory** page.

Configuring system boot mode and order

To configure the system boot mode and order, use the information in this topic.

When you select **Boot Options** under **Server Configuration**, you can configure the system boot mode and order.

Note: No unauthenticated in-band method is allowed to change security related system settings. For example, Secure Boot must NOT be able to configure over unauthenticated in-band APIs from the OS or UEFI shell. This includes OneCLI running in-band and obtaining temporary credentials using IPMI, or any tools and APIs to configure Secure Boot, TPM, UEFI Setup password related settings. All security related settings must require proper authentication with sufficient privilege.

For the system boot mode, the following two options are available:

UEFI Boot

Select this option to configure a server that supports Unified Extensible Firmware Interface (UEFI). If you are booting UEFI-enabled operating systems, this option might shorten boot time by disabling legacy option ROMs.

Legacy Boot

Select this option if you are configuring a server to boot an operating system that requires legacy (BIOS) firmware. Select this option only if you are booting non-UEFI enabled operating systems.

To configure the system boot order, select a device from the list of **Available devices** and click the right arrow to add the device to the boot order. To remove a device from the boot order, select a device from the

boot order list and click the left arrow to move the device back to the list of available devices. To change the boot order, select a device and click the up or down arrow to move the device up or down in priority.

When you make a change to the boot order, you must select a restart option before applying the change. The following options are available:

- **Restart server immediately:** The boot order changes are saved and the server is restarted immediately without shutting down the operating system.
- **Restart server normally:** The boot order changes are saved and the operating system is shutdown before restarting the server.
- **Manually restart later:** The boot order changes will be saved, but will not take effect until the next time the server is rebooted.

Configuring one-time boot

To temporarily ignore the configured boot and instead boot to a specified device one time, use the information in this topic.

Click **Boot Options** under **Server Configuration** and select a device from the drop-down menu to configure the device that the system will boot to one-time on the next server restart. The following choices are available:

PXE network

Sets up your server to attempt a Preboot Execution Environment network boot.

Primary removable media

The server is booted from the default USB device.

Default CD/DVD

The server is booted from the default CD/DVD drive.

F1 system setup

The server is booted into the Lenovo XClarity Provisioning Manager.

Diagnostic Partition

The server is booted into the Diagnostics section of the Lenovo XClarity Provisioning Manager.

Default Hard Disk

The server is booted from the default disk drive.

Primary remote media

The server is booted from the mounted virtual media.

No one-time boot

The configured boot order is used. There is no one-time boot override of the configured boot order.

When you change the type of boot to be performed with the one-time boot device, you can also specify the boot to be a legacy boot or a UEFI boot. Click the **Prefer Legacy Boot** check box if you would like the boot to be a legacy BIOS boot. Uncheck the box if you would like a UEFI boot. When you select a one-time change to the boot order, you must select a restart option before applying the change.

- **Restart server immediately:** The boot order change is saved and the server is restarted immediately without shutting down the operating system.
- **Restart server normally:** The boot order change is saved and the operating system is shutdown before restarting the server.
- **Manually restart later:** The boot order change is saved, but will not take effect until the next time the server is rebooted.

Managing the server power

To view power management information and perform power management functions, use the information in this topic.

Select **Power Policy** under **Server Configuration** to view power management information and perform power management functions.

Note: In a chassis containing blade or high-density server nodes, the chassis cooling and power is controlled by the chassis management controller instead of the XClarity Controller.

Configuring the power redundancy

To configure the power redundancy, use the information in this topic.

Available fields in the Power Redundancy section include the following:

- **Redundant (N+N):** There are two or more independent power sources that are capable of supplying power to the system simultaneously. This means that if one or more power sources fails, the other source (s) can continue to supply power to the system without any interruption. N+N redundancy provides a high level of fault tolerance and ensures that the system remains operational even in the event of multiple failures.
 - **Zero Output Mode:** Once enabled under Redundant configuration, some PSUs will automatically enter into standby state under light load conditions. In this manner, the remaining PSU delivers the entire power load to increase efficiency.
- **Redundant (N+1):** There is one primary power source that is capable of supplying power to the system. Additionally, there is at least one backup power source that is available to take over if the primary source fails. The backup source is designed to provide enough power to keep the system running until the primary source can be repaired or replaced. N+1 redundancy provides a lower level of fault tolerance compared to N+N redundancy.
- **Non-redundant mode:** In this mode, the server is not guaranteed to remain operational if a power supply is lost. The server will throttle if a power supply fails in an attempt to remain running.

Click **Apply** after making the configuration changes.

Configuring the power capping policy

To configure the power capping policy, use the information in this topic.

You can choose to enable or disable the power capping function. If power capping is enabled, a selection can be made to limit the amount of power used by the server. If power capping is disabled, the maximum power used by the server is determined by the Power Redundancy policy. To change the setting, first click **Reset**. Choose your preferred setting; then, click **Apply**.

Power capping can be enabled using AC power consumption measurements or DC power consumption measurements. From the drop-down menu, select the type of measurements that will be used to determine the power capping limit. When switching between AC and DC, the number on the slider will change accordingly.

There are two ways to change the power capping value:

- **Method 1:** Move the slider mark to the desired wattage to set the overall server power limit.
- **Method 2:** Input the value in the input box. The slider mark will automatically move to the corresponding position.

Click **Apply** after making the configuration changes.

Note: The **Power Policies** option is not available when the XClarity Controller is in a chassis containing blade or high-density server nodes. The power policy is controlled by the chassis management controller instead of the XClarity Controller.

Configuring the power restore policy

To configure how the server reacts when the power is restored after a power loss, use the information in this topic.

When configuring the power restore policy, the following three options are available:

Always Off

The server will remain powered off even when power is restored.

Restore

The server will automatically be powered on when power is restored if the server was powered on at the time that the power failure occurred. Otherwise, the server power will remain off when power is restored.

Always On

The server will automatically power on when power is restored.

Click **Apply** after making the configuration changes.

Note: The **Power Restore Policies** option is not available in a chassis containing blade or high-density server nodes. The power restore policy is controlled by the chassis management controller instead of the XClarity Controller.

Power actions

See the information in this topic to understand the power actions that can be made to the server.

Click **Power Action** in the **Quick Action** section of the XClarity Controller homepage.

The following table contains a description of the power and restart actions that can be performed on the server.

Table 6. Power actions and descriptions

Two column table containing descriptions of the server power and restart actions.

Power Action	Description
Power on server	Select this action item to power on the server and boot the operating system.
Power off server normally	Select this action item to shut down the operating system and power off the server.
Power off server immediately	Select this action item to power off the server without first shutting down the operating system.
Restart server normally	Select this action item to shut down the operating system and power cycle the server.
Restart server immediately	Select this action item to power cycle the server immediately without first shutting down the operating system.

Table 6. Power actions and descriptions (continued)

Power Action	Description
Boot server to system setup	Select this item to power on or reboot the server and automatically boot into system setup without needing to press F1 during boot.
Trigger non-maskable interrupt (NMI)	Select this action item to force a Non-maskable Interrupt (NMI) on a “hung” system. Selection of this action item allows the platform operating system to perform a memory dump that can be used for debug purposes of the system hang condition. The auto reboot on NMI setting from the F1 system setup menu determines whether or not the XClarity Controller will reboot the server after the NMI.
Schedule power actions	Select this action item to schedule daily and weekly power and restart actions for the server.
Restart management controller	Select this action item to restart the XClarity Controller
AC Power Cycle Server	Select this action to power cycle the server.
<p>Note: If the operating system is in the screen saver or locked mode when a shutdown of the operating system is attempted, the XClarity Controller might not be able to initiate a normal shutdown. The XClarity Controller will perform a hard reset or shutdown after the power off delay interval expires, while the operating system might still be running.</p> <p>Note: If the power LED on the front panel is rapidly blinking, the XClarity Controller may not be able to initiate a normal power-on sequence. The XClarity Controller can power on the system once the power LED begins to blink slowly.</p>	

Managing and monitoring power consumption with IPMI commands

Use the information in this topic to manage and monitor power consumption using IPMI commands.

This topic describes how the Intel Intelligent Power Node Manager and the Data Center Manageability Interface (DCMI) can be used to provide power and thermal monitoring and policy-based power management for a server using Intelligent Platform Management Interface (IPMI) power management commands.

For servers using Intel Node Manager SPS 3.0, XClarity Controller users can use IPMI power management commands provided by Intel’s Management Engine (ME) to control the Node Manager features and to monitor server power consumption. Server power management can also be accomplished using DCMI power management commands. Example Node Manager and DCMI power management commands are provided in this topic.

Managing the server power using Node Manager commands

Use the information in this topic to manage the server power using the Node Manager.

The Intel Node Manager firmware does not have an external interface; therefore, the Node Manager commands must first be received by the XClarity Controller and then sent to the Intel Node Manager. The XClarity Controller functions as a relay and a transport device for the IPMI commands using standard IPMI bridging.

Note: Changing Node manager policies using Node Manager IPMI commands might create conflicts with the XClarity Controller power management functionality. By default, bridging of the Node Manager commands is disabled to prevent any conflict.

For users who want to manage the server power using the Node Manager instead of the XClarity Controller, an OEM IPMI command consisting of (network function: **0x3A**) and (command: **0xC7**) is available for use.

To enable native Node Manager IPMI commands type: `ipmitool -H <$XClarity_Controller_IP> -U <USERID> -P <PASSWORD> raw 0x3a 0xc7 0x01`

To disable native Node Manager IPMI commands type: `ipmitool -H <$XClarity_Controller_IP> -U <USERID> -P <PASSWORD> raw 0x3a 0xc7 0x00`

The following information are examples of Node Manager power management commands.

Notes:

- By specifying IPMI **channel 0** and a target address of **0x2c**, you can use the IPMITOOL to send commands to the Intel Node Manager for processing. A request message is used to initiate an action and a response message is returned to the requester.
- Commands are displayed in the following format due to space limitations.

Power monitoring using the Get Global System Power Statistics, (command code 0xC8): Request: `ipmitool -H <$XClarity_Controller_IP> -U <USERID> -P <PASSWORD> -b 0x00 -t 0x2c raw 0x2E 0xC8 0x57 0x01 0x00 0x01 0x00 0x00` Response: 57 01 00 38 00 04 00 41 00 39 00 ec 56 f7 53 5a 86 00 00 50

Power capping using the Set Intel Node Manager Policy, (command code 0xC1): Request: `ipmitool -H <$XClarity_Controller_IP> -U <USERID> -P <PASSWORD> -b 0x00 -t 0x2c raw 0x2e 0xC1 0x57 0x01 0x00 0x10 0x01 0xA0 0x00 0x00 0x00 0x60 0xea 0x00 0x00 0x00 0x00 0x1e 0x00` Response: 57 01 00

Power savings using the Set Intel Node Manager Policy, (command code 0xC1): Request: `ipmitool -H <$XClarity_Controller_IP> -U <USERID> -P <PASSWORD> -b 0x00 -t 0x2c raw 0x2e 0xC1 0x57 0x01 0x00 0x10 0x01 0x00 0x00 0x00 0x00 0x60 0xea 0x00 0x00 0x00 0x00 0x1e 0x00`

Get device ID function using the Get Intel Management Engine Device ID: Request: `ipmitool -H <$XClarity_Controller_IP> -U <USERID> -P <PASSWORD> -b 0x00 -t 0x2c raw 0x06 0x01` Response: 50 01 03 05 02 21 57 01 00 05 0b 03 40 20 01

For additional Intel Node Manager commands, see the latest release of the **Intel Intelligent Power Node Manager External Interface Specification Using IPMI** at <https://businessportal.intel.com>.

Managing the server power using DCMI commands

Use the information in this topic to manage the server power using DCMI commands.

The DCMI provides monitoring and control functions that can be exposed through standard management software interfaces. Server power management functions can also be accomplished using DCMI commands.

The following information are examples of commonly used DCMI power management functions and commands. A request message is used to initiate an action and a response message is returned to the requester.

Note: Commands are displayed in the following formats due to space limitations.

Get Power Reading: Request: `ipmitool -H <$XClarity_Controller_IP> -U <USERID> -P <PASSWORD> raw 0x2c 0x02 0xdc 0x01 0x00 0x00` Response: dc 39 00 38 00 3b 00 39 00 e3 6f 0a 39 e8 03 00 00 40

Set Power Limit: Request: `ipmitool -H <$XClarity_Controller_IP> -U <USERID> -P <PASSWORD> raw 0x2c 0x04 0xdc 0x00 0x00 0x00 0x00 0xA0 0x00 0xe8 0x03 0x00 0x00 0x00 0x00 0xe8 0x03` Response: dc

Get Power Cap: Request:ipmitool -H <\$XClarity_Controller_IP> -U <USERID> -P <PASSWORD> raw 0x2c 0x03 0xdc 0x00 0x00 Response:dc 00 00 00 a0 00 e8 03 00 00 00 00 01 00

Activate the Power Limit: Request:ipmitool -H <\$XClarity_Controller_IP> -U <USERID> -P <PASSWORD> raw 0x2c 0x05 0xdc 0x01 0x00 0x00 Response:dc

Deactivate the Power Limit: Request:ipmitool -H <\$XClarity_Controller_IP> -U <USERID> -P <PASSWORD> raw 0x2c 0x05 0xdc 0x00 0x00 0x00 Response:dc

Note: On some servers, the Exception Actions for the **Set Power Limit** command might not be supported. For example, the **Hard Power Off system and log events to SEL** parameter might not be supported.

For the complete list of commands that are supported by the DCMI specification, see the latest release of the **Data Center Manageability Interface Specification** at <https://www.intel.com/content/dam/www/public/us/en/documents/technical-specifications/dcmi-v1-5-rev-spec.pdf>.

Remote Console Functionality

Use the information in this topic to understand how to remotely view and interact with the server console.

You can use the remote console functionality in the XClarity Controller web interface to view and interact with the server console. You can assign a disk image (ISO or IMG file) as a virtual drive on the server. The remote console functionality is available with the XClarity Controller Advanced and XClarity Controller Enterprise features and is only available through the web interface. You must log in to the XClarity Controller with a user ID that has Supervisor access or Remote Console Access privileges to use the remote console features. For more information about upgrading from XClarity Controller Standard to XClarity Controller Advanced or XClarity Controller Enterprise, see “[Upgrading XClarity Controller](#)” on page 6.

Use the remote console features to do the following:

- Remotely view video with graphic resolution up to 1280 x 1024 at 72 or 75Hz, regardless of the server state.
- Remotely access the server using the keyboard and mouse from a remote client.
- Mount ISO and IMG files that are located on your local system or on a remote system as virtual drives that are available for use by the server.
- Upload an IMG or ISO image to the XClarity Controller memory and mount it to the server as a virtual drive. Up to two files with a maximum total size of 50 MB may be uploaded into the XClarity Controller memory.

Notes:

- When the remote console feature is started in multi-user mode, (the XClarity Controller with the XClarity Controller Enterprise feature set supports up to six simultaneous sessions), the remote disk feature can be exercised by only one session at a time.
- The remote console is able to display only the video that is generated by the video controller on the system board. If a separate video controller adapter is installed and is used in place of the system's video controller, the XClarity Controller remote console cannot display the video content from the added adapter.
- If you have firewalls in your network, a network port must be opened to support the remote console feature. To view or change the network port number used by the remote console feature, see “[Service Enablement and Port Assignment](#)” on page 33.
- The remote console feature uses HTML5 for displaying the server video on web pages. To use this feature your browser must support displaying video content using HTML5 elements.

- If you are using self-signed certificates and an IPv6 address to access the BMC with the Internet Explorer browser, the remote console session may fail to start due to a certificate error. To avoid this issue, the self-signed certificate can be added to the Internet Explorer Trust Root certificate Authorities:
 - Select **Security** under **BMC Configuration** and download the self-signed certificate.
 - Change certificate file extension to *.crt and double-click the Web certificate file.
 - Clear IE11 browser cache.
 - Click **Install Certificate** to install the certificate to the Certificate Store by following the Certificate Import Wizard steps.

Enabling the remote console functionality

This topic provides information about the remote console functionality.

As mentioned earlier, the XClarity Controller remote console functionality is available only in the XClarity Controller Advanced and XClarity Controller Enterprise features. If you do not have the privilege to operate the remote console, you will see a lock icon.

After you have purchased and obtained the activation key for the XClarity Controller Advanced upgrade install it using the instructions under [“Installing an activation key” on page 85](#).

To use the remote console functionality, complete the following steps:

1. Click the image with a white diagonally pointing arrow in the Remote Console section of the XClarity Controller homepage or the Remote Console web page.
2. Select one of the following modes:
 - Start remote console in single-user mode
 - Start remote console in multiuser mode

Note: The XClarity Controller with XClarity Controller Enterprise feature set supports up to six simultaneous video sessions in the multiuser mode.

3. Select whether or not to allow others to request to send a disconnection request to a remote console user when someone wishes to use the remote console feature and the feature is already in use in Single User Mode, or when the maximum number of users are using the remote console feature in Multi User Mode. The **No response time interval** specifies how long the XClarity Controller will wait before automatically disconnecting the user if no response is received to the disconnection request.
4. Select whether or not to allow record the latest three server boot videos.
5. Select whether or not to allow record the latest three server crash videos.
6. Select whether or not to allow OS failure screen capture with HW error.
7. Click **Launch Remote Console** to open the remote console page in another tab. When all possible remote console sessions are in use, a dialog box will pop up. From this dialog box, the user can send a disconnection request to a remote console user who has enabled the setting to **Allow others to request my remote session disconnect**. The user can accept or deny the request to disconnect. If the user does not respond within the interval specified by the **No response time interval** setting, the user session will automatically be ended by the XClarity Controller.

Remote power control

This topic explains how to send server power and restart commands from the remote console window.

You can send server power and restart commands from the remote console window without returning to the main web page. To control the server power with the remote console, click **Power** and select one of the following commands:

Power On Server

Select this action item to power on the server and boot the operating system.

Power Off Server Normally

Select this action item to shut down the operating system and power off the server.

Power Off Server Immediately

Select this action item to power off the server without first shutting down the operating system.

Restart Server Normally

Select this action item to shut down the operating system and power cycle the server.

Restart Server Immediately

Select this action item to power cycle the server immediately without first shutting down the operating system.

Boot Server to System Setup

Select this item to power on or reboot the server and automatically boot into system setup without needing to press F1 during boot.

Remote console capture screen

Use the information in this topic to understand how to use the remote console screen capture feature.

The screen capture feature in the remote console window captures the video display contents of the server. To capture and save a screen image, complete the following steps:

Step 1. In the remote console window, click **Capture Screen**.

Step 2. In the pop-up window, click **Save File** and press **OK**. The file will be named `rpviewer.png` and will be saved to your default download folder.

Note: The screen capture image is saved as a PNG file type.

Remote console keyboard support

In the remote console window under **Keyboard**, the following option items are provided:

- Click **Virtual Keyboard** to launch the virtual keyboard. This feature is useful if you are using a tablet device that does not have a physical keyboard. The following options can be used to create macros and key combinations that can be sent to the server. The operating system on the client system that you are using may trap certain key combinations (for example Ctrl+Alt+Del) instead of transmitting them to the server. Other keys, such as F1 or Esc, may be intercepted by the program or browser that you are using. Macros provides a mechanism to send keystrokes to the server that the user might not be able to send.
- Click **Server Macros** to use server defined macros. Some server macros are predefined by the XClarity Controller firmware. Other server defined macros can be defined using Lenovo XClarity Essentials and downloaded from the XClarity Controller. These macros are defined for all users of the remote console feature.
- Click **Configure** to add or remove user defined macros. The user defined macros are defined only for the current remote console user. Other remote console users will not see each other's user defined macros.
 - Click the Add Macros icon and press the key sequences that you desire; then, click **Add** to add a new macro.
 - To remove a user defined macro, select the macro from the list and click the trash can icon.
 - To send a user defined macro to the server select the **User Defined Macros** option, and click on the macro that you want to send.

Remote console mouse support

Use this information to understand the options for remote mouse control.

The remote console window offers several options for mouse control, including absolute mouse control, relative mouse control (no acceleration), and mouse control (RHEL, older Linux).

Absolute and relative mouse control

Use this information to access the absolute and relative options for controlling the mouse.

To access the absolute and relative options for controlling the mouse, complete the following steps:

- Step 1. In the remote console window, click **Mouse**.
- Step 2. Click **Mouse Settings** from the drop-down menu.
- Step 3. Select one of the following **Mouse Acceleration** modes:

Absolute Positioning (Windows, Newer Linux & Mac OS X)

The client sends mouse location messages to the server that are relative to the origin (upper left area) of the viewing area.

Relative Positioning, no acceleration

The client sends the mouse location as an offset from the previous mouse position.

Relative Positioning (older Linux)

This mode applies an acceleration factor to align the mouse better on some Linux targets. The acceleration settings have been selected to maximize compatibility with older Linux distributions.

Screen Video Record/Replay

Use the information in this topic to record or replay remote presence screen videos.

The XClarity Controller web interface provides a DVR-like feature to support recording and playback remote presence screen videos. This function only supports video recording to a network folder. Currently, NFS and CIFS protocols are supported. Below are the steps in using the record and replay function.

1. On the remote console web page, click **Screen Recording** to open the settings window.
2. In the settings window, the following information may need to be specified.
 - If the “CIFS” mount type is selected, specify the **Remote Folder**, **User Name**, and **Password** parameters. The format for the CIFS remote folder is “//<remote IP address>/<folder name>”. For example: //xxx.xxx.xxx.xxx/folder.
 - If the “NFS” mount type is selected, specify the **Remote Folder** parameter. The format for the NFS remote folder is “<remote IP address>:/<folder name>”. For example: xxx.xxx.xxx.xxx:/folder.
 - Specify the video file name if necessary. If a file name has already been provided, an error message box will shown. To overwrite the existing file name, choose “Overwrite File Name”. If the “Auto” box is ticked, the video file name will be automatically generated.
 - “Max File Size” denotes the maximum video file size before the video recording will automatically stop.
 - “Max Recording Duration” denotes the maximum video recording duration before the recording will automatically stop.
3. Click **Start Recording** to start the video recording.
4. Click **Stop Recording** to stop the video recording. A popup window saying “Video Recording Completed” will appear, showing relevant video recording information.

5. Download the recorded videos from NFS or CIFS to your local folder. In the Remote Console Preview section of the XClarity Controller homepage, click **Recorded Videos** and select the video file to replay.

Remote console screen modes

Use the information in this topic to configure the remote console screen modes.

To configure the remote console screen modes, click **Screen Mode**.

The following menu options are available:

Full Screen

This mode fills the client desktop with the video display. Pressing the Esc key in this mode will exit full screen mode. Because the remote console menu is not visible in full screen mode, you will have to exit full screen mode to use any of the features provided by the remote console menu such as the keyboard macros.

Fit Screen

This is the default setting when the remote console is launched. In this setting, the target desktop is completely displayed without scroll bars. The aspect ratio is maintained.

Scaling Screen

With scaling enabled, the video image is sized so that the complete image is scaled to fill the console window.

Origin Screen

The video image has the same dimensions as the server end. Scroll bars are displayed if needed to allow viewing of video image areas that do not fit within the window.

Color Mode

Adjusts the color depth of the remote console window. There are two color-mode choices:

- Color: 7, 9, 12, 15, and 23 bit
- Grayscale: 16, 32, 64, and 128 shades

Note: Color mode adjustments are usually made if your connection to the remote server has limited bandwidth and you wish to reduce the bandwidth demand.

Media mount methods

Use the information in this topic to understand how to perform media mounts.

Three mechanisms are provided to mount ISO and IMG files as virtual drives.

- Virtual drives can be added to the server from the remote console session by clicking **Media**.
- Directly from the remote console web page, without establishing a remote console session.
- Standalone tool

Users need **Remote Console and Remote Disk Access** privileges to use the virtual media features.

Files can be mounted as virtual media from your local system or from a remote server, and can be accessed over the network or uploaded into the XClarity Controller memory using the RDOC feature. These mechanisms are described below.

- Local media are ISO or IMG files that are located on the system that you are using to access the XClarity Controller. This mechanism is only available through the remote console session, not directly from the

remote console web page and is only available with the XClarity Controller Enterprise features. To mount local media, click **Activate** in the **Mount Local Media** section. Up to four files can be concurrently mounted to the server.

Notes:

- When using the Google Chrome browser, an additional mounting option called **Mount files/folders** is available to let you drag and drop the file(s)/folder.
- If multiple concurrent remote console sessions are in progress with an XClarity Controller, this feature can be activated only by one of the sessions.
- Files that are located on a remote system can also be mounted as virtual media. Up to four files can be concurrently mounted as virtual drives. The XClarity Controller supports the following file sharing protocols:

- **CIFS - Common Internet File System:**

- Enter the URL that locates the file on the remote system.
- If you want the file to be presented to the server as read-only virtual media, tick the check box.
- Enter the credentials that are needed for the XClarity Controller to access the file on the remote system.

Note: The XClarity Controller does not support spaces in the user name, password, or URL. Make sure that the CIFS server does not have login credentials configured with a space in the user name or password and that the URL does not contain a space.

- Mount options are optional and defined by the CIFS protocol.
- If the remote server belongs to a collection of servers, where the security is centrally handled, enter the domain name to which the remote server belongs.

- **NFS - Network File System:**

- Enter the URL that locates the file on the remote system.
- If you want the file to be presented to the server as read-only virtual media, tick the checkbox.
- Mount options are optional and defined by the NFS protocol. Both NFSv3 and NFSv4 are supported. For example, to use NFSv3, you need to specify option 'nfsvers=3'. If the NFS server uses AUTH_SYS security flavor to authenticate NFS operations, you need to specify option 'sec=sys'.

- **HTTPFS - HTTP Fuse-based File System:**

- Enter the URL that locates the file on the remote system
- If you want the file to be presented to the server as read-only virtual media, tick the check box.

Note: Errors may occur during the mounting process for security certificates generated by Microsoft IIS. If this occurs, see [“Media mount error issues” on page 73](#).

Click **Mount all remote media** to mount the file as virtual media. To remove virtual media, click the trash can icon to the right of the mounted media.

- Up to two files can be uploaded in the XClarity Controller memory and mounted as virtual media using the XClarity Controller RDOC feature. The total size for both files must not exceed 50 MB. These files will remain in the XClarity Controller memory until they are removed, even if the remote console session has ended. The RDOC feature supports the following mechanisms when uploading the files:
 - **CIFS - Common Internet File System:** See the description above for details.

Example:

To mount an ISO file named account_backup.iso that is located on the backup_2016 directory of a CIFS server at the 192.168.0.100 IP address as a read-only virtual drive on the server, you would fill in

the fields as shown in the figure below. In this example, the server located at 192.168.0.100 is a member of a collection of servers under the domain “accounting”. The domain name is optional. If your CIFS server is not part of a domain, leave the **Domain** field blank. The CIFS “nocase” mount option is specified in the **Mount Options** field in this example indicating to the CIFS server that the uppercase/lowercase checking of the file name should be ignored. The **Mount Options** field is optional. The information entered by the user in this field is not used by the BMC and is simply passed on to the CIFS server when the mount request is made. Refer to the documentation for your CIFS server implementation to determine which options are supported by your CIFS server.

The BMC provides guidance when specifying the URL. If the URL being entered is not valid, the mount button will be greyed out and red text will be displayed under the URL field showing the expected format for the URL.

URL address in the form of //ipaddress/path/to/file or //domain-name/path/to/file. The domain-name can be alphanumeric characters, '.', '-' or '_'. It must contain at least two domain items.

- **NFS - Network File System:** See the description above for details.

Example:

To mount an ISO file named US_team.iso that is located on the “personnel” directory of an NFS server at the 10.243.28.77 IP address as a read-only virtual drive on the server, you would fill in the fields as shown in the figure below. The NFS “port=2049” mount option specifies that network port 2049 should be used to transfer the data. The **Mount Options** field is optional. The information entered by the user in this field is passed on to the NFS server when the mount request is made. Refer to the documentation for your NFS server implementation to determine which options are supported by your NFS server.

The BMC provides guidance when specifying the URL. If the URL being entered is not valid, the mount button will be greyed out and red text will be displayed under the URL field showing the expected format for the URL.

URL address in the form of ipaddress:/path/to/file or domain-name:/path/to/file. The domain-name can be alphanumeric characters, '.', '-' or '_'. It must contain at least two domain items.

– **HTTPS – Hypertext Transfer Protocol Secure:**

- Enter the URL that locates the file on the remote system.
- If you want the file to be presented to the server as read-only virtual media, tick the check box.
- Enter the credentials that are needed for the XClarity Controller to access the file on the remote system.

Notes:

- Errors may occur during the mounting process for security certificates generated by Microsoft IIS. If this occurs, see [“Media mount error issues” on page 73](#).
- The XClarity Controller does not support spaces in the user name, password, or URL. Make sure that the CIFS server does not have login credentials configured with a space in the user name or password and that the URL does not contain a space. **Example:**

To mount an ISO file named EthernetDrivers.ISO that is located on the “newdrivers” directory of a HTTPS server with the domain name “mycompany.com” using network port 8080 as a read-only virtual drive on the server, you would fill in the fields as shown in the figure below.

The screenshot shows a web interface titled "Remote Disc On Card (RDOC): 0 uploaded (50 MB available)". Below the title is a small instruction: "Upload an ISO or IMG image file to the BMC, then mount it to the host as a DVD or USB drive. The BMC storage space is restricted to 50 MB in total." A note below that says: "Note: The client session could be closed without affecting the mounted media." The main form has a dropdown menu set to "HTTPS". The "Input URL:" field contains "HTTPS://mycompany.com:8080/newdrivers/EthernetDrivers.ISO". There is a checked "Read-only" checkbox. The "User Name:" field contains "test" and the "Password:" field contains a masked password "*****". At the bottom of the form is a blue button labeled "Mount all RDOC files".

The BMC provides guidance when specifying the URL. If the URL being entered is not valid, the mount button will be greyed out and red text will be displayed under the URL field showing the expected format for the URL.

URL address in the form of https://ipaddress[:port]/path/to/file or HTTPS://domain-name[:port]/path/to/file. The domain-name can be alphanumeric characters, '.', '-' or '_'. It must contain at least two domain items. The port number is optional

– **SFTP – SSH File Transfer Protocol**

- Enter the URL that locates the file on the remote system.
- If you want the file to be presented to the server as read-only virtual media, tick the checkbox.
- Enter the credentials that are need to for the XClarity Controller to access the file on the remote system.

Notes:

- The XClarity Controller does not support spaces in the user name, password, or URL. Make sure that the CIFS server does not have login credentials configured with a space in the user name or password and that the URL does not contain a space.

- When the XClarity Controller connects to a HTTPS server, a pop-up window will appear showing information of the security certificate used by the HTTPS sever. The XClarity Controller is unable to verify the authentic of the security certificate.
- **LOCAL - Common Internet File System:**
 - Browse your system for the ISO or IMG file that you want to mount.
 - If you want the file to be presented to the server as read-only virtual media, check the check box.

Click **Mount all RDOC files** to mount the file as virtual media. To remove the virtual media, click the trash can icon to the right of the mounted media.

Standalone tool

For users that require mounting of the devices or images(.iso / .img) using the XClarity Controller, users can use the rdmount standalone code part of the OneCLI package. Specifically, rdmount will open a connection to XClarity Controller and will mount the device or images to the host.

rdmount has the following syntax:

```
rdmount -s ip_address -d <iso or device path> -l <userid> -p <password> -w port (443)
```

Example to mount an iso file:

```
$sudo ./rdmount -s 10.243.11.212 -d /home/user/temp/SLE-15-Installer-DVD-x86_64-RC2-DVD1.iso -l userid -p password -w 443
```

Remote disk using Java client

This sections describe how to mount local media using Java client.

You can use Java client to assign the server to a CD or DVD drive, a diskette drive, or USB flash drive that is on your computer, or you can specify a disk image on your computer for the server to use. You can use the drive for functions such as restarting (booting) the server, updating code, installing new software on the server, and installing or updating the operating system on the server. Drives and disk images are displayed as USB drives on the server.

Notes: The Remote Console Java supports one of the following Java environment, and it can be opened only if the HTML5 client is not running.

1. Oracle Java Runtime Environment 1.8/Java SE 8 or newer versions
2. OpenJDK 8. Distribution of AdoptOpenJDK with HotSpot JVM is supported.

If you use AdoptOpenJDK, you must use <https://openwebstart.com/> under OSX, Windows, and Linux.

Creating an image file

To create a new image file from a specified source folder, complete the following steps:

1. Click the **Create Image** option under the **Virtual Media** tab in the Virtual Media Java Client window. The Create Image from Folder window is displayed.
2. Click the **Browse** button associated with the **Source Folder** field to select the specific source folder.
3. Click the **Browse** button associated with the **New Image File** field to select the image file to use.
4. Click the **Create Image** button.




Figure 1. Creating an image file

Selecting devices to mount

To mount local image, folder and CD/DVD/USB drive, complete the following steps:

Click the **Select Devices to Mount** option under the **Virtual Media** tab in the Virtual Media Java Client window. The Select Devices to Mount window is displayed.




Figure 2. Select Devices to Mount Window

You can mount local image, folder and CD/DVD/USB drive by performing the following steps:

- **Mount Local Image:**
 1. Click the **Add Image** button to select the image you want to mount.
 2. Check the **Mapped** option.

3. Check the **Read Only** option to enable the function if needed.
4. Click the **Mount Selected** button and you can mount the local image successfully.




Figure 3. Mount Local Image

- **Mount Local Folder:**

1. Click the **Map Folder** button to select the local folder you want to mount.
2. Click the **Mount Selected** button and you can mount the local folder successfully.





Figure 4. Mount Local Folder

- **Mount CD/DVD or USB Drive:**

1. Click the **Scan Drives** button to detect plugged CD/DVD or USB Drive.
2. Check the **Mapped** option.
3. Check the **Read Only** option to enable the function if needed.
4. Click the **Mount Selected** button and you can mount the local image successfully.




Figure 5. Mount CD/DVD or USB Drive

The Select Devices to Mount window contains a list of the current local devices that are available for mounting. This window contains the following fields and buttons:

- The **Mapped** field contains the check box that allows you to select the devices to mount or map.
- The **Read Only** field contains the check box that allows you to select the mapped or mounted devices that will be **read-only** on the host server.
- The **Drive** field contains the device path on the local machine.
- Click the **Close** button to close the Select Devices to Mount window.
- Click the **Add Image** button to browse for the diskette image and ISO image file in your local file system that you want to add to the list of devices.
- Click the **Remove Image** button to remove an image that has been added to the list of devices.
- Click the **Mount Selected** button to mount or map all devices that are checked for mounting or mapping in the **Mapped** field.

Note: The folder will be mounted as read-only.

- Click the **Scan Drives** button to refresh the list of local devices.

Selecting devices to unmount

To unmount the host server devices, complete the following steps:

1. Click the **Unmount All** option under the **Virtual Media** tab in the Virtual Media Java Client window.
2. After selecting the **Unmount All** option you are presented with an Unmount All confirmation window. If you accept, **all** host server devices on the server are unmounted.

Note: You cannot unmount drives individually.




Figure 6. Unmount All

Media mount error issues

Use the information in this topic to troubleshoot media mount error issues.

When using security certificates generated by Microsoft IIS, you may encounter errors during the mounting process. If this occurs, replace the security certificate with a new one generated by openssl. Specifically, the newly generated pfx file is loaded into the Microsoft IIS server.

Below is an example showing how the new security certificate is generated via openssl in the Linux operating system.

```
$ openssl
OpenSSL>

$ openssl genrsa 1024 > server.key
Generating RSA private key, 1024 bit long modulus
.....+++++
.....+++++
e is 65537 (0x10001)

$ openssl req -new -key server.key > server.csr
You are about to be asked to enter information that will be incorporated
into your certificate request.
What you are about to enter is what is called a Distinguished Name or a DN.
There are quite a few fields but you can leave some blank
For some fields there will be a default value,
If you enter '.', the field will be left blank.
-----
Country Name (2 letter code) [AU]:CN
State or Province Name (full name) [Some-State]:BJ
Locality Name (eg, city) []:HD
Organization Name (eg, company) [Internet Widgits Pty Ltd]:Lenovo
Organizational Unit Name (eg, section) []:Lenovo
Common Name (e.g. server FQDN or YOUR name) []:10.245.18.66
Email Address []:test@test.com

Please enter the following 'extra' attributes
to be sent with your certificate request
A challenge password []:
An optional company name []:LNV

$ ls
server.csr  server.key

$ openssl req -x509 -days 3650 -key server.key -in server.csr > server.crt
You are about to be asked to enter information that will be incorporated
into your certificate request.
What you are about to enter is what is called a Distinguished Name or a DN.
There are quite a few fields but you can leave some blank
For some fields there will be a default value,
If you enter '.', the field will be left blank.
-----
Country Name (2 letter code) [AU]:CN
State or Province Name (full name) [Some-State]:BJ
Locality Name (eg, city) []:BJ
Organization Name (eg, company) [Internet Widgits Pty Ltd]:LNV
Organizational Unit Name (eg, section) []:LNV
Common Name (e.g. server FQDN or YOUR name) []:10.245.18.66
Email Address []:test@test.com

$ ls
server.crt  server.csr  server.key

$ openssl pkcs12 -export -out server.pfx -inkey server.key -in server.crt
Enter Export Password:
Verifying - Enter Export Password:

$ ls
server.crt  server.csr  server.key  server.pfx
```


Exiting the remote console session

This topic explains how to end your remote console session.

To exit your remote console session, close the remote console and the virtual media session windows.

Downloading service data

Use the information in this topic to collect service information about your server. This process is normally only done at the request of service personnel to assist in resolving a server problem.

In the XClarity Controller home page, click the **Service** option in the **Quick Action** section and select **Download Service Data**. Click **OK** to download the service data.

The process of collecting the service and support data takes a few minutes to generate the service data. The file will be saved to your default download folder. The naming convention for the service data file follows this convention: <machine type and model>_<serial number>_xcc_<date>-<time>.tgz

For example: 7X2106Z01A_2345678_xcc_170511-175656.tgz.

In addition to the tgz format, the service data can also be downloaded using the tzz format. Tzz uses a different compression algorithm and can be extracted with a utility such as “lzop”.

Server Properties

Use the information in this topic to change or view relevant server properties.

Setting Location and Contact

Use the information in this topic to set various parameters to help identify the system for operations and support personnel.

Select **Server Properties** under **Server Configuration**, to configure the **Location and Contact** information.

Contact

Allows you to specify the name and phone number of the person who should be contacted if the system experiences a problem.

Note: This field is the same as the Contact field in the SNMPv3 configuration and is required to enable SNMPv3.

Rack Name

Allows you to locate the server more easily by specifying which rack it is in.

Note: The field is optional and is not configurable in a Flex node.

Room Number

Allows you to locate the server more easily by specifying which room it is in.

Building

Allows you to locate the server more easily by specifying which building it is in.

Lowest U

Allows you to locate the server more easily by specifying the position in the rack.

Note: The field is optional and is not configurable in a Flex node.

Address

Allows you to specify the full postal address where the server is located.

Note: When the relevant information has been inputted, it will appear as a single line in the **Location** field in the SNMPv3 section and XClarity Controller home page.

Setting server timeouts

Use the information in this topic to set timeouts for the server.

These timeouts are used to restore operation to a server that has hung.

Select **Server Properties** under **Server Configuration**, to configure the server timeouts. The following server timeout selections are provided:

OS Watchdog

The OS watchdog is used to monitor the operating system to ensure that it is not hung. The Ethernet over USB interface must be enabled for this feature. See [“Configuring Ethernet over USB” on page 32](#) for details. The XClarity Controller contacts the operating system at an interval configured in the **OS Watchdog Time** selection. If the operating system does not respond before it is time for the next check, the XClarity Controller assumes that the operating system has hung. The XClarity Controller will capture the contents of the server display and then reboot the server in an attempt to restore operation. The XClarity Controller will reboot the server only once. If the operating system continues to hang after the reboot, instead of continually rebooting the server, the server will be left in the hung state so that the problem can be investigated and corrected. To rearm the OS watchdog, power the server off and back on. To enable the OS watchdog, select an interval from the OS Watchdog Time drop-down and click **Apply**. To disable the OS watchdog, select **None** on the OS Watchdog Time drop-down menu.

Loader Watchdog

The loader watchdog monitors the interval between the completion of POST and when the operating system begins running. The Ethernet over USB interface must be enabled for this feature. See [“Configuring Ethernet over USB” on page 32](#) for details. When POST is completed, the XClarity Controller starts a timer and begins to contact the operating system. If the operating system does not respond with the time configured in the Loader Watchdog selection, the XClarity Controller assumes that the operating system boot has hung. The XClarity Controller will then reboot the server in an attempt to restore operation. The XClarity Controller will reboot the server only once. If the operating system boot continues to hang after the reboot, instead of continually rebooting the server, the server will be left in the hung state so that the problem can be investigated and corrected. The loader watchdog is rearmed when server is switched off and back on or when the server successfully boots into the operating system. To enable the loader watchdog, select an interval from the Loader Watchdog drop-down and click **Apply**. To disable the loader watchdog select **None** on the Loader Watchdog drop-down.

Enable Power Off Delay

Use the Power Off Delay field to specify the number of minutes that the XClarity Controller subsystem will wait for the operating system to shutdown before forcing power off. To set the power off delay timeout value, select time interval from the drop-down and click **Apply**. To disable the XClarity Controller from forcing power off, select **None** from the drop-down selection.

Trespass message

To create a message that is displayed when a user logs in to the XClarity Controller, use the information in this topic.

Select **Server Properties** under **Server Configuration**. Use the **Trespass Message** option to configure a message that you want displayed to the user. When you are finished, click **Apply**.

The message text will be displayed in the Message area of the XClarity Controller login page when a user logs in.

Setting the XClarity Controller date and time

Use the information in this topic to understand XClarity Controller date and time settings. Instructions are provided to configure the XClarity Controller date and time. The XClarity Controller date and time is used to time stamp all events that are logged in the event log and alerts that are sent.

At the XClarity Controller home page, click the clock icon on the upper right-hand corner to view or change the XClarity Controller date and time. The XClarity Controller does not have its own real-time clock. You can configure the XClarity Controller to sync its time and date with a Network Time Protocol server or with the server's real-time clock hardware.

Syncing with NTP

Complete the following steps to synchronize the XClarity Controller clock with the NTP server:

- Select **Sync up time with NTP** and specify the NTP server address.
- Additional NTP servers can be specified by clicking the “+” icon.
- Specify how frequently you want the XClarity Controller to sync with the NTP server.
- The time obtained from the NTP server is in Coordinated Universal Time (UTC) format.
 - If you want the XClarity Controller to adjust its time and date for your local region, select the time zone offset for your locale from the drop-down menu.
 - If your location observes Daylight Saving Time, tick the **Automatically adjust for Daylight Saving Time (DST)** checkbox.
- When your configuration changes are complete, click **Apply**.

Syncing with the Host

The time kept in the server's real-time clock hardware may be in Coordinated Universal Time (UTC) format or may already have been adjusted and stored in local time format. Some operating systems store the real-time clock in UTC format while others store the time as local time. The server real-time clock does not indicate which format the time is in. Therefore when the XClarity Controller is configured to sync with the host's real-time clock, the user can choose how the XClarity Controller uses the time and date that is obtained from the real-time clock.

- Local (example: Windows): In this mode, the XClarity Controller treats the time and date that is obtained from the real-time clock as local time with any applicable time zone and DST offsets already applied.
- UTC (example: Linux): In this mode, the XClarity Controller treats the time and date that is obtained from the real-time clock as Coordinated Universal Time, with no time zone or DST offsets already applied. In this mode, you can choose to adjust the time and date for your local region by selecting the time zone offset for your locale from the drop-down menu. If your location observes Daylight Saving Time, you can also tick the **Automatically adjust for Daylight Saving Time (DST)** check box.
- When your configuration changes are complete, click **Apply**.

Notes:

- When daylight saving occurs, any actions that were scheduled for the XClarity Controller to perform during the interval when the clock jumps forward will not be performed. For example, if the US daylight start time is 2:00 am on March 12th, and a power action is scheduled for 2:10 am on March 12th, this action will not occur. Once the time reaches 2:00 am, the XClarity Controller will instead read the time as 3:00 am.
- XClarity Controller Date and Time settings cannot be modified in a Flex System.

Chapter 6. Configuring the Storage

Use the information in this chapter to understand the options available for storage configurations.

When configuring the storage, following options are available:

- Detail
- RAID setup

RAID Detail

For using RAID detail function, use the information in this topic.

This function displays the storage devices' physical structure and storage configuration along with details like their location, manufacturer, product name, status, capacity, interface, media, form factor and other info.

RAID Setup

To perform RAID setup functions, use the information in this topic.

Use the information in this topic to view and configure storage pools, associated virtual disks and drives for the RAID adapter. If the system is powered off, power it on in order to view the RAID information.

Viewing and configuring the virtual drives

Use the information in this topic to view and configure the virtual drives.

When you select **RAID Setup** under **Server Configuration**, the **Array Configuration** tab will be chosen and the existing virtual disks will be displayed by default. The logical drives are sorted by disk arrays and controllers. Detailed information about the virtual disk, such as the virtual disk strip size and bootable information is displayed.

To configure the RAID settings, click **Enable Edit mode**.

In edit mode, you can click the controller action menu, view the current RAID virtual disks and create new RAID virtual disks.

From the Controller Actions menu, you can perform the following actions:

Clear RAID configuration

Clears all the configuration and data on the selected controller.

Manage foreign configuration

Import any foreign drives that were detected. A foreign drive is a drive that was moved from a different RAID configuration to the current RAID controller

Note: You will be notified if no foreign drives are detected.

Information of the current RAID virtual disks for a particular controller are shown as respective “virtual disk cards”. Each card displays information such as the virtual disk name, status, capacity and actions. The pencil icon allows you to edit the information, and the trash can icon enables you to delete the “virtual disk card”.

Note: The capacity and RAID level cannot be changed.

If you click the virtual disk name, a virtual disk properties window will appear.

To create a new RAID virtual disk, follow the steps shown below:

Note: If there is no remaining storage capacity, you are unable to create a new virtual disk.

1. Select drives or a disk array which has free storage capacity

- a. When creating a virtual disk in a new disk array, you need to specify the RAID level. If there are not enough drives to select, and you click **Next**, an error message will appear under the RAID level field.

For some RAID levels, span is required . There is also a minimum amount of drives that need to be present in the span.

- 1) For these types of situations, the web interface will display **Span 1** by default.
 - 2) Select the drives and click **Add member** to add the drives to **Span 1**. When **Span 1** does not have enough drives, disable the **Add Span** link.
 - 3) Click **Add Span** to add **Span 2**. Select the drives and click **Add member** to add to **Span 2**.
 - 4) Click **Add member** to add drives to the last span. If you want to add drives to **Span 1** again, you need to click **Span 1** and select the drives to add to **Span 1**.
 - 5) If the number of spans reaches the maximum amount, disable **Add span**.
- b. To create virtual disks in an existing disk array, you need to select a disk array that has free capacity.

2. Creating a virtual disk

- a. By default, create a virtual disk that uses all the storage capacity. The **Add** icon is disabled when all of the storage is used. You can click the pencil icon to change the capacity or other properties.
- b. When you edit the first virtual disk to use only some of the storage capacity, the **Add** icon will be enabled. Click the icon to show the **Add Virtual Disk** window.
- c. If there is more than one virtual disk, the **Remove** icon will be enabled. This icon will not be shown if there is only one virtual disk. When you click the **Remove** icon, the selected row will be immediately deleted. There will be no confirmation window as the virtual disk has not been created yet.
- d. Click **Start Creating Virtual Disk** to start the process.

Note: When the controller is not supported, a message will appear.

Viewing and configuring the storage inventory

Use the information in this topic to view and configure the storage inventory.

Under the **Storage Inventory** tab, you can view and configure disk arrays, associated virtual drives and drives for the RAID controller.

• **For storage devices that support RAID configuration:**

1. If the controller includes configured disk arrays, it will display the installed drives based on the disk array. The following describes the items that appear in the window.
 - **Table title:** Shows the disk array ID, RAID level and the total number of drives.
 - **Table content:** Lists basic properties such as drive name, RAID state, type, serial number, part number, FRU number and actions. You can go to the **Inventory** page to view all the properties that the XClarity Controller can detect.
 - **Actions:** The following shows the action items that can be performed. Some actions will not be available when the drive is in a different state.
 - **Assign hot spare:** Specifies the drive as global hot spare or a dedicated hot spare.
 - **Remove hot spare:** Removes the drive from the hot spare.

- **Make disk drive offline:** Sets the drive to offline.
 - **Make disk drive online:** Sets the drive to online.
 - **Start Rebuild:** Rebuild the RAID.
 - **Make disk drive as reusable:** Sets the drive to reusable.
 - **Make disk drive as missing:** Sets the drive as missing.
 - **Make drive good to JBOD:** Adds drive to JBOD disk arrangement.
 - **Make drive unconfigured good:** Makes the drive available to be configured into an array, or for use as an emergency hot spare.
 - **Make drive unconfigured bad:** Marks the drive bad, preventing it from being used in an array or as an emergency hot spare.
 - **Make disk drive as prepare for removal:** Sets the drive for removal.
2. If the controller includes drives that have not yet been configured, they will be displayed in the **Non-RAID disk drives** table. By clicking the **Convert JBOD to Ready to Configure** option, a window will appear showing all the drives that support this action item. You can select one or more drives to convert.

For storage devices that do not support RAID configuration: The XClarity Controller may not be able to detect the properties of some drives.

Chapter 7. Updating Server Firmware

To update server firmware, use information in this topic.

Overview

General Information about updating server firmware.

The **Firmware Update** option on the navigation panel has 4 features:

- **System Firmware:** Overview of system firmware status and version. And to perform system firmware update.
- **Auto Promote Primary XCC to Backup:** Once enabled, the pending backup bank firmware will be synced from primary bank after the primary bank pass the Image Stability Metric (ISM) measurement.
- **Adapter Firmware:** Overview of adapter firmware installed, their status and version. And to perform adapter firmware update.

The current status and versions of firmware for the BMC, UEFI, LXPM, LXPM drivers, and adapters are displayed, including the BMC primary and backup versions. There are four categories for the firmware status:

- **Active:** The firmware is active.
- **Inactive:** The firmware is not active.
- **Pending:** The firmware is waiting to become active.
- **N/A:** No firmware has been installed for this component.

Attention:

- XCC and IMM must be updated to the latest version before updating uEFI. Updating in different order may result in strange or incorrect behavior.
- Installing the wrong firmware update might cause the server to malfunction. Before you install a firmware or device-driver update, read any readme and change history files that are provided with the downloaded update. These files contain important information about the update and the procedure for installing the update, including any special procedure for updating from an early firmware or device-driver version to the latest version. As the web browser may contain XCC cache data, it is recommended to reload the web page after the XCC firmware has been upgraded.
- Some firmware updates require system restarting, which performs firmware activation or internal update. This process in system booting is called “system maintenance mode”, that does not allow user power actions temporarily. The mode is also enabled during firmware update. User shall not disconnect AC power when the system enters maintenance mode.

System, Adapter and PSU Firmware Update

Steps to update System firmware, Adapter firmware and PSU firmware.

To manually apply update for **System Firmware**, **Adapter Firmware** and **PSU Firmware**, complete the following steps:

1. Click **Update Firmware** within each feature. The Update Server Firmware window opens.
2. Click **Browse** to select the firmware update file that you want to use.
3. Navigate to the file you want to select and click **Open**. You are returned to the Update Server Firmware window with the selected file displayed.

4. Click **Next >** to begin the upload and verify process on the selected file. A progress meter will be displayed as the file is being uploaded and verified. You can view this status window to verify that the file you selected to update is the correct file. For **System Firmware**, the status window will have information regarding the type of firmware file that is to be updated such as BMC, UEFI, or LXPM. After the firmware file is uploaded and verified successfully, click **Next** to select the device you want to update.
5. Click **Update** to begin the firmware update. A progress meter shows the progress of the update. When the firmware update is completed successfully, click **Finish**. If the update requires the XClarity Controller to be restarted in order to take effect, a warning message will be displayed. For details on how to restart the XClarity Controller, see [“Power actions” on page 58](#).

Chapter 8. License Management

The Lenovo XClarity Controller License Management allows you to install and manage optional server and systems management features.

There are multiple levels of XClarity Controller firmware functionality and features available for your server. The level of the firmware features installed on your server vary based on hardware type.

You can upgrade the XClarity Controller functionality by purchasing and installing an activation key.

To order an activation key, contact your sales representative or business partner.

Use the XClarity Controller web interface or the XClarity Controller CLI to manually install an activation key that lets you use an optional feature you have purchased. Before activating a key:

- The activation key must be on the system that you are using to login to the XClarity Controller.
- You must have ordered the license key and received its authorization code via mail or e-mail.

See “[Installing an activation key](#)” on page 85, “[Removing an activation key](#)” on page 85 or “[Exporting an activation key](#)” on page 86 for information about managing an activation key using the XClarity Controller web interface. See “[keycfg command](#)” on page 122 for information about managing an activation key using the XClarity Controller CLI.

To register an ID in administering your XClarity Controller license, click the following link: <https://fod.lenovo.com/lkms/angular/app/pages/index.htm#/welcome>

Additional information about license management for Lenovo servers is available at the following **Lenovo Press** website:

<https://lenovopress.com/redp4895-using-lenovo-features-on-demand>

Installing an activation key

Use the information in this topic to add an optional feature to your server.

To install an activation key, complete the following steps:

- Step 1. Click **License** under **BMC Configuration**.
- Step 2. Click **Upgrade License**.
- Step 3. In the **Add a new license** window, click **Browse**; then, select the activation key file to add in the File Upload window and click **Open** to add the file. To finish adding the key, click **Import** in the Add Activation Key window.

Note: If the activation key is not valid, an error window will appear.

Removing an activation key

Use the information in this topic to delete an optional feature from your server.

To remove a activation key, complete the following steps:

- Step 1. Click **License** under **BMC Configuration**.

- Step 2. Select the activation key to remove; then, click **Delete**.
- Step 3. In the Confirm Activation Key Deletion window, click **OK** to confirm activation key deletion or click **Cancel** to keep the key file.
The selected activation key is removed from the server and no longer appears in the License Management page.
-

Exporting an activation key

Use the information in this topic to export an optional feature from your server.

To export an activation key, complete the following steps:

- Step 1. Click **License** under **BMC Configuration**.
- Step 2. From the License Management page, select the activation key to export; then, click **Export**.
- Step 3. In the **Export the selected license** window, click **Export** to confirm activation key exporting or click **Cancel** to cancel the key exporting request.
- Step 4. Select the directory to save the file.
The selected activation key is exported from the server.

Chapter 9. Lenovo XClarity Controller Redfish REST API

The Lenovo XClarity Controller provides a Redfish compliant set of easy-to-use REST APIs that can be used to access Lenovo XClarity Controller data and services from applications running outside of the Lenovo XClarity Controller framework.

This allows for easy integration of Lenovo XClarity Controller capabilities into other software, whether the software is running on the same system as the Lenovo XClarity Controller server, or on a remote system within the same network. These APIs are based on the industry standard Redfish REST API and are accessed via the HTTPS protocol.

The XClarity Controller Redfish REST API user guide can be found here: https://pubs.lenovo.com/xcc-restapi/xcc_restapi_book.pdf.

Lenovo provides open source sample Redfish scripts that can be used as reference for developing software that communicates with Lenovo Redfish REST API. These sample scripts can be found here:

- Python: <https://github.com/lenovo/python-redfish-lenovo>
- PowerShell: <https://github.com/lenovo/powershell-redfish-lenovo>

DMTF specifications related to the Redfish API are available at: <https://redfish.dmtf.org/>. This website provides general specifications and other reference material on the Redfish REST API.

Chapter 10. Command-line interface

Use the information in this topic to enter commands that manage and monitor the XClarity Controller without having to use the XClarity Controller web interface.

Use the XClarity Controller command line interface (CLI) to access the XClarity Controller without having to use the web interface. It provides a subset of the management functions that are provided by the web interface.

You can access the CLI through a SSH session. You must be authenticated by the XClarity Controller before you can issue any CLI commands.

Accessing the command-line interface

Use the information in this topic to access the CLI.

To access the CLI, start an SSH session to the XClarity Controller IP address (see [“Configuring serial-to-SSH redirection” on page 89](#) for more information).

Logging in to the command-line session

Use the information in this topic to log in to the command line session.

To log in to the command line, complete the following steps:

- Step 1. Establish a connection with the XClarity Controller.
- Step 2. At the user name prompt, type the user ID.
- Step 3. At the password prompt, type the password that you use to log in to the XClarity Controller.

You are logged in to the command line. The command-line prompt is `system>`. The command-line session continues until you type `exit` at the command line. You are logged off and the session is ended.

Configuring serial-to-SSH redirection

This topic provides information about using the XClarity Controller as a serial terminal server.

Serial-to-SSH redirection enables a system administrator to use the XClarity Controller as a serial terminal server. A server serial port can be accessed from a SSH connection when serial redirection is enabled.

Note: The CLI `console 1` command is used to start a serial redirection session with the COM port.

Example session

```
$ ssh USERID@10.240.1.12
Password:
```

```
system>
```

All traffic from the SSH session is routed to COM2.

```
ESC (
```

Type the exit key sequence to return to the CLI. In this example, press Esc and then type a left parenthesis. The CLI prompt displays to indicate return to the IMM CLI.

```
system>
```

Command syntax

Review the guidelines in this topic to understand how to enter commands in the CLI.

Read the following guidelines before you use the commands:

- Each command has the following format:
command [**arguments**] [**-options**]
- The command syntax is case sensitive.
- The command name is all lowercase.
- All arguments must immediately follow the command. The options immediately follow the arguments.
- Each option is always preceded by a hyphen (-). An option can be a short option (single letter) or a long option (multiple letters).
- If an option has an argument, the argument is mandatory, for example:
ifconfig eth0 -i 192.168.70.34 -g 192.168.70.29 -s 255.255.255.0
where **ifconfig** is the command, eth0 is an argument, and -i, -g, and -s are options. In this example, all three options have arguments.
- Brackets indicate that an argument or option is optional. Brackets are not part of the command that you type.

Features and limitations

This topic contains information about CLI features and limitations.

The CLI has the following features and limitations:

- Multiple concurrent CLI sessions are allowed via SSH.
- One command is allowed per line (1024-character limit, including spaces).
- There is no continuation character for long commands. The only editing function is the Backspace key to erase the character that you just typed.
- The Up Arrow and Down Arrow keys can be used to browse through the last eight commands. The **history** command displays a list of the last eight commands, which you can then use as a shortcut to execute a command, as in the following example:

```
system > history
 0 ifconfig eth0
 1 readlog
 2 readlog
 3 readlog
 4 history
system > !0
-state enabled
-c dthens
-i 192.168.70.125
-g 0.0.0.0
-s 255.255.255.0
-n XClarity ControllerA00096B9E003A
-r auto
-d auto
-m 1500
```



```
-b 00:09:6B:9E:00:3A
-l 00:00:00:00:00:00
system >
```

- In the CLI, the output buffer limit is 2 KB. There is no buffering. The output of an individual command cannot exceed 2048 characters. This limit does not apply in serial redirect mode (the data is buffered during serial redirect).
- Simple text messages are used to denote command execution status, as in the following example:

```
system> power on
ok
system> power state
Power: On
State: System power off/State unknown
system>
```
- The command syntax is case sensitive.
- There must be at least one space between an option and its argument. For example, `ifconfig eth0 -i192.168.70.133` is incorrect syntax. The correct syntax is `ifconfig eth0 -i 192.168.70.133`.
- All commands have the `-h`, `-help`, and `?` options, which give syntax help. All of the following examples will give the same result:

```
system> power -h
system> power -help
system> power ?
```
- Some of the commands that are described in the following sections might not be available for your system configuration. To see a list of the commands that are supported by your configuration, use the `help` or `?` option, as shown in the following examples:

```
system> help
system> ?
```
- In a Flex System, some settings are managed by the CMM and cannot be modified on the XClarity Controller.

Alphabetical command listing

This topic contains a list of CLI commands in alphabetic order. Links are provided to topics for each command. Each command topic provides information about the command, its function, syntax, and usage.

The complete list of all XClarity Controller CLI commands, in alphabetical order, is as follows:

- [“accseccfg command” on page 107](#)
- [“adapter command” on page 168](#)
- [“alertcfg command” on page 108](#)
- [“alertentries command” on page 154](#)
- [“asu command” on page 109](#)
- [“backup command” on page 112](#)
- [“batch command” on page 156](#)
- [“clearcfg command” on page 157](#)
- [“clearlog command” on page 94](#)
- [“clock command” on page 157](#)
- [“console command” on page 107](#)
- [“dbgshimm command” on page 171](#)
- [“dhcpinfo command” on page 113](#)

- “dns command” on page 114
- “encaps command” on page 115
- “ethtousb command” on page 116
- “exit command” on page 93
- “fans command” on page 95
- “ffdc command” on page 95
- “firewall command” on page 117
- “fuelg command” on page 105
- “gprofile command” on page 118
- “hashpw command” on page 118
- “help command” on page 93
- “history command” on page 93
- “hreport command” on page 96
- “identify command” on page 158
- “ifconfig command” on page 119
- “info command” on page 158
- “keycfg command” on page 122
- “ldap command” on page 123
- “led command” on page 97
- “mhlog command” on page 97
- “m2raid command” on page 170
- “ntp command” on page 125
- “portcfg command” on page 126
- “portcontrol command” on page 127
- “ports command” on page 128
- “power command” on page 102
- “pxeboot command” on page 106
- “rdmount command” on page 129
- “readlog command” on page 99
- “reset command” on page 104
- “restore command” on page 130
- “restoredefaults command” on page 130
- “roles command” on page 131
- “seccfg command” on page 132
- “set command” on page 132
- “smtp command” on page 133
- “snmp command” on page 133
- “snmpalerts command” on page 135
- “spreset command” on page 159
- “srcfg command” on page 137
- “sshcfg command” on page 138

- “ssl command” on page 139
- “sslcfg command” on page 140
- “storage command” on page 159
- “storekeycfg command” on page 143
- “syncrep command” on page 144
- “syshealth command” on page 100
- “temps command” on page 101
- “thermal command” on page 145
- “timeouts command” on page 146
- “tls command” on page 147
- “trespass command” on page 147
- “uefipw command” on page 148
- “usbeth command” on page 149
- “usbfw command” on page 149
- “users command” on page 149
- “volts command” on page 101
- “vpd command” on page 102

Utility commands

This topic provides an alphabetic list of utility CLI commands.

There are currently 3 utility commands:

exit command

Use this command to log off the CLI session,

Use the **exit** command to log off and end the CLI session.

help command

This command displays a list of all commands.

Use the **help** command to display a list of all commands with a short description for each. You can also type **?** at the command prompt.

history command

This command provides a list of previously issued commands.

Use the **history** command to display an indexed history list of the last eight commands that were issued. The indexes can then be used as shortcuts (preceded by **!**) to reissue commands from this history list.

Example:

```
system> history
0 ifconfig eth0
1 readlog
2 readlog
3 readlog
```

```

4 history
system> ifconfig eth0
-state enabled
-c dthens
-i 192.168.70.125
HISTORY-g 0.0.0.0
-s 255.255.255.0
-n XCCA00096B9E003A
-r auto
-d auto
-m 1500
-b 00:09:6B:9E:00:3A
-l 00:00:00:00:00:00
system>

```

Monitor commands

This topic provides an alphabetic list of monitor CLI commands.

There are currently 11 monitor commands:

clearlog command

This command is used to clear the IMM event log.

Use the **clearlog** command to clear the event log of the IMM. You must have the authority to clear event logs to use this command.

Note: This command is intended only for support personnel use.

The following table shows the arguments for the options.

Table 7. clearlog command

The following table is a one-row two column table consisting of the option and option descriptions.

Option	Description
-t <all platform audit>	Event type, choose which type of event to clear. If not specified, all event types will be selected.

Event type descriptions

- all: All event type, including platform event and audit event.
- platform: Platform event type.
- audit: Audit event type.

Example:

```

system> clearlog
All event log cleared successfully
system> clearlog -t all
All event log cleared successfully
system> clearlog -t platform
Platform event log cleared successfully
system> clearlog -t audit
Audit event log cleared successfully

```

fans command

This command is used to display the velocity of the server fans.

Use the **fans** command to display the speed for each of the server fans.

Example:

```
system> fans
fan1 75%
fan2 80%
fan3 90%
system>
```

ffdc command

This command is used to generate a new service data file.

Use the first failure data capture (**ffdc**) command to generate and transfer service data to Support.

The following list consist of commands to be used with the **ffdc** command:

- **generate**, create a new service data file
- **status**, check status of service data file
- **copy**, copy existing service data
- **delete**, delete existing service data

The following table shows the arguments for the options.

Table 8. ffdc command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-t	Type number	1 (processor dump) and 4 (service data). The processor dump contains all logs and files available. The service data contains only a subset of the logs and files. The default value is 1.
-f ¹	Remote filename or sftp target directory.	For sftp, use full path or trailing / on directory name (~/ or /tmp/). The default value is the system generated name.
-ip ¹	Address of the tftp/sftp server	
-pn ¹	Port number of the tftp/sftp server	The default value is 69/22.
-u ¹	Username for the sftp server	
-pw ¹	Password for the sftp server	
1. Additional argument for generate and copy commands		

Syntax:

```
ffdc [options]
```

option:

- t 1 or 4
- f
- ip ip_address

```
-pn port_number
-u username
-pw password
```

Example:

```
system> ffdc generate
Generating ffdc...
system> ffdc status
Type 1 ffdc: in progress
system> ffdc copy -t 1 -ip 192.168.70.230 -u User2 -pw PasswOrd -f /tmp/
Waiting for ffdc.....
Copying ffdc...
ok
system> ffdc status
Type 1 ffdc: completed
8737AC1_DSY0123_xcc_120317-153327.tgz
```

```
system> ffdc generate
Generating ffdc...
system> ffdc status
Type 1 ffdc: in progress
system> ffdc status
Type 1 ffdc: in progress
system> ffdc copy -ip 192.168.70.230
Copying ffdc...
ok
system> ffdc status
Type 1 ffdc: completed
8737AC1_DSY0123_xcc_120926-105320.tgz
system>
```

hreport command

Use this command to show embedded health report.

The following table shows the hreport commands.

Table 9. hreport commands

The following table is a multi-row two column table consisting of the different hreport command descriptions.

Option	Description
generate	Create new health report
status	Check status
copy	Copy existing health report
delete	Delete existing health report

The following table shows the arguments for the generate and copy options.

Table 10. generate and copy command

The following table is a multi-row two column table consisting of the generate and copy command options and option descriptions.

Table 10. generate and copy command (continued)

Option	Description
-f	Remote filename or sftp target directory (default is system generated name ((for sftp, use full path or trailing / on directory name (~/ or /tmp/))
-ip	Address of tftp/sftp server
-pn	Port number of tftp/sftp server (default 69/22)
-u	Username for sftp server
-pw	Password for sftp server

mhlog command

Use this command to display maintenance history activity log entries.

The following table shows the arguments for the options.

Table 11. mhlog command

The following table is a multi-row two column table consisting of the options and option descriptions.

Option	Description
-c <count>	Display 'count' entries (1-250)
-i <index>	Display entries starting at index (1-250)
-f	Remote filename of log file
-ip	Address of tftp/sftp server
-pn	Port number of tftp/sftp server (default 69/22)
-u	Username for sftp server
-pw	Password for sftp server

Example

Display will look something like this:

Type	Message	Time
-----	-----	----
Hardware	SAS Backplane1(SN: XXXX9CE009L) is added.	05/08/2020,04:23:18
Hardware	CPU 1(SKU NO: 50844440) is added.	05/08/2020,04:23:22
Hardware	CPU 2(SKU NO: 50844440) is added.	05/08/2020,04:23:22
Hardware	M2 Card(SN: R1SH9AJ0037) is added.	05/08/2020,04:23:22
Firmware	Primary XCC firmware is updated to TGBT99T by XCC Web.	05/08/2020,06:40:37
Firmware	Primary XCC firmware is activated to TGBT99T .	05/08/2020,06:41:26
Hardware	PSU1(SN: D1DG94C0075) is added.	05/08/2020,06:43:28

led command

Use this command to display and set LED states.

The **led** command displays and sets the server LED states.

- Running the **led** command with no options displays the status of the front panel LEDs.

- The **led -d** command option must be used with **led -identify on** command option.

The following table shows the arguments for the options.

Table 12. *led* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-l	Get the status of all system and system subcomponent LEDs	
-chklog	Turn off check log LED	off
-identify	Change state of enclosure identify LED	off, on, blink
-d	Turn on identification LED for specified time period	Time period (seconds)

Syntax:

led [options]

option:

- l
- chklog off
- identify **state**
- d **time**

Example:

system> **led**

```
Fault          Off
Identify       On           Blue
Chklog         Off
Power         Off
```

system> **led -l**

```
Label          Location      State      Color
Battery        Planar        Off
BMC Heartbeat  Planar        Blink      Green
BRD            Lightpath Card Off
Channel A      Planar        Off
Channel B      Planar        Off
Channel C      Planar        Off
Channel D      Planar        Off
Channel E      Planar        Off
Chklog         Front Panel  Off
CNFG          Lightpath Card Off
CPU            Lightpath Card Off
CPU 1          Planar        Off
CPU 2          Planar        Off
DASD          Lightpath Card Off
DIMM          Lightpath Card Off
DIMM 1        Planar        Off
DIMM 10       Planar        Off
DIMM 11       Planar        Off
DIMM 12       Planar        Off
DIMM 13       Planar        Off
DIMM 14       Planar        Off
DIMM 15       Planar        Off
DIMM 16       Planar        Off
```


DIMM 2	Planar	Off	
DIMM 3	Planar	Off	
DIMM 4	Planar	Off	
DIMM 5	Planar	Off	
DIMM 6	Planar	Off	
DIMM 7	Planar	Off	
DIMM 8	Planar	Off	
DIMM 9	Planar	Off	
FAN	Lightpath Card	Off	
FAN 1	Planar	Off	
FAN 2	Planar	Off	
FAN 3	Planar	Off	
Fault	Front Panel (+)	Off	
Identify	Front Panel (+)	On	Blue
LINK	Lightpath Card	Off	
LOG	Lightpath Card	Off	
NMI	Lightpath Card	Off	
OVER SPEC	Lightpath Card	Off	
PCI 1	FRU	Off	
PCI 2	FRU	Off	
PCI 3	FRU	Off	
PCI 4	FRU	Off	
Planar	Planar	Off	
Power	Front Panel (+)	Off	
PS	Lightpath Card	Off	
RAID	Lightpath Card	Off	
Riser 1	Planar	Off	
Riser 2	Planar	Off	
SAS ERR	FRU	Off	
SAS MISSING	Planar	Off	
SP	Lightpath Card	Off	
TEMP	Lightpath Card	Off	
VRM	Lightpath Card	Off	

system>

readlog command

This command displays the IMM event logs.

Use the **readlog** command to display the IMM event log entries. Five event logs are displayed at a time. The entries are displayed from the most recent to the oldest.

readlog displays the first five entries in the event log, starting with the most recent, on its first execution, and then the next five for each subsequent call.

readlog -a displays all entries in the event log, starting with the most recent.

readlog -f resets the counter and displays the first 5 entries in the event log, starting with the most recent.

readlog -date date displays event log entries for the specified date, specified in mm/dd/yy format. It can be a pipe (|) separated list of dates.

readlog -sev severity displays event log entries for the specified severity level (E, W, I). It can be a pipe (|) separated list of severity levels.

readlog -i ip_address sets the IPv4 or IPv6 IP address of the TFTP or SFTP server where the event log is saved. The **-i** and **-l** command options are used together to specify the location.

readlog -l filename sets the file name of the event log file. The **-i** and **-l** command options are used together to specify the location.

readlog -pn port_number displays or sets the port number of the TFTP or SFTP server (default 69/22).

readlog -u username specifies the user name for the SFTP server.

readlog -pw password specifies the password for the SFTP server.

Syntax:

readlog [**options**]

option:

- a
- f
- date **date**
- sev **severity**
- i **ip_address**
- l **filename**
- pn **port_number**
- u **username**
- pw **password**

Example:

```
system> readlog -f
1 I 2017-06-17T09:31:59.217 Remote Login Successful. Login ID: USERID
from SSH at IP address 10.134.78.180
2 I 2017-06-17T07:23:04.685 Remote Login Successful. Login ID: USERID
from webguis at IP address 10.134.78.180.
3 I 2017-06-16T11:00:35.581 Login ID: USERID from webguis at IP address 10.134.78.180 has logged off.
4 I 2017-06-16T11:00:15.174 Login ID: USERID from webguis at IP address 10.104.209.144 has logged off.
5 I 2017-06-16T10:40:14.352 Login ID: USERID from webguis at IP address 10.104.209.144 has logged off.
system> readlog
6 E SERVPROC 12/18/03 10:09:31 Fan 2 Fault. Multiple fan failures
7 E SERVPROC 12/18/03 10:09:31 Fan 1 Fault. Single fan failure
8 I SERVPROC 12/18/03 10:09:25 Ethernet[0] Link Established at 100Mb, Full Duplex.
9 I SERVPROC 12/18/03 10:09:24 Ethernet[0] configured to do Auto Speed/Auto Duplex.
10 I SERVPROC 12/18/03 10:09:24 Ethernet[0] MAC Address currently
being used: 0x00-09-6B-CA-0C-80
system>
```

syshealth command

This command provides a summary of the health or active events.

Use the **syshealth** command to display a summary of the health or active events of the server. The power state, system state, hardware state (includes fan, power supply, storage, processor, memory), restart count, and IMM software status are displayed.

Syntax:

syshealth [**argument**]

argument:

- summary -display the system health summary
- activeevents -display active events
- cooling - display cooling devices health status
- power - display power modules health status
- storage - display local storage health status
- processors - display processors health status
- memory - display memory health status

Example:

```
system> syshealth summary
Power On
State OS booted
Restarts 29
```

```
system> syshealth activeevents
No Active Event Available!
```

temps command

This command displays all temperature and temperature threshold information.

Use the **temps** command to display all the temperatures and temperature thresholds. The same set of temperatures are displayed as in the web interface.

Example

```
system> temps
```

Temperatures are displayed in degrees Fahrenheit/Celsius

	WR	W	T	SS	HS
CPU1	N/A	N/A	80/27	N/A	N/A
CPU2	N/A	N/A	80/27	N/A	N/A
DASD1	66/19	73/23	82/28	88/31	92/33
Amb	59/15	70/21	83/28	90/32	95/35

```
system>
```

Notes:

1. The output has the following column headings:
 - WR: warning reset (Positive-going Threshold Hysteresis value)
 - W: warning (Upper non-critical Threshold)
 - T: temperature (Current value)
 - SS: soft shutdown (Upper critical Threshold)
 - HS: hard shutdown (Upper non-recoverable Threshold)
2. All temperature values are in degrees Fahrenheit/Celsius.
3. N/A represents not applicable.

volts command

Use this command to display the server voltage information.

Use the **volts** command to display all the voltages and voltage thresholds. The same set of voltages are displayed as in the web interface.

Example:

```
system> volts
```

i	HSL	SSL	WL	WRL	V	WRH	WH	SSH	HSH
5v	5.02	4.00	4.15	4.50	4.60	5.25	5.50	5.75	6.00
3.3v	3.35	2.80	2.95	3.05	3.10	3.50	3.65	3.70	3.85
12v	12.25	11.10	11.30	11.50	11.85	12.15	12.25	12.40	12.65
-5v	-5.10	-5.85	-5.65	-5.40	-5.20	-4.85	-4.65	-4.40	-4.20
-3.3v	-3.35	-4.10	-3.95	-3.65	-3.50	-3.10	-2.95	-2.80	-2.70
VRM1					3.45				
VRM2					5.45				

```
system>
```

Note: The output has the following column headings:

HSL: hard shutdown low (Lower non-recoverable Threshold)

SSL: soft shutdown low (Lower critical Threshold)
WL: warning low (Lower non-critical Threshold)
WRL: warning reset low (Negative-going Threshold Hysteresis value)
V: voltage (current value)
WRH: warning reset high (Positive-going Threshold Hysteresis value)
WH: warning high (Upper non-critical Threshold)
SSH: soft shutdown high (Upper critical Threshold)
HSH: hard shutdown high (Upper non-recoverable Threshold)

vpd command

This command displays configuration and informational data (vital product data) associated with the hardware and software of the server.

Use the **vpd** command to display vital product data for the system (sys), IMM (bmc), server BIOS (uefi), Lenovo XClarity Provisioning Manager (lxpm), server firmware (fw), server components (comp) and PCIe devices (pcie). The same information is displayed as in the web interface.

Syntax:

vpd sys - displays Vital Product Data for the system
vpd bmc - displays Vital Product Data for the management controller
vpd uefi - displays Vital Product Data for system BIOS
vpd lxpm - displays Vital Product Data for system LXPM
vpd fw - displays Vital Product Data for the system firmware
vpd comp - displays Vital Product Data for the system components
vpd pmem - displays Vital Product Data for Intel Optane PMem
vpd pcie - displays Vital Product Data for PCIe devices

Example:

```
system> vpd bmc
Type          Status      Version    Build      ReleaseDate
-----
BMC (Primary) Active      0.00      DVI399T   2017/06/06
BMC (Backup)  Inactive   1.00      TEI305J   2017/04/13
system>
```

Server power and restart control commands

This topic provides an alphabetic list of power and restart CLI commands.

There are currently 4 server power and restart commands:

power command

This command describes how to control the server power.

Use the **power** command to control the server power. To issue **power** commands, you must have the Remote Server Power/Restart Access authority level.

The following table contains a subset of commands that can be used with the **power** command.

Table 13. *power* command

The following table is a multi-row three column table consisting of the power commands, command descriptions, and associated values for the commands.

Command	Description	Value
power on	Use this command to turn on the server power.	on, off
power off	Use this command to turn off the server power. Note: The -s option shuts down the operating system before the server is turned off.	on, off
power cycle	Use this command to turn off the server power and then turn on the server power. Note: The -s option shuts down the operating system before the server is turned off.	
power enterS3	Use this command to place the operating system into the S3 (sleep) mode. Note: This command is used only when the operating system is on. The S3 mode is not supported on all servers.	
power rp	Use this option to specify the host power restore policy.	alwayson alwaysoff restore
power S3resume	Use this command to wake up the operating system from the S3 (sleep) mode. Note: This command is used only when the operating system is on. The S3 mode is not supported on all servers.	
power state	Use this command to display the server power state and the current state of the server.	on, off

The following table contains the options for the **power on**, **power off**, and **power cycle** commands.

Table 14. *power* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-s	Use this option to shut down the operating system before the server is turned off. Note: The -s option is implied when using the -every option for the power off and power cycle commands.	
-every	Use this option with the power on , power off , and power cycle commands to control the server power. You can set up the dates, times, and frequency (daily or weekly) to power on, power off, or power cycle your server.	Note: The values for this option are presented on separate lines due to space limitations. Sun Mon Tue Wed Thu Fri Sat Day clear
-t	Use this option to specify the time in hours and minutes to power on the server, shut down the operating system, and power off or restart the server.	Use the following format: hh:mm

Table 14. *power* command (continued)

Option	Description	Values
-d	Use this option to specify the date to power on the sever. This is an additional option for the power on command. Note: The -d and -every options, cannot be used together on the same command.	Use the following format: mm/dd/yyyy
-clear	Use this option to clear the scheduled power on date. This is an additional option for the power on command.	

Syntax:

```
power on
power off [-s]
power state
power cycle [-s]
```

The following information are examples of the **power** command.

To shut down the operating system and power off the server every Sunday at 1:30, enter the following command:

```
system> power off
-every Sun -t 01:30
```

To shut down the operating system and restart the server every day at 1:30, enter the following command:

```
system> power cycle
-every Day -t 01:30
```

To power on the server every Monday at 1:30, enter the following command:

```
system> power on
-every Mon -t 13:00
```

To power on the server on Dec 31 2013 at 11:30 PM, enter the following command:

```
system> power on
-d 12/31/2013 -t 23:30
```

To clear a weekly power cycle, enter the following command:

```
system> power cycle
-every clear
```

reset command

This command describes how to reset the server.

Use the **reset** command to restart the server. To use this command, you must have power and restart access authority.

The following table shows the arguments for the options.

Table 15. *reset* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Table 15. *reset* command (continued)

Option	Description	Values
-s	Shut down the operating system before the server is reset.	
-d	Delay performing the reset for the given number of seconds.	0 - 120
-nmi	Generate a non-maskable interrupt (NMI) on the server.	

Syntax:

`reset [option]`

option:

-s

-d

-nmi

fuelg command

This command displays information about the server power.

Use the **fuelg** command to display information about server power usage and configure server power management. This command also configures policies for power redundancy loss. The following table shows the arguments for the options.

Table 16. *fuelg* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-pme	Enable or disable power management and capping on the server.	on, off
-pcapmode	Set the power capping mode for the server.	input, output
-pcap	A numeric value that falls within the range of power capping values displayed when running the fuelg command, with no options, on the target.	numeric wattage value
-history	Display power consumption or performance history	pc, perf
-period	A numeric value to display history (1, 6, 12, 24 hours)	numeric value in hours
-pm	Set the policy mode for loss of redundant power.	<ul style="list-style-type: none"> • bt- basic with throttling • rt- redundant with throttling (default) • ort- N_1 redundant with throttling
-zm	Enable or disable zero output mode. This setting can only be set when the policy mode is set to redundant with throttling.	on, off

Table 16. *fuelg* command (continued)

Option	Description	Values
-perf	Display the current compute utilization, including system, microprocessor, and I/O.	percentage
-pc	Display current power consumption	<ul style="list-style-type: none"> • output- display current DC power consumption. For Rack and Tower servers it will include the power consumption of the system, CPU, memory and other components, For ITE blade servers it will only include the system power consumption. • input- Display current input power consumption, including system power consumption.

Syntax:

`fuelg [options]`

option:

- pme **on|off**
- pcapmode **input|output**
- pcap
- history
- period
- pm **bt|rt**
- zm **on|off**
- perf
- pc **input|output**

Example:

```
system> fuelg
-pme: on
system>
```

pxeboot command

This command displays and sets the condition of the Preboot eXecution Environment.

Running **pxeboot** with no options, returns the current Preboot eXecution Environment setting. The following table shows the arguments for the options.

Table 17. *pxeboot* command

The following table is a single-row three column table consisting of the option, option description, and associated values for the option.

Option	Description	Values
-en	Sets the Preboot eXecution Environment condition for the next system restart.	enabled, disabled

Syntax:

`pxeboot [options]`

option:

- en **state**

Example:
system> pxeboot
-en disabled
system>

Serial redirect command

This topic contains the serial redirect command.

There is only one serial redirect command: the [“console command” on page 107](#).

console command

This command is used to start a serial redirect console session.

Use the **console** command to start a serial redirect console session to the designated serial port of the IMM.

Syntax:
console 1

Configuration commands

This topic provides an alphabetic list of configuration CLI commands.

There are currently 41 configuration commands:

accsecfg command

Use this command to display and configure account security settings.

Running the **accsecfg** command with no options displays all account security information. The following table shows the arguments for the options.

Table 18. *accsecfg* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-am	Sets user authentication method.	local, ldap, localldap, ldaplocal
-lp	Lockout period after maximum login failures (minutes).	Between 0 and 2880, 0 = lockout period does not expire
-pe	Password expiration time period (days).	Between 0 and 365, 0 = never expire
-pew	Password expiration warning time period Note: The Password expiration warning time period must be less than Password expiration time period.	Between 0 and 30, 0 = never warn
-pc	Password complexity rules enabled.	on, off
-pl	Password length.	If password complexity rules are enabled, the password length is between 8 and 32. Otherwise, it is between 0 and 32.

Table 18. `accseccfg` command (continued)

Option	Description	Values
-ci	Minimum password change interval (hours).	between 0 and 240, 0 = change immediately
-lf	Maximum number of login failures.	Between 0 and 10, 0 = never locked
-chgdft	Change default password after first login.	on, off
-chgnew	Change new user password after first login.	on, off
-rc	Password reuse cycle.	Between 0 and 10, 0 = reuse immediately
-wt	Web and Secure Shell inactivity session timeout (minutes).	Between 0 and 1440

Syntax:

```
accseccfg [options]
```

option:

```
-legacy
-high
-custom
-am authentication method
-lp lockout_period
-pe time_period
-pr state
-pc state
-pd number_characters
-pl number_characters
-ci minimum_interval
-lf number_failures
-chgdft state
-chgnew state
-rc reuse_cycle
-wt timeout
```

Example:

```
system> accseccfg
-legacy
-am local
-lp 2
-pe 0
-pr off
-pd 1
-pl 4
-ci 0
-lf 0
-chgdft off
-chgnew off
-rc 0
-wt user
system>
```

alertcfg command

Use this command to display and configure the IMM global remote alert parameters.

Running the **alertcfg** command with no options displays all global remote alert parameters. The following table shows the arguments for the options.

Table 19. *alertcfg* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-dr	Sets wait time between retries before the IMM resends an alert.	0 to 4.0 minutes, in 0.5 minute increments
-da	Sets wait time before the IMM sends an alert to the next recipient in the list.	0 to 4.0 minutes, in 0.5 minute increments
-rl	Sets the number of additional times that the IMM attempts to send an alert, if previous attempts were unsuccessful.	0 to 8

Syntax:

```

alertcfg [options]
  options:
    -rl retry_limit
    -dr retry_delay
    -da agent_delay

```

Example:

```

system>alertcfg
-dr 1.0
-da 2.5
-rl 5
system>

```

asu command

This command is used to configure UEFI settings.

Advanced Settings Utility commands (ASU) are used to configure UEFI settings. The host system must be rebooted for any UEFI setting changes to take effect.

The following table contains a subset of commands that can be used with the **asu** command.

Table 20. *asu* command

The following table is a multi-row three column table consisting of a subset of commands that can be used in conjunction with the **asu** command. Descriptive information and associated values for the commands are provided.

Command	Description	Value
delete	Use this command to delete an instance or record of a setting. The setting must be an instance that allows deletion, for example, iSCSI.AttemptName.1.	setting_instance
help	Use this command to display help information for one or more settings.	setting

Table 20. asu command (continued)

Command	Description	Value
set	Use this command to change the value of a setting. Set the UEFI setting to the input value. Notes: <ul style="list-style-type: none"> • Set one or more setting/value pairs. • The setting can contain wildcards if it expands to a single setting. • The value must be enclosed in quotes if it contains spaces. • Ordered list values are separated by the equal symbol (=). For example, set B*.Bootorder "CD/DVD Rom=Hard Disk 0=PXE Network." 	setting value
showgroups	Use this command to display the available setting groups. This command displays the names of known groups. Group names may vary depending on the installed devices.	setting
show	Use this command to display the current value of one or more settings.	setting
showvalues	Use this command to display all possible values for one or more settings. Notes: <ul style="list-style-type: none"> • This command will display information about the allowable values for the setting. • The minimum and maximum number of instances allowed for the setting is displayed. • The default value will be displayed if available. • The default value is enclosed with opening and closing angle brackets (< and >). • Text values show the minimum and maximum length and regular expression. 	setting
Notes: <ul style="list-style-type: none"> • In the command syntax, setting is the name of a setting that you want to view or change, and value is the value that you are placing on the setting. • Setting can be more than one name, except when using the set command. • Setting can contain wildcards, for example an asterisk (*) or a question mark (?). • Setting can be a group, a setting name, or all. 		

Examples of the syntax for the **asu** command are presented in the following list:

- To display all of the asu command options enter `asu --help`.
- To display verbose help for all commands enter `asu -v --help`.
- To display verbose help for one command enter `asu -v set --help`.
- To change a value enter `asu set setting value`.
- To display the current value enter `asu show setting`.
- To display settings in long batch format enter `asu show -l -b all`
- To display all possible values for a setting enter `asu showvalues setting`. Example **show values** command:
system> `asu showvalues S*.POST*`

```
SystemRecovery.POSTWatchdogTimer==<Disable>=Enable
SystemRecovery.POSTWatchdogTimerValue=numeric min=5 max=20 step=1 default=5
system>
```

The following table shows the arguments for the options.

Table 21. *asu options*

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-b	Display in batch format.	
--help ¹	Display command usage and options. The --help option is placed before the command, for example asu --help show .	
--help ¹	Display help for the command. The --help option is placed after the command, for example, asu show --help .	
-l	Long format setting name (include the configuration set).	
-m	Mixed format setting name (use the configuration id).	
-v ²	Verbose output.	
1. The --help option can be used with any command. 2. The -v option is used only between asu and the command.		

Syntax:

```
asu [options] command [cmdopts]
```

options:

- v **verbose output**
- help **display main help**

cmdopts:

- help **help for the command**

Note: See individual commands for more command options.

Use the asu transaction commands to set multiple UEFI settings and create and execute batch mode commands. Use the **tropen** and **trset** commands to create a transaction file containing multiple settings to be applied. A transaction with a given id is opened using the **tropen** command. Settings are added to the set using the **trset** command. The completed transaction is committed using the **trcommit** command. When you are finished with the transaction, it can be deleted with the **trrm** command.

Note: The UEFI settings restore operation will create a transaction with an id using a random three digit number.

The following table contains transaction commands that can be used with the **asu** command.

Table 22. *asu transaction commands*

The following table is a multi-row three column table consisting of the transactions commands, the command descriptions, and associated values for the commands.

Table 22. asu transaction commands (continued)

Command	Description	Value
tropen id	This command creates a new transaction file containing several settings to be set.	Id is the identifying string, 1 - 3 alphanumeric characters.
trset id	This command adds one or more settings or value pairs to a transaction.	Id is the identifying string, 1 - 3 alphanumeric characters.
trlist id	This command displays the contents of the transaction file first. This can be useful when the transaction file is created in the CLI shell.	Id is the identifying string, 1 - 3 alphanumeric characters.
trcommit id	This command commits and executes the contents of the transaction file. The results of the execution and any errors will be displayed.	Id is the identifying string, 1 - 3 alphanumeric characters.
trrm id	This command removes the transaction file after it has been committed.	Id is the identifying string, 1 - 3 alphanumeric characters.

Example of establishing multiple UEFI settings:

```
asu tropen TR1
asu trset TR1 UEFI.BootModes.SystemBootMode "UEFI and Legacy"
asu trset TR1 BootOrder.BootOrder "CD/DVD Rom=Hard Disk 0=PXE Network"
asu trset TR1 BootOrder.WolBootOrder "CD/DVD Rom=Hard Disk 0=PXE Network"
asu trset TR1 UEFI.DevicesandIOPorts.Com1BaudRate 115200
asu trset TR1 UEFI.DevicesandIOPorts.Com1DataBits 8
asu trset TR1 UEFI.DevicesandIOPorts.Com1FlowControl Disable
asu trset TR1 UEFI.DevicesandIOPorts.Com1Parity None
asu trset TR1 UEFI.DevicesandIOPorts.Com1StopBits 1
asu trset TR1 UEFI.DevicesandIOPorts.COMPort1 Enable
asu trcommit TR1
```

backup command

Use this command to create a backup file containing the current system security settings.

Table 23. backup command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-f	Backup file name	Valid file name
-pp	Password or pass-phrase used to encrypt passwords inside the backup file	Valid password or quote-delimited pass-phrase
-ip	IP address of TFTP/SFTP server	Valid IP address
-pn	Port number of TFTP/SFTP server	Valid port number (default 69/22)
-u	Username for SFTP server	Valid user name
-pw	Password for SFTP server	Valid password
-fd	Filename for XML description of backup CLI commands	Valid filename

Syntax:

```

backup [options]
option:
  -f    filename
  -pp   password
  -ip   ip address
  -pn   port number
  -u    username
  -pw   password
  -fd   filename

```

Example:

```

system> backup f xcc-back.cli pp xxxxxx ip 192.168.70.200
ok
system>

```

dhcpinfo command

Use this command to view the DHCP server-assigned IP configuration for eth0.

Use the **dhcpinfo** command to view the DHCP server-assigned IP configuration for eth0, if the interface is configured automatically by a DHCP server. You can use the **ifconfig** command to enable or disable DHCP.

Syntax:

```
dhcpinfo eth0
```

Example:

```

system> dhcpinfo eth0
-server : 10.240.0.10
-n      : XCC-7X19-123456789A
-i      : 10.243.4.66
-i6     : ::
-g      : 10.243.0.1
-s      : 255.255.240.0
-d      : labs.lenovo.com
-d6     :
-dns1   : 10.240.0.10
-dns2   : 10.240.0.11
-dns3   : 0.0.0.0
-dns61  : ::
-dns62  : ::
-dns63  : ::

```

The following table describes the output from the example.

Table 24. *dhcpinfo* command

The following table is a multi-row two column table describing the options that are used in the previous example.

Option	Description
-server	DHCP server that assigned the configuration
-n	Assigned host name
-i	Assigned IPv4 address

Table 24. *dhcpcinfo* command (continued)

Option	Description
-g	Assigned gateway address
-s	Assigned subnet mask
-d	Assigned domain name
-dns1	Primary IPv4 DNS server IP address
-dns2	Secondary IPv4 DNS IP address
-dns3	Tertiary IPv4 DNS server IP address
-i6	IPv6 address
-d6	IPv6 domain name
-dns61	Primary IPv6 DNS server IP address
-dns62	Secondary IPv6 DNS IP address
-dns63	Tertiary IPv6 DNS server IP address

dns command

Use this command to view and set the DNS configuration of the IMM.

Note: In a Flex System, DNS settings cannot be modified on the IMM. DNS settings are managed by the CMM.

Running the **dns** command with no options displays all DNS configuration information. The following table shows the arguments for the options.

Table 25. *dns* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-state	DNS state	on, off
-ddns	DDNS state	enabled, disabled
-i1	Primary IPv4 DNS server IP address	IP address in dotted decimal IP address format.
-i2	Secondary IPv4 DNS IP address	IP address in dotted decimal IP address format.
-i3	Tertiary IPv4 DNS server IP address	IP address in dotted decimal IP address format.
-i61	Primary IPv6 DNS server IP address	IP address in IPv6 format.
-i62	Secondary IPv6 DNS IP address	IP address in IPv6 format.
-i63	Tertiary IPv6 DNS server IP address	IP address in IPv6 format.
-p	IPv4/IPv6 priority	ipv4, ipv6

Syntax:

dns [options]

option:

-state **state**


```

-ddns state
-i1 first_ipv4_ip_address
-i2 second_ipv4_ip_address
-i3 third_ipv4_ip_address
-i61 first_ipv6_ip_address
-i62 second_ipv6_ip_address
-i63 third_ipv6_ip_address
-p priority

```

Note: The following example shows an IMM configuration where DNS is disabled.

Example:

```

system> dns
  -state : disabled
  -i1    : 0.0.0.0
  -i2    : 0.0.0.0
  -i3    : 0.0.0.0
  -i61   : ::
  -i62   : ::
  -i63   : ::
  -ddns  : enabled
  -dnsrc : DHCP
  -ddn   :
  -ddncur : labs.lenovo.com
  -p     : ipv6
  -dscvry : enabled

```

system>

The following table describes the options used in the previous example.

Table 26. *dns* command output

The following table is a multi-row two column table describing the options used in the previous example.

Option	Description
-state	State of DNS (on or off)
-i1	Primary IPv4 DNS server IP address
-i2	Secondary IPv4 DNS IP address
-i3	Tertiary IPv4 DNS server IP address
-i61	Primary IPv6 DNS server IP address
-i62	Secondary IPv6 DNS IP address
-i63	Tertiary IPv6 DNS server IP address
-ddns	State of DDNS (enabled or disabled)
-dnsrc	Preferred DDNS domain name (dhcp or manual)
-ddn	Manually specified DDN
-ddncur	Current DDN (read only)
-p	Preferred DNS servers (ipv4 or ipv6)

encaps command

Use this command to let the BMC quit encapsulation mode.

The following table shows the arguments for the options.

Table 27. *encaps command*

The following table is a one-row two column table consisting of the options and option descriptions.

Option	Description
lite off	Let BMC quit encapsulation mode and open global access to all users

ethtousb command

Use the **ethtousb** command to display and configure Ethernet to Ethernet-over-USB port mapping.

The command allows you to map an external Ethernet port number to a different port number for Ethernet-over-USB.

Running the **ethtousb** command with no options displays Ethernet-over-USB information. The following table shows the arguments for the options.

Table 28. *ethtousb command*

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-en	Ethernet-over-USB state	enabled, disabled
-mx	Configure port mapping for index x	Port pair, separated by a colon (:), of the form port1:port2 Where: <ul style="list-style-type: none"> The port index number, x, is specified as an integer from 1 to 10 in the command option. port1 of the port pair is the External Ethernet port number. port2 of the port pair is the Ethernet-over-USB port number.
-rm	Remove port mapping for specified index	1 through 10 Port map indexes are displayed using the ethtousb command with no options.

Syntax:

```
ethtousb [options]
```

option:

- en **state**
- m**xport_pair**
- rm **map_index**

Example:

```
system> ethtousb -en enabled -m1 100:200 -m2 101:201
```

```
system> ethtousb
```

```
-en enabled
```

```
-m1 100:200
```

```
-m2 101:201
```

```
system> ethtousb -rm 1
```

```
system>
```

firewall command

Use this command to configure the firewall to restrict access from certain addresses and optionally limits access time frame. If no option is specified, the current settings will be displayed.

The following table shows the arguments for the options.

Table 29. *firewall command*

The following table is a multi-row three column table consisting of the options and option descriptions.

Option	Description	Values
-bips	Block 1-3 IP addresses (comma separated, CIDR or range)	Valid IP addresses Note: IPv4 and IPv6 addresses can use CIDR format to block a range of addresses.
-bmacs	Block 1-3 MAC addresses (comma separated)	Valid MAC addresses Note: MAC address filtering works only with specific addresses.
-bbd	Block begin date	Date with format <YYYY-MM-DD>
-bed	Block end date	Date with format <YYYY-MM-DD>
-bbt	Block begin time	Time with format <HH:MM>
-bet	Block end time	Time with format <HH:MM>
-bti	Block 1-3 time intervals (comma separated) e.g., firewall - bti 01:00-02:00,05:05-10:30 will block access during 01:00-02:00 & 05:05-10:30 every day	Time range with format <HH:MM-HH:MM>
-clr	Clear the firewall rule for a given type	ip, mac, datetime, interval, all
The following options are for IP address blocking		
-iplp	IP address lockout period in minutes.	Numeric value between 0 and 2880, 0 = never expire
-iplf	Maximum number of login failures before IP address is locked out. Note: If this value is not 0, then it must be greater than or equal to <Maximum number of login failures> that is set by <accsecfg -lf>	Numeric value between 0 and 32, 0 = never lock
-ipbl	Show/configure the list of IP addresses being locked out.	del, clrall, show <ul style="list-style-type: none"> • -del: delete an IPv4 or IPv6 address from block list • -clrall: clear all blocking IP • -show: show all blocking IPs

Example:

- “firewall”: Show all options’ value and IP addresses blocking list.
- “firewall -bips 192.168.1.1,192.168.1.0/24,192.168.1.1-192.168.1.5”: Block the access from multi IPs
- “firewall -bti 01:00-02:00,05:05-10:30,14:15-20:00”: Block all access during 01:00-02:00,05:05-10:30,14:15-20:00 every day.
- “firewall -clr all”: Clear all rules of “Block List and Time Restriction”.
- “firewall -iplp 60”:Set IP address lockout period to 60 minutes.

- “firewall -iplf 5”:Set maximum number of login failures to 5 times.
- “firewall -ipbl -del 192.168.100.1”:Delete 192.168.100.1 from IP address blocking list.
- “firewall -ipbl -del 3fcc:1234::2”:Delete 3fcc:1234::2 from IP address blocking list.
- “firewall -ipbl -clral!”: Delete all blocking IP addresses.
- “firewall -ipbl -show”: Show all blocking IP addresses.

gprofile command

Use this command to display and configure group profiles for the IMM.

The following table shows the arguments for the options.

Table 30. gprofile command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-clear	Delete a group	enabled, disabled
-n	The name of the group	String of up to 63 characters for group_name . The group_name must be unique.
-a	Role-based authority level	supervisor, operator, rbs <role list>: nsc am rca rcvma pr bc cel ac Role list values are specified using a pipe separated list of values.
-h	Display the command usage and options	

Syntax:

gprofile [1 - 16 group_profile_slot_number] [options]

options:

- clear **state**
- n **group_name**
- a **authority level:**
 - nsc **network and security**
 - am **user account management**
 - rca **remote console access**
 - rcvma **remote console and remote disk access**
 - pr **remote server power/restart access**
 - bc **basic adapter configuration**
 - cel **ability to clear event logs**
 - ac **advanced adapter configuration**
- h **help**

hashpw command

Use this command with the -sw option to enable/disable the third-party password function or with the -re option to enable/disable the allowance of retrieving third-party password.

The following table shows the arguments for the options.

Table 31. hashpw command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Table 31. hashpw command (continued)

Option	Description	Values
-sw	Third-Party Password switch status	enabled, disabled
-re	Third-Party Password read status Note: Read can be set if the switch is enabled.	enabled, disabled

Example:

```
system> hashpw -sw enabled -re enabled
system> users -5 -n guest5 -shp ef92b778bafe771e89245b89ecbc08a44a4e166c06659911881f383d4473e94f -a super
system> users -5 ghp
ef92b778bafe771e89245b89ecbc08a44a4e166c06659911881f383d4473e94f
system> users
Account      Login ID      Advanced Attribute      Role      Password Expires
-----
1            USERID      Native      Administrator      Password doesn't expire
5            guest5      Third-party Password      Administrator      90 day(s)
```

ifconfig command

Use this command to configure the Ethernet interface.

Type `ifconfig eth0` to display the current Ethernet interface configuration. To change the Ethernet interface configuration, type the options, followed by the values. To change the interface configuration, you must have at least Adapter Networking and Security Configuration authority.

Note: In a Flex System, the VLAN settings are managed by a Flex System CMM and cannot be modified on the IMM.

The following table shows the arguments for the options.

Table 32. ifconfig command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-b	Burned-in MAC Address (read-only and not configurable)	
-state	Interface state	disabled, enabled
-c	Configuration method	dhcp, static, dthens (dthens corresponds to the try dhcp server, if it fails use static config option on the web interface)
-i	Static IP address	Address in valid format.
-g	Gateway address	Address in valid format.
-s	Subnet mask	Address in valid format.
-n	Host name	String of up to 63 characters. The string can include letters, digits, periods, underscores, and hyphens.
-r	Data rate	10, 100, auto
-d	Duplex mode	full, half, auto

Table 32. ifconfig command (continued)

Option	Description	Values
-m	MTU	Numeric between 60 and 1500.
-l	LAA	MAC address format. Multicast addresses are not allowed (the first byte must be even).
-dn	Domain name	Domain name in valid format.
-auto	Autonegotiation setting, which determines whether the Data rate and Duplex network settings are configurable	true, false
-ghn	Obtain hostname from DHCP	disabled, enabled
-nic	switch NIC mode ¹	shared, dedicated, shared:nixX ²
-failover ²	Failover mode	none, shared, shared:nicX
-nssync ³	Network setting synchronization	enabled, disabled
-address_table	Table of automatically-generated IPv6 addresses and their prefix lengths Note: The option is visible only if IPv6 and stateless auto-configuration are enabled.	This value is read-only and is not configurable.
-ipv6	IPv6 state	disabled, enabled
-lla	Link-local address Note: The link-local address only appears if IPv6 is enabled.	The link-local address is determined by the IMM. This value is read-only and is not configurable.
-ipv6static	Static IPv6 state	disabled, enabled
-i6	Static IP address	Static IP address for Ethernet channel 0 in IPv6 format.
-p6	Address prefix length	Numeric value between 1 and 128.
-g6	Gateway or default route	IP address for the gateway or default route for Ethernet channel 0 in IPv6.
-dhcp6	DHCPv6 state	enabled, disabled
-sa6	IPv6 stateless autoconfig state	enabled, disabled
-vlan	Enable or disable the VLAN tagging	enabled, disabled

Table 32. ifconfig command (continued)

Option	Description	Values
-vlanid	Network packet identification tag for the IMM	Numeric value between 1 and 4094.
<p>Notes:</p> <ol style="list-style-type: none"> -nic will also show the status of nic. [active] indicates which nic XCC is currently using For example: -nic: shared:nic3 nic1: dedicate nic2: ext card slot #3 nic3: ext card slot 5 [active] Indicates that nic3 is in shared mode, on slot 5, nic2 is on slot3, nic1 is XCC dedicated port and XCC is using nic3. The shared:nicX value is available on servers that have an optional mezzanine network card installed. This mezzanine network card can be used by the IMM. If the IMM is configured to use the dedicated management network port, the -failover option will direct the IMM to switch to the shared network port if the dedicated port is disconnected. If the failover mode is enabled, the -nssync option directs the IMM to use the same network settings that are used on the dedicated management network port for the shared network port. 		

Syntax:

```
ifconfig eth0 [options]
```

options:

- state **interface_state**
- c **config_method**
- i **static_ipv4_ip_address**
- g **ipv4_gateway_address**
- s **subnet_mask**
- n **hostname**
- r **data_rate**
- d **duplex_mode**
- m **max_transmission_unit**
- l **locally_administered_MAC**
- b **burned_in_MAC_address**
- dn **domain_name**
- auto **state**
- nic **state**
- failover mode
- nssync **state**
- address_table
- lla **ipv6_link_local_addr**
- dhcp6 **state**
- ipv6 **state**
- ipv6static **state**
- sa6 **state**
- i6 **static_ipv6_ip_address**
- g6 **ipv6_gateway_address**
- p6 **length**
- vlan **state**
- vlanid **VLAN ID**

Example:

```
system> ifconfig eth0
-state      : enabled
-c          : dthens
-ghn       : disabled
-i         : 192.168.70.125
```

```

-g      : 0.0.0.0
-s      : 255.255.255.0
-n      : IMM00096B9E003A
-auto   : true
-r      : auto
-d      : auto
-vlan   : disabled
-vlanid : 1
-m      : 1500
-b      : 00:09:6B:9E:00:3A
-l      : 00:00:00:00:00:00
-dn     :
-ipv6   : enabled
-ipv6static : disabled
-i6     : ::
-p6     : 64
-g6     : ::
-dhcp6  : enabled
-sa6    : enabled
-lla    : fe80::6eae:8bff:fe23:91ae
-nic    : shared:nic3
         nic1: dedicate
         nic2: ext card slot #3
         nic3: ext card slot #5 [active]
-address_table :

```

```

system> ifconfig eth0 -c static -i 192.168.70.133
These configuration changes will become active after the next reset of the IMM.

```

keycfg command

Use this command to display, add, or delete activation keys.

Activation keys control access to optional IMM functionality.

Notes:

- When the **keycfg** command is run without any options, the list of installed activation keys is displayed. Key information displayed includes an index number for each activation key, the type of activation key, the date through which the key is valid, the number of uses remaining, the key status, and a key description.
- Add new activation keys through file transfer.
- Delete old keys by specifying the number of the key or the type of key. When deleting keys by type, only the first key of a given type is deleted.

The following table shows the arguments for the options.

Table 33. *keycfg* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-add	Add activation key	Values for the -ip, -pn, -u, -pw, and -f command options
-ip	IP address of TFTP server with activation key to add	Valid IP address for TFTP server

Table 33. *keycfg* command (continued)

Option	Description	Values
-pn	Port number for TFTP/SFTP server with activation key to add	Valid port number for TFTP/SFTP server (default 69/22)
-u	User name for SFTP server with activation key to add	Valid user name for SFTP server
-pw	Password for SFTP server with activation key to add	Valid password for SFTP server
-f	File name for activation key to add	Valid file name for activation key file
-del	Delete activation key by index number	Valid activation key index number from keycfg listing
-deltype	Delete activation key by key type	Valid key type value

Syntax:

`keycfg [options]`

option:

- add
- ip **tftp/sftp server ip address**
- pn **pn port number of tftp/sftp server (default 69/22)**
- u **username for sftp server**
- pw **password for sftp server**
- f **filename**
- del **n (where n is a valid ID number from listing)**
- deltype **x (where x is a Type value)**

Example:

```
system> keycfg
ID Type Valid Uses Status Description
1 4 10/10/2010 5 "valid" "IMM remote presence"
2 3 10/20/2010 2 "valid" "IMM feature
3 32796 NO CONSTRAINTS NO CONSTRAINTS "valid" "IBM Security Key Lifecycle Manager for SEDs FoD"
system>
```

Note: The **Description** field for ID number 3 is displayed on separate lines due to space limitations.

ldap command

Use this command to display and configure the LDAP protocol configuration parameters.

The following table shows the arguments for the options.

Table 34. *ldap* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-a	User authentication method	local only, LDAP only, local first then LDAP, LDAP first then local
-aom	Authentication only mode	enabled, disabled

Table 34. *ldap command (continued)*

Option	Description	Values
-b	Binding method	anonymous, bind with ClientDN and password, bind with Login Credential
-c	Client distinguished name	String of up to 127 characters for client_dn
-d	Search domain	String of up to 63 characters for search_domain
-f	Group filter	String of up to 127 characters for group_filter
-fn	Forest name	For active directory environments. String of up to 127 characters.
-g	Group search attribute	String of up to 63 characters for group_search_attr
-l	Login permission attribute	String of up to 63 characters for string
-p	Client password	String of up to 15 characters for client_pw
-pc	Confirm client password	String of up to 15 characters for confirm_pw Command usage is: ldap -p client_pw -pc confirm_pw This option is required when you change the client password. It compares the confirm_pw argument with the client_pw argument. The command will fail if the arguments do not match.
-ep	Encrypted password	Backup/restore password (internal use only)
-r	Root entry distinguished name (DN)	String of up to 127 characters for root_dn
-rbs	Enhanced Role-Based Security for active directory users	enabled, disabled
-s1ip	Server 1 host name/IP address	String up to 127 characters or an IP address for host name/ip_addr
-s2ip	Server 2 host name/IP address	String up to 127 characters or an IP address for host name/ip_addr
-s3ip	Server 3 host name/IP address	String up to 127 characters or an IP address for host name/ip_addr
-s4ip	Server 4 host name/IP address	String up to 127 characters or an IP address for host name/ip_addr
-s1pn	Server 1 port number	A numeric port number up to 5 digits for port_number
-s2pn	Server 2 port number	A numeric port number up to 5 digits for port_number
-s3pn	Server 3 port number	A numeric port number up to 5 digits for port_number
-s4pn	Server 4 port number	A numeric port number up to 5 digits for port_number
-t	Server target name	When the rbs option is enabled, this field specifies a target name that can be associated with one or more roles on the Active Directory server through the Role-Based Security (RBS) Snap-In tool.
-u	UID search attribute	String of up to 63 characters for search_attrib
-v	Get LDAP server address through DNS	off, on
-h	Displays the command usage and options	

Syntax:

ldap [options]

options:

- a loc|ldap|loclid|ldloc
- aom enable/disabled
- b anon|client|login
- c client_dn
- d search_domain
- f group_filter
- fn forest_name
- g group_search_attr
- l string
- p client_pw
- pc confirm_pw
- ep encrypted_pw
- r root_dn
- rbs enable|disabled
- s1ip host name/ip_addr
- s2ip host name/ip_addr
- s3ip host name/ip_addr
- s4ip host name/ip_addr
- s1pn port_number
- s2pn port_number
- s3pn port_number
- s4pn port_number
- t name
- u search_attr
- v off|on
- h

ntp command

Use this command to display and configure the Network Time Protocol (NTP).

The following table shows the arguments for the options.

Table 35. ntp command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-en	Enables or disables the Network Time Protocol.	enabled, disabled
-i ¹	Name or IP address of the Network Time Protocol server. This is the index number of the Network Time Protocol server.	The name of the NTP server to be used for clock synchronization. The range of the index number of the NTP server is from -i1 through -i4.
-f	The frequency (in minutes) that the IMM clock is synchronized with the Network Time Protocol server.	3 - 1440 minutes
-synch	Requests an immediate synchronization with the Network Time Protocol server.	No values are used with this parameter.
1. -i is the same as i1.		

Syntax:

```
ntp [options]
options:
-en state
-i hostname/ip_addr
-f frequency
-synch
```

Example:

```
system> ntp
-en: disabled
-f: 3 minutes
-i: not set
```

portcfg command

Use this command to configure the IMM for the serial redirection feature.

The IMM must be configured to match the server internal serial port settings. To change the serial port configuration, type the options, followed by the values. To change the serial port configuration, you must have at least Adapter Networking and Security Configuration authority.

Note: The server external serial port can only be used by the IMM for IPMI functionality. The CLI is not supported through the serial port. The **serred** and **cliath** options that were present in the Remote Supervisor Adapter II CLI are not supported.

Running the **portcfg** command with no options displays serial port configuration. The following table shows the arguments for the options.

Note: The number of data bits (8) is set in the hardware and cannot be changed.

Table 36. portcfg command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-b	Baud rate	9600, 19200, 38400, 57600, 115200
-p	Parity	none, odd, even
-s	Stop bits	1, 2
-climode	CLI mode	0, 1, 2 Where: <ul style="list-style-type: none">• 0 = none: The CLI is disabled• 1 = cliems: The CLI is enabled with EMS-compatible keystroke sequences• 2 = cliuser: The CLI is enabled with user-defined keystroke sequences

Syntax:

```
portcfg [options]
options:
-b baud_rate
-p parity
-s stopbits
```

-climode **mode**

Example:

```
system> portcfg
-b: 57600
-climode: 2 (CLI with user defined keystroke sequence)
-p: even
-s: 1
system> portcfg -b 38400
ok
system>
```

portcontrol command

Use this command to turn a network service port on or off.

Currently this command only supports control of the port for the IPMI protocol. Type **portcontrol** to display the IPMI port state. To enable or disable the IPMI network port, type the **-ipmi** option followed by the **on** or **off** values.

Table 37. portcontrol command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-all	Enable or disable all interfaces and discovery protocols	on, off
-cim	Enable or disable CIM discovery	on, off
-ipmi	Enable or disable the ipmi access via LAN	on, off
-ipmi-kcs	Enable or disable ipmi access from server	on, off
-rest	Enable or disable REST discovery	on, off
-slp	Enable or disable SLP discovery	on, off
-snmp	Enable or disable SNMP discovery	on, off
-ssdp	Enable or disable SSDP discovery	on, off
-cli	Enable or disable CLI discovery	on, off
-web	Enable or disable WEB discovery	on, off

Syntax:

```
portcontrol [options]
```

options:

```
-ipmi on/off
```

Example:

```
system> portcontrol
cim : on
ipmi : on
ipmi-kcs : on
rest : on
slp : on
snmp : off
ssdp : on
cli : on
web : on
```

ports command

Use this command to display and configure IMM ports.

Running the **ports** command with no options displays information for all IMM ports. The following table shows the arguments for the options.

Table 38. *ports* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-open	Display open ports	
-reset	Reset ports to default settings	
-http	HTTP port number	Default port number: 80
-https	HTTPS port number	Default port number: 443
-sshp	SSH legacy CLI port number	Default port number: 22
-snmpap	SNMP agent port number	Default port number: 161
-snmptp	SNMP traps port number	Default port number: 162
-rpp	Remote presence port number	Default port number: 3900
-cimhp	CIM over HTTP port number	Default port number: 5988
-cimhsp	CIM over HTTPS port number	Default port number: 5989

Syntax:

```
ports [options]
```

option:

- open
- reset
- http **port_number**
- https **port_number**
- sshp **port_number**
- snmpap **port_number**
- snmptp **port_number**
- rpp **port_number**
- cimhp **port_number**
- cimhsp **port_number**

Example:

```
system> ports
```

```

-http 80
-https 443
-rpp 3900
-snmppap 161
-snmptp 162
-sshp 22
-cimhp 5988
-cimhsp 5989
system>

```

rdmount command

Use this command to mount remote disk images or network shares

The following table shows the arguments for the options.

Table 39. *rdmount* command

The following table is a multi-row two column table consisting of the options and option descriptions.

Notes:

- Up to two files can be uploaded in the XClarity Controller memory and mounted as virtual media using the XClarity Controller RDOC feature. The total size for both files must not exceed 50 MB. The uploaded images are read only unless the `-rw` option is used.
- When using the HTTP, SFTP, or FTP protocols to mount or map the images, the total size for all the images must not exceed 50 MB. There is no size limit if the NFS or SAMBA protocols are used.

Option	Description
-r	rdoc operation (if used, must be first option) -r -map: mount the RDOC images -r -unmap<filename>: unmount the mounted RDOC images -r -maplist: shows the mounted RDOC images via the XClarity Controller web browser and the CLI interface
-map	-t <samba nfs http sftp ftp> filesystem type -ro read-only -rw read-write -u user -p password -l file location (URL format) -o option (extra option string for samba and nfs mounts) -d domain (domain for samba mount)
-maplist	shows the mapped images
-unmap <id fname>	use id with network images, filename with rdoc
-mount	mount the mapped images
-unmount	unmount the mounted images

restore command

Use this command to restore system settings from a backup file.

The following table shows the arguments for the options.

Table 40. restore command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-f	Backup file name	Valid file name
-pp	Password or pass-phrase used to encrypt passwords inside the backup file	Valid password or quote-delimited pass-phrase
-ip	IP address of TFTP/SFTP server	Valid IP address
-pn	Port number of TFTP/SFTP server	Valid port number (default 69/22)
-u	Username for SFTP server	Valid user name
-pw	Password for SFTP server	Valid password

Syntax:

```
restore [options]
```

option:

-f **filename**

-pp **password**

-ip **ip_address**

-pn **port_number**

username

-pw **password**

Example:

```
system> restore f xcc-back.cli pp xxxxxx ip 192.168.70.200
```

```
ok
```

```
system>
```

restoredefaults command

Use this command to restore all IMM settings to the factory default.

- There are no options for the **restoredefaults** command.
- You will be asked to confirm the command before it is processed.

Syntax:

```
restoredefaults
```

Example:

```
system> restoredefaults
```

This action will cause all IMM settings to be set to factory defaults.

If this is the local system, you will lose your TCP/IP connection as a result. You will need to reconfigure the IMM network interface to restore connectivity. After the IMM configuration is cleared, the IMM will be restarted.


```
Proceed? (y/n)
Y
Restoring defaults
```

roles command

Use this command to display or configure roles.

The following table shows the arguments for the options.

Table 41. roles command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-n	Role to configure	Limited to 32 characters
-p	Set privileges	custom:am rca rcvma pr cel bc nsc ac us <ul style="list-style-type: none"> • am: User account management access • rca: Remote console access • rcvma: Remote console and remote disk (virtual media) access • pr: Remote server power/restart access • cel: Ability to clear event logs • bc: Adapter Configuration (basic) • nsc: Adapter Configuration (network and security) • ac: Adapter Configuration (advanced) • us: UEFI Security <p>Note: the above custom permission flags can be used in any combination</p>
d	Delete a row	

Syntax

```
roles [-options] - display/configure roles
  - role_account -role number[3-31]
options:
-n      - role name (limited to 32 characters)
-p      - privilege (custom:am|rca|rcvma|pr|cel|bc|nsc|ac|us)
  am    - User account management access
  rca    - Remote console access
  rcvma - Remote console and remote disk (virtual media) access
  pr     - Remote server power/restart access
  cel    - Ability to clear event logs
  bc     - Adapter Configuration (basic)
  nsc    - Adapter Configuration (network and security)
  ac     - Adapter Configuration (advanced)
  us     - UEFI Security
  Note: the above custom permission flags can be used in any combination
-d      - delete a row
```

Example

```
system> roles -3 -n test1 -p custom:am|rca|rcvma
ok
```

```
system> roles
Account          Role                Privilege          Assigned To
-----
0                Administrator      all               USERID
1                ReadOnly          none
2                Operator          custom:pr|cel|bc|nsc
3                test1             custom:am|rca|rcvma
```

seccfg command

Use this command to perform firmware rollback.

The following table shows the arguments for the options.

Table 42. *seccfg* command

The following table is a multi-row two column table consisting of the options and option descriptions.

Option	Description	Value
-fwrb	Allows firmware rollback to previous versions	yes, no
-rppen	Remote physical presence enable (read only)	/
-rppto	Remote physical presence timeout (read only)	/
-rpp	Physical presence (if enabled by BIOS)	yes, no
-aubp	enable or disable the function of auto backup to primary promotion	enabled, disabled

set command

Use this command to change some IMM settings.

- Some IMM settings can be changed with a simple **set** command.
- Some of these settings, such as environment variables, are used by the CLI.

The following table shows the arguments for the options.

Table 43. *set* command

The following table is a single-row three column table consisting of the command description and associated information.

Option	Description	Values
value	Set value for specified path or setting	Appropriate value for specified path or setting.

Syntax:

```
set [options]
```

option:

```
value
```

smtp command

Use this command to display and configure settings for the SMTP interface.

Running the **smtp** command with no options displays all SMTP interface information. The following table shows the arguments for the options.

Table 44. *smtp* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-auth	SMTP authentication support	enabled, disabled
-authpw	SMTP authentication encrypted password	Valid password string
-authmd	SMTP authentication method	CRAM-MD5, LOGIN
-authn	SMTP authentication user name	String (limited to 256 characters)
-authpw	SMTP authentication password	String (limited to 256 characters)
-pn	SMTP port number	Valid port number
-s	SMTP server IP address or host name	Valid IP address or host name (63 character limit)

Syntax:

```
smtp [options]
```

option:

```
-auth enabled|disabled  
-authpw password  
-authmd CRAM-MD5|LOGIN  
-authn username  
-authpw password  
-s ip_address_or_hostname  
-pn port_number
```

Example:

```
system> smtp  
-s test.com  
-pn 25  
system>
```

snmp command

Use this command to display and configure SNMP interface information.

Running the **snmp** command with no options displays all SNMP interface information. The following table shows the arguments for the options.

Table 45. *snmp* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Table 45. snmp command (continued)

Option	Description	Values
-a3	SNMPv3 agent	on, off Notes: To enable the SNMPv3 agent, the following criteria must be met: <ul style="list-style-type: none"> • IMM contact specified using the -cn command option. • IMM location specified using the -l command option.
-t1	SNMPv1 traps	on, off
-t2	SNMPv2 traps	on, off
-t	SNMPv3 traps	on, off
-l	IMM location	String (limited to 47 characters). Notes: <ul style="list-style-type: none"> • Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. • Clear the IMM location by specifying no argument or by specifying an empty string as the argument, such as "".
-cn	IMM contact name	String (limited to 47 characters). Notes: <ul style="list-style-type: none"> • Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. • Clear the IMM contact name by specifying no argument or by specifying an empty string as the argument, such as "".
-c	SNMP community name	String (limited to 15 characters). Notes: <ul style="list-style-type: none"> • Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. • Clear an SNMP community name by specifying no argument or by specifying an empty string as the argument, such as "".
-ct	SNMPv2 trap community name	String (limited to 15 characters). Notes: <ul style="list-style-type: none"> • Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments. • Clear the IMM contact name by specifying no argument or by specifying an empty string as the argument, such as "".
-ci	SNMP community IP address/host name	Valid IP address or hostname (limited to 63 characters). Notes: <ul style="list-style-type: none"> • An IP address or host name can only contain dots, underscores, minus signs, letters and digits. No embedded spaces or consecutive periods are allowed. • Clear an SNMP community IP address or host name by specifying no argument.

Table 45. snmp command (continued)

Option	Description	Values
-cti	SNMPv2 trap community IP address/hostname	Valid IP address or hostname (limited to 63 characters). Notes: <ul style="list-style-type: none"> An IP address or host name can only contain dots, underscores, minus signs, letters and digits. No embedded spaces or consecutive periods are allowed. Clear an SNMP community IP address or host name by specifying no argument.
-eid	SNMP engine id	String (limited 1 to 27 characters)

Syntax:

```
snmp [options]
option:
-a3 state
-t state
-l location
-cn contact_name
-t1 state
-c community name
-ci community IP address/hostname
-t2 state
-ct community name
-cti community IP address/hostname
-eid engine id
```

Example:

```
system> snmp
-t enabled
-a3 enabled
-l ZhangjiangMansion
-cn Kelvin
-t1 enabled
-c community1
-ci host1
-t2 enabled
-ct community2
-cti host2
-eid XCC-7Z70-DSYM09X
system>
```

snmpalerts command

Use this command to manage alerts sent via the SNMP.

Running **snmpalerts** with no options displays all SNMP alert settings. The following table shows the arguments for the options.

Table 46. snmpalerts command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Table 46. *snmpalerts* command (continued)

Option	Description	Values
-status	SNMP alert status	on, off
-crt	Sets critical events that send alerts	all, none, custom:te vo po di fa cp me in re ot Custom critical alert settings are specified using a pipe separated list of values of the form snmpalerts -crt custom:te vo , where custom values are: <ul style="list-style-type: none"> • te: critical temperature threshold exceeded • vo: critical voltage threshold exceeded • po: critical power failure • di: hard disk drive failure • fa: fan failure • cp: microprocessor failure • me: memory failure • in: hardware incompatibility • re: power redundancy failure • ot: all other critical events
-crten	Send critical event alerts	enabled, disabled
-wrn	Sets warning events that send alerts	all, none, custom:rp te vo po fa cp me ot Custom warning alert settings are specified using a pipe separated list of values of the form snmpalerts -wrn custom:rp te , where custom values are: <ul style="list-style-type: none"> • rp: power redundancy warning • te: warning temperature threshold exceeded • vo: warning voltage threshold exceeded • po: warning power threshold exceeded • fa: non-critical fan event • cp: microprocessor in degraded state • me: memory warning • ot: all other warning events
-wrnen	Send warning event alerts	enabled, disabled

Table 46. *snmpalerts* command (continued)

Option	Description	Values
-sys	Sets routine events that send alerts	all, none, custom:lo tio ot po bf til pf el ne Custom routine alert settings are specified using a pipe separated list of values of the form snmpalerts -sys custom:lo tio , where custom values are: <ul style="list-style-type: none"> • lo: successful remote login • tio: operating system timeout • ot: all other informational and system events • po: system power on/off • bf: operating system boot failure • til: operating system loader watchdog timeout • pf: predicted failure (PFA) • el: event log 75% full • ne: network change
-sysen	Send routine event alerts	enabled, disabled

Syntax:

```
snmpalerts [options]
options:
  -status status
  -crt event_type
  -crten state
  -wrn event_type
  -wrnen state
  -sys event_type
  -sysen state
```

srcfg command

Use this command to indicate the key sequence to enter the CLI from the serial redirection mode.

To change the serial redirect configuration, type the options, followed by the values. To change the serial redirect configuration, you must have at least Adapter Networking and Security Configuration authority.

Note: The IMM hardware does not provide for a serial port to serial port pass-through capability. Therefore the `-passthru` and `entercliseq` options which are present in the Remote Supervisor Adapter II CLI are not supported.

Running the **srcfg** command with no options displays the current serial redirection keystroke sequence. The following table shows the arguments for the `srcfg -entercliseq` command option.

Table 47. *srcfg* command

The following table is a single-row three column table consisting of the option, option description, and value information for the option.

Table 47. *srcfg* command (continued)

Option	Description	Values
-entercliseq	Enter a CLI keystroke sequence	User-defined keystroke sequence to enter the CLI. Note: This sequence must have at least one character and at most 15 characters. The caret symbol (^) has a special meaning in this sequence. It denotes Ctrl for keystrokes that map to Ctrl sequences (for example, ^[for the escape key and ^M for carriage return). All occurrences of ^ are interpreted as part of a Ctrl sequence. Refer to an ASCII-to-key conversion table for a complete list of Ctrl sequences. The default value for this field is ^[(which is Esc followed by (.

Syntax:

`srcfg [options]`

options:

-entercliseq **entercli_keyseq**

Example:

```
system> srcfg
-entercliseq ^[Q
system>
```

sshcfg command

Use this command to display and configure SSH parameters.

Running the **sshcfg** command with no options displays all SSH parameters. The following table shows the arguments for the options.

Table 48. *sshcfg* command

This following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-cstatus	State of SSH CLI	enabled, disabled
-hk gen	Generate SSH server private key	
-hk rsa	Display server RSA public key	

Syntax:

`sshcfg [options]`

option:

-cstatus **state**
-hk gen
-hk rsa

Example:

```
system> sshcfg
-cstatus enabled
CLI SSH port 22
ssh-rsa 2048 bit fingerprint: b4:a3:5d:df:0f:87:0a:95:f4:d4:7d:c1:8c:27:51:61
1 SSH public keys installed
system>
```


ssl command

Use this command to display and configure the SSL parameters.

To enable an SSL client, a client certificate must be installed. Running the **ssl** command with no options displays SSL parameters. The following table shows the arguments for the options.

Table 49. *ssl* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-ce	Enables or disables an SSL client	on, off
-se	Enables or disables an SSL server	on, off
-cime	Enables or disables CIM over HTTPS on the SSL server	on, off

Syntax:

```
portcfg [options]
options:
  -ce state
  -se state
  -cime state
```

Parameters: The following parameters are presented in the option status display for the **ssl** command and are output only from the CLI:

Server secure transport enable

This status display is read-only and cannot be set directly.

Server Web/CMD key status

This status display is read-only and cannot be set directly. Possible command line output values are as follows:

- Private Key and Cert/CSR not available
- Private Key and CA-signed cert installed
- Private Key and Auto-gen self-signed cert installed
- Private Key and Self-signed cert installed
- Private Key stored, CSR available for download

SSL server CSR key status

This status display is read-only and cannot be set directly. Possible command line output values are as follows:

- Private Key and Cert/CSR not available
- Private Key and CA-signed cert installed
- Private Key and Auto-gen self-signed cert installed
- Private Key and Self-signed cert installed
- Private Key stored, CSR available for download

SSL client LDAP key status

This status display is read-only and cannot be set directly. Possible command line output values are as follows:

- Private Key and Cert/CSR not available
- Private Key and CA-signed cert installed
- Private Key and Auto-gen self-signed cert installed
- Private Key and Self-signed cert installed
- Private Key stored, CSR available for download

SSL client CSR key status

This status display is read-only and cannot be set directly. Possible command line output values are as follows:

- Private Key and Cert/CSR not available
- Private Key and CA-signed cert installed
- Private Key and Auto-gen self-signed cert installed
- Private Key and Self-signed cert installed
- Private Key stored, CSR available for download

sslcfg command

Use this command to display and configure the SSL for the IMM and manage certificates.

Running the **sslcfg** command with no options displays all SSL configuration information. The **sslcfg** command is used to generate a new encryption key and self-signed certificate or certificate signing request (CSR). The following table shows the arguments for the options.

Table 50. sslcfg command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-server	SSL server status	enabled, disabled Note: The SSL server can be enabled only if a valid certificate is in place.
-client	SSL client status	enabled, disabled Note: The SSL client can be enabled only if a valid server or client certificate is in place.
-cim	CIM over HTTPS status	enabled, disabled Note: CIM over HTTPS can be enabled only if a valid server or client certificate is in place.
-cert	Generate self-signed certificate	server, client, sysdir, storekey Notes: <ul style="list-style-type: none"> • Values for the -c, -sp, -cl, -on, and -hn command options are required when generating a self-signed certificate. • Values for the -cp, -ea, -ou, -s, -gn, -in, and -dq command options are optional when generating a self-signed certificate.
-csr	Generate a CSR	server, client, sysdir, storekey Notes: <ul style="list-style-type: none"> • Values for the -c, -sp, -cl, -on, and -hn command options are required when generating a CSR. • Values for the -cp, -ea, -ou, -s, -gn, -in, -dq, -cpwd, and -un command options are optional when generating a CSR.

Table 50. `sslcfg` command (continued)

Option	Description	Values
-i	IP address for TFTP/SFTP server	Valid IP address Note: An IP address for the TFTP or SFTP server must be specified when uploading a certificate, or downloading a certificate or CSR.
-pn	Port number of TFTP/SFTP server	Valid port number (default 69/22)
-u	User name for SFTP server	Valid user name
-pw	Password for SFTP server	Valid password
-l	Certificate filename	Valid filename Note: A filename is required when downloading or uploading a certificate or CSR. If no filename is specified for a download, the default name for the file is used and displayed.
-dnld	Download certificate file	This option takes no arguments; but, must also specify values for the -cert or -csr command option (depending on the certificate type being downloaded). This option takes no arguments; but, must also specify values for the -i command option, and -l (optional) command option.
-upld	Imports certificate file	This option takes no arguments, but must also specify values for the -cert , -i , and -l command options.
-tcx	Trusted certificate x for SSL client	import, download, remove Note: The trusted certificate number, x , is specified as an integer from 1 to 3 in the command option.
-c	Country	Country code (2 letters) Note: Required when generating a self-signed certificate or CSR.
-sp	State or province	Quote-delimited string (maximum 60 characters) Note: Required when generating a self-signed certificate or CSR.
-cl	City or locality	Quote-delimited string (maximum 50 characters) Note: Required when generating a self-signed certificate or CSR.
-on	Organization name	Quote-delimited string (maximum 60 characters) Note: Required when generating a self-signed certificate or CSR.
-hn	IMM host name	String (maximum 60 characters) Note: Required when generating a self-signed certificate or CSR.
-cp	Contact person	Quote-delimited string (maximum 60 characters) Note: Optional when generating a self-signed certificate or CSR.
-ea	Contact person email address	Valid email address (maximum 60 characters) Note: Optional when generating a self-signed certificate or CSR.
-ou	Organizational unit	Quote-delimited string (maximum 60 characters) Note: Optional when generating a self-signed certificate or CSR.
-s	Surname	Quote-delimited string (maximum 60 characters) Note: Optional when generating a self-signed certificate or CSR.
-gn	Given name	Quote-delimited string (maximum 60 characters) Note: Optional when generating a self-signed certificate or CSR.
-in	Initials	Quote-delimited string (maximum 20 characters) Note: Optional when generating a self-signed certificate or CSR.
-dq	Domain name qualifier	Quote-delimited string (maximum 60 characters) Note: Optional when generating a self-signed certificate or CSR.

Table 50. `sslcfg` command (continued)

Option	Description	Values
-cpwd	Challenge password	String (minimum 6 characters, maximum 30 characters) Note: Optional when generating a CSR.
-un	Unstructured name	Quote-delimited string (maximum 60 characters) Note: Optional when generating a CSR.

Syntax:

`sslcfg` [**options**]

option:

- server **state**
- client **state**
- cim **state**
- cert **certificate_type**
- csr **certificate_type**
- i **ip_address**

port **number**

username

- pw **password**
- l **filename**
- dnld
- upld
- tc **xaction**
- c **country_code**
- sp **state_or_province**
- cl **city_or_locality**
- on **organization_name**
- hn **bmc_hostname**
- cp **contact_person**
- ea **email_address**
- ou **organizational_unit**
- s **surname**
- gn **given_name**
- in **initials**
- dq **dn_qualifier**
- cpwd **challenge_password**
- un **unstructured_name**

Examples:

```
system> sslcfg
```

```
-server enabled
```

```
-client disabled
```

```
-sysdir enabled
```

```
SSL Server Certificate status:
```

```
A self-signed certificate is installed
```

```
SSL Client Certificate status:
```

```
A self-signed certificate is installed
```

```
SSL CIM Certificate status:
```

```
A self-signed certificate is installed
```

```
SSL Client Trusted Certificate status:
```

```
Trusted Certificate 1: Not available
```

```
Trusted Certificate 2: Not available
```

```
Trusted Certificate 3: Not available
```

```
Trusted Certificate 4: Not available
```

Client certificate examples:

- To generate a CSR for a storage key, enter the following command:

```
system> sslcfg
-csr storekey -c US -sp NC -cl rtp -on Lenovo -hn XCC-5cf3fc6e0c9d
-cp Contact -ea "" -ou""
ok
```

The above example is displayed on multiple lines due to space limitations.

- To download a certificate from the IMM to another server, enter the following command:

```
system> sslcfg
-csr storekey -dnld -i 192.168.70.230 -l storekey.csr
ok
```
- To upload the certificate processed by the Certificate Authority (CA), enter the following command:

```
system> sslcfg
-cert storekey -upld -i 192.168.70.230 -l tklm.der
```
- To generate a self-signed certificate, enter the following command:

```
system> sslcfg
-cert storekey -c US -sp NC -cl rtp -on Lenovo -hn XCC-5cf3fc6e0c9d
-cp Contact -ea "" -ou ""
ok
```

The above example is displayed on multiple lines due to space limitations.

SKLM Server certificate example:

- To import the SKLM server certificate, enter the following command:

```
system> storekeycfg
-add -ip 192.168.70.200 -f tklm-server.der
ok
```

storekeycfg command

Use this command to configure the host name or IP address and network port for a SKLM server.

You can configure up to four SKLM server targets. The **storekeycfg** command is also used to install and remove the certificates that are used by the IMM for authentication to the SKLM server.

The following table shows the arguments for the options.

Table 51. *storekeycfg* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-add	Add the activation key	Values are -ip, -pn, -u, -pw, and -f command options
-ip	Host name or IP address for the TFTP/SFTP server	Valid host name or IP address for TFTP/SFTP server
-pn	Port number of the TFTP or SFTP server	Valid port number for TFTP/SFTP server (default value is 69/22)
-u	User name for SFTP server	Valid user name for SFTP server
-pw	Password for SFTP server	Valid password for SFTP server
-f	File name for activation key	Valid file name for activation key file name

Table 51. storekeycfg command (continued)

Option	Description	Values
-del	Use this command to delete the activation key by index number	Valid activation key index number from keycfg listing
-dgrp	Add the device group	Device group name
-sxiip	Add the host name or IP address for the SKLM server	Valid host name or IP address for SKLM server. Numeric value of 1, 2, 3, or 4.
-sxpn	Add the port number of the SKLM server	Valid port number for SKLM server. Numeric value of 1, 2, 3, or 4.
-testx	Test the configuration and connection to the SKLM server	Numeric value of 1, 2, 3, or 4
-h	Display the command usage and options	

Syntax:

storekeycfg [options]

options:

- add **state**
- ip **ip_address**
- pn **port_number**
- u **username**
- pw **password**
- f **filename**
- del **key_index**
- dgrp **device_group_name**
- sxiip **ip_address**
- sxpn **port_number**
- testx **numeric value of SKLM server**
- h

Examples:

To import the SKLM server certificate, enter the following command:

```
system> storekeycfg
add -ip 192.168.70.200 -f tklm-server.der
system> ok
```

To configure the SKLM server address and port number, enter the following command:

```
system> storekeycfg
-s1ip 192.168.70.249
system> ok
```

To set the device group name, enter the following command:

```
system> storekeycfg
-dgrp IBM_SYSTEM_X_SED
system> ok
```

syncprep command

Use this command to launch firmware sync from remote repository.

The following table shows the arguments for the options.

Table 52. *syncprep* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-t	Protocol to connect repository	samba, nfs
-l	Location of remote repository	In URL format
-u	User	
-p	Password	
-o	Option	Extra option string for samba and nfs mounts
-d	Domain	Domain for samba mount
-q	Query current update status	
-c	Cancel the sync process	

Syntax

`syncprep [options]` Launch firmware sync from remote repository

options:

- t <samba|nfs> protocol to connect repository
- l location of remote repository (URL format)
- u User
- p Password
- o option (extra option string for samba and nfs mounts)
- d domain (domain for samba mount)
- q query current update status
- c cancel the sync process

Example

```
(1) start sync with repository
system> syncprep -t samba -l url -u user -p password
(2) query current update status
system> syncprep -q
(3)cancel the sync process
system> syncprep -c
```

thermal command

Use this command to display and configure the thermal mode policy of the host system.

Running the **thermal** command with no options displays the thermal mode policy. The following table shows the arguments for the options.

Table 53. *thermal* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-mode	Thermal mode selection	normal, performance, minimal, efficiency, custom
-table	Vendor, device identification (ID) and alternate thermal table	

Syntax:

`thermal [options]`

option:

-mode **thermal_mode**

-table **vendorID_devicetable_number**

Example:

```
system> thermal
```

```
-mode normal
```

```
-table 80860126 1 10DE0DFA 3
```

```
system>
```

timeouts command

Use this command to display or change the timeout values.

- To display the timeouts, type `timeouts`.
- To change timeout values, type the options followed by the values.
- To change timeout values, you must have at least Adapter Configuration authority.

The following table shows the arguments for the timeout values. These values match the graduated scale pull-down options for server timeouts on the web interface.

Table 54. *timeouts* command

The following table is a multi-row four column table consisting of the options, option descriptions, and associated values for the options.

Option	Timeout	Units	Values
-f	Power off delay	minutes	disabled, 0.5, 1, 2, 3, 4, 5, 7.5, 10, 15, 20, 30, 60, 120
-l	Loader timeout	minutes	disabled, 0.5, 1, 1.5, 2, 2.5, 3, 3.5, 4, 4.5, 5, 7.5, 10, 15, 20, 30, 60, 120
-o	Operating system timeout	minutes	disabled, 2.5, 3, 3.5, 4
-s	OS failure screen capture with HW error	/	disabled, enabled

Syntax:

`timeouts [options]`

options:

-f **power_off_delay_watchdog_option**

-o **OS_watchdog_option**

-l **loader_watchdog_option**

-s **OS failure screen capture with HW error**

Example:

```
system> timeouts
```

```
-o disabled
```

```
-l 3.5
```

```
-f disabled
```

```
-s disabled
```

```
system> timeouts -o 2.5
```

```
ok
```

```
system> timeouts
```



```
-o 2.5
-l 3.5
-f disabled
-s disabled
```

tls command

Use this command to set the minimum TLS level.

The following table shows the arguments for the options.

Table 55. *tls* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-min	Select the minimum TLS level	1.0, 1.1, 1.2 ¹ , 1.3
-h	List the usage and options	
Notes: 1. When the cryptography mode is set to the NIST-800-131A Compliance mode, the TLS version must be set to 1.2.		

Usage:

```
tls [-options] - configures the minimum TLS level
  -min <1.0 | 1.1 | 1.2 | 1.3> - Selects the minimum TLS level
  -h - Lists usage and options
```

Examples:

To get the usage for the `tls` command, issue the following command:

```
system> tls
-h
system>
```

To obtain the current `tls` version, issue the following command:

```
system> tls
-min 1.2
system>
```

To change the current `tls` version to 1.2, issue the following command:

```
system> tls
-min 1.2
ok
system>
```

trespass command

Use this command to configure and display the trespass messages.

The **trespass** command can be used to configure and display the trespass messages. The trespass messages will be displayed to any user logging in through the WEB or CLI interface.

The following table shows the arguments for the options.

Table 56. uefipw command

The following table is a multi-row two column table consisting of the options and option descriptions.

Option	Description
-s	Configure trespass messages
-h	Lists usage and options

Syntax:

usage:

```
trespass display the trespass message
-s <trespass message> configure trespass message
-h - Lists usage and options
```

Example:

Note: The trespass message does not contain any space.

```
system> trespass -s testingmessage
ok
system> trespass
testingmessage
```

The trespass message contains spaces:

```
system> trespass -s "testing message"
ok
system> trespass
testing message
```

uefipw command

Use this command to configure UEFI admin passwords. The password is write-only.

The **uefipw** command can be used with the “-p” option to configure the UEFI admin password for XCC or with the “-ep” option for LXCA to configure the UEFI admin password by CLI interface. The password is write-only.

The following table shows the arguments for the options.

Table 57. uefipw command

The following table is a multi-row two column table consisting of the options and option descriptions.

Option	Description
-cp	Current password (limited to 20 characters)
-p	New password (limited to 20 characters)
-cep	Current password encrypted
-ep	New password encrypted

Syntax:

usage:

```
uefipw [-options] - Configure the UEFI admin password
```

options:

```
-cp - current password (limited to 20 characters)
```

- p - new password (limited to 20 characters)
- cep - current password encrypted
- ep - new password encrypted

usbeth command

Use this command to enable or disable the in-band LAN over USB interface.

Syntax:

usbeth [**options**]

options:

-en <enabled|disabled>

Example:

```
system>usbeth
-en : disabled
system>usbeth -en enabled
ok
system>usbeth
-en : disabled
```

usbfpc command

Use this command to control the BMC use of the front panel USB port

The following table shows the arguments for the options.

Table 58. usbfpc command

The following table is a multi-row two column table consisting of the options and option descriptions.

Option	Description
-mode <bmc server shared>	Set usage mode to BMC, server, or shared
-it <minutes>	Inactivity timeout in minutes (shared mode)
-btn <on off>	Enable using id button to toggle owner (shared mode)
-own <bmc server >	Set owner to bmc or server (shared mode)

users command

Use this command to access all user accounts and their authority levels.

The **users** command is also used to create new user accounts and modify existing accounts. Running the **users** command with no options displays a list of users and some basic user information. The following table shows the arguments for the options.

Table 59. users command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-user_index	User account index number	1 through 12, inclusive, or all for all users.
-n	User account name	Unique string containing only numbers, letters, periods, and underscores. Minimum of 4 characters and maximum of 16 characters.

Table 59. users command (continued)

Option	Description	Values
-p	User account password	String that contains at least one alphabetic and one non-alphabetic character. Minimum of 6 characters and maximum of 20 characters. Null creates an account without a password that the user must set during their first login.
-a	Authority level	The authority level can be one of the following levels: <ul style="list-style-type: none"> • super (supervisor) • ro (read only) • Any combination of the following values, separated by : <ul style="list-style-type: none"> – am (user account management access) – rca (remote console access) – rcvma (remote console and virtual media access) – pr (remote server power/restart access) – cel (ability to clear event logs) – bc (adapter configuration [basic]) – nsc (adapter configuration [network and security]) – ac (adapter configuration [advanced])
-ep	Encryption password (for backup/restore)	Valid password
-clear	Erase specified user account If you are authorized, you can remove your own account or the account of other users, even if they are currently logged in, unless it is the only account remaining with User Account Management privileges. Sessions that are already in progress when user accounts are deleted will not be automatically terminated.	User account index number to erase must be specified, following the form: <code>users -clear -user_index</code>
-curr	Display users currently logged in	
-sauth	SNMPv3 authentication protocol	HMAC-SHA, none
-spriv	SNMPv3 privacy protocol	CBC-DES, AES, none
-spw	SNMPv3 privacy password	Valid password
-sepw	SNMPv3 privacy password (encrypted)	Valid password
-sacc	SNMPv3 access type	get, set
-strap	SNMPv3 trap host name	Valid host name

Table 59. users command (continued)

Option	Description	Values
-pk	Display SSH public key for user	<p>User account index number.</p> <p>Notes:</p> <ul style="list-style-type: none"> • Each SSH key assigned to the user is displayed, along with an identifying key index number. • When using the SSH public key options, the -pk option must be used after the user index (-userindex option), of the form: users -2 -pk. • All keys are in OpenSSH format. • For Flex nodes, the users commands are limited to only local IPMI and SNMP accounts. The option -pk is not supported for Flex Systems.
-e	Display entire SSH key in OpenSSH format (SSH public key option)	<p>This option takes no arguments and must be used exclusive of all other users -pk options.</p> <p>Note: When using the SSH public key options, the -pk option must be used after the user index (-userindex option), of the form: users -2 -pk -e.</p>
-remove	Remove SSH public key from user (SSH public key option)	<p>Public key index number to remove must be given as a specific -key_index or -all for all keys assigned to the user.</p> <p>Notes:</p> <ul style="list-style-type: none"> • When using the SSH public key options, the -pk option must be used after the user index (-userindex option), of the form: users -2 -pk -remove -1. • For Flex nodes, the users commands are limited to only local IPMI and SNMP accounts. The option -remove is not supported for Flex Systems.
-add	Add SSH public key for user (SSH public key option)	<p>Quote-delimited key in OpenSSH format</p> <p>Notes:</p> <ul style="list-style-type: none"> • The -add option is used exclusive of all other users -pk command options. • When using the SSH public key options, the -pk option must be used after the user index (-userindex option), of the form: users -2 -pk -add "AAAAB3NzC1yc2EAAAABIWAAA QEA vfnTUzRF7pdBuaBy4d0/aIFasa/Gtc+o/wLZnuC4aD HMA1UmnMyL0CiIaNOy400ICEKcqjKEhrYmtAoVtfKApv Y39GpnSGRC/qcLGWLM4cmirKL5kxHNOqIcwbT1NPceoKH j46X7E +mqlfWnAhhjDpcVFjagM3Ek2y7w/tBGrwGgN7DP HJU1tzcJy68mEAnIrzjUoR98Q3/B9cJD77ydGKe8rPdI2 hIEpXR5dNUiupA1Yd8PSSMgdukASKEd3eRRZTBL3SA tMu cUsTkYjLXcqex10Qz4+N50R6MbNcwlx+mTEAvvcpJhug a70UNPGhLJML6k7jeJiQ8Xd2p Xb0ZQ==" • For Flex nodes, the users commands are limited to only local IPMI and SNMP accounts. The option -add is not supported for Flex Systems.

Table 59. users command (continued)

Option	Description	Values
-upld	Upload an SSH public key (SSH public key option)	Requires the -i and -l options to specify key location. Notes: <ul style="list-style-type: none"> The -upld option is used exclusive of all other users -pk command options (except for -i and -l). To replace a key with a new key, you must specify a -key_index. To add a key to the end of the list of current keys, do not specify a key index. When using the SSH public key options, the -pk option must be used after the user index (-userindex option), of the form: users -2 -pk -upld -i tftp://9.72.216.40/ -l file.key. For Flex nodes, the users commands are limited to only local IPMI and SNMP accounts. The option -upld is not supported for Flex Systems.
-dnld	Download the specified SSH public key (SSH public key option)	Requires a -key_index to specify the key to download and the -i and -l options to specify the download location on another computer running a TFTP server. Notes: <ul style="list-style-type: none"> The -dnld option is used exclusive of all other users -pk command options (except for -i, -l, and -key_index). When using the SSH public key options, the -pk option must be used after the user index (-userindex option), of the form: users -2 -pk -dnld -1 -i tftp://9.72.216.40/ -l file.key.
-i	IP address of TFTP/SFTP server for uploading or downloading a key file (SSH public key option)	Valid IP address Note: The -i option is required by the users -pk -upld and users -pk -dnld command options.
-pn	Port number of TFTP/SFTP server (SSH public key option)	Valid port number (default 69/22) Note: An optional parameter for the users -pk -upld and users -pk -dnld command options.
-u	User name for SFTP server (SSH public key option)	Valid user name Note: An optional parameter for the users -pk -upld and users -pk -dnld command options.
-pw	Password for SFTP server (SSH public key option)	Valid password Note: An optional parameter for the users -pk -upld and users -pk -dnld command options.
-l	File name for uploading or downloading a key file via TFTP or SFTP (SSH public key option)	Valid file name Note: The -l option is required by the users -pk -upld and users -pk -dnld command options.
-af	Accept connections from host (SSH public key option)	A comma-separated list of hostnames and IP addresses, limited to 511 characters. Valid characters include: alphanumeric, comma, asterisk, question mark, exclamation point, period, hyphen, colon and percent sign.
-cm	Comment (SSH public key option)	Quote-delimited string of up to 255 characters. Note: When using the SSH public key options, the -pk option must be used after the user index (-userindex option), of the form: users -2 -pk -cm "This is my comment.".

Syntax:

users [-options] - display/configure user accounts

options:

- [1-12] - user account number
- l - display password expiration days
- n - username (limited to 16 characters)
- p - password (limited to 32 characters)
- shp - set hashpassword (total 64 characters)
- ssalt - set salt (limited to 64 characters)
- ghp - get hashpassword
- gsalt - get salt
- ep - encrypted password (used with backup/restore)

- a - authority level (super, ro, custom:am|rca|rcvma|pr|cel|bc|nsc|ac)
 - am - User account management access
 - rca - Remote console access
 - rcvma - Remote console and remote disk (virtual media) access
 - pr - Remote server power/restart access
 - cel - Ability to clear event logs
 - bc - Adapter Configuration (basic)
 - nsc - Adapter Configuration (network and security)
 - ac - Adapter Configuration (advanced)

- clear - clear user account
- curr - display current users
- sauth (none|HMAC-SHA) - snmpv3 authentication protocol
- spriv (none|CBC-DES|AES) - snmpv3 privacy protocol
- spw password - snmpv3 privacy password
- sepw encryptedpassword - snmpv3 privacy password (encrypted)
- sacc (Get) - snmpv3 Access type
- strap hostname - snmpv3 trap hostname

- pk - SSH public keys options:
 - e - Displays the entire key in OpenSSH format
 - remove - Removes the specified key for the specified user
 - add - Adds a public key for the specified user
 - upld - Used to upload a public key in OpenSSH/RFC4716 format
 - dnld - Used to download the specified public key to a TFTP/SFTP server
 - i - IP address of the TFTP/SFTP
 - pn - port number of tftp/sftp server (default 69/22)
 - u - username for sftp server
 - pw - password for sftp server
 - l - Filename of the key file when uploading or downloading via TFTP/SFTP
 - af - accept connections from host, in the format: from="<list>", where <list> is a comma-separated list of hostnames and IP addresses (limited to 511 characters)
 - cm - comment (limited to 255 characters, must be quote-delimited)

Note: -a custom permission flags can be used in any combinations.

Example:

```
system> users
```

Account	Login ID	Advanced Attribute	Role	Password Expires
-----	-----	-----	-----	-----
1	USERID	Native	Administrator	89 day(s)

```
system> users -2 -n sptest -p Passw0rd12 -a super
```

The user is required to change the password when the user logs in to the management server for the first time
ok

```
system> users
```

Account	Login ID	Advanced Attribute	Role	Password Expires
-----	-----	-----	-----	-----

```

1          USERID          Native          Administrator          90 day(s)
2          sptest          Native          Administrator          Password expired
system> hashpw -sw enabled -re enabled
system> users -5 -n guest5 -shp 292bcbc41bb078cf5bd258db60b63a4b337c8c954409442cfad7148bc6428fee -ssalt abc -a super
system> users -5 ghp
292bcbc41bb078cf5bd258db60b63a4b337c8c954409442cfad7148bc6428fee
system> users -5 gsalt
abc
system> users -2 -n sptest -p Passw0rd12 -a custom:amlrca
The user is required to change the password when the user logs in to the management server for the first time
ok

```

IMM control commands

This topic provides an alphabetic list of IMM control CLI commands.

There are currently 7 IMM control commands:

alertentries command

Use this command to manage alert recipients.

- **alertentries** with no options display all alert entry settings.
- **alertentries -number -test** generates a test alert to the given recipient index number.
- **alertentries -number** (where number is 0 - 12) display alert entry settings for the specified recipient index number or allow you to modify the alert settings for that recipient.

The following table shows the arguments for the options.

Table 60. *alertentries* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-number	Alert recipient index number to display, add, modify, or delete	1 through 12
-status	Alert recipient status	on, off
-type	Alert type	email, syslog
-log	Include event log in alert email	on, off
-n	Alert recipient name	String
-e	Alert recipient email address	Valid email address
-ip	Syslog IP address or host name	Valid IP address or host name
-pn	Syslog port number	Valid port number
-del	Delete specified recipient index number	
-test	Generate a test alert to specified recipient index number	

Table 60. alertentries command (continued)

Option	Description	Values
-crt	Sets critical events that send alerts	all, none, custom:te vo po di fa cp me in re ot Custom critical alert settings are specified using a pipe separated list of values of the form alertentries -crt custom:te vo , where custom values are: <ul style="list-style-type: none"> te: critical temperature threshold exceeded vo: critical voltage threshold exceeded po: critical power failure di: hard disk drive failure fa: fan failure cp: microprocessor failure me: memory failure in: hardware incompatibility re: power redundancy failure ot: all other critical events
-crten	Send critical event alerts	enabled, disabled
-wrn	Sets warning events that send alerts	all, none, custom:rp te vo po fa cp me ot Custom warning alert settings are specified using a pipe separated list of values of the form alertentries -wrn custom:rp te , where custom values are: <ul style="list-style-type: none"> rp: power redundancy warning te: warning temperature threshold exceeded vo: warning voltage threshold exceeded po: warning power threshold exceeded fa: non-critical fan event cp: microprocessor in degraded state me: memory warning ot: all other warning events
-wrnen	Send warning event alerts	enabled, disabled
-sys	Sets routine events that send alerts	all, none, custom:lo tio ot po bf til pf el ne Custom routine alert settings are specified using a pipe separated list of values of the form alertentries -sys custom:lo tio , where custom values are: <ul style="list-style-type: none"> lo: successful remote login tio: operating system timeout ot: all other informational and system events po: system power on/off bf: operating system boot failure til: operating system loader watchdog timeout pf: predicted failure (PFA) el: event log 75% full ne: network change
-sysen	Send routine event alerts	enabled, disabled

Syntax:

```
alertentries [options]
options:
  -number recipient_number
  -status status
  -type alert_type
  -log include_log_state
  -n recipient_name
  -e email_address
  -ip ip_addr_or_hostname
  -pn port_number
  -del
  -test
  -crt event_type
  -crten state
  -wrn event_type
  -wrnen state
  -sys event_type
  -sysen state
```

Example:

```
system> alertentries
1. test
2. <not used>
3. <not used>
4. <not used>
5. <not used>
6. <not used>
7. <not used>
8. <not used>
9. <not used>
10. <not used>
11. <not used>
12. <not used>
```

```
system> alertentries -1
-status off
-log off
-n test
-e test@mytest.com
-crt all
-wrn all
-sys none
system>
```

batch command

Use this command to execute one or more CLI commands that are contained in a file.

- Comment lines in the batch file begin with a #.
- When running a batch file, commands that fail are returned along with a failure return code.
- Batch file commands that contain unrecognized command options might generate warnings.

The following table shows the arguments for the options.

Table 61. *batch command*

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Table 61. *batch* command (continued)

Option	Description	Values
-f	Batch file name	Valid file name
-ip	IP address of TFTP/SFTP server	Valid IP address
-pn	Port number of TFTP/SFTP server	Valid port number (default 69/22)
-u	Username for SFTP server	Valid user name
-pw	Password for SFTP server	Valid password

Syntax:

```
batch [options]
```

option:

```
-f filename
-ip ip_address
-pn port_number
username
-pw password
```

Example:

```
system> batch -f sslcfg.cli -ip 192.168.70.200
1 : sslcfg client dnld ip 192.168.70.20
Command total/errors/warnings: 8 / 1 / 0
system>
```

clearcfg command

Use this command to set the IMM configuration to its factory defaults.

You must have at least Advanced Adapter Configuration authority to issue this command. After the configuration of the IMM is cleared, the IMM is restarted.

clock command

Use this command to display the current date and time. You can set the UTC offset and daylight saving time settings.

The BMC obtains the time from the host server or NTP server.

The time obtained from the host may be local time or UTC time. The host option should be set to UTC if NTP is not used and the host uses UTC format. UTC offset can be in the format of +0200, +2:00, +2, or 2, for positive offsets, and -0500, -5:00 or -5, for negative offsets. UTC offset and daylight savings times are used with NTP or when the host mode is UTC.

For a UTC offset of +2, -7, -6, -5, -4 and -3 special daylight saving time settings are required.

- For +2, the daylight saving time options are as follows: off, ee (Eastern Europe), tky (Turkey), bei (Beirut), amm (Amman), jem (Jerusalem).
- For -7, the daylight saving time settings are as follows: off, mtn (Mountain), maz (Mazatlan).
- For -6, the daylight saving time settings are as follows: off, mex (Mexico), cna (Central North America).
- For -5, the daylight saving time settings are as follows: off, cub (Cuba), ena (Eastern North America).
- For -4, the daylight saving time settings are as follows: off, asu (Asuncion), cui (Cuiaba), san (Santiago), cat (Canada - Atlantic).
- For -3, the daylight saving time settings are as follows: off, gtb (Godthab), bre (Brazil - East).

Syntax:

```
clock [options]
```

options:

```
-u UTC offset
```

```
-dst on/off/special case
```

```
-host - local | utc , format of time obtained from host (default: utc)
```

Windows systems use local, Linux uses utc

Example:

```
system> clock
```

```
12/12/2011 13:15:23 GMT-5:00 dst on
```

identify command

Use this command to turn the chassis identification LED on or off, or to have it flash.

The **-d** option can be used with the **-s on** option to turn the LED on for only the number of seconds specified with the **-d** option. The LED turns off after the number of seconds elapses.

Syntax:

```
identify [options]
```

options:

```
-s on/off/blink
```

```
-d seconds
```

Example:

```
system> identify
```

```
-s off
```

```
system> identify -s on -d 30
```

```
ok
```

```
system>
```

info command

Use this command to display and configure information about the IMM.

Running the **info** command with no options displays all IMM location and contact information. The following table shows the arguments for the options.

Table 62. info command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-name	IMM name	String
-contact	Name of IMM contact person	String
-location	IMM location	String
-room ¹	IMM room identifier	String
-rack ¹	IMM rack identifier	String
-rup ¹	Position of IMM in rack	String
-ruh	Rack unit height	Read only

Table 62. *info* command (continued)

Option	Description	Values
-bbay	Blade bay location	Read only
1. Value is read only and cannot be reset if the IMM resides in a Flex System.		

Syntax:

`info [options]`

option:

- name **xcc_name**
- contact **contact_name**
- location **xcc_location**
- room **room_id**
- rack **rack_id**
- rup **rack_unit_position**
- ruh **rack_unit_height**
- bbay **blade_bay**

spreset command

Use this command to restart the IMM.

You must have at least Advanced Adapter Configuration authority to issue this command.

Agent-less commands

This topic provides an alphabetic list of Agent-less commands.

There are currently 3 Agent-less commands:

storage command

Use this command to display and configure (if supported by the platform) information about the server's storage devices that are managed by the IMM.

The following table shows the arguments for the options.

Table 63. *storage* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Table 63. storage command (continued)

Option	Description	Values
-list	List the storage targets managed by the IMM.	controllers pools volumes drives Where target is: <ul style="list-style-type: none"> • controllers: list the supported RAID controllers¹ • pools: list the storage pools associated with the RAID controller¹ • volumes: list the storage volumes associated with the RAID controller¹ • drives: list the storage drives associated with the RAID controller¹
-list -target target_id	List the storage targets managed by the IMM according to the target_id .	pools volumes drives ctrl[x] pool[x] Where target and target_id are: <ul style="list-style-type: none"> • pools ctrl[x]: list the storage pools associated with the RAID controller, based on the target_id¹ • volumes ctrl[x] pool[x]: list the storage volumes associated with the RAID controller, based on the target_id¹ • drives ctrl[x] pool[x]: list the storage drives associated with the RAID controller, based on the target_id¹
-list flashdimms	List the Flash DIMMs managed by the IMM.	
-list devices	Display the status of all disks and Flash DIMMS managed by the IMM.	
-show target_id	Display information for the selected target that is managed by the IMM.	Where target_id is: ctrl[x] vol[x] disk[x] pool[x] flashdimmm[x] 3
-show target_id info	Display detailed information for the selected target that is managed by the IMM.	Where target_id is: ctrl[x] vol[x] disk[x] pool[x] flashdimmm[x] 3
-show target_id firmware ³	Display the firmware information for the selected target that is managed by the IMM.	Where target_id is: ctrl[x] disk[x] flashdimmm[x] ²
-showlog target_id < m:n all > ³	Display the event logs of the selected target that is managed by the IMM.	Where target_id is: ctrl[x] ⁴ m:n all Where m:n is one to the maximum number of event logs Where all are all of the event logs
-config ctrl -scanforgn -target target_id ³	Detect the foreign RAID configuration.	Where target_id is: ctrl[x] ⁵

Table 63. storage command (continued)

Option	Description	Values
-config ctrl -imptforgn -target target_id ³	Import the foreign RAID configuration.	Where target_id is: ctrl[x] ⁵
-config ctrl -clrforgn -target target_id ³	Clear the foreign RAID configuration.	Where target_id is: ctrl[x] ⁵
-config ctrl -clrcfg -target target_id ³	Clear the RAID configuration.	Where target_id is: ctrl[x] ⁵
-config drv -mkoffline -target target_id ³	Change the drive state from online to offline.	Where target_id is: disk[x] ⁵
-config drv -mkonline -target target_id ³	Change the drive state from offline to online.	Where target_id is: disk[x] ⁵
-config drv -mkmissing -target target_id ³	Mark the offline drive as an unconfigured good drive.	Where target_id is: disk[x] ⁵
-config drv -prprm -target target_id ³	Prepare an unconfigured good drive for removal.	Where target_id is: disk[x] ⁵
-config drv -undoprprm -target target_id ³	Cancel the prepare an unconfigured good drive for removal operation.	Where target_id is: disk[x] ⁵
-config drv -mkbad -target target_id ³	Change the unconfigured good drive to a unconfigured bad drive.	Where target_id is: disk[x] ⁵
-config drv -mkgood -target target_id ³	Change an unconfigured bad drive to a unconfigured good drive. or Convert the just a bunch of disks (JBOD) drive to an unconfigured good drive.	Where target_id is: disk[x] ⁵
-config drv -addhsp -[dedicated pools] -target target_id ³	Assign the selected drive as a hot spare to one controller or to existing storage pools.	Where target_id is: disk[x] ⁵
-config drv -rmhsp -target target_id ³	Remove the hot spare.	Where target_id is: disk[x] ⁵
-config vol -remove -target target_id ³	Remove one volume.	Where target_id is: vol[x] ⁵

Table 63. storage command (continued)

Option	Description	Values
<p><code>-config vol -set [-N] [-w] [-r] [-i] [-a] [-d] [-b] -target target_id³</code></p>	<p>Modify the properties of one volume.</p>	<ul style="list-style-type: none"> • [-N volume_name] is the name of the volume • [-w <0 1 2>] is the cache write policy: <ul style="list-style-type: none"> – Type 0 for the Write Through policy – Type 1 for the Write Back policy – Type 2 for the Write With Battery Backup Unit (BBU) policy • [-r <0 1 2>] is the cache read policy: <ul style="list-style-type: none"> – Type 0 for the No Read Ahead policy – Type 1 for the Read Ahead Policy – Type 2 for the Adaptive Read Ahead policy • [-i <0 1>] is the cache I/O policy: <ul style="list-style-type: none"> – Type 0 for the Direct I/O policy – Type 1 for the Cached I/O policy • [-a <0 2 3>] is the access policy: <ul style="list-style-type: none"> – Type 0 for the Read Write policy – Type 2 for the Read Only policy – Type 3 for the Blocked policy • [-d <0 1 2>] is the disk cache policy: <ul style="list-style-type: none"> – Type 0 if the policy is unchanged – Type 1 to enable policy⁶ – Type 2 to disable policy • [-b <0 1>] is the background initialization: <ul style="list-style-type: none"> – Type 0 to enable initialization – Type 1 to disable initialization • -target_id is vol[x]⁵
<p><code>-config vol -add<[-R] [-D disk] [-H disk] [-1 hole]> [-N] [-w] [-r]^{3,7}</code></p>	<p>Create one volume for a new storage pool when the target is a controller.</p> <p>or</p> <p>Create one volume with an existing storage pool when the target is a storage pool.</p>	<ul style="list-style-type: none"> • [-R <0 1 5 1E 6 10 50 60 00 1ERLQ0 1EORLQ0>] This option defines the RAID level and is only used with a new storage pool • [-D disk [id11]:disk[id12]:..disk[id21]:disk[id22]:...] This option defines the drive group (including spans) and is only used with a new storage pool • [-H disk [id1]:disk[id2]:...] This option defines the hot spare group and is only used with a new storage pool • [-1 hole] This option defines the index number of the free hole space for an existing storage pool • [-N volume_name] is the name of the volume • [-w <0 1 2>] is the cache write policy: <ul style="list-style-type: none"> – Type 0 for the Write Through policy – Type 1 for the Write Back policy – Type 2 for the Write With Battery Backup Unit (BBU) policy

Table 63. storage command (continued)

Option	Description	Values
		<ul style="list-style-type: none"> • [-r <0 1 2>] is the cache read policy: <ul style="list-style-type: none"> – Type 0 for the No Read Ahead policy – Type 1 for the Read Ahead policy – Type 2 for the Adaptive Read Ahead policy
-config vol -add[-i] [-a] [-d] [-f] [-S] [-P] -target target_id ³	Create one volume for a new storage pool when the target is a controller. or Create one volume with an existing storage pool when the target is a storage pool.	<ul style="list-style-type: none"> • [-i <0 1>] is the cache I/O policy: <ul style="list-style-type: none"> – Type 0 for the Direct I/O policy – Type 1 for the Cached I/O policy • [-a <0 2 3>] is the access policy: <ul style="list-style-type: none"> – Type 0 for the Read Write policy – Type 2 for the Read Only policy – Type 3 for the Blocked policy • [-d <0 1 2>] is the disk cache policy: <ul style="list-style-type: none"> – Type 0 if the policy remains unchanged – Type 1 to enable the policy⁶ – Type 2 to disable the policy • [-f <0 1 2>] is the type of initialization: <ul style="list-style-type: none"> – Type 0 for no initialization – Type 1 for quick initialization – Type 2 for full initialization • [-S volume_size] is the size of the new volume in MB • [-P strip_size] is the volume strip size for example, 128K or 1M • -target target_id is: <ul style="list-style-type: none"> – ctrl[x] (new storage pool)⁵ – pool[x] (existing storage pool)⁵
-config vol -getfreecap [-R] [-D disk] [-H disk] -target target_id ³	Get the free capacity amount of the drive group.	<ul style="list-style-type: none"> • [-R <0 1 5 1E 6 10 50 60 00 1E RLQ0 1E0 RLQ0>] This option defines the RAID level and is only used with a new storage pool • [-D disk [id11]:[id12]:..<[id21]:[id22]:..] This option defines the drive group (including spans) and is only used with a new storage pool • [-H disk [id1]:[id2]:..] This option defines the hot spare group and is only used with a new storage pool • -target target_id is: <ul style="list-style-type: none"> – ctrl[x]⁵

Table 63. storage command (continued)

Option	Description	Values
-help	Display the command usage and options	
<p>Notes:</p> <ol style="list-style-type: none"> 1. This command is only supported on servers where the IMM can access the RAID controller. 2. Firmware information is displayed only for associated controllers, disks, and Flash DIMMs. Firmware information for associated pools and volumes are not displayed. 3. Information is displayed on multiple lines due to space limitations. 4. This command is only supported on servers that support RAID logs. 5. This command is only supported on servers that support RAID configurations. 6. The Enable value does not support RAID level 1 configurations. 7. A partial list of available options are listed here. The remaining options for the storage -config vol -add command are listed in the following row. 		

Syntax:

storage [**options**]

option:

- config **ctrl|drv|vol** -option [-options] -target **target_id**
- list **controllers|pools|volumes|drives**
- list **pools** -target **ctrl[x]**
- list **volumes** -target **ctrl[x]|pool[x]**
- list **drives** -target **ctrl[x]|pool[x]**
- list devices
- list flashdimms
- show **target_id**
- show {**ctrl[x]|pool[x]|disk[x]|vol[x]|flashdimmm[x]**} **info**
- show {**ctrl[x]|disk[x]|flashdimmm[x]**}**firmware**
- showlog **ctrl[x]m:n|all**
- h **help**

Examples:

```

system> storage
-config ctrl -clrcfg -target ctrl[0]
ok
system>
system> storage
-config ctrl -clrforgn -target ctrl[0]
ok
system>
system> storage
-config ctrl -imptforgn -target ctrl[0]
ok
system>
system> storage
-config ctrl -scanforgn -target ctrl[0]
Detect 1 foreign configuration(s) on controller ctrl[0]
system>
system> storage
-config drv -addhsp -dedicated pool[0-1] -target disk[0-0]
ok
system>
system> storage
-config drv -addhsp -target disk[0-0]
ok
system>
system> storage
-config drv -mkbad -target disk[0-0]

```

```

ok
system>
system> storage
-config drv -mkgood -target disk[0-0]
ok
system>
system> storage
-config drv -mkmissing -target disk[0-0]
ok
system>
system> storage
-config drv -mkoffline -target disk[0-0]
ok
system>
system> storage
-config drv -mkonline -target disk[0-0]
ok
system>
system> storage
-config drv -prprm -target disk[0-0]
ok
system>
system> storage
-config drv -rmhsp -target disk[0-0]
ok
system>
system> storage
-config drv -undoprprm -target disk[0-0]
ok
system>
system> storage
-config vol -add -1 1 -target pool[0-1]
ok
system>
system> storage
-config vol -add -R 1 -D disk[0-0]:disk[0-1] -w 1 -r 2 -i 0 -a 0 -d 0 -f 0
-N LD_volume -S 100000 -P 64K -H disk[0-2] -target ctrl[0]
ok
system>
system> storage
-config vol -getfreecap -R 1 -D disk[0-0]:disk[0-1] -H disk[0-2] -target ctrl[0]
The drive group configuration is good with free capacity 500000MB
system>
system> storage
-config vol -remove -target vol[0-1]
ok
system>
system> storage
-config vol -set -N LD_volume -w 0 -target vol[0-0]
ok
system>
system> storage
-list controllers
ctrl[0]    ServerRAID M5110e(Slot No. 0)
ctrl[1]    ServerRAID M5110f(Slot No. 1)
system>
system> storage
-list drives
disk[0-0]  Drive 0
disk[0-1]  Drive 1
disk[0-2]  Drive 2

```

```

system>
system> storage
-list flashdimms
flashdimm[1]    Flash DIMM 1
flashdimm[4]    Flash DIMM 4
flashdimm[9]    Flash DIMM 9
system>
system> storage
-list pools
pool[0-0]       Storage Pool 0
pool[0-1]       Storage Pool 1
system>
system> storage
-list volumes
system>storage -list volumes
vol[0-0]        Volume 0
vol[0-1]        Volume 1
Vol[0-2]        Volume 2
system>
system> storage
-list drives -target ctrl[0]
disk[0-0]       Drive 0
disk[0-1]       Drive 1
disk[0-2]       Drive 2
system>
system> storage
-list drives -target pool[0-0]
disk[0-0]       Drive 0
disk[0-1]       Drive 1
system>
system> storage
-list pools -target ctrl[0]
pool[0-0]       Storage Pool 0
system>
system> storage
-list volumes -target ctrl[0]
vol[0-0]        Volume 0
vol[0-1]        Volume 1
system>
system> storage
-list volumes -target pool[0-0]
vol[0-0]        Volume 0
vol[0-1]        Volume 1
system>
system> storage
-show ctrl[0] firmware
Total Firmware number: 2
Name: RAID Firmware1
Description: RAID Firmware
Manufacture: IBM
Version: 4.01(3)T
Release Date: 01/05/2013
Name: RAID Firmware2
Description: RAID Firmware
system>
system> storage
-show ctrl[0] info
Product Name: ServerRAID M5110e
Firmware Package Version: 23.7.0.1.2
Battery Backup: Installed
Manufacture: IBM

```

```

UUID: 1234567890123456
Model Type / Model: 1234AHH
Serial No.: 12345678901
FRU No.: 5005076049CC4
Part No.: LSI2004
Cache Model Status: Unknown
Cache Model Memory Size: 300MB
Cache Model Serial No.: PBKUDOXTAOP04Y
PCI Slot Number: 0
PCI Bus Number: 2
PCI Device Number: 2
PCI Function Number: 10
PCI Device ID: 0x1000
PCI Subsystem Device ID: 0x1413
Ports: 2
Port 1: 12345678901234
Port 2: 12345678901235
Storage Pools: 2
Slot No. Pool 0
Slot No. Pool 1
Drives: 3
disk[0-0] Drive 0
disk[0-1] Drive 1
disk[0-2] Drive 2
system>
system> storage
-show disk[0-0] firmware
Total Firmware number: 1
Name: Drive
Description:
Manufacture:
Version: BE24
Release Date:
system>
system> storage
-show disk[0-0] info
Product Name: ST98394893
State: Online
Slot No.: 0
Disk Type: SATA
Media Type: HDD
Health Status: Normal
Capacity: 100.000GB
Speed: 6.0Gb/s
Current Temperature: 33C
Manufacture: ATA
Device ID: 5
Enclosure ID: 0x00FC
Machine Type:
Model:
Serial No.: 9XKJKL
FRU No.:
Part No.:
system>
system> storage
-show flashdimm[15]
Name: CPU1 DIMM 15
Health Status: Normal
Operational Status: Online
Capacity(GB): 400GB
Model Type: DDR3

```

```

Part Number: 93E40400GGM101PAT
FRU S/N: 44000000
Manuf ID: Diablo Technologies
Temperature: 0C
Warranty Writes: 100%
Write Endurance: 100%
F/W Level: A201.0.0.49152
system>
system> storage
-show pool[0-0]
RAID State: RAID 0
RAID Capacity: 67.000GB (0.000GB free)
Drives: 2
disk[0-0]    Drive 0
disk[0-1]    Drive 1
Volumes: 2
vol[0-0]     Volume 0
vol[0-1]     Volume 1
system>
system> storage
-show pool[0-1] info
RAID State: RAID 1
RAID Capacity: 231.898GB (200.000GB free)
Holes: 2
#1 Free Capacity: 100.000GB
#2 Free Capacity: 100.000GB

Drives: 2
disk[0-1]    Drive 1
disk[0-2]    Drive 2

Volume: 1
vol[0-1]     LD_volume
system>
system> storage
-show vol[0-0]
Name: Volume 0
Stripe Size: 64KB
Status: Offline
Capacity: 100.000GB
system>
system> storage
-show vol[0-0] info
Name: LD_volume
Status: Optimal
Stripe Size: 64KB
Bootable: Not Bootable
Capacity: 231.898GB
Read Policy: No Read Ahead
Write Policy: Write Through
I/O Policy: Direct I/O
Access Policy: Read Write
Disk Cache Policy: Unchanged
Background Initialization: Enable
system>

```

adapter command

This command is used to display PCIe adapter inventory information.

If the **adapter** command is not supported, the server responds with the following message when the command is issued:

Your platform does not support this command.

If you remove, replace, or configure any adapters, you must restart the server (at least once) to view the updated adapter information.

The following table shows the arguments for the options.

Table 64. *adapter* command

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Option	Description	Values
-list	List all PCIe adapters in the server	
-show target_id	Show the detailed information for the target PCIe adapter	target_id [info firmware ports chips] Where: <ul style="list-style-type: none"> • info: display the hardware information for the adapter • firmware: display all firmware information for the adapter • ports: display all Ethernet port information for the adapter • chips: display all GPU chip information for the adapter
-h	Display the command usage and options	

Syntax:

adapter [**options**]

option:

- list
- show **target_id [info|firmware|ports|chips]**
- h **help**

Examples:

```

system> adapter
list
ob-1      Flex System CN4054 10Gbps Virtual Fabric Adapter
ob-2      GPU Card 1
slot-1    Raid Controller 1
slot-2    Adapter 01:02:03
system> adapter
show ob-1 info
Product Name: Flex System CN4054 10Gbps Virtual Fabric Adapter
Card Interface: PCIe x 16
Function Count: 2

Function Name: xxx Emulx xx component1
Segment Number: 2348
Bus Number: 23949
Device Number: 1334
Function Number: 21
Vendor Id: 12
Device Id: 33
Revision Id: 1

```

Class Code: 2
Sub Vendor: 334
Sub Device: 223
Slot Description: a slot
Slot Type: 23
Slot Data Bus Width: 0
Hot Plug: 12
PCI Type: 11
Blade Slot Port: xxx
UUID: 39302938485
Manufacturer: IBM
Serial Number: 998AAGG
Part Number: ADB233
Model: 345
Function Sku: 221
Fod Uid: 2355
Required Daughter: 0
Max Data Width: 0
Connector Layout: pci x

Package Type: dici
Function Name: xxx nVidia xx component2
Segment Number: 2348
Bus Number: 23949
Device Number: 1334
Function Number: 21
Vendor Id: 12
Device Id: 33
Revision Id: 1
Class Code: 2
Sub Vendor: 334
Sub Device: 223
Slot Description: a slot
Slot Type: 23
Slot Data Bus Width: 0
Hot Plug: 12
PCI Type: 11
Blade Slot Port: xxx
UUID: 39302938485
Manufacturer: IBM
Serial Number: 998AAGG
Part Number: ADB233
Model: 345
Function Sku: 221
Fod Uid: 2355
Required Daughter: 0
Max Data Width: 0
Connector Layout: pci x
Package Type: dici

m2raid command

Use this command to get M.2 related inventory information and manage the virtual volumes.

The following table shows the arguments for the options.

Table 65. m2raid command

The following table is a multi-row two column table consisting of the options and option descriptions.

Table 65. m2raid command (continued)

Option	Description
-h/?	Print the help info for this command
-version	Display the controller firmware information
-disks	Display the media disks information
-volumes	Display the virtual volumes information
-create	Create a virtual volume, the VD_Name, RaidLevel and StripeSize can be specified
-delete	Delete a virtual volume
-import	Import a foreign virtual volume. After importing the virtual volume, a system reboot will rebuild the virtual volume automatically.

Usage

m2raid [-options] - raid configuration for M.2 adapter with Mirroring Enablem
options:

- version - displays controller firmware version.
- disks - displays information of media disks.
- volumes - displays information of virtual volumes
- create -VD_Name <nameStr> -RaidLevel <0|1> -StripeSize <32|64> - create virt
- delete -VD_ID <0|1> - delete the virtual volume
- import -VD_ID <0|1> - import a foreign virtual volume

Example

```
system> m2raid -version
ThinkSystem M.2 with Mirroring Enablement Kit
Firmware Version = 2.3.10.1193

system> m2raid -disks
M.2 Bay0      32GB M.2 SATA SSD      LEN      100%
M.2 Bay1      32GB M.2 SATA SSD      LEN      100%

system> m2raid -volumes
VD_ID  VD_Name  RaidLevel  StripSize  VD Capacity  Status
0      M2RAID   1          64k       29 GB       Optimal

system> m2raid -delete -VD_ID 0
VD_ID 0 is deleted

system> m2raid -create -VD_Name M2RAID -RaidLevel 1 -StripeSize 64
New volume is created

system> m2raid -import -VD_ID 0
VD_ID 0 is imported
```

Support commands

This topic provides an alphabetic list of Support commands.

There is only one support command: the [“dbgshimm command”](#) on page 171.

dbgshimm command

Use this command to unlock network access to the secure debug shell.

Note: This command is intended only for support personnel use.

The following table shows the arguments for the options.

Table 66. dbgshimm command

The following table is a multi-row two column table consisting of the options and option descriptions.

Option	Description
status	Display status
enable	Enable debug access (default if no option specified)
disable	Disable debug access

Chapter 11. IPMI interface

This chapter describes the IPMI interface supported by the XClarity Controller.

For details of the standard IPMI commands, refer to the Intelligent Platform Management Interface (IPMI) Specification document (version 2.0 or above). This document provides descriptions on the OEM parameters used with the standard IPMI and OEM IPMI commands supported by the XClarity Controller firmware.

Managing the XClarity Controller with IPMI

Use the information in this topic to manage the XClarity Controller using the Intelligent Platform Management Interface (IPMI).

The XClarity Controller comes with a user ID set initially to a user name of USERID and password of PASSWORD (with a zero, not the letter O). This user has Supervisor access.

Important: Change this user name and password during your initial configuration for enhanced security.

In a Flex System, a user can configure a Flex System CMM to centrally manage the XClarity Controller IPMI user accounts. In this circumstance, you might not be able to access the XClarity Controller using the IPMI until the CMM has configured the IPMI user IDs.

Note: The user ID credentials configured by the CMM might be different than the USERID/PASSWORD combination described above. If no IPMI user IDs have been configured by the CMM, the network port associated with the IPMI protocol will be closed.

The XClarity Controller also provides the following IPMI remote server management capabilities:

IPMI Command-line interfaces

The IPMI command line interface provides direct access to server-management functions through the IPMI 2.0 protocol. You can use the IPMITool to issue commands to control server power, view server information, and identify the server. For more information about the IPMITool, see [“Using IPMITool” on page 173](#).

Serial over LAN

To manage servers from a remote location, use the IPMITool to establish a Serial over LAN (SOL) connection. For more information about the IPMITool, see [“Using IPMITool” on page 173](#).

Using IPMITool

Use the information in this topic to access information about the IPMITool.

The IPMITool provides various tools that you can use to manage and configure an IPMI system. You can use the IPMITool in-band or out-of-band to manage and configure the XClarity Controller.

For more information about the IPMITool, or to download the IPMITool, go to <https://github.com/ipmitool/ipmitool>.

IPMI Commands with OEM Parameters

Get / Set LAN Configuration Parameters

In order to reflect the capabilities provided by the XCC for some of the network settings, the values for some of the parameter data is defined as shown below.

DHCP

In addition to the usual methods of obtaining an IP address, the XCC provides a mode where it attempts to obtain an IP address from a DHCP server for a given period of time and if unsuccessful fails over to using a static IP address.

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Parameter	#	Parameter Data
IP Address Source	4	<u>data 1</u> [7:4] – reserved [3:0] – address source 0h = unspecified 1h = static address (manually configured) 2h = address obtained by XCC running DHCP 3h = address obtained by BIOS or system software 4h = address obtained by XCC running other address assignment protocol. The XCC uses the value 4h to indicate the address mode of DHCP with failover to static.

Ethernet Interface Selection

The XCC hardware contains dual 10/100 Ethernet MACs with RMII interfaces. The XCC hardware also contains dual 1Gbps Ethernet MACs with RGMII interfaces. One of the MACs is usually connected to the shared server NIC and the other MAC is used as a dedicated system management port. Only one Ethernet port on a server is active at a given time. Both ports will not be simultaneously enabled.

On some servers, the system designers may choose to connect up only one or the other of these Ethernet interfaces on the system planar. In those systems, only the Ethernet interface that is connected on the planar is supported by the XCC. A request to use the unconnected port returns a CCh completion code.

The package IDS for all optional network cards are numbered as follows:

- optional card #1, package ID = 03h (eth2),
- optional card #2, package ID = 04h (eth3),

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Parameter	#	Parameter Data
<p>OEM Parameter</p> <p>This parameter number is used by the XCC to indicate which of the possible Ethernet ports (logical packages) should be used.</p> <p>This parameter in the Get/Set LAN Configuration Parameters command does not use a Set Selector or a require Block Selector, so these fields should be set to 00h.</p> <p>The response data will return 3 bytes, or optionally 4 bytes if the device is in an NCSI package.</p> <p>Byte 1 = completion code</p> <p>Byte 2 = revision</p> <p>Byte 3 = 00h for eth0, or 01h for eth1, etc...</p> <p>Byte 4 = (optional) channel number, if the device is an NCSI package</p>	C0h	<p><u>data1</u></p> <p>00h = eth0</p> <p>01h = eth1</p> <p>02h = eth2</p> <p>etc...</p> <p>FFh = disable all external network ports)</p> <p>XCC supports a 2nd optional data byte to specify which channel in a package is used</p> <p><u>data2</u></p> <p>00h = channel 0</p> <p>01h = channel 1</p> <p>etc...</p> <p>If data2 is not specified in the request, channel 0 is assumed</p>

The data1 byte is used to specify the logical package. It may be a dedicated systems management NIC or an NCSI interface into the NIC shared with the server.

The data2 byte is used to specify the channel for logical package, if the package is an NCSI device. If the data2 is not specified in the request and the logical package is an NCSI device, channel 0 is assumed. If data2 is specified in the request but the logical package is not an NCSI device, the channel information is ignored.

Examples:

Appendix A: If channel 2 of the shared NIC on the planar (package ID = 0, eth0) is to be used as the management port , the input data would be: 0xC0 0x00 0x02

Appendix B: If the first channel of the first network mezzanine card is to be used, the input would be: 0xC0 0x02 0x0

Ethernet over USB Enable/Disable

The parameter below is used to enable or disable the XCC inband interface.

The following table is a multi-row three column table consisting of the options, option descriptions, and associated values for the options.

Parameter	#	Parameter Data
<p>OEM Parameter</p> <p>(This parameter number is used by the XCC to enable or disable the Ethernet over USB interface.)</p> <p>This parameter in the Get LAN Configuration Parameters command does not use a Set Selector or a require Block Selector, so these fields should be set to 00h.</p> <p>The response data will return 3 bytes:</p> <p>Byte 1 = completion code</p> <p>Byte 2 = revision</p> <p>Byte 3 = 00h (disabled), or 01h (enabled)</p>	C1h	<p><u>data 1</u></p> <p>0x00 = disabled</p> <p>0x01 = enabled</p>

The data1 byte is used to specify the logical package. It may be a dedicated systems management NIC or an NCSI interface into the NIC shared with the server.

The data2 byte is used to specify the channel for logical package, if the package is an NCSI device. If the data2 is not specified in the request and the logical package is an NCSI device, channel, 0 is assumed. If data2 is specified in the request but the logical package is not an NCSI device, the channel information is ignored.

Examples:

Appendix A: If channel 2 of the shared NIC on the planar (package ID = 0, eth0) is to be used as the management port, the input data would be: 0xC0 0x00 0x02

Appendix B: If the first channel of the first network mezzanine card is to be used, the input would be: 0xC0 0x02 0x0

IPMI option for getting the DUID-LLT

An additional read-only value that needs to be exposed via IPMI is the DUID. According to RFC3315, this format of DUID is based on the Link Layer Address Plus Time.

Parameter	#	Parameter Data
<p>OEM Parameter</p> <p>(This parameter number is used by the XCC to enable or disable the Ethernet over USB interface.)</p> <p>This parameter in the Get LAN Configuration Parameters command does not use a Set Selector or a require Block Selector, so these fields should be set to 00h.</p> <p>The response data will return 3 bytes:</p> <ul style="list-style-type: none"> Byte 1 = completion code Byte 2 = Parameter Revision (as in IPMI spec) Byte 3 = length of following data bytes (16 bytes currently) Byte 4-n DUID_LLT 	C2h	

Ethernet configuration parameters

The parameters below may be used to configure specific Ethernet settings.

Parameter	#	Parameter Data
<p>OEM Parameter</p> <p>(This parameter number is used by the XCC to enable or disable Auto-negotiation setting for Ethernet Interface.)</p> <p>The response data will return 3 bytes:</p> <ul style="list-style-type: none"> Byte 1 = completion code Byte 2 = revision Byte 3 = 00h (disabled), or 01h (enabled) 	C3h	<p><u>data 1</u></p> <p>0x00 = disabled</p> <p>0x01 = enabled</p> <p>Note: On Flex and ThinkSystem D2 Enclosure (ThinkSystem SD530 Compute Node) systems the auto-negotiation setting is not changeable because it could break the network communication path via the CMM and SMM.</p>
<p>OEM Parameter</p> <p>(This parameter number is used by the XCC to get or set the Data rate of Ethernet Interface.)</p> <p>The response data will return 3 bytes:</p> <ul style="list-style-type: none"> Byte 1 = completion code Byte 2 = revision Byte 3 = 00h (10Mb), or 01h (100Mb) 	C4h	<p><u>data 1</u></p> <p>0x00 = 10Mbit</p> <p>0x01 = 100Mbit</p>

Parameter	#	Parameter Data
<p>OEM Parameter</p> <p>(This parameter number is used by the XCC to get or set the Duplex setting of the Ethernet interface.)</p> <p>The response data will return 3 bytes:</p> <ul style="list-style-type: none"> Byte 1 = completion code Byte 2 = revision Byte 3 = 00h (Half Duplex), or 01h (Full Duplex) 	C5h	<p><u>data 1</u></p> <p>0x00 = Half Duplex</p> <p>0x01 = Full Duplex</p>
<p>OEM Parameter</p> <p>(This parameter number is used by the XCC to get or set the Maximum transmission unit (MTU) of the Ethernet interface.)</p> <p>The response data will return 3 bytes:</p> <ul style="list-style-type: none"> Byte 1 = completion code Byte 2 = revision Byte 3-4 = size of MTU 	C6h	<p><u>data 1</u></p> <p>Size of MTU</p>
<p>OEM Parameter</p> <p>(This parameter number is used by the XCC to get or set Locally administered MAC address.)</p> <p>The response data will return 3 bytes:</p> <ul style="list-style-type: none"> Byte 1 = completion code Byte 2 = revision Byte 3 – 8 = Mac Address 	C7h	<p><u>data 1 - 6</u></p> <p>Mac Address</p>

IPMI option for getting the Link-Local Address

This is a read-only parameter to retrieve the IPV6 Link-Local Address.

Parameter	#	Parameter Data
<p>OEM Parameter</p> <p>This parameter is used to obtain the Link-Local address of the XCC:</p> <p>The response data will return the following:</p> <ul style="list-style-type: none"> Byte 1 = completion code Byte 2 = Parameter Revision (as in IPMI spec) Byte 3 = IPV6 address prefix length Byte 4-19 Local Link address in binary format 	C8h	

IPMI option for enabling/disabling IPv6

This is a read/write parameter to enable/disable IPV6 in the XCC.

Parameter	#	Parameter Data
<p>OEM Parameter</p> <p>This parameter is used to enable/disable IPv6 in the XCC</p> <p>The response data will return the following:</p> <ul style="list-style-type: none"> Byte 1 = completion code Byte 2 = Parameter Revision (as in IPMI spec) Byte 3 = 00h (disabled), or 01h (enabled) 	C9h	<p><u>data 1</u></p> <p>0x00 = disabled</p> <p>0x01 = enabled</p>

Ethernet-over-USB Pass-through to external network

The parameter below is used to configure the Ethernet-over-USB to external Ethernet pass-through.

Parameter	#	Parameter Data
<p>OEM Parameter</p> <p>This parameter in the Get/Set LAN Configuration Parameters command does not use a Set Selector or a require Block Selector, so these fields should be set to 00h.</p> <p>The Get response data will return the following:</p> <ul style="list-style-type: none"> Byte 1 = completion code Byte 2 = revision Byte 3 = reserved (00h) Bytes 4:5 = Ethernet-over-USB Port number (LSByte first) Bytes 6:7 = External Ethernet Port number (LSByte first) <p>The number of bytes to follow can vary (1, 4, or 16 bytes) depending upon the addressing mode:</p> <ul style="list-style-type: none"> • Byte 8 = pre-defined modes: <ul style="list-style-type: none"> 00h = the pass-through is disabled 01h = the CMM's IP address is used Bytes 8:11 = IPv4 external network IP address in binary form Bytes 8:23 = IPv6 external network IP address in binary form <p>Completion codes:</p> <ul style="list-style-type: none"> 00h – success 80h – parameter not supported C1h – command not supported C7h – request data length invalid 	CAh	<p>Set LAN Configuration Parameters:</p> <p><u>data 1</u></p> <p>reserved (= 00h)</p> <p><u>data 2:3</u></p> <p>Ethernet over USB Port number, LSByte first</p> <p><u>data 4:5</u></p> <p>External Ethernet Port number, LSByte first</p> <p>The number of bytes to follow can vary (1, 4, or 16 bytes) depending upon the addressing mode:</p> <p><u>data 6</u></p> <p>00h = disable the pass-through</p> <p>01h = use the CMM's IP address</p> <p><u>data 6:9</u></p> <p>IPv4 external network IP address in binary form</p> <p><u>data 6:21</u></p> <p>IPv6 external network IP address in binary form</p>
<p>OEM Parameter</p> <p>This parameter is used to set and get the lan over usb ip address and netmask of the XCC:</p> <p>The response data will return the following:</p> <ul style="list-style-type: none"> Byte 1 = completion code Byte 2 = Parameter Revision (as in IPMI spec) 	CBh	<p>Data 1:4</p> <p>IP address of XCC -side lan over usb interface.</p> <p>Data 5:8</p> <p>Netmask of XCC -side lan over usb interface</p>

Parameter	#	Parameter Data
Byte 3:10 = IP address and Netmask value (MS-byte) first		
<p>OEM Parameter</p> <p>This parameter is used to set and get the lan over usb ip address of the Host OS:</p> <p>The response data will return the following:</p> <ul style="list-style-type: none"> Byte 1 = completion code Byte 2 = Parameter Revision (as in IPMI spec) <p>Byte 3:6 = IP address (MS-byte) first</p>	CCh	<p>Data 1:4</p> <p>IP address of Host-side lan over usb interface.</p>

Query Logical Package Inventory

The parameter below is used to query NCSI package inventory.

Parameter	#	Parameter Data
<p>OEM Parameter</p> <p>This parameter in the Get/Set LAN Configuration Parameters command does not use a Set Selector or a require Block Selector, so these fields should be set to 00h.</p> <p>Query package inventory operation</p> <p>The query package information operation is performed by issuing the request with two 0x00 data bytes besides the D3h parameter number.</p> <p>Query package inventory :</p> <p>--> 0x0C 0x02 0x00 0xD3 0x00 0x00</p> <p>The XCC response includes a byte of information for each package that is present:</p> <ul style="list-style-type: none"> bits 7:4 = number of NCSI channels in the package bits 3:0 = the logical package number <p>Response</p> <p>--> 0x00 0x00 0x40 0x01 0x32</p> <p>indicates that 3 logical packages are present:</p> <ul style="list-style-type: none"> package 0 has 4 NCSI channels package 1 is not an NCSI NIC , so it does not support NCSI channels package 2 has 3 NCSI channels 	D3h	Get/Set LAN Configuration Parameters:

Get/Set Logical Package Data

The parameter below is used to read and to set the priority assigned to each package.

Parameter	#	Parameter Data
<p>OEM Parameter</p> <p>This parameter in the Get/Set LAN Configuration Parameters command does not use a Set Selector or a require Block Selector, so these fields should be set to 00h.</p> <p>The command supports 2 operations:</p> <ul style="list-style-type: none"> • Read package priority • Set package priority <p>Read package priority operation</p> <p>The read package priority operation is performed by issuing the request with two 0x00 data bytes besides the D4h parameter number.</p> <p>Read package priority:</p> <p>--> 0x0C 0x02 0x01 0xD4 0x00 0x00</p> <p>Response</p> <p>--> 0x00 0x00 0x00 0x12 0x23</p> <p>logical package 0 = priority 0 logical package 2 = priority 1 logical package 3 = priority 2</p> <p>Set package priority operation</p> <p>The set package priority operation is performed by issuing the request with one or more parameters in addition to the D4h parameter number.</p> <p>Set package priority:</p> <p>--> 0x0C 0x01 0x01 0xD4 0x00 0x12 0x23</p> <p>set logical package 0 = priority 0 set logical package 2 = priority 1 set logical package 3 = priority 2</p> <p>Response:</p>	<p>D4</p>	<p>Get/Set LAN Configuration Parameters:</p> <p>Bit [7-4] = priority of the logical package (1 = highest, 15 = lowest)</p> <p>Bit [3-0] = logical package number</p>

Parameter	#	Parameter Data
completion code only, no additional data		

Get/Set XCC networking synchronization status

Parameter	#	Parameter Data
<p>OEM Parameter</p> <p>The byte is used to config to synchronize networking setting between dedicated and shared nic mode</p> <p>This parameter in the Get LAN Configuration Parameters command does not use a Set Selector or a require Block Selector, so these fields should be set to 00h.</p> <p>The response data will return 3 bytes:</p> <ul style="list-style-type: none"> Byte 1 = completion code Byte 2 = revision Byte 3 = 00h (enabled) , or 01h (disabled) 	D5h	<p><u>data 1</u></p> <p>0x00 = Synchronization</p> <p>0x01 = Independence</p>

The byte is used to config to synchronize networking setting between dedicated and shared nic mode , the default value was 0h here, it mean XCC will automatically update networking setting between mode change and use shared nic (on board) as major reference , if set as 1h , each networking setting will be independent here , which is we can configure different networking setting between mode, such as VLAN enable on Dedicated and set VLAN disable on Shared NIC mode.

Get/Set XCC networking mode

Parameter	#	Parameter Data
<p>OEM Parameter</p> <p>This parameter is used to get/set network mode of XCC management NIC.</p> <p>The response data will return 4 bytes:</p> <p>Byte 1 = completion code</p> <p>Byte 2 = revision</p> <p>Byte 3 = applied/specified netmode</p> <p>Byte 4 = package id of applied netmode</p> <p>Byte 5 = channel id of applied netmode</p>	D6h	<p>Set LAN Configuration Parameters:</p> <p><u>data 1</u></p> <p>Netmode to set</p> <p>Get LAN Configuration Parameters:</p> <p><u>data 1</u></p> <p>Netmode to get, This is an optional data, defaults to query current netmode</p>

OEM IPMI Commands

The XCC supports the following IPMI OEM commands. Each command requires a different level of privilege as listed as below.

Code	Netfn 0x2E Commands	Privilege
0xCC	Reset XCC to Default	PRIV_USR

Code	Netfn 0x3A Commands	Privilege
0x00	Query Firmware version	PRIV_USR
0x0D	Board Information	PRIV_USR
0x1E	Chassis Power Restore Delay Options	PRIV_USR
0x38	NMI and Reset	PRIV_USR
0x49	Initiate Data Collection	PRIV_USR
0x4A	Push File	PRIV_USR
0x4D	Data Collection Status	PRIV_USR
0x50	Get Build Information	PRIV_USR
0x55	Get/Set Host Name	PRIV_USR
0x6B	Query FPGA Firmware Revision Level	PRIV_USR
0x6C	Query Board Hardware Revision Level	PRIV_USR

Code	Netfn 0x3A Commands	Privilege
0x6D	Query PSoC Firmware Revision Level	PRIV_USR
0x98	FP USB Port Control	PRIV_USR
0xC7	Native NM IPMI Switch	PRIV_ADM

Reset XCC to Default Command

This command resets the XCC configuration setting to the default values.

Net Function = 0x2E			
Code	Command	Request, Response Data	Description
0xCC	Reset XCC to Default	<p>Request:</p> <p>Byte 1 – 0x5E Byte 2 – 0x2B</p> <p>Byte 3 – 0x00</p> <p>Byte 4 – 0x0A Byte 5 – 0x01</p> <p>Byte 6 – 0xFF</p> <p>Byte 7 – 0x00 Byte 8 – 0x00</p> <p>Byte 9 – 0x00</p> <p>Response:</p> <p>Byte 1 – Completion Code Byte 2 – 0x5E Byte 3 – 0x2B</p> <p>Byte 4 – 0x00</p> <p>Byte 5 – 0x0A Byte 6 – 0x01</p> <p>Byte 7 – Response Data</p> <p>0 = Success non-zero = Failure</p>	This command resets the XCC configuration settings to the default values.

Board / Firmware Information Commands

This section lists the commands for querying the board and firmware information.

Net Function = 0x3A			
Code	Command	Request, Response Data	Description
0x00	Query Firmware Version	<p>Request:</p> <p>No data on request</p> <p>Response:</p> <p>Byte 1 – Completion Code</p> <p>Byte 2 – Major version</p> <p>Byte 3 – Minor version</p>	<p>This command returns the major and minor version numbers of the firmware. If the command is made with the optional 1 byte of request data, the XCC response also returns the third field (Revision) of the version.</p> <p>(Major.Minor.Revision)</p>
0x0D	Query Board Information	<p>Request: N/A</p> <p>Response:</p> <p>Byte 1 – System ID</p> <p>Byte 2 – Board Revision</p>	<p>This command returns the Board ID and planar revision.</p>
0x50	Query Build Information	<p>Request: N/A</p> <p>Response:</p> <p>Byte 1 – Completion Code.</p> <p>Bytes 2:10 – ASCIIZ Build Name</p> <p>Bytes 11:23 – ASCIIZ Build Date</p> <p>Bytes 24:31 – ASCII Build Time</p>	<p>This command returns the build name, build date, and build time. The build name and build date strings have a zero termination.</p> <p>The format of the build date is YYYY-MM-DD.</p> <p>e.g. “ZUBT99A ”</p> <p>“2005-03-07”</p> <p>“23:59:59”</p>

Net Function = 0x3A			
Code	Command	Request, Response Data	Description
0x6B	Query FPGA Firmware Revision Level	<p>Request:</p> <p>Byte 1 – FPGA Device Type*</p> <p>FPGA Device Type</p> <p>0 = Local (Active level)</p> <p>1 = CPU Card 1 (Active level)</p> <p>2 = CPU Card 2 (Active level)</p> <p>3 = CPU Card 3 (Active level)</p> <p>4 = CPU Card 4 (Active level)</p> <p>5 = Local Primary ROM</p> <p>6 = Local Recovery ROM</p> <p>Response:</p> <p>Byte 1 – Completion Code</p> <p>Byte 2 – Major revision level</p> <p>Byte 3 – Minor revision level</p> <p>Byte 4 – Sub-Minor revision level</p> <p>(Test Byte on XCC platforms)</p>	<p>This command returns the revision level of the FPGA firmware.</p> <p>If Byte 1 is omitted then Local (Active level) will be selected</p>
0x6C	Query Board Hardware Revision Level	<p>Request:</p> <p>No Data.</p> <p>Response:</p> <p>Byte 1 – Completion Code</p> <p>Byte 2 – Revision level</p>	<p>This command returns the revision level of the board hardware where the FPGA resides.</p>
0x6D	Query PSoC Firmware Revision Level	<p>Request:</p> <p>None</p> <p>Response:</p> <p>Byte 1 – Completion Code</p> <p>Byte 2 – bin#</p> <p>Byte 3 – APID</p> <p>Byte 4 – Rev</p> <p>Byte 5-6 – FRU ID</p>	<p>This command returns the revision level of all of the detected PSoC devices.</p> <p>Note: bin# represents a physical location. Consult the system specification for details.</p>

Net Function = 0x3A			
Code	Command	Request, Response Data	Description
		Bytes 6:N – repeat of Bytes 2-6 for each detected PSoC	

System Control Commands

The IPMI specification provides basic power and reset control. Lenovo adds additional control functions.

Net Function = 0x2E							
Code	Command	Request, Response Data	Description				
0x1E	Chassis Power Restore Delay Options	<p>Request:</p> <table border="1"> <tr> <td>Byte 1</td> <td>Request Type: 0x00 = Set Delay Options 0x01 = Query Delay Options</td> </tr> <tr> <td>Byte 2</td> <td>(if byte 1 = 0x00) 0x00 = Disabled (default) 0x01 = Random 0x02 - 0xFF Reserved</td> </tr> </table> <p>Response:</p> <p>Byte 1 – Completion Code</p> <p>Byte 2 – Delay Options (for Query request only)</p>	Byte 1	Request Type: 0x00 = Set Delay Options 0x01 = Query Delay Options	Byte 2	(if byte 1 = 0x00) 0x00 = Disabled (default) 0x01 = Random 0x02 - 0xFF Reserved	<p>This setting is used, when the chassis power restore policy is set to always power-on or restore to power-on (if previously powered-on), after AC is applied/returns. There are 2 choices: Disabled (the default setting, no delay when powered-on), and Random. The random delay setting, provides a random delay between 1 and 15 seconds, from the time AC is applied/returns and when the server is automatically powered-on.</p> <p>The command is supported by XCC only on Rack servers.</p>
Byte 1	Request Type: 0x00 = Set Delay Options 0x01 = Query Delay Options						
Byte 2	(if byte 1 = 0x00) 0x00 = Disabled (default) 0x01 = Random 0x02 - 0xFF Reserved						
0x38	NMI and reset	<p>Request:</p> <p>Byte 1 – Number of seconds 0 = NMI Only</p> <p>Byte 2 – Reset type 0 = soft reset 1 = power cycle</p> <p>Response :</p> <p>Byte 1 – Completion code</p>	<p>This command is used to perform a system NMI. Optionally the system can be reset (rebooted) or power cycled after the NMI.</p> <p>If the “Number of Seconds” field is not 0, then the system will be reset or power cycled after the specified number of seconds.</p> <p>Byte 2 of the request is optional. If byte 2 is not provided, or if it has a value of 0x00, a soft reset is performed. If byte 2 is 0x01, the system is power cycled.</p>				

Miscellaneous Commands

This section is for commands that do not fit into any other section.

Net Function = 0x3A											
Code	Command	Request, Response Data	Description								
0x55	Get/Set Hostname	<p>Request Length = 0:</p> <p>Empty Request Data</p> <p>Response:</p> <table border="1"> <tr> <td>Byte 1</td> <td>Completion Code</td> </tr> <tr> <td>Bytes 2-65</td> <td>Current Hostname. ASCIIZ, Null terminated string.</td> </tr> </table> <p>Request Length 1-64:</p> <table border="1"> <tr> <td>Bytes 1-64</td> <td>DHCP Hostname ASCIIZ Terminate with 00h</td> </tr> </table>	Byte 1	Completion Code	Bytes 2-65	Current Hostname. ASCIIZ, Null terminated string.	Bytes 1-64	DHCP Hostname ASCIIZ Terminate with 00h	<p>Use this command to Get/Set the Hostname.</p> <p>When setting the Hostname, the desired value must be terminated by a 00h. The hostname is limited to 63 characters plus the null.</p>		
Byte 1	Completion Code										
Bytes 2-65	Current Hostname. ASCIIZ, Null terminated string.										
Bytes 1-64	DHCP Hostname ASCIIZ Terminate with 00h										
0x98	FP USB Port Control	<p>Request:</p> <p>Byte 1</p> <table border="1"> <tr> <td>01h:</td> <td>Get current owner of front panel USB port</td> </tr> </table> <p>Response:</p> <p>Byte 1 – Completion Code</p> <p>Byte 2</p> <table border="1"> <tr> <td>00h:</td> <td>Owned by host</td> </tr> <tr> <td>01h:</td> <td>Owned by BMC</td> </tr> </table> <p>Request:</p> <p>Byte 1</p> <table border="1"> <tr> <td>02h:</td> <td>Get the configuration of front panel USB port</td> </tr> </table>	01h:	Get current owner of front panel USB port	00h:	Owned by host	01h:	Owned by BMC	02h:	Get the configuration of front panel USB port	<p>This command is used for query status/configuration of FP USB port, configure mode/timeout of FP USB port and switch USB port owner between host and BMC</p> <p>In configuration, FP USB can has 3 modes – dedicated to host, solely owned by BMC or shared mode that allows owner switch between host and BMC.</p> <p>If shared mode is enabled, the USB port is connected to BMC when server is powered off and connected to the server when the server power is on.</p> <p>When shared mode is enabled and server power is on, the BMC will return USB port back to the server after inactivity timeout in configuration occurs.</p> <p>If the server has identification button, users can enable/disable the ID button to switch owner of FP USB port by holding the ID button for more than 3 seconds.</p> <p>Hysteresis in seconds will be set when automatically switching the</p>
01h:	Get current owner of front panel USB port										
00h:	Owned by host										
01h:	Owned by BMC										
02h:	Get the configuration of front panel USB port										

Net Function = 0x3A																							
Code	Command	Request, Response Data	Description																				
		<p>Response:</p> <p>Byte 1 – Completion Code</p> <p>Byte 2</p> <table border="1"> <tr> <td>00h:</td> <td>Dedicated to host</td> </tr> <tr> <td>01h:</td> <td>Dedicated to BMC</td> </tr> <tr> <td>02h:</td> <td>Shared mode</td> </tr> </table> <p>Byte 3:4 – Inactivity timeout in minutes(MSB first)</p> <p>Byte 5 – Enable ID button</p> <table border="1"> <tr> <td>00h:</td> <td>Disabled</td> </tr> <tr> <td>01h:</td> <td>Enabled</td> </tr> </table> <p>Byte 6 – Hysteresis (optional) in seconds</p> <p>Request:</p> <p>Byte 1</p> <p>03h: set the configuration of front panel USB port</p> <p>Byte 2</p> <table border="1"> <tr> <td>00h:</td> <td>Dedicated to host</td> </tr> <tr> <td>01h:</td> <td>Dedicated to BMC</td> </tr> <tr> <td>02h:</td> <td>Shared mode</td> </tr> </table> <p>Byte 3:4 – Inactivity timeout in minutes(MSB first)</p> <p>Byte 5 – Enable ID button</p> <table border="1"> <tr> <td>00h:</td> <td>Disabled</td> </tr> <tr> <td>01h:</td> <td>Enabled</td> </tr> </table> <p>Byte 6 – Hysteresis (optional) in seconds</p> <p>Response:</p> <p>Byte 1 – Completion CodeByte 2</p>	00h:	Dedicated to host	01h:	Dedicated to BMC	02h:	Shared mode	00h:	Disabled	01h:	Enabled	00h:	Dedicated to host	01h:	Dedicated to BMC	02h:	Shared mode	00h:	Disabled	01h:	Enabled	<p>port during the power cycle. This is an optional parameter.</p> <p>SD530 Servers</p> <p>On the SD530 platform the port is optional and if present is wired directly to the XCC, and only to the XCC. Switching the port to the Host in not available.</p> <ul style="list-style-type: none"> When the command is issued with byte 1 = 1, the XCC will always respond that the port is owned by the BMC. When the command is issued with byte 1 = 2, the XCC will always respond that the port is dedicated to the BMC. When the command is issued with byte 1 = 3 or byte 1 =4, the XCC will respond with completion code D6h. <p>Non-SD530 Servers</p> <p>On the non-SD530 platform the XCC’s use of the front panel USB port can be disabled by switching to the “Host Only” mode.</p> <p>When the command is issued with byte 1 = 5 or byte 1 =6, the XCC will respond with completion code D6h.</p>
00h:	Dedicated to host																						
01h:	Dedicated to BMC																						
02h:	Shared mode																						
00h:	Disabled																						
01h:	Enabled																						
00h:	Dedicated to host																						
01h:	Dedicated to BMC																						
02h:	Shared mode																						
00h:	Disabled																						
01h:	Enabled																						

Net Function = 0x3A															
Code	Command	Request, Response Data	Description												
		<table border="1"> <tr> <td>00h:</td> <td>Switch to host</td> </tr> <tr> <td>01h:</td> <td>Switch to BMC</td> </tr> </table> <p>Response:</p> <p>Byte 1 – Completion Code</p> <p>Byte 1</p> <table border="1"> <tr> <td>05h:</td> <td>Enable/ Disable the front panel USB port</td> </tr> </table> <p>Byte 2</p> <table border="1"> <tr> <td>00h:</td> <td>Disable</td> </tr> <tr> <td>01h:</td> <td>Enable</td> </tr> </table> <p>Response:</p> <p>Byte 1 – Completion Code</p> <p>Request:</p> <p>Byte 1</p> <table border="1"> <tr> <td>06h:</td> <td>Read the Enable/ Disable state of the front panel USB port</td> </tr> </table> <p>Response:</p> <p>Byte 1 - Completion Code</p> <p>Byte 2</p>	00h:	Switch to host	01h:	Switch to BMC	05h:	Enable/ Disable the front panel USB port	00h:	Disable	01h:	Enable	06h:	Read the Enable/ Disable state of the front panel USB port	
00h:	Switch to host														
01h:	Switch to BMC														
05h:	Enable/ Disable the front panel USB port														
00h:	Disable														
01h:	Enable														
06h:	Read the Enable/ Disable state of the front panel USB port														
0xC7	Native NM IPMI Switch	<p>Request Length = 0:</p> <p>Empty request data</p> <p>Response:</p> <table border="1"> <tr> <td>Byte 1</td> <td>Completion Code</td> </tr> <tr> <td>Bytes 2</td> <td>Current Enable/ Disable Status</td> </tr> </table>	Byte 1	Completion Code	Bytes 2	Current Enable/ Disable Status	This command is used to enable/disable the bridging function of XCC for Native Intel IPMI commands.								
Byte 1	Completion Code														
Bytes 2	Current Enable/ Disable Status														

Net Function = 0x3A											
Code	Command	Request, Response Data	Description								
		<p>Request Length= 1:</p> <table border="1"> <tr> <td>Byte 1</td> <td>Native NM IPMI Interface Enable/Disable attribute</td> </tr> <tr> <td></td> <td>00h – Disable</td> </tr> <tr> <td></td> <td>01h – Enable</td> </tr> </table> <p>Response:</p> <table border="1"> <tr> <td>Byte 1</td> <td>Completion Code</td> </tr> </table>	Byte 1	Native NM IPMI Interface Enable/Disable attribute		00h – Disable		01h – Enable	Byte 1	Completion Code	
Byte 1	Native NM IPMI Interface Enable/Disable attribute										
	00h – Disable										
	01h – Enable										
Byte 1	Completion Code										

Chapter 12. Edge servers

This topic describes specific functions for Edge servers.

Notes:

1. The system requires you to change the XCC password on you first login.
2. The IPMI-over-LAN is disabled by default.
3. The IPMI-over-KCS is disabled by default.

System Lockdown Mode

When **System Lockdown Mode** is in active state, it means that system is under lockdown mode. You could activate the system and unlock it, otherwise the host system will not be allowed to boot.

Note: System Lockdown Mode is only available for SE350 with Security Pack but not SE350 standard. Version can be checked at **Home** tab under **System Information and Settings**.

Click **Security** under **BMC Configuration** and scroll to **System Lockdown Mode**.

System Lockdown Mode

To activate the system and exit **System Lockdown Mode**, complete the following steps.

1. Click **Inactive** button and a **Key Vault Activation** window will pop-up to show the **Challenge Text**.
2. Contact your IT administrator and provide **Challenge Text**.
3. Obtain **Challenge Response** from your IT administrator and enter it in **Key Vault Activation** window.
4. Click **OK** button and then Click **Apply**.
5. If all setting works correctly, you will see **System Lockdown Mode** changes to **Inactive**.

Note: When System Lockdown Mode is in active state, any access to system secrets is **denied**, such as SED Authentication Keys.

To force the system to enter System Lockdown Mode, complete the following steps.

1. Click **Active** button.
2. Click **OK** button and then Click **Apply**.

Motion Detection

You can enable this function to protect your server by detecting any physical movement of your server. If Motion Detection is enabled, you can set the following items depending on your preference and configuration.

- **Sensitivity Level:** Select the sensitivity level from **Low**, **Medium** and **High** according to your preference
- **Orientation:** Select your configuration from **Stand Desktop**, **Wall Mount (Horizontal)**, **Wall Mount (Vertical)**, **Bookshelf** and **Ceiling Mount**.

Note: Motion Detection would be disabled automatically when the system entering the lockdown mode.

Chassis Intrusion Detection

You can enable this function to protect your server by detecting any physical movement of the top cover.

Additional Configurations

If the Wireless enabled LOM Package is installed, there are three settings you can choose for a detected tamper event.

Under some unusual circumstances, **Challenge Text** may fail to be verified by ThinkShield Key Vault Portal, it might be necessary to reset the device internal counter prior to activate the device under your IT administrator's request.

SED Authentication Key (AK) Manager

To the system installed with SED (self-encrypting drive), this feature controls BMC to deploy SED Authentication Key. You can use SED Authentication Key to encrypt boot and data drives and boot the system without manual intervention

Note: This operation is not allowed when the system is not activated (System Lockdown Mode is asserted) or current user does not have the authority to manage SED Authentication Key.

Note: System Lockdown Mode is only available for SE350 with Security Pack but not SE350 standard. Version can be checked at **Home** tab under **System Information and Settings**.

Note: The SE350 also supports an auto backup feature as long as the either ThinkSystem M.2 Enablement Kit or ThinkSystem M.2 Mirroring Enablement Kit is healthy. If hardware is damaged, but both SED and M.2 Kit are healthy, they can be installed into another SE350 and the SED AK can then be restored. However, in order to be prepared for a full hardware crash, Lenovo recommends making a SED AK backup.

Click **Security** under **BMC Configuration** and scroll to **SED Authentication Key (AK) Manager**.

Change the SED AK

Generate SED AK from Password: Set the password and reenter it for the confirmation. Click **Re-generate** to get the new SED AK.

Generate a Random SED AK: Click **Re-generate** to get a Random SED AK.

Backup the SED AK: Set the password and re-enter it for the confirmation. Click **Start Backup** to back the SED AK; then, download the SED AK file and store it safely for future use.

Note: If you use the backup SED AK file to restore a configuration, the system will ask for the password that you set here.

Recover the SED AK: You can only perform this task while the SED is not functioning properly. There are two ways to recover the SED AK:

- **Recover SED AK using Password:** Use the password that set in **Generate SED AK from Password** mode to recover the SED AK.
- **Recover SED AK from Backup file:** Upload the backup file generated in **Backup the SED AK** mode and enter the corresponding backup file password to recover the SED AK.

Edge Networking

This function page only supported while the Wireless enabled LOM Package is installed.

For the network topology preset tables, please see https://thinksystem.lenovofiles.com/help/topic/SE350/pdf_files.html for more details.

Wi-Fi Connectivity

Click **Enabled** and you can configure settings according to your Wi-Fi configuration.

LTE Connectivity

This allows you to control LTE connectivity for the Edgenetwork board.

Edge Network Board Address

IPv4 or IPv6 status	DHCP Server status	Method
Disabled	Disabled	Obtain IP from DHCP
Enabled	Enabled	Use static IP address
Enabled	Disabled	Obtain IP from DHCP or Use static IP address depending on your usage.

BMC Network Bridge

You can access the BMC via **Down Link Ports, Wi-Fi Ports, Up Link Ports** or **None**.

Note: Select **None** refers that this function is disabled.

Edge Network Board Troubleshooting

Restart Immediately: You can restart the network board by this button.

Reset To Factory Defaults: You can reset the network board to default setting by this button.

Appendix A. Getting help and technical assistance

If you need help, service, or technical assistance or just want more information about Lenovo products, you will find a wide variety of sources available from Lenovo to assist you.

On the World Wide Web, up-to-date information about Lenovo systems, optional devices, services, and support are available at:

<http://datacentersupport.lenovo.com>

Note: This section includes references to IBM web sites and information about obtaining service. IBM is Lenovo's preferred service provider for ThinkSystem.

Before you call

Before you call, there are several steps that you can take to try and solve the problem yourself. If you decide that you do need to call for assistance, gather the information that will be needed by the service technician to more quickly resolve your problem.

Attempt to resolve the problem yourself

You can solve many problems without outside assistance by following the troubleshooting procedures that Lenovo provides in the online help or in the Lenovo product documentation. The Lenovo product documentation also describes the diagnostic tests that you can perform. The documentation for most systems, operating systems, and programs contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the operating system or program.

You can find the product documentation for your ThinkSystem products at the following location:

<https://pubs.lenovo.com/>

You can take these steps to try to solve the problem yourself:

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Check for updated software, firmware, and operating-system device drivers for your Lenovo product. The Lenovo Warranty terms and conditions state that you, the owner of the Lenovo product, are responsible for maintaining and updating all software and firmware for the product (unless it is covered by an additional maintenance contract). Your service technician will request that you upgrade your software and firmware if the problem has a documented solution within a software upgrade.
- If you have installed new hardware or software in your environment, check <http://www.lenovo.com/serverproven/> to make sure that the hardware and software is supported by your product.
- Go to <http://datacentersupport.lenovo.com> and check for information to help you solve the problem.
 - Check the Lenovo forums at https://forums.lenovo.com/t5/Datacenter-Systems/ct-p/sv_eg to see if someone else has encountered a similar problem.

You can solve many problems without outside assistance by following the troubleshooting procedures that Lenovo provides in the online help or in the Lenovo product documentation. The Lenovo product documentation also describes the diagnostic tests that you can perform. The documentation for most systems, operating systems, and programs contains troubleshooting procedures and explanations of error

messages and error codes. If you suspect a software problem, see the documentation for the operating system or program.

Gathering information needed to call Support

If you believe that you require warranty service for your Lenovo product, the service technicians will be able to assist you more efficiently if you prepare before you call. You can also see <http://datacentersupport.lenovo.com/warrantylookup> for more information about your product warranty.

Gather the following information to provide to the service technician. This data will help the service technician quickly provide a solution to your problem and ensure that you receive the level of service for which you might have contracted.

- Hardware and Software Maintenance agreement contract numbers, if applicable
- Machine type number (Lenovo 4-digit machine identifier)
- Model number
- Serial number
- Current system UEFI and firmware levels
- Other pertinent information such as error messages and logs

As an alternative to calling Lenovo Support, you can go to <https://www-947.ibm.com/support/servicerequest/Home.action> to submit an Electronic Service Request. Submitting an Electronic Service Request will start the process of determining a solution to your problem by making the pertinent information available to the service technicians. The Lenovo service technicians can start working on your solution as soon as you have completed and submitted an Electronic Service Request.

Collecting service data

To clearly identify the root cause of a server issue or at the request of Lenovo Support, you might need collect service data that can be used for further analysis. Service data includes information such as event logs and hardware inventory.

Service data can be collected through the following tools:

- **Lenovo XClarity Controller**

You can use the Lenovo XClarity Controller web interface or the CLI to collect service data for the server. The file can be saved and sent to Lenovo Support.

- For more information about using the web interface to collect service data, see https://pubs.lenovo.com/xcc/NN1ia_c_servicesandsupport.html.
- For more information about using the CLI to collect service data, see https://pubs.lenovo.com/xcc/nn1ia_r_ffdcommand.html.

- **Lenovo XClarity Administrator**

Lenovo XClarity Administrator can be set up to collect and send diagnostic files automatically to Lenovo Support when certain serviceable events occur in Lenovo XClarity Administrator and the managed endpoints. You can choose to send diagnostic files to Lenovo Support using Call Home or to another service provider using SFTP. You can also manually collect diagnostic files, open a problem record, and send diagnostic files to the Lenovo Support Center.

You can find more information about setting up automatic problem notification within the Lenovo XClarity Administrator at https://pubs.lenovo.com/lxca/admin_setupcallhome.html.

- **Lenovo XClarity Provisioning Manager**

Use the Collect Service Data function of Lenovo XClarity Provisioning Manager to collect system service data. You can collect existing system log data or run a new diagnostic to collect new data.

- **Lenovo XClarity Essentials**

Lenovo XClarity Essentials can be run in-band from the operating system. In addition to the hardware service data, Lenovo XClarity Essentials can collect information about the operating system, such as the operating system event log.

To obtain service data, you can run the `getinfor` command. For more information about running the `getinfor`, see https://pubs.lenovo.com/lxce-onecli/onecli_r_getinfor_command.html.

Contacting Support

You can contact Support to obtain help for your issue.

You can receive hardware service through a Lenovo Authorized Service Provider. To locate a service provider authorized by Lenovo to provide warranty service, go to <https://datacentersupport.lenovo.com/us/en/serviceprovider> and use filter searching for different countries. For Lenovo support telephone numbers, see <https://datacentersupport.lenovo.com/us/en/supportphonenumber> for your region support details.

Appendix B. Notices

Lenovo may not offer the products, services, or features discussed in this document in all countries. Consult your local Lenovo representative for information on the products and services currently available in your area.

Any reference to a Lenovo product, program, or service is not intended to state or imply that only that Lenovo product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any Lenovo intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any other product, program, or service.

Lenovo may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document is not an offer and does not provide a license under any patents or patent applications. You can send inquiries in writing to the following:

Lenovo (United States), Inc.
1009 Think Place
Morrisville, NC 27560
U.S.A.
Attention: Lenovo VP of Intellectual Property

LENOVO PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. Lenovo may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

The products described in this document are not intended for use in implantation or other life support applications where malfunction may result in injury or death to persons. The information contained in this document does not affect or change Lenovo product specifications or warranties. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of Lenovo or third parties. All information contained in this document was obtained in specific environments and is presented as an illustration. The result obtained in other operating environments may vary.

Lenovo may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Any references in this publication to non-Lenovo Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this Lenovo product, and use of those Web sites is at your own risk.

Any performance data contained herein was determined in a controlled environment. Therefore, the result obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

Trademarks

Lenovo, the Lenovo logo, ThinkSystem, Flex System, System x, NeXtScale System, and x Architecture are trademarks of Lenovo in the United States, other countries, or both.

Intel and Intel Xeon are trademarks of Intel Corporation in the United States, other countries, or both.

Internet Explorer, Microsoft, and Windows are trademarks of the Microsoft group of companies.

Linux is a registered trademark of Linus Torvalds.

Other company, product, or service names may be trademarks or service marks of others.

Important notes

Processor speed indicates the internal clock speed of the microprocessor; other factors also affect application performance.

CD or DVD drive speed is the variable read rate. Actual speeds vary and are often less than the possible maximum.

When referring to processor storage, real and virtual storage, or channel volume, KB stands for 1 024 bytes, MB stands for 1 048 576 bytes, and GB stands for 1 073 741 824 bytes.

When referring to hard disk drive capacity or communications volume, MB stands for 1 000 000 bytes, and GB stands for 1 000 000 000 bytes. Total user-accessible capacity can vary depending on operating environments.

Maximum internal hard disk drive capacities assume the replacement of any standard hard disk drives and population of all hard-disk-drive bays with the largest currently supported drives that are available from Lenovo.

Maximum memory might require replacement of the standard memory with an optional memory module.

Each solid-state memory cell has an intrinsic, finite number of write cycles that the cell can incur. Therefore, a solid-state device has a maximum number of write cycles that it can be subjected to, expressed as total bytes written (TBW). A device that has exceeded this limit might fail to respond to system-generated commands or might be incapable of being written to. Lenovo is not responsible for replacement of a device that has exceeded its maximum guaranteed number of program/erase cycles, as documented in the Official Published Specifications for the device.

Lenovo makes no representations or warranties with respect to non-Lenovo products. Support (if any) for the non-Lenovo products is provided by the third party, not Lenovo.

Some software might differ from its retail version (if available) and might not include user manuals or all program functionality.

Particulate contamination

Attention: Airborne particulates (including metal flakes or particles) and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the device that is described in this document.

Risks that are posed by the presence of excessive particulate levels or concentrations of harmful gases include damage that might cause the device to malfunction or cease functioning altogether. This specification sets forth limits for particulates and gases that are intended to avoid such damage. The limits must not be viewed or used as definitive limits, because numerous other factors, such as temperature or moisture content of the air, can influence the impact of particulates or environmental corrosives and gaseous contaminant transfer. In the absence of specific limits that are set forth in this document, you must implement practices that maintain particulate and gas levels that are consistent with the protection of human health and safety. If Lenovo determines that the levels of particulates or gases in your environment have caused damage to the device, Lenovo may condition provision of repair or replacement of devices or parts on implementation of appropriate remedial measures to mitigate such environmental contamination. Implementation of such remedial measures is a customer responsibility.

Table 67. Limits for particulates and gases

Contaminant	Limits
Particulate	<ul style="list-style-type: none"> The room air must be continuously filtered with 40% atmospheric dust spot efficiency (MERV 9) according to ASHRAE Standard 52.2¹. Air that enters a data center must be filtered to 99.97% efficiency or greater, using high-efficiency particulate air (HEPA) filters that meet MIL-STD-282. The deliquescent relative humidity of the particulate contamination must be more than 60%². The room must be free of conductive contamination such as zinc whiskers.
Gaseous	<ul style="list-style-type: none"> Copper: Class G1 as per ANSI/ISA 71.04-1985³ Silver: Corrosion rate of less than 300 Å in 30 days
<p>¹ ASHRAE 52.2-2008 - Method of Testing General Ventilation Air-Cleaning Devices for Removal Efficiency by Particle Size. Atlanta: American Society of Heating, Refrigerating and Air-Conditioning Engineers, Inc.</p> <p>² The deliquescent relative humidity of particulate contamination is the relative humidity at which the dust absorbs enough water to become wet and promote ionic conduction.</p> <p>³ ANSI/ISA-71.04-1985. Environmental conditions for process measurement and control systems: Airborne contaminants. Instrument Society of America, Research Triangle Park, North Carolina, U.S.A.</p>	

Telecommunication regulatory statement

This product may not be certified in your country for connection by any means whatsoever to interfaces of public telecommunications networks. Further certification may be required by law prior to making any such connection. Contact a Lenovo representative or reseller for any questions.

Electronic emission notices

When you attach a monitor to the equipment, you must use the designated monitor cable and any interference suppression devices that are supplied with the monitor.

Additional electronic emissions notices are available at:

<https://pubs.lenovo.com/>

Taiwan BSMI RoHS declaration

單元 Unit	限用物質及其化學符號 Restricted substances and its chemical symbols					
	鉛Lead (Pb)	汞Mercury (Hg)	鎘Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr ⁶⁺)	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
機架	○	○	○	○	○	○
外部蓋板	○	○	○	○	○	○
機械組零件	-	○	○	○	○	○
空氣傳動設備	-	○	○	○	○	○
冷卻組零件	-	○	○	○	○	○
內存模塊	-	○	○	○	○	○
處理器模塊	-	○	○	○	○	○
鍵盤	-	○	○	○	○	○
調製解調器	-	○	○	○	○	○
監視器	-	○	○	○	○	○
滑鼠	-	○	○	○	○	○
電纜組零件	-	○	○	○	○	○
電源	-	○	○	○	○	○
儲備設備	-	○	○	○	○	○
電池匣組零件	-	○	○	○	○	○
有mech的電路卡	-	○	○	○	○	○
無mech的電路卡	-	○	○	○	○	○
雷射器	-	○	○	○	○	○
<p>備考1. “超出0.1 wt %” 及 “超出0.01 wt %” 係指限用物質之百分比含量超出百分比含量基準值。 Note1 : “exceeding 0.1wt%” and “exceeding 0.01 wt%” indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.</p> <p>備考2. “○” 係指該項限用物質之百分比含量未超出百分比含量基準值。 Note2 : “○” indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.</p> <p>備考3. “-” 係指該項限用物質為排除項目。 Note3 : The “-” indicates that the restricted substance corresponds to the exemption.</p>						

Taiwan import and export contact information

Contacts are available for Taiwan import and export information.

委製商/進口商名稱: 台灣聯想環球科技股份有限公司
進口商地址: 台北市南港區三重路 66 號 8 樓
進口商電話: 0800-000-702

Index

A

- absolute mouse control 64
- accseccfg command 107
- activation key
 - export 86
 - install 85, 122
 - manage 122
 - remove 85, 122
- Active Directory Users
 - LDAP 149
- active system events
 - overview 47
- adapter command 168
- adapter information
 - Server Configuration 55
- advanced Ethernet
 - settings 29, 174
- advanced management module 1
- Agent-less commands 159
- alertcfg command 108
- alertentries command 154
- alphabetical command list 91
- asu command 109
- audit log 51
- autonegotiation
 - set 119

B

- backup command 112
- baseboard management controller (BMC) 1
- batch command 156
- binding method
 - LDAP server 123
- BIOS (basic input/output system) 1
- block list and time restriction
 - settings 34
- blue screen capture 63
- BMC
 - certificate signing request 40
- BMC management
 - BMC configuration
 - back up BMC configuration 45
 - backup and restore BMC configuration 45
 - restore BMC configuration 46
 - restore to factory default 46
- browser requirements 6

C

- CA-signed
 - certificate 40
- centralized management
 - encryption keys 39
- certificate classifications
 - CA-signed 40
 - self-assigned 40
- certificate management
 - CIM over HTTPS 139–140
 - client 40
 - Drive Access 143
 - HTTPS server 139–140
 - LDAP 139–140
 - server 43
 - SSH server 138

- certificate signing request
 - BMC 40
- CIM over HTTP port
 - set 128
- CIM over HTTPS
 - certificate management 139–140
 - security 139–140
- CIM over HTTPS port
 - set 128
- clearcfg command 157
- clearlog command 94
- CLI key sequence
 - set 126
- client
 - certificate management 40
- client certificate management
 - CA-signed 40
 - self-assigned 40
- client distinguished name
 - LDAP server 123
- clock command 157
- collecting service data 75, 200
- command-line interface (CLI)
 - accessing 89
 - command syntax 90
 - description 89
 - features and limitations 90
 - logging in 89
- commands
 - accseccfg 107
 - adapter 168
 - alertcfg 108
 - alertentries 154
 - asu 109
 - backup 112
 - batch 156
 - clearcfg 157
 - clearlog 94
 - clock 157
 - console 107
 - dbgshimm 171
 - dhcpcfg 113
 - dns 114
 - encaps 115
 - ethtousb 116
 - exit 93
 - fans 95
 - ffdc 95
 - firewall 117
 - fuelg 105
 - gprofile 118
 - hashpw 118
 - help 93
 - history 93
 - hreport 96
 - identify 158
 - ifconfig 119
 - info 158
 - keycfg 122
 - ldap 123
 - led 97
 - m2raid 170
 - mhlog 97
 - ntp 125
 - portcfg 126
 - portcontrol 127
 - ports 128
 - power 102
 - pxeboot 106

- rdmount 129
- readlog 99
- reset 104
- restore 130
- restoredefaults 130
- roles 131
- seccfg 132
- set 132
- smtp 133
- snmp 133
- snmpalerts 135
- sreset 159
- srcfg 137
- sshcfg 138
- ssl 139
- sslcfg 140
- storage 159
- storekeycfg 143
- syncprep 144
- syshealth 100
- temps 101
- thermal 145
- timeouts 146
- TLS 147
- trespass 147
- uefipw 148
- usbeth 149
- usbfw 149
- users 149
- volts 101
- vpd 102
- commands, alphabetical list 91
- commands, types of
 - Agent-less 159
 - configuration 107
 - IMM control 154
 - monitor 94
 - serial redirect 107
 - server power and restart 102
 - Support 171
 - utility 93
- configuration commands 107
- configuration restore
 - IMM 130
- configure
 - block list and time restriction 34
 - DDNS 114
 - DDNS settings 31
 - DNS 114
 - DNS settings 31
 - Ethernet 119
 - Ethernet over USB 116
 - Ethernet over USB settings 32
 - Ethernet settings 29, 174
 - IPMI 33
 - IPMI over KCS Access 38
 - IPv4 119
 - IPv6 119
 - LDAP 123
 - LDAP server 123
 - LDAP settings 24
 - network protocols 29
 - network service port 127
 - port assignments 33
 - ports 128
 - prevent system firmware down-level 39
 - security settings 36
 - serial port 126
 - SKLM device group 40
 - SKLM key repository servers 40
 - SMTP 133
 - SNMPv1 133
 - SNMPv1 traps 133
 - SNMPv3 alert settings 32
 - SNMPv3 user accounts 149

- SSH server 38
- USB 116
- user account security levels 107
- configuring
 - front panel USB port to management 35
 - global login settings 22
 - serial-to-SSH redirection 89
- configuring the server
 - options to configure
 - the server 55
- configuring the storage
 - options to configure
 - the storage 79
- configuring the XClarity Controller
 - options to configure
 - the XClarity Controller 17
- console command 107
- contamination, particulate and gaseous 204
- create
 - user account 149
- creating a personalized support web page 199
- Cryptography Setting
 - Cryptography Setting 43
- custom support web page 199

D

- date
 - set 157
- date and time, XClarity Controller
 - setting 77
- dbgshimm command 171
- dcmi
 - functions and commands 60
 - power management 60
- DDNS
 - configure 114
 - custom domain name 114
 - DHCP server specified domain name 114
 - domain name source 114
 - manage 114
- default configuration
 - IMM 130
- default static IP address 10
- delete
 - user 149
- delete group
 - enable, disable 118
- device group
 - drive access page 40
- dhcpinfo command 113
- distinguished name, client
 - LDAP server 123
- distinguished name, root
 - LDAP server 123
- DNS
 - configure 114
 - IPv4 addressing 114
 - IPv6 addressing 114
 - LDAP server 123
 - server addressing 114
- dns command 114
- domain name source
 - DDNS 114
- domain name, custom
 - DDNS 114
- domain name, DHCP server specified
 - DDNS 114
- Drive Access
 - certificate management 143
 - security 143
- drive access page
 - configure 40

- device group 40
- key management servers 40
- SKLM certificate management 40
- Drive Access tab
 - security option 39–40

E

- email and syslog notifications 52
- encaps command 115
- encryption keys
 - centralized management 39
- enhanced role-based security
 - LDAP 149
- enterprise level features 5
- Ethernet
 - configure 119
- Ethernet over USB
 - configure 116
 - port forwarding 116
- ethtousb command 116
- event log 51
- event window
 - log 51
- exit command 93
- exiting the remote console session 75
- export
 - activation key 86
- Extended Audit Log
 - extended audit log 43

F

- fans command 95
- features of XClarity Controller 2
- Features on Demand
 - install feature 122
 - manage 122
 - remove feature 122
- ffdc command 95
- firewall command 117
- firmware
 - view server 102
- firmware, server
 - updating 83
- Flex servers 1
- Flex System 1
- FoD
 - install feature 122
 - manage 122
 - remove feature 122
- fuelg command 105
- functions and commands
 - dcmi 60
 - node manager 59

G

- gaseous contamination 204
- Getting help 199
- global login
 - settings 22
- global login settings
 - account security policy settings 23
- gprofile command 118
- group filter
 - LDAP 123
- group search attribute
 - LDAP 123

H

- hardware health 47
- hardware service and support telephone numbers 201
- hash password 20
- hashpw command 118
- help 199
- help command 93
- history command 93
- host name
 - LDAP server 123
 - set 119
 - SMTP server 133
- hreport command 96
- HTTP port
 - set 128
- HTTPS port
 - set 128
- HTTPS server
 - certificate management 139–140
 - security 139–140

I

- identify command 158
- ifconfig command 119
- IMM
 - configuration restore 130
 - default configuration 130
 - reset 159
 - reset configuration 130
 - restore configuration 130
 - spreset 159
- IMM control commands 154
- important notices 204
- info command 158
- install
 - activation key 85, 122
- install feature
 - Features on Demand 122
 - FoD 122
- IP address
 - configuring 9
 - IPv4 9
 - IPv6 9
 - LDAP server 123
 - SMTP server 133
- IP address, default static 10
- IPMI
 - configure 33
 - remote server management 173
- ipmi bridging
 - power management 59
 - through XClarity Controller 59
- ipmi commands
 - power consumption 59
- IPMI interface
 - description 173
- IPMI over KCS Access
 - configure 38
- IPMItool 173
- IPv4
 - configure 119
- IPv4 addressing
 - DNS 114
- IPv6 9
 - configure 119
- IPv6 addressing
 - DNS 114

K

- key management servers
 - configure 40
 - drive access page 40
- keyboard support in remote console 63
- keycfg command 122

L

- LDAP
 - Active Directory Users 149
 - certificate management 139–140
 - configure 123
 - configuring 17
 - enhanced role-based security 149
 - group filter 123
 - group search attribute 123
 - login permission attribute 123
 - role-based security, enhanced 149
 - security 139–140
 - server target name 123
- ldap command 123
- LDAP server
 - binding method 123
 - client distinguished name 123
 - configure 123
 - DNS 123
 - host name 123
 - IP address 123
 - password 123
 - port number 123
 - pre-configured 123
 - root distinguished name 123
 - search domain 123
 - UID search attribute 123
- LDAP server port
 - set 123
- led command 97
- License Management 85
- logging in to the XClarity Controller 12
- login attempt authentication 17
- login permission attribute
 - LDAP 123

M

- m2raid command 170
- MAC address
 - manage 119
- maintenance history 52
- manage
 - activation key 122
 - DDNS 114
 - Features on Demand 122
 - FoD 122
 - MAC address 119
 - SNMPv1 communities 133
 - user 149
- management
 - server certificate 43
 - SKLM certificate 40
- managing power
 - using IPMI commands 59
- maximum transmission unit
 - set 119
- media mount error issues 73
- media mount methods 65
- mhlog command 97
- MIBs Introduction 7
- minimum, levels
 - TLS 147

- monitor commands 94
- monitoring power
 - using IPMI commands 59
- monitoring the server status 47
- mouse control
 - absolute 64
 - relative 64
 - relative with default Linux acceleration 64
- mouse support in remote console 64
- MTU
 - set 119
- multiple language support 7

N

- network connection 10
 - default static IP address 10
 - IP address, default static 10
 - static IP address, default 10
- network protocol properties
 - assert physical presence 39
 - block list and time restriction 34
 - DDNS 31
 - DNS 31
 - Ethernet over USB 32
 - Ethernet settings 29, 174
 - IPMI 33
 - IPMI over KCS Access 38
 - port assignments 33
 - prevent system firmware down-level 39
 - SNMP alert settings 32
- network service port
 - configure 127
- network settings
 - IPMI commands 33
- new local account
 - creating 18
- node manager
 - functions and commands 59
- notes, important 204
- notices 203
- notices and statements 8
- ntp command 125

O

- OEM IPMI Commands 185
- one-time
 - setting up 56
- OneCLI 1
- online publications
 - documentation update information 1
 - error code information 1
 - firmware update information 1
- operating-system requirements 6
- operating-system screen capture 63
- option
 - SKM 39
- OS failure screen data
 - capture 54
- overview 47
 - ssl 36

P

- particulate contamination 204
- password
 - LDAP server 123
 - user 149
- port assignments

- configure 33
- settings 33
- port forwarding
 - Ethernet over USB 116
- port number
 - LDAP server 123
 - SMTP server 133
- port numbers
 - set 128
- portcfg command 126
- portcontrol command 127
- ports
 - configure 128
 - set numbers 128
 - view open 128
- ports command 128
- power
 - managing using IPMI commands 59
 - monitoring using IPMI commands 59
- power command 102
- power consumption
 - ipmi commands 59
- power management
 - dcmi 60
 - ipmi bridging 59
- power management option
 - power actions 58
 - power capping policy 57
 - power redundancy 57
 - power restore policy 58
 - Server Management tab 57
- pre-configured
 - LDAP server 123
- prevent system firmware down-level
 - configure 39
- pxeboot command 106

R

- RAID detail
 - Server Configuration 79
- RAID setup
 - Server Configuration 79
- rdmount command 129
- readlog command 99
- relative mouse control 64
- relative mouse control for Linux (default Linux acceleration) 64
- remote access 2
- remote console
 - absolute mouse control 64
 - keyboard support 63
 - mouse support 64
 - power and restart commands 62
 - relative mouse control 64
 - relative mouse control for Linux (default Linux acceleration) 64
 - screen capture 63
 - video viewer 61
 - virtual media session 61
- remote console feature 61
- remote console functionality 61
 - enabling 62
- remote console mouse support 64
- remote console port
 - set 128
- remote console screen modes 65
- remote power control 62
- remove
 - activation key 85, 122
- remove feature
 - Features on Demand 122
 - FoD 122
- requirements

- operating system 6
- web browser 6
- reset
 - IMM 159
- reset command 104
- reset configuration
 - IMM 130
- restart XClarity Controller 46
- restore command 130
- restore configuration
 - IMM 130
- restoredefaults command 130
- role-based levels
 - operator 118
 - rbs 118
 - supervisor 118
- role-based security, enhanced
 - LDAP 149
- roles command 131
- root distinguished name
 - LDAP server 123

S

- screen video record/replay
 - server management 64
- search domain
 - LDAP server 123
- seccfg command 132
- security
 - CIM over HTTPS 139–140
 - Drive Access 143
 - HTTPS server 139–140
 - LDAP 139–140
 - SSH server 38, 138
 - ssl certificate handling 37
 - SSL certificate management 37
 - ssl overview 36
- security option
 - Drive Access tab 39–40
- Security option
 - Drive Access tab 40
- self-assigned
 - certificate 40
- Serial over LAN 173
- serial port
 - configure 126
- serial redirect command 107
- serial-to-SSH redirection 89
- server
 - certificate management 43
 - configuration options 55
- server addressing
 - DNS 114
- server certificate
 - management 43
- server configuration
 - server properties 75
- Server Configuration
 - adapter information 55
 - RAID detail 79
 - RAID setup 79
- server firmware
 - updating 83
- server management
 - one-time 56
 - OS failure screen data 54
 - screen video record/replay 64
 - server firmware 83
 - server timeouts, setting 76
 - system boot mode 55
 - system boot order 55
- Server Management tab

- power management option 57
- server power and restart
 - commands 102
- server properties
 - server configuration 75
 - setting location and contact 75
- server status
 - monitoring 47
- server target name
 - LDAP 123
- server timeout
 - selections 76
- service and support
 - before you call 199
 - hardware 201
 - software 201
- service data 200
 - collecting 75
 - downloading 75
- set
 - autonegotiation 119
 - CIM over HTTP port 128
 - CIM over HTTPS port 128
 - CLI key sequence 126
 - date 157
 - host name 119
 - HTTP port 128
 - HTTPS port 128
 - LDAP server port 123
 - maximum transmission unit 119
 - MTU 119
 - remote console port 128
 - SNMP agent port 128
 - SNMP Traps port 128
 - SNMPv1 contact 133
 - SNMPv3 contact 133
 - SSH CLI port 128
 - time 157
 - user authentication method 107
 - web inactivity timeout 107
- set command 132
- set port numbers 128
- setting
 - the XClarity Controller date and time 77
- setting location and contact 75
- setting server timeouts 76
- settings
 - advanced 29, 174
 - block list and time restriction 34
 - DDNS 31
 - DNS 31
 - Ethernet 29, 174
 - Ethernet over USB 32
 - global login 22
 - account security policy settings 23
 - LDAP 24
 - port assignments 33
 - security 36
 - SNMP alert 32
 - SSH server 38
- SKLM
 - key management servers 40
- SKLM certificate
 - management 40
- SKLM certificate management
 - drive access page 40
- SKLM device group
 - configuration 40
- SKM
 - option 39
- SMTP
 - configure 133
 - server host name 133
 - server IP address 133
 - server port number 133
- smtp command 133
- SNMP agent port
 - set 128
- snmp command 133
- SNMP TRAP recipients 52
- SNMP Traps port
 - set 128
- snmpalerts command 135
- SNMPv1
 - configure 133
- SNMPv1 communities
 - manage 133
- SNMPv1 contact
 - set 133
- SNMPv1 traps
 - configure 133
- SNMPv3 contact
 - set 133
- SNMPv3 settings
 - user 149
- SNMPv3 user accounts
 - configure 149
- software service and support telephone numbers 201
- preset command 159
- srcfg command 137
- SSH CLI port
 - set 128
- SSH keys
 - user 149
- SSH server
 - certificate management 138
 - security 138
- sshcfg command 138
- SSL
 - certificate handling 37
 - certificate management 37
- ssl command 139
- sslcfg command 140
- standard level features 2
- static IP address, default 10
- storage
 - configuration options 79
- storage command 159
- storage devices 159
 - storage command 159
- storage inventory 80
- storekeycfg command 143
- Support commands 171
- support for multiple languages 7
- support web page, custom 199
- syncrep command 144
- syshealth command 100
- system information 48
- system utilization 50

T

- Taiwan BSMI RoHS declaration 206
- Taiwan import and export contact information 206
- target name, server
 - LDAP 123
- telecommunication regulatory statement 205
- telephone numbers 201
- temps command 101
- the system information
 - viewing 48
- the system utilization
 - viewing 50
- thermal command 145
- ThinkSystem Server Firmware
 - description 1
- time

- set 157
- timeouts command 146
- TLS
 - minimum level 147
- TLS command 147
- tools
 - IPMItool 173
- trademarks 204
- trespass command 147
- trespass message option 76

U

- uefipw command 148
- UID search attribute
 - LDAP server 123
- USB
 - configure 116
- usbeth command 149
- usfbp command 149
- user
 - delete 149
 - manage 149
 - password 149
 - SNMPv3 settings 149
 - SSH keys 149
- user account
 - create 149
 - deleting 20
- user account security levels
 - configure 107
- user authentication method 17
 - set 107
- users
 - view current 149
- users command 149
- using
 - remote console feature 61
 - remote console function 61
- utility commands 93

V

- Video Viewer
 - absolute mouse control 64
 - mouse support 64
 - power and restart commands 62
 - relative mouse control 64
 - relative mouse control for Linux (default Linux acceleration) 64
 - screen capture 63
 - video color mode 63
- view and configure the virtual drives 79

- view current
 - users 149
- view firmware information
 - server 102
- view open ports 128
- volts command 101
- vpd command 102

W

- Web browser requirements 6
- web inactivity session timeout 23
- web inactivity timeout
 - set 107
- web interface
 - logging in to web interface 12
- web interface, opening and using 9
- working with
 - events in the audit log 51
 - events in the event log 51

X

- XClarity Controller
 - configuration options 17
 - configure network protocol 29
 - description 1
 - features 2
 - ipmi bridging 59
 - network connection 10
 - new functions 1
 - serial redirection 89
 - web interface 9
 - XClarity Controller advanced level 2
 - XClarity Controller enterprise level 2
 - XClarity Controller standard level 2
- XClarity Controller features
 - enterprise level 5
 - standard level 2
- XClarity Controller features advanced level features
 - advanced level 5
- XClarity Controller functions
 - on web interface 13
- XClarity Controller management
 - configuring LDAP 17
 - configuring user accounts 17
 - creating a new local user 18
 - deleting a user account 20
 - security settings 36
 - XClarity Controller properties
 - date and time 77
- XClarity Provisioning Manager
 - Setup utility 10



Part Number: SP47A30085

Printed in China

(1P) P/N: SP47A30085

