FRONT Rack Mounting Template	BACK Rack Mounting Template
10	10
Note: If the rack rail has round holes, install the M5 clip nuts	Note: If the rack rail has round holes, install the M5 clip nuts
• If you have an adjustable rack, set the distance between the	from the installation kit. M5 clip nut If you have an adjustable rack, set the distance between the
front and rear EIA flanges to 719 mm (28.3 inches) outside to outside. • Make sure that there is sufficient room in front of the front rack rail to provide minimum bezel clearance of 50 mm	front and rear EIA flanges to 719 mm (28.3 inches) outside to outside. • Make sure that there is sufficient room in front of the front rack rail to provide minimum bezel clearance of 50 mm
(1.97 inches).	(1.97 inches).
10	
10	10
10	10
10	1U
10	Screws required to secure rails before installing chassis
lenovo.	
P/N 00FE376 Printed in the U.S.A.	
Screws required to secure rails before installing chassis	

Front of Template

Back of Template