



ThinkSystem SR780a V3 Messages and Codes Reference



Machine Types: 7DJ5

Note

Before using this information and the product it supports, be sure to read and understand the safety information and the safety instructions, which are available at:

https://pubs.lenovo.com/safety_documentation/

In addition, be sure that you are familiar with the terms and conditions of the Lenovo warranty for your server, which can be found at:

<http://datacentersupport.lenovo.com/warrantylookup>

First Edition (September 2024)

© Copyright Lenovo 2024.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration (GSA) contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925

Contents

| | | | |
|--|-------------|--|-------------|
| Contents | i | List of UEFI events. | 172 |
| Chapter 1. Messages | 1 | Chapter 4. XClarity Provisioning Manager events | .205 |
| Event and alert message format | 1 | LXPM events organized by severity | 205 |
| Chapter 2. XClarity Controller events | 5 | List of XClarity Provisioning Manager events | 208 |
| XCC events that automatically notify Support | 6 | Appendix A. Getting help and technical assistance | .229 |
| XCC events organized by severity. | 7 | Before you call | 229 |
| List of XClarity Controller events | 28 | Collecting service data | 230 |
| Chapter 3. UEFI events | .167 | Contacting Support | 231 |
| UEFI events organized by severity | 167 | | |

Chapter 1. Messages

When attempting to resolve issues with your server, the best practice is to begin with the event log of the application that is managing the server.

- If you are managing the server from the Lenovo XClarity Administrator, begin with the Lenovo XClarity Administrator event log.
- If you are using some other management application, begin with the Lenovo XClarity Controller event log.

The event log contains server hardware events that are recorded by the Lenovo XClarity Controller or by UEFI. In addition, events can be generated when you perform diagnostic testing on hard drives or memory through the Lenovo XClarity Provisioning Manager (although these events are not stored in the event log).

Use this section to view the events that can be generated by Lenovo XClarity Controller, UEFI, or the Lenovo XClarity Provisioning Manager. For each event, a user action is available to help you understand what must be done to resolve the issue.

Important:

- The server supports Lenovo XClarity Controller 2 (XCC2). For additional information about Lenovo XClarity Controller 2 (XCC2), refer to <https://pubs.lenovo.com/lxcc-overview/>.
- Lenovo XClarity Provisioning Manager (LXPM) supported version varies by product. All versions of Lenovo XClarity Provisioning Manager are referred to as Lenovo XClarity Provisioning Manager and LXPM in this document, unless specified otherwise. To see the LXPM version supported by your server, go to <https://pubs.lenovo.com/lxpm-overview/>.

Event and alert message format

You can use the following content to help you understand the event and alert message format.

The following information is provided for each event message.

Event identifier

A string that uniquely identifies the event or class of events. This is a 12 character string in the following format:

FQXppnnxxxxc

where:

- *pp* indicates the product where the event originate, as follows.
 - **CM**. Chassis Management.
 - **HM**. Hardware manager.
 - **PM**. XClarity Provisioning manger - LXPM (LEPT).
 - **SF**. System Firmware.
 - **SP**. Service Processor.
- *nn* identifies the component or system management where the event originated, as follows:

Components

- **AA**. Canister/Appliance - Contains system components not expected to be serviced by a customer.
- **CA**. Cooling - Fans, blowers, mux cards, policies, chillers/refrigeration, water management units, water pumps, water filtration, air flow sensors, thermal monitors.

- **DA.** Display - Graphics adapters, op panel, monitor/console (including front/back panel, control panel, LCD panel etc).
- **IO.** I/O connectivity - PCI/USB hub, bridge, bus, risers, configuration settings, interconnect, keyboard, mouse, KVM.
- **MA.** Memory - Includes DIMMs, memory card, configuration settings, memory controller, redundant modes (mirroring, spare, etc), RAID memory, NVRAM, EPROM.
- **PU.** Processing - Involves the processor, processor cards and system board (system board assembly), configuration settings, and microcode, cache, Trusted Computing Module, processor interconnect (QPI cables).
- **PW.** Power - Can be power supplies, VRMs, VRDs, voltage levels, system power state, policies, batteries, AT power width, TPMD, power controllers, external power, Battery Backup Unit (UPS), PDUs.
- **SB.** System Board - Main system board, associated risers, system planar, mid-planes, backplanes, interconnects.
- **SD.** Client Data Storage Device - Flash storage adapters, drives, cd/dvd drives, SSD, SAS, DASD, Flash storage, tape, volumes, remoteCopy, flashCopy, managed Storage Systems.
- **SR.** Storage RAID - Adapters, configuration, settings, interconnect, arrays, drive enclosures.
- **VD.** VPD - Configuration settings, EPROMs, communication.

Systems Management - FSM, PSM, HMC, FDMC UEFI, CMM, IOMC, CCE, PMC, DPSM, SVC, management of storage, services, IMM, FSP, systems management networking.

- **BR.** Systems Management - Backup/Restore & Failover (HA).
- **BT.** System management - Boot, reboot, hard/warm reset, shutdown.
- **CL.** LEPT Clone.
- **CN.** Systems Management - Console.
- **CP.** Systems Management - Config Patterns.
- **CR.** Systems Management - Core / Virtual Appliance.
- **DD.** Device Driver - AIX, IBM I, Subsystem Device Driver (SDD), IPMI Service.
- **DM.** Systems Management - Data Management.
- **EA.** Vendor Events.
- **EM.** Events Monitoring - LEPT Dash Board.
- **EM.** Systems Management - Events / Monitoring.
- **FC.** Systems Management - FlexCat OS/Config deployment.
- **FW.** System management - Firmware.
- **HA.** Hypervisor - Virtual Components, Boots, Crashes, SRIOV, LPARs.
- **IF.** Interconnect (Fabric) - common, podm, icm, Irim (SWFW major, various minors & functions).
- **II.** Interconnect (Interfaces) - cimp, smis, cli, mapi (SCFG major).
- **IM.** Interconnect (PCI Manager) - pcim (SWFW major, various minors and functions).
- **IN.** Interconnect (Networking) - bos, ethm, fcf, npiv (FCF major plus SWFW major, various minors & functions) data network, network settings, ports, security, adapters, switches, fiber channel, optical ports, Ethernet.
- **IP.** Interconnect (PIE) - tbd.
- **IU.** Interconnect (Utilities / Infrastructure) - util, infr, serv, isds (IBIS major), remote copy (storage).
- **NM.** Network Management - LEPT Welcompage.
- **NM.** Systems Management - Network Management.
- **OH.** OS/Hypervisor Interface - Passing of error logs, partition management, services (time, etc).
- **OS.** LEPT OS Deploy.
- **OS.** OS - Power Linux, AIX IPL, AIX, crash and dump codes, IBM i kernal code, IBM i OS, management of storage.
- **PR.** System management - Entity presence.
- **RC.** Systems Management - Remote Control.
- **SD.** LEPT Storage Test.
- **SE.** Systems Management - Security.
- **SR.** LEPT Raid Setup.
- **SS.** Service & Support - LEPT FFDC Collection.

- **SS.** Systems Management - Service & Support.
- **TR.** Time Reference - RTC, Master clock, drawer clocks, NTP.
- **UN.** Unknown/any entity.
- **UP.** LEPT Firmware Update.
- **UP.** Systems Management - Updates.
- **WD.** System management - Watchdog.
- **xxxx** is an incrementing number of the Sub-System events set.
- **c** identifies the severity, as follows.
 - **A.** Reserved as Immediate Action.
 - **B.** Unknown / No action.
 - **D.** Reserved - Immediate Decision.
 - **E.** Reserved - Eventual Action.
 - **F.** Warning / No Action.
 - **G.** Warning / Deferred Action.
 - **H.** Minor / Deferred Action.
 - **I.** Information / No Action.
 - **J.** Minor / Immediate Action.
 - **K.** Major / Deferred Action.
 - **L.** Major / Immediate Action.
 - **M.** Critical / Immediate Action.
 - **N.** Fatal / Immediate Action.
 - **W.** Reserved - System Wait.

Chapter 2. XClarity Controller events

When a hardware event is detected by the Lenovo XClarity Controller on the server, the Lenovo XClarity Controller writes that event in the system-event log on the server.

Notes: Event identifier (ID) is a unique identifier used to search for XCC events. The event message may have one or more arguments, which could be replaceable text of FRU name or sensor name to identify the failed component. So one XCC event ID could represent a generic event or similar faults that happened on different hardware components. The general way of problem determination is to locate the event by ID, identify the hardware component by message argument if it contains hardware component name, and then perform actions defined in User Action.

Example:

FQXSPCA0017M: Sensor [SensorElementName] has transitioned to critical from a less severe state where:

- FQXSPCA0017M is the event ID.
- [SensorElementName] is a sensor variable, indicating the name of hardware component. It can be CPU, PCI adapter, OCP card or chipset. You can find the event by the event ID FQXSPCA0017M and perform actions defined in User Action for the component.

For additional information about the Lenovo XClarity Controller event log, see “Viewing Event Logs” section in the XCC documentation compatible with your server at <https://pubs.lenovo.com/lxcc-overview/>.

For each event code, the following fields are displayed:

Event identifier

An identifier that uniquely identifies an event.

Event description

The logged message string that appears for an event. When the event string is displayed in the event log, information such as a specific component is displayed. In this documentation, that additional information appears as variables, which include but not limited to the following:

- [SensorElementName], [ManagedElementName], [ProcessorElementName], [ComputerSystemElementName], [PowerSupplyElementName], ...
- [arg1], [arg2], [arg3], [arg4], [arg5]...

Explanation

Provides additional information to explain why the event occurred.

Severity

An indication of the level of concern for the condition. The following severities can be displayed.

- **Informational.** The event was recorded for audit purposes, usually a user action or a change of states that is normal behavior.
- **Warning.** The event is not as severe as an error, but if possible, the condition should be corrected before it becomes an error. It might also be a condition that requires additional monitoring or maintenance.
- **Error.** The event is a failure or critical condition that impairs service or an expected function.

Alert Category

Similar events are grouped together in categories. The alert category is in the following format: *severity - device*, where:

- *severity* is one of the following severity levels:
 - **Critical.** A key component in the server is no longer functioning.
 - **Warning.** The event might progress to a critical level.
 - **System.** The event is the result of a system error or a configuration change.
- *device* is the specific device in the server that caused the event to be generated.

Serviceable

Specifies whether user action is required to correct the problem.

CIM Information

Provides the prefix of the message ID and the sequence number that is used by the CIM message registry.

SNMP Trap ID

The SNMP trap ID that is found in the SNMP alert management information base (MIB).

Automatically contact Service

You can configure the Lenovo XClarity Administrator to automatically notify Support (also known as call home) if certain types of errors are encountered. If you have configured this function and this field is set to Yes, Lenovo Support will be notified automatically if the event is generated. While you wait for Lenovo Support to call, you can perform the recommended actions for the event.

Note: This documentation includes references to IBM web sites, products, and information about obtaining service. IBM is Lenovo's preferred service provider for the Lenovo server products.

For more information about enabling Call Home from Lenovo XClarity Administrator, see https://pubs.lenovo.com/lxca/admin_setupcallhome. In addition, see “XCC events that automatically notify Support” on page 6 for a consolidated list of all Lenovo XClarity Controller events that are called home to Lenovo Support.

User Action

Indicates what actions you should perform to solve the event. Perform the steps listed in this section in the order shown until the problem is solved. If you cannot solve the problem after performing all steps, contact Lenovo Support.

XCC events that automatically notify Support

You can configure the XClarity Administrator to automatically notify Support (also known as *call home*) if certain types of errors are encountered. If you have configured this function, see the table for a list of events that automatically notify Support.

Table 1. Events that automatically notify Support

| Event ID | Message String |
|--------------|---|
| FQXSPCA0002M | Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted. |
| FQXSPEM4014I | The RAID controller has problem with the battery. Please contact technical support to resolve this issue.([arg1],[arg2],[arg3],[arg4],[arg5]) |
| FQXSPEM4015I | The RAID controller detected unrecoverable error. The controller needs replacement.([arg1],[arg2],[arg3],[arg4],[arg5]) |
| FQXSPEM4025I | One or more virtual drive have problem. Please contact technical support to resolve this issue.([arg1],[arg2],[arg3],[arg4],[arg5]) |
| FQXSPEM4026I | Drive error was detected by RAID controller. Please contact technical support to resolve this issue.([arg1],[arg2],[arg3],[arg4],[arg5]) |

Table 1. Events that automatically notify Support (continued)

| Event ID | Message String |
|--------------|--|
| FQXSPIO0011N | An Uncorrectable Error has occurred on [SensorElementName]. |
| FQXSPIO0015M | Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName]. |
| FQXSPMA0011G | Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]. |
| FQXSPPU0004M | [ProcessorElementName] has Failed with FRB1/BIST condition. |
| FQXSPPW0035M | Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted. |
| FQXSPPW0063M | Sensor [SensorElementName] has transitioned to critical from a less severe state. |
| FQXSPSD0001L | The [StorageVolumeElementName] has a fault. |
| FQXSPSD0002G | Failure Predicted on [StorageVolumeElementName] for array [ComputerSystemElementName]. |
| FQXSPSD0002L | Drive [arg1] in the enclosure/chassis(MTM-SN: [arg2]) has a fault. |
| FQXSPSD0003G | Failure Predicted on drive [arg1] in the enclosure/chassis (MTM-SN: [arg2]). |
| FQXSPSD0005L | Array [ComputerSystemElementName] is in critical condition. |
| FQXSPSD0008L | Array failed on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]). |
| FQXSPSS4004I | Test Call Home Generated by user [arg1]. |
| FQXSPSS4005I | Manual Call Home by user [arg1]: [arg2]. |

XCC events organized by severity

The following table lists all XCC events, organized by severity (Information, Error, and Warning).

Table 2. Events organized by severity

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSPBR4000I | Management Controller [arg1]: Configuration restored from a file by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPBR4002I | Management Controller [arg1] Reset was caused by restoring default values. | Informational |
| FQXSPBR4004I | Server timeouts set by user [arg1]: EnableOSWatchdog=[arg2], OSWatchdogTimeout=[arg3], EnableLoaderWatchdog=[arg4], LoaderTimeout=[arg5]. | Informational |
| FQXSPBR4005I | Management Controller [arg1]: Configuration saved to a file by user [arg2]. | Informational |
| FQXSPBR4006I | Management Controller [arg1]: Configuration restoration from a file by user [arg2] completed from [arg3] at IP address [arg4]. | Informational |
| FQXSPBR4009I | Management Controller [arg1]: cloning configuration from neighbor server [arg2] by group name [arg3]. | Informational |
| FQXSPBR400AI | Management Controller [arg1]: cloning configuration from neighbor server [arg2] by group name [arg3] completed. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSPBR400BI | Management Controller [arg1]: cloning configuration from neighbor server [arg2] by group name [arg3] failed to complete. | Informational |
| FQXSPBR400CI | Management Controller [arg1]: cloning configuration from neighbor server [arg2] by group name [arg3] failed to start. | Informational |
| FQXSPBR400DI | Neighbor group clone configuration was initiated by user [arg1]. | Informational |
| FQXSPBR400EI | Neighbor group firmware update was initiated by user [arg1]. | Informational |
| FQXSPBR400FI | The neighbor group management is [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPBT0007I | No bootable media available for system [ComputerSystemElementName]. | Informational |
| FQXSPCA0012I | Sensor [SensorElementName] has transitioned to normal state. | Informational |
| FQXSPCA2002I | Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted. | Informational |
| FQXSPCA2003I | Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted. | Informational |
| FQXSPCA2005I | Numeric sensor [NumericSensorElementName] going low (lower non-recoverable) has deasserted. | Informational |
| FQXSPCA2007I | Numeric sensor [NumericSensorElementName] going high (upper non-critical) has deasserted. | Informational |
| FQXSPCA2009I | Numeric sensor [NumericSensorElementName] going high (upper critical) has deasserted. | Informational |
| FQXSPCA2011I | Numeric sensor [NumericSensorElementName] going high (upper non-recoverable) has deasserted. | Informational |
| FQXSPCA2017I | Sensor [SensorElementName] has transitioned to a less severe state from critical. | Informational |
| FQXSPCA2019I | Sensor [SensorElementName] has deasserted the transition to non-recoverable from a less severe state. | Informational |
| FQXSPCN4000I | Serial Redirection set by user [arg1]: Mode=[arg2], BaudRate=[arg3], StopBits=[arg4], Parity=[arg5], SessionTerminateSequence=[arg6]. | Informational |
| FQXSPCN4001I | Remote Control session started by user [arg1] in [arg2] mode. | Informational |
| FQXSPCN4002I | User [arg1] has terminated an active CLI console session. | Informational |
| FQXSPCN4003I | Remote Control session started by user [arg1] in [arg2] mode has been closed. | Informational |
| FQXSPCN4004I | User [arg1] has created an active [arg2] console session. | Informational |
| FQXSPCN4005I | A [arg1] console session is timeout. | Informational |
| FQXSPCN4006I | User [arg1] has terminated an active IPMI console session. | Informational |
| FQXSPCR2001I | Sensor [SensorElementName] has deasserted the transition to non-recoverable from a less severe state. | Informational |
| FQXSPDM4000I | Inventory data changed for device [arg1], new device data hash=[arg2], new master data hash=[arg3] . | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|--|---------------|
| FQXSPDM4001I | Storage [arg1] has changed. | Informational |
| FQXSPDM4003I | TKLM servers set by user [arg1]: TKLMServer1=[arg2] Port=[arg3], TKLMServer2=[arg4] Port=[arg5], TKLMServer3=[arg6] Port=[arg7], TKLMServer4=[arg8] Port=[arg9]. | Informational |
| FQXSPDM4004I | TKLM servers device group set by user [arg1]: TKLMServerDeviceGroup=[arg2] . | Informational |
| FQXSPDM4005I | User [arg1] has generated a new encryption key pair and installed a self-signed certificate for the TKLM client. | Informational |
| FQXSPDM4006I | User [arg1] has generated a new encryption key and certificate signing request for the TKLM client. | Informational |
| FQXSPDM4007I | User [arg1] has imported a signed certificate for the TKLM client from [arg2]. | Informational |
| FQXSPDM4008I | User [arg1] has imported a server certificate for the TKLM server. | Informational |
| FQXSPDM4009I | User [arg1] has [arg2] file [arg3] from [arg4]. | Informational |
| FQXSPDM4010I | Inventory data collecting and processing complete for [arg1], sequence number is [arg2]. | Informational |
| FQXSPDM4011I | EKMS server protocol set by user [arg1]: TKLMServerProtocol=[arg2] . | Informational |
| FQXSPDM4012I | User [arg1] has changed the polling configuration for the key management server.: Polling enabled=[arg2] Interval=[arg3] | Informational |
| FQXSPDM4013I | User [arg1] has changed the caching configuration for the key management server: Caching enabled=[arg2] Interval=[arg3] | Informational |
| FQXSPEA2001I | Sensor [SensorElementName] has deasserted the transition from normal to non-critical state. | Informational |
| FQXSPEA2002I | Sensor [SensorElementName] has transitioned to a less severe state from critical. | Informational |
| FQXSPEA2003I | Link up is detected on port [arg1] of the PCIe device [arg2]. | Informational |
| FQXSPDM0003I | The Log [RecordLogElementName] has been cleared. | Informational |
| FQXSPDM0004I | The Log [RecordLogElementName] is full. | Informational |
| FQXSPDM0005I | The Log [RecordLogElementName] is almost full. | Informational |
| FQXSPDM0009I | The System [ComputerSystemElementName] has generated an auxiliary Log Entry in Log [RecordLogElement]. | Informational |
| FQXSPDM4000I | The [arg1] on system [arg2] cleared by user [arg3]. | Informational |
| FQXSPDM4001I | The [arg1] on system [arg2] is 75% full. | Informational |
| FQXSPDM4002I | The [arg1] on system [arg2] is 100% full. | Informational |
| FQXSPDM4003I | LED [arg1] state changed to [arg2] by [arg3]. | Informational |
| FQXSPDM4004I | SNMP [arg1] enabled by user [arg2] . | Informational |
| FQXSPDM4005I | SNMP [arg1] disabled by user [arg2] . | Informational |
| FQXSPDM4006I | Alert Configuration Global Event Notification set by user [arg1]: RetryLimit=[arg2], RetryInterval=[arg3], EntryInterval=[arg4]. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|--|---------------|
| FQXSPEM4007I | Alert Recipient Number [arg1] updated: Name=[arg2], DeliveryMethod=[arg3], Address=[arg4], IncludeLog=[arg5], Enabled=[arg6], EnabledAlerts=[arg7], AllowedFilters=[arg8] by user [arg9] from [arg10] at IP address [arg11]. | Informational |
| FQXSPEM4008I | SNMP Traps enabled by user [arg1]: EnabledAlerts=[arg2], AllowedFilters=[arg3] . | Informational |
| FQXSPEM4009I | The UEFI Definitions have been changed. | Informational |
| FQXSPEM4010I | UEFI Reported: [arg1]. | Informational |
| FQXSPEM4011I | XCC failed to log previous event [arg1]. | Informational |
| FQXSPEM4012I | User [arg1] made system [arg2] Encapsulation lite Mode. | Informational |
| FQXSPEM4013I | Battery error was detected by RAID controller. The battery unit needs replacement.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPEM4014I | The RAID controller has problem with the battery. Please contact technical support to resolve this issue.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPEM4015I | The RAID controller detected unrecoverable error. The controller needs replacement.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPEM4016I | The RAID controller detected one or more problems. Please contact technical support for additional assistance.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPEM4017I | The RAID controller detected one or more possible configuration changes within the subsystem. Please check the drive LED status. If necessary, contact technical support for additional assistance.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPEM4018I | Enclosure/Chassis issue detected with one or more units. Please check the enclosure/chassis units to repair the problem.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPEM4019I | Connectivity issue detected with the enclosure/chassis. Please check your cable configurations to repair the problem.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPEM4020I | Fan problem detected with the enclosure/chassis. Please check the enclosure/chassis unit fan for correct operation.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPEM4022I | Enclosure/Chassis power supply has problem. Please check the enclosure/chassis unit power supply for correct operation.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPEM4023I | One or more virtual drive are in abnormal status that may cause unavailable virtual drive. Please check the event logs and if events are targeted to the same disk then replace the drive. If necessary, contact technical support for additional assistance.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPEM4024I | The RAID controller detected one or more possible configuration problem within the subsystem. Please check the event logs and if events are targeted to the same disk then replace the drive. If necessary, contact technical support for additional assistance.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|---------------|--|---------------|
| FQXSPPEM4025I | One or more virtual drive have problem. Please contact technical support to resolve this issue.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPPEM4026I | Drive error was detected by RAID controller. Please contact technical support to resolve this issue.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPPEM4027I | Drive error was detected by RAID controller. Please check the event logs and if events are targeted to the same disk then replace the drive. If necessary, contact technical support for additional assistance. ([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPPEM4028I | The port [arg1] of PCIe device [arg2] at [arg3] has link [arg4]. | Informational |
| FQXSPPEM4029I | All PCIe slots on [arg1] may not be functional based upon your current CPU population. | Informational |
| FQXSPPEM4030I | A scheduled operation on the RAID controller has encountered an issue. Refer to RAID Logs under Server Management, Local Storage, for details.([arg1],[arg2],[arg3],[arg4],[arg5]) | Informational |
| FQXSPPEM4031I | SSD wear threshold setting is changed from [arg1] to [arg2] by user [arg3] from [arg4] at IP address [arg5]. | Informational |
| FQXSPPEM4032I | Acoustic Mode [arg1] has been engaged. Fan speed limits are in place. | Informational |
| FQXSPPEM4033I | Acoustic Mode [arg1] has been disengaged to allow adequate cooling. | Informational |
| FQXSPPEM4036I | Dust filter measurement schedule is configured on server [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPPEM4037I | Attempting to perform scheduled dust filter measurement on server [arg1]. | Informational |
| FQXSPPEM4038I | Dust filter measurement schedule is disabled on server [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPPEM4039I | Attempting to perform an immediate dust filter measurement on server [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPPEM4041I | The SmartNIC in slot [arg1] encountered boot timeout. | Informational |
| FQXSPPEM4042I | The SmartNIC in slot [arg1] went through a crash dump. | Informational |
| FQXSPPEM4044I | Dust filter measurement was successfully completed, no action is needed. | Informational |
| FQXSPFC4000I | The bare metal connection process has been started. | Informational |
| FQXSPFC4001I | The bare metal update application reports a status of [arg1]. | Informational |
| FQXSPFC4002I | System running in setup. | Informational |
| FQXSPFC4003I | UEFI deployment boot mode is enabled for NextBoot. | Informational |
| FQXSPFC4004I | UEFI deployment boot mode is enabled for NextAc. | Informational |
| FQXSPFC4005I | UEFI deployment boot mode has been disabled. | Informational |
| FQXSPFW0003I | The System [ComputerSystemElementName] encountered firmware progress. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSPIO0000I | The connector [PhysicalConnectorElementName] has been detected as present or connected. | Informational |
| FQXSPIO0010I | A Correctable Bus Error has occurred on bus [SensorElementName]. | Informational |
| FQXSPIO0016I | Identifying slot [PhysicalConnectorElementName] on system [ComputerSystemElementName]. | Informational |
| FQXSPIO2003I | System [ComputerSystemElementName] has recovered from a diagnostic interrupt. | Informational |
| FQXSPIO2004I | Bus [SensorElementName] has recovered from a bus timeout. | Informational |
| FQXSPIO2006I | System [ComputerSystemElementName] has recovered from an NMI. | Informational |
| FQXSPIO2007I | A PCI PERR recovery has occurred on system [ComputerSystemElementName]. | Informational |
| FQXSPIO2008I | A PCI SERR on system [ComputerSystemElementName] has deasserted. | Informational |
| FQXSPIO2010I | Bus [SensorElementName] has recovered from a Correctable Bus Error. | Informational |
| FQXSPIO2013I | Bus [SensorElementName] has recovered from a Fatal Bus Error. | Informational |
| FQXSPIO4002I | GPU Board Status was recovered by [arg1] of [arg1]. | Informational |
| FQXSPIO4003I | The PCIe switch has changed to normal mode by user [arg1] from [arg2] at IP address [arg3]. | Informational |
| FQXSPIO4004I | The PCIe switch has changed to update-ready mode by user [arg1] from [arg2] at IP address [arg3]. | Informational |
| FQXSPMA0022I | Post Package Repair Success for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]. | Informational |
| FQXSPMA0025I | Sensor [SensorElementName] has asserted. | Informational |
| FQXSPMA2001I | Error Detected and Corrected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has deasserted. | Informational |
| FQXSPMA2007I | Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered. | Informational |
| FQXSPMA2010I | [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled. | Informational |
| FQXSPMA2012I | An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName]. | Informational |
| FQXSPMA2024I | Sensor [SensorElementName] has deasserted. | Informational |
| FQXSPNM4000I | Management Controller [arg1] Network Initialization Complete. | Informational |
| FQXSPNM4001I | Ethernet Data Rate modified from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4002I | Ethernet Duplex setting modified from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4003I | Ethernet MTU setting modified from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4004I | Ethernet locally administered MAC address modified from [arg1] to [arg2] by user [arg3]. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSPNM4005I | Ethernet interface [arg1] by user [arg2]. | Informational |
| FQXSPNM4006I | Hostname set to [arg1] by user [arg2]. | Informational |
| FQXSPNM4007I | IP address of network interface modified from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4008I | IP subnet mask of network interface modified from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4009I | IP address of default gateway modified from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4011I | ENET[[arg1]] DHCP-HSTN=[arg2], DN=[arg3], IP@=[arg4], SN=[arg5], GW@=[arg6], DNS1@=[arg7] . | Informational |
| FQXSPNM4012I | ENET[[arg1]] IP-Cfg:HstName=[arg2], IP@=[arg3] ,NetMsk=[arg4], GW@=[arg5] . | Informational |
| FQXSPNM4013I | LAN: Ethernet[[arg1]] interface is no longer active. | Informational |
| FQXSPNM4014I | LAN: Ethernet[[arg1]] interface is now active. | Informational |
| FQXSPNM4015I | DHCP setting changed to [arg1] by user [arg2]. | Informational |
| FQXSPNM4016I | Domain name set to [arg1] by user [arg2]. | Informational |
| FQXSPNM4017I | Domain Source changed to [arg1] by user [arg2]. | Informational |
| FQXSPNM4018I | DDNS setting changed to [arg1] by user [arg2]. | Informational |
| FQXSPNM4019I | DDNS registration successful. The domain name is [arg1]. | Informational |
| FQXSPNM4020I | IPv6 enabled by user [arg1] . | Informational |
| FQXSPNM4021I | IPv6 disabled by user [arg1] . | Informational |
| FQXSPNM4022I | IPv6 static IP configuration enabled by user [arg1]. | Informational |
| FQXSPNM4023I | IPv6 DHCP enabled by user [arg1]. | Informational |
| FQXSPNM4024I | IPv6 stateless auto-configuration enabled by user [arg1]. | Informational |
| FQXSPNM4025I | IPv6 static IP configuration disabled by user [arg1]. | Informational |
| FQXSPNM4026I | IPv6 DHCP disabled by user [arg1]. | Informational |
| FQXSPNM4027I | IPv6 stateless auto-configuration disabled by user [arg1]. | Informational |
| FQXSPNM4028I | ENET[[arg1]] IPv6-LinkLocal:HstName=[arg2], IP@=[arg3] ,Pref=[arg4]. | Informational |
| FQXSPNM4029I | ENET[[arg1]] IPv6-Static:HstName=[arg2], IP@=[arg3] ,Pref=[arg4], GW@=[arg5] . | Informational |
| FQXSPNM4030I | ENET[[arg1]] DHCPv6-HSTN=[arg2], DN=[arg3], IP@=[arg4], Pref=[arg5], DNS1@=[arg5]. | Informational |
| FQXSPNM4031I | IPv6 static address of network interface modified from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4033I | Telnet port number changed from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4034I | SSH port number changed from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4035I | Web-HTTP port number changed from [arg1] to [arg2] by user [arg3]. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSPNM4036I | Web-HTTPS port number changed from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4037I | CIM/XML HTTP port number changed from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4038I | CIM/XML HTTPS port number changed from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4039I | SNMP Agent port number changed from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4040I | SNMP Traps port number changed from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4041I | Syslog port number changed from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4042I | Remote Presence port number changed from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4043I | SMTP Server set by user [arg1] to [arg2]:[arg3]. | Informational |
| FQXSPNM4044I | Telnet [arg1] by user [arg2]. | Informational |
| FQXSPNM4045I | DNS servers set by user [arg1]: UseAdditionalServers=[arg2], PreferredDNStype=[arg3], IPv4Server1=[arg4], IPv4Server2=[arg5], IPv4Server3=[arg6], IPv6Server1=[arg7], IPv6Server2=[arg8], IPv6Server3=[arg9]. | Informational |
| FQXSPNM4046I | LAN over USB [arg1] by user [arg2]. | Informational |
| FQXSPNM4047I | LAN over USB Port Forwarding set by user [arg1]: ExternalPort=[arg2], USB-LAN port=[arg3]. | Informational |
| FQXSPNM4048I | PXE boot requested by user [arg1]. | Informational |
| FQXSPNM4049I | User [arg1] has initiated a TKLM Server Connection Test to check connectivity to server [arg2]. | Informational |
| FQXSPNM4050I | User [arg1] has initiated an SMTP Server Connection Test. | Informational |
| FQXSPNM4051I | User [arg1] has set the SMTP Server reverse-path to [arg2]. | Informational |
| FQXSPNM4052I | DHCP specified hostname is set to [arg1] by user [arg2]. | Informational |
| FQXSPNM4053I | DNS discovery of Lenovo XClarity Administrator has been [arg1] by user [arg2]. | Informational |
| FQXSPNM4054I | The hostname from DHCP is [arg1] by user [arg2]. | Informational |
| FQXSPNM4055I | The hostname from DHCP is invalid. | Informational |
| FQXSPNM4056I | The NTP server address [arg1] is invalid. | Informational |
| FQXSPNM4057I | Security: IP address: [arg1] had [arg2] login failures, it will be blocked to access for [arg3] minutes. | Informational |
| FQXSPNM4058I | IP address of network interface [arg1] is modified from [arg2] to [arg3] by user [arg4]. | Informational |
| FQXSPNM4059I | IP subnet mask of network interface [arg1] is modified from [arg2] to [arg3] by user [arg4]. | Informational |
| FQXSPNM4060I | IP address of default gateway of network interface [arg1] is modified from [arg2] to [arg3] by user [arg4]. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|--|---------------|
| FQXSPNM4061I | WiFi interface is [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPNM4062I | IP address of WiFi interface is modified from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4063I | IP subnet mask of WiFi interface is modified from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4064I | IP address of default gateway of WiFi interface is modified from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPNM4065I | Country code of WiFi interface is modified to [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPOS4000I | OS Watchdog response [arg1] by [arg2] . | Informational |
| FQXSPOS4001I | Watchdog [arg1] Screen Capture Occurred . | Informational |
| FQXSPOS4004I | Operating System status has changed to [arg1]. | Informational |
| FQXSPOS4005I | Host Power-On password changed by user [arg1] from [arg2] at IP address [arg3]. | Informational |
| FQXSPOS4006I | Host Power-On password cleared by user [arg1] from [arg2] at IP address [arg3]. | Informational |
| FQXSPOS4007I | Host Admin password changed by user [arg1] from [arg2] at IP address [arg3]. | Informational |
| FQXSPOS4008I | Host Admin password cleared by user [arg1] from [arg2] at IP address [arg3]. | Informational |
| FQXSPOS4009I | OS Crash Video Captured. | Informational |
| FQXSPOS4011I | OS failure screen capture with hardware error is [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPOS4012I | POST watchdog Screen Capture Occurred. | Informational |
| FQXSPPP4000I | Attempting to [arg1] server [arg2] by user [arg3]. | Informational |
| FQXSPPP4001I | Server Power Off Delay set to [arg1] by user [arg2]. | Informational |
| FQXSPPP4002I | Server [arg1] scheduled for [arg2] at [arg3] by user [arg4]. | Informational |
| FQXSPPP4003I | Server [arg1] scheduled for every [arg2] at [arg3] by user [arg4]. | Informational |
| FQXSPPP4004I | Server [arg1] [arg2] cleared by user [arg3]. | Informational |
| FQXSPPP4005I | The power cap value changed from [arg1] watts to [arg2] watts by user [arg3]. | Informational |
| FQXSPPP4006I | The minimum power cap value changed from [arg1] watts to [arg2] watts. | Informational |
| FQXSPPP4007I | The maximum power cap value changed from [arg1] watts to [arg2] watts. | Informational |
| FQXSPPP4008I | The soft minimum power cap value changed from [arg1] watts to [arg2] watts. | Informational |
| FQXSPPP4011I | Power capping was activated by user [arg1]. | Informational |
| FQXSPPP4012I | Power capping was deactivated by user [arg1]. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSPPP4013I | Static Power Savings mode has been turned on by user [arg1]. | Informational |
| FQXSPPP4014I | Static Power Savings mode has been turned off by user [arg1]. | Informational |
| FQXSPPP4015I | Dynamic Power Savings mode has been turned on by user [arg1]. | Informational |
| FQXSPPP4016I | Dynamic Power Savings mode has been turned off by user [arg1]. | Informational |
| FQXSPPP4017I | Power cap and external throttling occurred. | Informational |
| FQXSPPP4018I | External throttling occurred . | Informational |
| FQXSPPP4019I | Power cap throttling occurred. | Informational |
| FQXSPPP4020I | The measured power value has returned below the power cap value. | Informational |
| FQXSPPP4021I | The new minimum power cap value has returned below the power cap value. | Informational |
| FQXSPPP4022I | The server was restarted for an unknown reason. | Informational |
| FQXSPPP4023I | The server is restarted by chassis control command. | Informational |
| FQXSPPP4024I | The server was reset via push button. | Informational |
| FQXSPPP4025I | The server was powered-up via power push button. | Informational |
| FQXSPPP4026I | The server was restarted when the watchdog expired.. | Informational |
| FQXSPPP4027I | The server was restarted for OEM reason. | Informational |
| FQXSPPP4028I | The server was automatically powered on because the power restore policy is set to always on. | Informational |
| FQXSPPP4029I | The server was automatically powered on because the power restore policy is set to restore previous power state.. | Informational |
| FQXSPPP4030I | The server was reset via Platform Event Filter. | Informational |
| FQXSPPP4031I | The server was power-cycled via Platform Event Filter. | Informational |
| FQXSPPP4032I | The server was soft reset. | Informational |
| FQXSPPP4033I | The server was powered up via Real Time Clock (scheduled power on). | Informational |
| FQXSPPP4034I | The server was powered off for an unknown reason. | Informational |
| FQXSPPP4035I | The server was powered off by chassis control command. | Informational |
| FQXSPPP4036I | The server was powered off via push button. | Informational |
| FQXSPPP4037I | The server was powered off when the watchdog expired. | Informational |
| FQXSPPP4038I | The server stayed powered off because the power restore policy is set to always off. | Informational |
| FQXSPPP4039I | The server stayed powered off because the power restore policy is set to restore previous power state.. | Informational |
| FQXSPPP4040I | The server was powered off via Platform Event Filter. | Informational |
| FQXSPPP4041I | The server was powered off via Real Time Clock (scheduled power off). | Informational |
| FQXSPPP4042I | Management Controller [arg1] reset was initiated due to Power-On-Reset. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSPPP4043I | Management Controller [arg1] reset was initiated by PRESET. | Informational |
| FQXSPPP4044I | Management Controller [arg1] reset was initiated by CMM. | Informational |
| FQXSPPP4045I | Management Controller [arg1] reset was initiated by XCC firmware. | Informational |
| FQXSPPP4046I | Remote power permission is [arg1]. | Informational |
| FQXSPPP4047I | Management Controller [arg1] reset was initiated by user [arg2]. | Informational |
| FQXSPPP4048I | Attempting to AC power cycle server [arg1] by user [arg2]. | Informational |
| FQXSPPP4049I | Management Controller [arg1] reset was initiated by Front Panel. | Informational |
| FQXSPPP4050I | Management Controller [arg1] reset was initiated to activate PFR Firmware. | Informational |
| FQXSPPP4051I | The programmable GPU total power capping value in slot [arg1] is changed to [arg2] watts by user [arg3] from [arg4] at IP address [arg5]. | Informational |
| FQXSPPP4052I | The programmable GPU peak power capping value in slot [arg1] is changed to [arg2] watts by user [arg3] from [arg4] at IP address [arg5]. | Informational |
| FQXSPPP4053I | This message is reserved. | Informational |
| FQXSPPP4054I | Unbalanced PSU config is detected, system is using less node PSU capacity. | Informational |
| FQXSPPR2001I | [ManagedElementName] detected as absent. | Informational |
| FQXSPPU0014I | CPU protective power limitation is asserted. | Informational |
| FQXSPPU2001I | An Over-Temperature Condition has been removed on [ProcessorElementName]. | Informational |
| FQXSPPU2002I | The Processor [ProcessorElementName] is no longer operating in a Degraded State. | Informational |
| FQXSPPU2014I | CPU protective power limitation is deasserted. | Informational |
| FQXSPPU2015I | Sensor [SensorElementName] has deasserted. | Informational |
| FQXSPPW0001I | [PowerSupplyElementName] has been added to container [PhysicalPackageElementName]. | Informational |
| FQXSPPW0005I | [PowerSupplyElementName] is operating in an Input State that is out of range. | Informational |
| FQXSPPW0008I | [SensorElementName] has been turned off. | Informational |
| FQXSPPW0009I | [PowerSupplyElementName] has been Power Cycled. | Informational |
| FQXSPPW2001I | [PowerSupplyElementName] has been removed from container [PhysicalPackageElementName]. | Informational |
| FQXSPPW2002I | [PowerSupplyElementName] has returned to OK status. | Informational |
| FQXSPPW2003I | Failure no longer predicted on [PowerSupplyElementName]. | Informational |
| FQXSPPW2006I | [PowerSupplyElementName] has returned to a Normal Input State. | Informational |
| FQXSPPW2007I | [PowerSupplyElementName] Configuration is OK. | Informational |
| FQXSPPW2008I | [PowerSupplyElementName] has been turned on. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSPPW2018I | [PowerSupplyElementName] out-of-range has returned to a Normal Input State. | Informational |
| FQXSPPW2031I | Numeric sensor [NumericSensorElementName] going low (lower non-critical) has deasserted. | Informational |
| FQXSPPW2035I | Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted. | Informational |
| FQXSPPW2057I | Sensor [SensorElementName] has deasserted the transition from normal to non-critical state. | Informational |
| FQXSPPW2061I | Sensor [SensorElementName] has transitioned to a less severe state from critical. | Informational |
| FQXSPPW2062I | Sensor [SensorElementName] has transitioned to a less severe state from critical. | Informational |
| FQXSPPW2063I | Sensor [SensorElementName] has transitioned to a less severe state from critical. | Informational |
| FQXSPPW2101I | Redundancy Degraded for [RedundancySetElementName] has deasserted. | Informational |
| FQXSPPW2104I | Non-redundant:Sufficient Resources from Redundancy Degraded or Fully Redundant for [RedundancySetElementName] has deasserted. | Informational |
| FQXSPPW2110I | Non-redundant:Insufficient Resources for [RedundancySetElementName] has deasserted. | Informational |
| FQXSPPW4001I | PCIe Power Brake for [arg1] has been [arg2]. | Informational |
| FQXSPPW4003I | The customized total graphics power is within the pre-configured limit. | Informational |
| FQXSPSD0000I | The [StorageVolumeElementName] has been added. | Informational |
| FQXSPSD0001I | The [StorageVolumeElementName] Drive [arg1] in the enclosure/chassis(MTM-SN: [arg2]) has been added. | Informational |
| FQXSPSD0003I | Hot Spare enabled for [ComputerSystemElementName]. | Informational |
| FQXSPSD0005I | Hot Spare enabled for drive [arg1] in the enclosure/chassis (MTM-SN: [arg2]). | Informational |
| FQXSPSD0007I | Rebuild in progress for Array in system [ComputerSystemElementName]. | Informational |
| FQXSPSD0008I | Array rebuild in progress on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]). | Informational |
| FQXSPSD2000I | The [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName]. | Informational |
| FQXSPSD2001I | The [StorageVolumeElementName] has recovered from a fault. | Informational |
| FQXSPSD2002I | Failure no longer Predicted on [StorageVolumeElementName] for array [ComputerSystemElementName]. | Informational |
| FQXSPSD2005I | Critical Array [ComputerSystemElementName] has deasserted. | Informational |
| FQXSPSD2006I | Array in system [ComputerSystemElementName] has been restored. | Informational |
| FQXSPSD2007I | Rebuild completed for Array in system [ComputerSystemElementName]. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSPSD2008I | Drive [arg1] in the enclosure/chassis(MTM-SN: [arg2]) has recovered from a fault. | Informational |
| FQXSPSD2010I | Drive [arg1] in the enclosure/chassis(MTM-SN: [arg2]) has been removed. | Informational |
| FQXSPSD2011I | Failure no longer Predicted on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]). | Informational |
| FQXSPSD2012I | Hot Spare disabled for drive [arg1] in the enclosure/chassis (MTM-SN: [arg2]). | Informational |
| FQXSPSD2013I | Array critical deasserted on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]). | Informational |
| FQXSPSD2014I | Array restored on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]). | Informational |
| FQXSPSD2015I | Array rebuild completed on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]). | Informational |
| FQXSPSE2000I | The Chassis [PhysicalPackageElementName] was closed. | Informational |
| FQXSPSE2010I | System guard changed to compliant status. | Informational |
| FQXSPSE4001I | Remote Login Successful. Login ID: [arg1] using [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE4002I | Security: Userid: [arg1] using [arg2] had [arg3] login failures from WEB client at IP address [arg4]. | Informational |
| FQXSPSE4003I | Security: Login ID: [arg1] had [arg2] login failures from CLI at [arg3]. | Informational |
| FQXSPSE4004I | Remote access attempt failed. Invalid userid or password received. Userid is [arg1] from WEB browser at IP address [arg2]. | Informational |
| FQXSPSE4005I | Remote access attempt failed. Invalid userid or password received. Userid is [arg1] from TELNET client at IP address [arg2]. | Informational |
| FQXSPSE4007I | Security: Userid: [arg1] using [arg2] had [arg3] login failures from an SSH client at IP address [arg4]. | Informational |
| FQXSPSE4008I | SNMPv1 [arg1] set by user [arg2]: Name=[arg3], AccessType=[arg4], Address=[arg5], . | Informational |
| FQXSPSE4009I | LDAP Server configuration set by user [arg1]: SelectionMethod=[arg2], DomainName=[arg3], Server1=[arg4], Server2=[arg5], Server3=[arg6], Server4=[arg7]. | Informational |
| FQXSPSE4010I | LDAP set by user [arg1]: RootDN=[arg2], UIDSearchAttribute=[arg3], BindingMethod=[arg4], EnhancedRBS=[arg5], TargetName=[arg6], GroupFilter=[arg7], GroupAttribute=[arg8], LoginAttribute=[arg9]. | Informational |
| FQXSPSE4011I | Secure Web services (HTTPS) [arg1] by user [arg2]. | Informational |
| FQXSPSE4012I | Secure CIM/XML(HTTPS) [arg1] by user [arg2]. | Informational |
| FQXSPSE4013I | Secure LDAP [arg1] by user [arg2]. | Informational |
| FQXSPSE4014I | SSH [arg1] by user [arg2]. | Informational |
| FQXSPSE4015I | Global Login General Settings set by user [arg1]: AuthenticationMethod=[arg2], LockoutPeriod=[arg3], SessionTimeout=[arg4]. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSPSE4016I | Global Login Account Security set by user [arg1]: PasswordRequired=[arg2], PasswordExpirationPeriod=[arg3], MinimumPasswordReuseCycle=[arg4], MinimumPasswordLength=[arg5], MinimumPasswordChangeInterval=[arg6], MaxmumLoginFailures=[arg7], LockoutAfterMaxFailures=[arg8]. | Informational |
| FQXSPSE4017I | User [arg1] created. | Informational |
| FQXSPSE4018I | User [arg1] removed. | Informational |
| FQXSPSE4019I | User [arg1] password modified. | Informational |
| FQXSPSE4020I | User [arg1] role set to [arg2]. | Informational |
| FQXSPSE4021I | User [arg1] custom privileges set: [arg2][arg3][arg4][arg5][arg6][arg7][arg8][arg9]. | Informational |
| FQXSPSE4022I | User [arg1] for SNMPv3 set: AuthenticationProtocol=[arg2], PrivacyProtocol=[arg3], AccessType=[arg4], HostforTraps=[arg5] by user [arg6] from [arg7] at IP address [arg8]. | Informational |
| FQXSPSE4023I | SSH Client key added for user [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE4024I | SSH Client key imported for user [arg1] from [arg2] by user [arg3] from [arg4] at IP address [arg5]. | Informational |
| FQXSPSE4025I | SSH Client key removed from user [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE4026I | Security: Userid: [arg1] had [arg2] login failures from a CIM client at IP address [arg3]. | Informational |
| FQXSPSE4027I | Remote access attempt failed. Invalid userid or password received. Userid is [arg1] from a CIM client at IP address [arg2]. | Informational |
| FQXSPSE4028I | Security: Userid: [arg1] had [arg2] login failures from IPMI client at IP address [arg3]. | Informational |
| FQXSPSE4029I | Security: Userid: [arg1] had [arg2] login failures from SNMP client at IP address [arg3]. | Informational |
| FQXSPSE4030I | Security: Userid: [arg1] had [arg2] login failures from IPMI serial client. | Informational |
| FQXSPSE4031I | Remote Login Successful. Login ID: [arg1] from [arg2] serial interface. | Informational |
| FQXSPSE4032I | Login ID: [arg1] from [arg2] at IP address [arg3] has logged off. | Informational |
| FQXSPSE4033I | Login ID: [arg1] from [arg2] at IP address [arg3] has been logged off. | Informational |
| FQXSPSE4034I | User [arg1] has removed a certificate. | Informational |
| FQXSPSE4035I | A certificate has been revoked . | Informational |
| FQXSPSE4036I | The [arg1] certificate is expired and has been removed. | Informational |
| FQXSPSE4037I | Crypto mode modified from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPSE4038I | Minimum TLS level modified from [arg1] to [arg2] by user [arg3]. | Informational |
| FQXSPSE4039I | Temporary user account [arg1] is created by inband tool. | Informational |
| FQXSPSE4040I | Temporary user account [arg1] expires. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|--|---------------|
| FQXSPSE40411 | Security: Userid: [arg1] had [arg2] login failures from a SFTP client at IP address [arg3]. | Informational |
| FQXSPSE40421 | The third-party password function [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE40431 | Retrieving the third-party password [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE40441 | User [arg1] third-party hashed password has been [arg2] by user [arg3] from [arg4] at IP address [arg5]. | Informational |
| FQXSPSE40451 | The Salt of user [arg1] third-party password has been [arg2] by user [arg3] from [arg4] at IP address [arg5]. | Informational |
| FQXSPSE40461 | The third-party password of the user [arg1] has been retrieved by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE40471 | Role [arg1] is [arg2] and assigned with custom privileges [arg3][arg4] [arg5][arg6][arg7][arg8][arg9][arg10][arg11] by user [arg12] . | Informational |
| FQXSPSE40481 | Role [arg1] is removed by user [arg2]. | Informational |
| FQXSPSE40491 | Role [arg1] is assigned to user [arg2] by user [arg3]. | Informational |
| FQXSPSE40501 | [arg1] sent IPMI command from [arg2], raw data: [arg3][arg4][arg5]. | Informational |
| FQXSPSE40511 | Management Controller [arg1] joined the neighbor group [arg2] by user [arg3] at IP address [arg4]. | Informational |
| FQXSPSE40521 | The password of neighbor group [arg1] is modified by [arg2] [arg3] at IP address [arg4]. | Informational |
| FQXSPSE40531 | Management Controller [arg1] left the neighbor group [arg2] by user [arg3] at IP address [arg4]. | Informational |
| FQXSPSE40541 | IPMI SEL wrapping mode is [arg1] by user [arg2] at IP address [arg3]. | Informational |
| FQXSPSE40551 | SED encryption is enabled by user [arg1] at IP address [arg2]. | Informational |
| FQXSPSE40561 | SED AK is [arg1] by user [arg2] at IP address [arg3]. | Informational |
| FQXSPSE40571 | User [arg1] created by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE40581 | User [arg1] removed by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE40591 | User [arg1] password modified by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE40601 | User [arg1] role set to [arg2] by user [arg3] from [arg4] at IP address [arg5]. | Informational |
| FQXSPSE40611 | User [arg1] custom privileges set: [arg2][arg3][arg4][arg5][arg6][arg7] [arg8][arg9] by user [arg10] from [arg11] at IP address [arg12]. | Informational |
| FQXSPSE40621 | The system guard snapshot is captured by user [arg1] from [arg2] at IP address [arg3]. | Informational |
| FQXSPSE40631 | The system guard configuration is updated: status=[arg1], hardware inventory=[arg2] and action=[arg3] by user [arg4] from [arg5] at IP address [arg6]. | Informational |
| FQXSPSE40641 | SNMPv3 engine ID is changed from [arg1] to [arg2] by user [arg3] from [arg4] at IP address [arg5]. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSPSE4065I | SFTP [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE4066I | Security mode is modified from [arg1] to [arg2] by user [arg3] from [arg4] at IP address [arg5]. | Informational |
| FQXSPSE4067I | User [arg1] accessible interfaces is set to [arg2][arg3][arg4][arg5][arg6] by user [arg7] from [arg8] at IP address [arg9]. | Informational |
| FQXSPSE4068I | Security: Userid: [arg1] using [arg2] had [arg3] login failures from Redfish client at IP address [arg4]. | Informational |
| FQXSPSE4069I | LDAP set by user [arg1]: RootDN=[arg2], UIDSearchAttribute=[arg3], BindingMethod=[arg4], TargetName=[arg5], GroupFilter=[arg6], GroupAttribute=[arg7], LoginAttribute=[arg8]. | Informational |
| FQXSPSE4070I | Lockdown mode is [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE4071I | Chassis Intrusion detection is [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE4072I | Random SED AK is regenerated by user [arg1] from [arg2] at IP address [arg3]. | Informational |
| FQXSPSE4073I | Motion detection is [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE4074I | Security mode downgrades because the XCC2 Platinum Upgrade key is expired or deleted. | Informational |
| FQXSPSE4075I | [arg1] by KCS to allow secure boot to be enabled by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE4076I | [arg1] by KCS to allow secure boot to be disabled by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE4077I | Bluetooth button on front panel is [arg1] on server [arg2] by user [arg3] from [arg4] at IP address [arg5]. | Informational |
| FQXSPSE4078I | Bluetooth is [arg1] by pressing bluetooth button on front panel. | Informational |
| FQXSPSE4079I | The Operator role is [arg1] to contain Remote Console Access permission by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPSE4080I | The user [arg1] attempts to clear CMOS from [arg2] at IP address [arg4]. | Informational |
| FQXSPSE4081I | BMC returns the valid local cached key to UEFI for SED drives. | Informational |
| FQXSPSE4082I | Remote key management server is unaccessible. | Informational |
| FQXSPSE4083I | The local cached key has expired and destroyed it. | Informational |
| FQXSPSE4084I | Periodic connection to remote key management server succeeded. | Informational |
| FQXSPSE4085I | Periodic connection to remote key management server failed. | Informational |
| FQXSPSE4088I | The chassis care-taker node ID is changed from [arg1] to [arg2]. | Informational |
| FQXSPSE4089I | The chassis node with node ID [arg1] is inserted. | Informational |
| FQXSPSE4090I | The chassis node with node ID [arg1] is removed. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSPSE40911 | SNMPv2 [arg1] set by user [arg2]: Name=[arg3], AccessType=[arg4], Address=[arg5]. | Informational |
| FQXSPSE40921 | SNMPv1 [arg1] set by user [arg2]: Name=[arg3], AccessType=[arg4]. | Informational |
| FQXSPSE40931 | SNMPv1 [arg1] set by user [arg2]: address=[arg3]. | Informational |
| FQXSPSE40941 | SNMPv2 [arg1] set by user [arg2]: Name=[arg3], AccessType=[arg4]. | Informational |
| FQXSPSE40951 | SNMPv2 [arg1] set by user [arg2]: address=[arg3]. | Informational |
| FQXSPSR20011 | Sensor [SensorElementName] has deasserted the transition to non-recoverable from a less severe state. | Informational |
| FQXSPSS40001 | Management Controller Test Alert Generated by [arg1]. | Informational |
| FQXSPSS40011 | Server General Settings set by user [arg1]: Name=[arg2], Contact=[arg3], Location=[arg4], Room=[arg5], RackID=[arg6], Rack U-position=[arg7], Address=[arg8]. | Informational |
| FQXSPSS40021 | License key for [arg1] added by user [arg2]. | Informational |
| FQXSPSS40031 | License key for [arg1] removed by user [arg2]. | Informational |
| FQXSPSS40041 | Test Call Home Generated by user [arg1]. | Informational |
| FQXSPSS40051 | Manual Call Home by user [arg1]: [arg2]. | Informational |
| FQXSPSS40061 | Call Home to [arg1] failed to complete: [arg2]. | Informational |
| FQXSPSS40071 | The BMC functionality tier is changed from [arg1] to [arg2]. | Informational |
| FQXSPSS40081 | The [arg1] setting has been changed to [arg2] by user [arg3]. | Informational |
| FQXSPSS40091 | System enters LXPM maintenance mode. | Informational |
| FQXSPSS40101 | Test Audit Log generated by user [arg1]. | Informational |
| FQXSPSS40111 | Fan speed boost setting is changed from [arg1] to [arg2]. | Informational |
| FQXSPTR40001 | Management Controller [arg1] clock has been set from NTP server [arg2]. | Informational |
| FQXSPTR40011 | Date and Time set by user [arg1]: Date=[arg2], Time=[arg3], DST Auto-adjust=[arg4], Timezone=[arg5]. | Informational |
| FQXSPTR40021 | Synchronize time setting by user [arg1]: Mode=Sync with NTP Server, NTPServerHost1=[arg2]:[arg3],NTPServerHost2=[arg4]:[arg5], NTPServerHost3=[arg6]:[arg7],NTPServerHost4=[arg8]:[arg9], NTPUpdateFrequency=[arg10]. | Informational |
| FQXSPTR40031 | Synchronize time setting by user [arg1]: Mode=Sync with server clock. | Informational |
| FQXSPUN00171 | Sensor [SensorElementName] has transitioned to normal state. | Informational |
| FQXSPUN00261 | Device [LogicalDeviceElementName] has been added. | Informational |
| FQXSPUN00481 | The RAID controller in PCI slot [arg1] in optimal status. | Informational |
| FQXSPUN00561 | Sensor [SensorElementName] has deasserted. | Informational |
| FQXSPUN20091 | Sensor [SensorElementName] has deasserted. | Informational |
| FQXSPUN20121 | Sensor [SensorElementName] has deasserted. | Informational |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSPUN2018I | Sensor [SensorElementName] has deasserted the transition from normal to non-critical state. | Informational |
| FQXSPUN2019I | Sensor [SensorElementName] has transitioned to a less severe state from critical. | Informational |
| FQXSPUN2023I | Sensor [SensorElementName] has deasserted the transition to non-recoverable. | Informational |
| FQXSPUN2049I | The RAID controller in PCI slot [arg1] is no longer in warning status. | Informational |
| FQXSPUN2050I | The RAID controller in PCI slot [arg1] is no longer in critical status. | Informational |
| FQXSPUN2058I | The remaining life for all SSDs is above threshold [arg1]. | Informational |
| FQXSPUP0002I | A firmware or software change occurred on system [ComputerSystemElementName]. | Informational |
| FQXSPUP4001I | Flash of [arg1] from [arg2] succeeded for user [arg3] . | Informational |
| FQXSPUP4002I | Flash of [arg1] from [arg2] failed for user [arg3]. | Informational |
| FQXSPUP4006I | Auto promote primary XCC to backup is [arg1] by user [arg2] from [arg3] at IP address [arg4]. | Informational |
| FQXSPUP4007I | Violation access to XCC SPI flash is detected and isolated. | Informational |
| FQXSPUP4008I | Violation access to UEFI SPI flash is detected and isolated. | Informational |
| FQXSPUP4010I | Flash [arg1] of [arg2] from [arg3] succeeded for user [arg4] . | Informational |
| FQXSPUP4011I | Flash [arg1] of [arg2] from [arg3] failed for user [arg4]. | Informational |
| FQXSPWD0000I | Watchdog Timer expired for [WatchdogElementName]. | Informational |
| FQXSPWD0001I | Reboot of system [ComputerSystemElementName] initiated by watchdog [WatchdogElementName]. | Informational |
| FQXSPWD0002I | Powering off system [ComputerSystemElementName] initiated by watchdog [WatchdogElementName]. | Informational |
| FQXSPWD0003I | Power cycle of system [ComputerSystemElementName] initiated by watchdog [WatchdogElementName]. | Informational |
| FQXSPWD0004I | Watchdog Timer interrupt occurred for [WatchdogElementName]. | Informational |
| FQXSPBR4001I | Running the backup Management Controller [arg1] main application. | Warning |
| FQXSPCA0001J | Numeric sensor [NumericSensorElementName] going low (lower non-critical) has asserted. | Warning |
| FQXSPCA0007J | Numeric sensor [NumericSensorElementName] going high (upper non-critical) has asserted. | Warning |
| FQXSPDM4002I | Device [arg1] VPD is not valid. | Warning |
| FQXSPEA0001J | Sensor [SensorElementName] has transitioned from normal to non-critical state. | Warning |
| FQXSPEA0003J | Link down is detected on port [arg1] of the PCIe device [arg2]. | Warning |
| FQXSPDM4040I | Dust filter measurement is completed. The airflow pathway is obstructed, check and replace the dust filter, or remove any obstructing object. | Warning |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|---------------|---|----------|
| FQXSPEM4043I | A [arg1] failure has been detected and need [arg2] to recover. | Warning |
| FQXSPPIO0014J | Bus [SensorElementName] is operating in a degraded state. | Warning |
| FQXSPPIO4001I | GPU Board Status was changed by [arg1] of [arg1]. | Warning |
| FQXSPMA0001I | Error Detected and Corrected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]. | Warning |
| FQXSPMA0010J | [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled. | Warning |
| FQXSPMA0011G | Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]. | Warning |
| FQXSPMA0024G | Sensor [SensorElementName] has asserted. | Warning |
| FQXSPMA4034G | Health of DIMM [arg1] is in warning state and sub-state is [arg2]. | Warning |
| FQXSPNM4010I | DHCP[[arg1]] failure, no IP address assigned. | Warning |
| FQXSPNM4032I | DHCPv6 failure, no IP address assigned. | Warning |
| FQXSPPP4009I | The measured power value exceeded the power cap value. | Warning |
| FQXSPPP4010I | The new minimum power cap value exceeded the power cap value. | Warning |
| FQXSPPU0010G | The Processor [ProcessorElementName] is operating in a Degraded State due to [ProcessorElementName]. | Warning |
| FQXSPPU0015G | Sensor [SensorElementName] has asserted. | Warning |
| FQXSPPW0003G | Failure predicted on [PowerSupplyElementName]. | Warning |
| FQXSPPW0006I | [PowerSupplyElementName] has lost input. | Warning |
| FQXSPPW0031J | Numeric sensor [NumericSensorElementName] going low (lower non-critical) has asserted. | Warning |
| FQXSPPW0057J | Sensor [SensorElementName] has transitioned from normal to non-critical state. | Warning |
| FQXSPPW0101J | Redundancy Degraded for [RedundancySetElementName] has asserted. | Warning |
| FQXSPPW0104J | Non-redundant:Sufficient Resources from Redundancy Degraded or Fully Redundant for [RedundancySetElementName] has asserted. | Warning |
| FQXSPPW4002I | Total graphics power value has exceeded the pre-configured limit. | Warning |
| FQXSPSD0002G | Failure Predicted on [StorageVolumeElementName] for array [ComputerSystemElementName]. | Warning |
| FQXSPSD0003G | Failure Predicted on drive [arg1] in the enclosure/chassis (MTM-SN: [arg2]). | Warning |
| FQXSPSE0000F | The Chassis [PhysicalPackageElementName] was opened. | Warning |
| FQXSPSE0010J | System guard detected inventory mismatch with trusted snapshot. | Warning |
| FQXSPSE4006I | XCC detected an invalid SSL certificate in the Management Controller [arg1] . | Warning |
| FQXSPUN0009G | Sensor [SensorElementName] has asserted. | Warning |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|----------|
| FQXSPUN0018J | Sensor [SensorElementName] has transitioned from normal to non-critical state. | Warning |
| FQXSPUN0058J | The remaining life for [arg1] is lower than the threshold [arg2]. | Warning |
| FQXSPUN0059J | Sensor [SensorElementName] has transitioned from normal to warning state. | Warning |
| FQXSPUN0060G | Sensor [SensorElementName] has asserted. | Warning |
| FQXSPBR4003I | Platform Watchdog Timer expired for [arg1]. | Error |
| FQXSPBR4007I | Management Controller [arg1]: Configuration restoration from a file by user [arg2] failed to complete from [arg3] at IP address [arg4]. | Error |
| FQXSPBR4008I | Management Controller [arg1]: Configuration restoration from a file by user [arg2] failed to start from [arg3] at IP address [arg4]. | Error |
| FQXSPCA0002M | Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted. | Error |
| FQXSPCA0003M | Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted. | Error |
| FQXSPCA0005N | Numeric sensor [NumericSensorElementName] going low (lower non-recoverable) has asserted. | Error |
| FQXSPCA0009M | Numeric sensor [NumericSensorElementName] going high (upper critical) has asserted. | Error |
| FQXSPCA0011N | Numeric sensor [NumericSensorElementName] going high (upper non-recoverable) has asserted. | Error |
| FQXSPCA0017M | Sensor [SensorElementName] has transitioned to critical from a less severe state. | Error |
| FQXSPCA0019N | Sensor [SensorElementName] has transitioned to non-recoverable from a less severe state. | Error |
| FQXSPCR0001N | Sensor [SensorElementName] has transitioned to non-recoverable from a less severe state. | Error |
| FQXSPEA0002M | Sensor [SensorElementName] has transitioned to critical from a less severe state. | Error |
| FQXSPFW0000N | The System [ComputerSystemElementName] encountered a POST Error. | Error |
| FQXSPFW0002N | The System [ComputerSystemElementName] encountered a firmware hang. | Error |
| FQXSPIO0003N | A diagnostic interrupt has occurred on system [ComputerSystemElementName]. | Error |
| FQXSPIO0004L | A bus timeout has occurred on bus [SensorElementName]. | Error |
| FQXSPIO0006N | A software NMI has occurred on system [ComputerSystemElementName]. | Error |
| FQXSPIO0007N | A PCI PERR has occurred on system [ComputerSystemElementName]. | Error |
| FQXSPIO0008N | A PCI SERR has occurred on system [ComputerSystemElementName]. | Error |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|--|----------|
| FQXSPIO0011N | An Uncorrectable Error has occurred on [SensorElementName]. | Error |
| FQXSPIO0013N | A Fatal Bus Error has occurred on bus [SensorElementName]. | Error |
| FQXSPIO0015M | Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName]. | Error |
| FQXSPMA0002N | Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]. | Error |
| FQXSPMA0006N | Parity Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]. | Error |
| FQXSPMA0007L | Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]. | Error |
| FQXSPMA0008N | Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName]. | Error |
| FQXSPMA0012M | An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName]. | Error |
| FQXSPMA0034M | System had DIMM PMIC power fault, DIMM need to replace, NO virtual reset function. | Error |
| FQXSPMA4035M | Health of DIMM [arg1] is in error state and sub-state is [arg2]. | Error |
| FQXSPOS4002I | Watchdog [arg1] Failed to Capture Screen. | Error |
| FQXSPOS4003I | Platform Watchdog Timer expired for [arg1]. | Error |
| FQXSPOS4010I | OS Crash Video Capture Failed. | Error |
| FQXSPPU0001N | An Over-Temperature Condition has been detected on [ProcessorElementName]. | Error |
| FQXSPPU0003N | [ProcessorElementName] has Failed with IERR. | Error |
| FQXSPPU0004M | [ProcessorElementName] has Failed with FRB1/BIST condition. | Error |
| FQXSPPU0009N | [ProcessorElementName] has a Configuration Mismatch. | Error |
| FQXSPPU0011N | An SM BIOS Uncorrectable CPU complex error for [ProcessorElementName] has asserted. | Error |
| FQXSPPW0002L | [PowerSupplyElementName] has Failed. | Error |
| FQXSPPW0007L | [PowerSupplyElementName] has a Configuration Mismatch. | Error |
| FQXSPPW0035M | Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted. | Error |
| FQXSPPW0061M | Sensor [SensorElementName] has transitioned to critical from a less severe state. | Error |
| FQXSPPW0062M | Sensor [SensorElementName] has transitioned to critical from a less severe state. | Error |
| FQXSPPW0063M | Sensor [SensorElementName] has transitioned to critical from a less severe state. | Error |
| FQXSPPW0110M | Non-redundant:Insufficient Resources for [RedundancySetElementName] has asserted. | Error |

Table 2. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|--|----------|
| FQXSPSD0001L | The [StorageVolumeElementName] has a fault. | Error |
| FQXSPSD0002L | Drive [arg1] in the enclosure/chassis(MTM-SN: [arg2]) has a fault. | Error |
| FQXSPSD0005L | Array [ComputerSystemElementName] is in critical condition. | Error |
| FQXSPSD0007L | Array critical asserted on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]). | Error |
| FQXSPSD0008L | Array failed on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]). | Error |
| FQXSPSE4000I | Certificate Authority [arg1] has detected a [arg2] Certificate Error. | Error |
| FQXSPSR0001N | Sensor [SensorElementName] has transitioned to non-recoverable from a less severe state. | Error |
| FQXSPUN0019M | Sensor [SensorElementName] has transitioned to critical from a less severe state. | Error |
| FQXSPUN0023N | Sensor [SensorElementName] has transitioned to non-recoverable. | Error |
| FQXSPUP0007L | Invalid or Unsupported firmware or software was detected on system [ComputerSystemElementName]. | Error |
| FQXSPUP4000I | Please ensure that the Management Controller [arg1] is flashed with the correct firmware. The Management Controller is unable to match its firmware to the server. | Error |
| FQXSPUP4003I | [arg1] firmware mismatch internal to system [arg2]. Please attempt to flash the [arg3] firmware. | Error |
| FQXSPUP4004I | XCC firmware mismatch between nodes/servers [arg1] and [arg2]. Please attempt to flash the XCC firmware to the same level on all nodes/servers. | Error |
| FQXSPUP4005I | FPGA firmware mismatch between nodes/servers [arg1] and [arg2]. Please attempt to flash the FPGA firmware to the same level on all nodes/servers. | Error |
| FQXSPUP4009I | Please ensure that the system is flashed with the correct [arg1] firmware. The Management Controller is unable to match the firmware to the server. | Error |

List of XClarity Controller events

This section lists all messages that can be sent from the XClarity Controller.

- **FQXSPBR4000I: Management Controller [arg1]: Configuration restored from a file by user [arg2] from [arg3] at IP address [arg4].**

This message is for the use case where a user restores a Management Controller configuration from a file.

Severity: Info
 Serviceable: No
 Automatically notify Support: No
 Alert Category: System - Other
 SNMP Trap ID: 22
 CIM Prefix: IMM CIM ID: 0027

User Action:

Information only; no action is required.

- **FQXSPBR4001: Running the backup Management Controller [arg1] main application.**

This message is for the use case where a Management Controller has resorted to running the backup main application.

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: System - other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0030

User Action:

Complete the following steps until the problem is solved:

1. Update the BMC firmware.
2. NOTE: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
3. If problem persists, collect Service Data log.
4. Contact Lenovo Support.

- **FQXSPBR4002: Management Controller [arg1] Reset was caused by restoring default values.**

This message is for the use case where a Management Controller has been reset due to a user restoring the configuration to default values.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0032

User Action:

Information only; no action is required.

- **FQXSPBR4003: Platform Watchdog Timer expired for [arg1].**

This message is for the use case when an implementation has detected a Platform Watchdog Timer Expired

Severity: Error
Serviceable: No
Automatically notify Support: No
Alert Category: System - OS Timeout
SNMP Trap ID: 21
CIM Prefix: IMM CIM ID: 0039

User Action:

Complete the following steps until the problem is solved:

1. Reconfigure the watchdog timer to a higher value.
2. Make sure that the BMC Ethernet-over-USB interface is enabled.
3. Reinstall the RNDIS or cdc_ether device driver for the operating system.

4. Disable the watchdog timer.
5. Check the integrity of the installed operating system.
6. If problem persists, collect Service Data log.
7. Contact Lenovo Support.

- **FQXSPBR4004I: Server timeouts set by user [arg1]: EnableOSWatchdog=[arg2], OSWatchdogTimeout=[arg3], EnableLoaderWatchdog=[arg4], LoaderTimeout=[arg5].**

A user configures Server Timeouts

Severity: Info
 Serviceable: No
 Automatically notify Support: No
 Alert Category: System - Other
 SNMP Trap ID: 22
 CIM Prefix: IMM CIM ID: 0095

User Action:

Information only; no action is required.

- **FQXSPBR4005I: Management Controller [arg1]: Configuration saved to a file by user [arg2].**

A user saves a Management Controller configuration to a file.

Severity: Info
 Serviceable: No
 Automatically notify Support: No
 Alert Category: System - Other
 SNMP Trap ID: 22
 CIM Prefix: IMM CIM ID: 0109

User Action:

Information only; no action is required.

- **FQXSPBR4006I: Management Controller [arg1]: Configuration restoration from a file by user [arg2] completed from [arg3] at IP address [arg4].**

This message is for the use case where a user restores a Management Controller configuration from a file and it completes.

Severity: Info
 Serviceable: No
 Automatically notify Support: No
 Alert Category: System - Other
 SNMP Trap ID: 22
 CIM Prefix: IMM CIM ID: 0136

User Action:

Information only; no action is required.

- **FQXSPBR4007I: Management Controller [arg1]: Configuration restoration from a file by user [arg2] failed to complete from [arg3] at IP address [arg4].**

This message is for the use case where a user restores a Management Controller configuration from a file and the restoration fails to complete.

Severity: Error
 Serviceable: No

Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0137

User Action:

Complete the following steps until the problem is solved:

1. Retry the operation.
2. AC cycle the system.
3. If Problem persists, collect Service Data log.
4. Contact Lenovo Support.

- **FQXSPBR4008I: Management Controller [arg1]: Configuration restoration from a file by user [arg2] failed to start from [arg3] at IP address [arg4].**

This message is for the use case where a user restores a Management Controller configuration from a file and the restoration fails to start.

Severity: Error
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0138

User Action:

Complete the following steps until the problem is solved:

1. Check if password for encrypted backup config file is correct.
2. Retry the operation.
3. AC cycle the system.
4. If problem persists, collect Service Data log.
5. Contact Lenovo Support.

- **FQXSPBR4009I: Management Controller [arg1]: cloning configuration from neighbor server [arg2] by group name [arg3].**

This message is for the use case where a user synchronizes a Management Controller configuration by Federation.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0255

User Action:

Information only; no action is required.

- **FQXSPBR400AI: Management Controller [arg1]: cloning configuration from neighbor server [arg2] by group name [arg3] completed.**

This message is for the use case where a user synchronizes a Management Controller configuration by Federation and it completes.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0256

User Action:

Information only; no action is required.

- **FQXSPBR400BI: Management Controller [arg1]: cloning configuration from neighbor server [arg2] by group name [arg3] failed to complete.**

This message is for the use case where a user synchronizes a Management Controller configuration by Federation and the restoration fails to complete.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0257

User Action:

Information only; no action is required.

- **FQXSPBR400CI: Management Controller [arg1]: cloning configuration from neighbor server [arg2] by group name [arg3] failed to start.**

This message is for the use case where a user synchronizes a Management Controller configuration by Federation and the restoration fails to start.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0258

User Action:

Information only; no action is required.

- **FQXSPBR400DI: Neighbor group clone configuration was initiated by user [arg1].**

This message is for the user initiated a Federation clone configuration.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0259

User Action:

Information only; no action is required.

- **FQXSPBR400EI: Neighbor group firmware update was initiated by user [arg1].**

This message is for the user started a Federation update.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0260

User Action:

Information only; no action is required.

- **FQXSPBR400FI: The neighbor group management is [arg1] by user [arg2] from [arg3] at IP address [arg4].**

Neighbor group management is enabled or disabled by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0272

User Action:

Information only; no action is required.

- **FQXSPBT0007I: No bootable media available for system [ComputerSystemElementName].**

This message is for the use case when an implementation has detected a System with No Bootable Media.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0286

User Action:

Please ensure that bootable media is installed well.

- **FQXSPCA0001J: Numeric sensor [NumericSensorElementName] going low (lower non-critical) has asserted.**

This message is for the use case when an implementation has detected a Lower Non-critical sensor going low has asserted.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Temperature
SNMP Trap ID: 12
CIM Prefix: PLAT CIM ID: 0476

User Action:

Complete the following steps:

1. Ensure the room and inlet water temperature/flow rate to the rack are within server environmental specification to adjust the temperature.
 2. If the problem issue still exist, check XCC Web GUI to check the temperature value is still higher than system spec. If warning is seen post service action on GPU then it is possible the thermal interface material take time to melt and the warnings are expected to deassert after a day of normal operation.
 3. Please contact Lenovo support.
 4. If the message persists more than 24 hours after GPU is replaced, contact Lenovo service
- **FQXSPCA0002M: Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.**

This message is for the use case when an implementation has detected a Lower Critical sensor going low has asserted.

Severity: Error
 Serviceable: Yes
 Automatically notify Support: Yes
 Alert Category: Critical - Fan Failure
 SNMP Trap ID: 11
 CIM Prefix: PLAT CIM ID: 0480

User Action:

Complete the following steps:

1. Ensure fans are installed correctly.
2. If fan is installed with issue , please reinstall fan.
3. If the problem still exist, then please contact Lenovo support.

- **FQXSPCA0003M: Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.**

This message is for the use case when an implementation has detected a Lower Critical sensor going low has asserted.

Severity: Error
 Serviceable: Yes
 Automatically notify Support: No
 Alert Category: Critical - Temperature
 SNMP Trap ID: 0
 CIM Prefix: PLAT CIM ID: 0480

User Action:

Complete the following steps:

1. Ensure the room and inlet water temperature/flow rate to the rack are within server environmental specification or adjust the temperature/flow rate.
2. If the problem issue still exist, check XCC Web GUI to check the temperature value is still higher than system spec.
3. Please contact Lenovo support.
4. If the message persists more than 24 hours after GPU is replaced, contact Lenovo service

- **FQXSPCA0005N: Numeric sensor [NumericSensorElementName] going low (lower non-recoverable) has asserted.**

This message is for the use case when an implementation has detected a Lower Non-recoverable sensor going low has asserted.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0484

User Action:

Complete the following steps:

1. Ensure the room, water temperature and water flow rate are within server environmental specification to adjust the temperature.
 2. If the problem issue still exist, check XCC Web GUI to check the temperature value is still higher than system spec.
 3. Please contact Lenovo support.
 4. If the message persists more than 24 hours after GPU is replaced, contact Lenovo service
- **FQXSPCA0007J: Numeric sensor [NumericSensorElementName] going high (upper non-critical) has asserted.**

This message is for the use case when an implementation has detected an Upper Non-critical sensor going high has asserted.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Temperature
SNMP Trap ID: 12
CIM Prefix: PLAT CIM ID: 0490

User Action:

Complete the following steps:

1. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers/air-baffles are in place, clean, and correctly installed.
 2. Ensure the room, water temperature and water flow rate are within server environmental specification to adjust the temperature.
 3. If the problem issue still exist, check XCC Web GUI to check the temperature value is still higher than system spec.
 4. Please contact Lenovo support.
 5. If the message persists more than 24 hours after GPU is replaced, contact Lenovo service
- **FQXSPCA0009M: Numeric sensor [NumericSensorElementName] going high (upper critical) has asserted.**

This message is for the use case when an implementation has detected an Upper Critical sensor going high has asserted.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0494

User Action:

Complete the following steps:

1. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers/air-baffles are in place, clean, and correctly installed.
 2. Ensure the room, water temperature and water flow rate are within server environmental specification to adjust the temperature.
 3. Ensure GPU/NVswitch cold plates are securely installed.
 4. If the problem issue still exist, check XCC Web GUI to check the temperature value is still higher than system spec.
 5. Please contact Lenovo support.
 6. If the message persists more than 24 hours after GPU is replaced, contact Lenovo service
- **FQXSPCA0011N: Numeric sensor [NumericSensorElementName] going high (upper non-recoverable) has asserted.**

This message is for the use case when an implementation has detected an Upper Non-recoverable sensor going high has asserted.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0498

User Action:

Complete the following steps:

1. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers/air-baffles are in place, clean, and correctly installed.
 2. Ensure the room, water temperature and water flow rate are within server environmental specification to adjust the temperature.
 3. Ensure GPU/NVswitch cold plates are securely installed.
 4. If the problem issue still exist, check XCC Web GUI to check the temperature value is still higher than system spec.
 5. Please contact Lenovo support.
 6. If the message persists more than 24 hours after GPU is replaced, contact Lenovo service
- **FQXSPCA0012I: Sensor [SensorElementName] has transitioned to normal state.**

This message is for the use case when an implementation has detected a Sensor transition to the normal state.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Fan
SNMP Trap ID: 165
CIM Prefix: PLAT CIM ID: 0518

User Action:

Information only; no action is required

- **FQXSPCA0017M: Sensor [SensorElementName] has transitioned to critical from a less severe state.**

This message is for the use case when an implementation has detected a Sensor transitioned to critical from less severe.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0522

User Action:

Complete the following steps:

1. Check the event log of XClarity Controller for any fan or cooling-related issues or power-related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place, clean, and correctly installed.
3. Ensure CPU/GPU/NVswitch cold plates are securely installed.
4. Make sure that the room temperature, water temperature and water flow rate within operating specifications.

- **FQXSPCA0019N: Sensor [SensorElementName] has transitioned to non-recoverable from a less severe state.**

This message is for the use case when an implementation has detected a Sensor transitioned to non-recoverable from less severe.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0524

User Action:

"Complete the following steps:

1. Check the event log of XClarity Controller for any fan or cooling-related issues or power-related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place, clean, and correctly installed.
3. Ensure CPU/GPU/NVswitch cold plates are securely installed.
4. Make sure that the room temperature, water temperature and water flow rate is within operating specifications.
5. If the message persists more than 24 hours after GPU is replaced, contact Lenovo service"

- **FQXSPCA2002I: Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.**

This message is for the use case when an implementation has detected a Lower Critical sensor going low has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Fan Failure

SNMP Trap ID: 11
CIM Prefix: PLAT CIM ID: 0481

User Action:

Information only; no action is required

- **FQXSPCA2003I: Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.**

This message is for the use case when an implementation has detected a Lower Critical sensor going low has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0481

User Action:

Information only;no action is required.

- **FQXSPCA2005I: Numeric sensor [NumericSensorElementName] going low (lower non-recoverable) has deasserted.**

This message is for the use case when an implementation has detected a Lower Non-recoverable sensor going low has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0485

User Action:

Information only; no action is required.

- **FQXSPCA2007I: Numeric sensor [NumericSensorElementName] going high (upper non-critical) has deasserted.**

This message is for the use case when an implementation has detected an Upper Non-critical sensor going high has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Temperature
SNMP Trap ID: 12
CIM Prefix: PLAT CIM ID: 0491

User Action:

Information only; no action is required

- **FQXSPCA2009I: Numeric sensor [NumericSensorElementName] going high (upper critical) has deasserted.**

This message is for the use case when an implementation has detected an Upper Critical sensor going high has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0495

User Action:

Information only; no action is required

- **FQXSPCA2011I: Numeric sensor [NumericSensorElementName] going high (upper non-recoverable) has deasserted.**

This message is for the use case when an implementation has detected an Upper Non-recoverable sensor going high has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0499

User Action:

Information only; no action is required

- **FQXSPCA2017I: Sensor [SensorElementName] has transitioned to a less severe state from critical.**

This message is for the use case when an implementation has detected a Sensor transition to less severe from critical.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0523

User Action:

Information only; no action is required

- **FQXSPCA2019I: Sensor [SensorElementName] has deasserted the transition to non-recoverable from a less severe state.**

This message is for the use case when an implementation has detected that the Sensor transition to non-recoverable from less severe has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0525

User Action:

Information only; no action is required

- **FQXSPCN4000I: Serial Redirection set by user [arg1]: Mode=[arg2], BaudRate=[arg3], StopBits=[arg4], Parity=[arg5], SessionTerminateSequence=[arg6].**

A user configured the Serial Port mode

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0078

User Action:

Information only; no action is required.

- **FQXSPCN4001I: Remote Control session started by user [arg1] in [arg2] mode.**

Remote Control session started

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0128

User Action:

Information only; no action is required.

- **FQXSPCN4002I: User [arg1] has terminated an active CLI console session.**

A user has terminated an active CLI console session

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0145

User Action:

Information only; no action is required.

- **FQXSPCN4003I: Remote Control session started by user [arg1] in [arg2] mode has been closed.**

Remote Control session closed

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0194

User Action:

Information only; no action is required.

- **FQXSPCN4004I: User [arg1] has created an active [arg2] console session.**

A user has created an IPMI/CLI console session

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0317

User Action:

Information only; no action is required.

- **FQXSPCN4005I: A [arg1] console session is timeout.**

An IPMI/CLI console session is timeout

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0318

User Action:

Information only; no action is required.

- **FQXSPCN4006I: User [arg1] has terminated an active IPMI console session.**

A user has terminated an active IPMI console session

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0319

User Action:

Information only; no action is required.

- **FQXSPCR0001N: Sensor [SensorElementName] has transitioned to non-recoverable from a less severe state.**

This message is for the use case when an implementation has detected a Sensor transitioned to non-recoverable from less severe.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0524

User Action:

Complete the following steps:

1. Please flash uEFI image to the latest level.

2. If the problem still exist, please remove and re-install CMOS battery for 30 seconds to clear CMOS contents.
3. If the problem still exist, please contact local service.

- **FQXSPCR2001I: Sensor [SensorElementName] has deasserted the transition to non-recoverable from a less severe state.**

This message is for the use case when an implementation has detected that the Sensor transition to non-recoverable from less severe has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0525

User Action:

Information only; no action is required

- **FQXSPDM4000I: Inventory data changed for device [arg1], new device data hash=[arg2], new master data hash=[arg3] .**

Something has caused the physical inventory to change

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0072

User Action:

Information only; no action is required.

- **FQXSPDM4001I: Storage [arg1] has changed.**

This message is for the use case where an IP address for the Storage Management has changed

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0139

User Action:

Information only; no action is required.

- **FQXSPDM4002I: Device [arg1] VPD is not valid.**

The VPD for a device is invalid

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0142

User Action:

Collect Service Data log and contact Lenovo Support.

- **FQXSPDM4003I: TKLM servers set by user [arg1]: TKLMServer1=[arg2] Port=[arg3], TKLMServer2=[arg4] Port=[arg5], TKLMServer3=[arg6] Port=[arg7], TKLMServer4=[arg8] Port=[arg9].**

A user configured the TKLM servers

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0146

User Action:

Information only; no action is required.

- **FQXSPDM4004I: TKLM servers device group set by user [arg1]: TKLMServerDeviceGroup=[arg2] .**

A user configured the TKLM device group

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0147

User Action:

Information only; no action is required.

- **FQXSPDM4005I: User [arg1] has generated a new encryption key pair and installed a self-signed certificate for the TKLM client.**

User generated a new encryption key pair and installed a self-signed certificate for the TKLM client

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0148

User Action:

Information only; no action is required.

- **FQXSPDM4006I: User [arg1] has generated a new encryption key and certificate signing request for the TKLM client.**

User generated a new encryption key and certificate signing request for the TKLM client

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0149

User Action:

Information only; no action is required.

- **FQXSPDM4007I: User [arg1] has imported a signed certificate for the TKLM client from [arg2].**

User imported a signed certificate for the TKLM client

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0150

User Action:

Information only; no action is required.

- **FQXSPDM4008I: User [arg1] has imported a server certificate for the TKLM server.**

User imported a server certificate for the TKLM Server

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0151

User Action:

Information only; no action is required.

- **FQXSPDM4009I: User [arg1] has [arg2] file [arg3] from [arg4].**

User has mounted/unmounted file from URL or server

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0162

User Action:

Information only; no action is required.

- **FQXSPDM4011I: EKMS server protocol set by user [arg1]: TKLMServerProtocol=[arg2] .**

A user configured the EKMS server protocol

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0293

User Action:

Information only; no action is required.

- **FQXSPDM4012I: User [arg1] has changed the polling configuration for the key management server.: Polling enabled=[arg2] Interval=[arg3]**

User changed the polling configuration for the key management server

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0334

User Action:

Information only; no action is required.

- **FQXSPDM4013I: User [arg1] has changed the caching configuration for the key management server: Caching enabled=[arg2] Interval=[arg3]**

User changed the caching configuration for the key management server

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0335

User Action:

Information only; no action is required.

- **FQXSPEA0001J: Sensor [SensorElementName] has transitioned from normal to non-critical state.**

This message is for the use case when an implementation has detected a Sensor transitioned to non-critical from normal.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0520

User Action:

Use Storcli or LSA to check if there is any warning or critical RAID event.

- **FQXSPEA0002M: Sensor [SensorElementName] has transitioned to critical from a less severe state.**

This message is for the use case when an implementation has detected a Sensor transitioned to critical from less severe.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0522

User Action:

Use storcli or LSA software tool to check if there is any warning or critical RAID event.

- **FQXSPEA0003J: Link down is detected on port [arg1] of the PCIe device [arg2].**

This message is for the use case when an implementation has detected a Link down of PCIe device.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0520

User Action:

Information only; no action is required.

1. Note: This event will be set to Warning Severity for the LAN on Motherboard (LOM) interface and Informational Severity for all other Network Adapters present where link status can be monitored.

- **FQXSPEA2001I: Sensor [SensorElementName] has deasserted the transition from normal to non-critical state.**

This message is for the use case when an implementation has detected that a Sensor has deasserted a transition to non-critical from normal.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0521

User Action:

Use storcli or LSA to check if there is any warning or critical RAID event.

- **FQXSPEA2002I: Sensor [SensorElementName] has transitioned to a less severe state from critical.**

This message is for the use case when an implementation has detected a Sensor transition to less severe from critical.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0523

User Action:

Use Storcli or LSA to check if there is any warning or critical RAID event.

- **FQXSPEA2003I: Link up is detected on port [arg1] of the PCIe device [arg2].**

This message is for the use case when an implementation has detected that a link up of PCIe.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0521

User Action:

Information only; no action is required.

- **FQXSPPEM4000I: The [arg1] on system [arg2] cleared by user [arg3].**

This message is for the use case where a Management Controller Event Log on a system is cleared by a user.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0020

User Action:

Information only; no action is required.

- **FQXSPPEM4001I: The [arg1] on system [arg2] is 75% full.**

This message is for the use case where a Management Controller Event Log on a system is 75% full.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Event Log Fullness
SNMP Trap ID: 35
CIM Prefix: IMM CIM ID: 0037

User Action:

Information only; no action is required.

- **FQXSPPEM4002I: The [arg1] on system [arg2] is 100% full.**

This message is for the use case where a Management Controller Event Log on a system is 100% full.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Event Log Fullness
SNMP Trap ID: 35
CIM Prefix: IMM CIM ID: 0038

User Action:

To avoid losing older log entries, save the log as a text file and clear the log.

- **FQXSPPEM4003I: LED [arg1] state changed to [arg2] by [arg3].**

A user has modified the state of an LED

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0071

User Action:

Information only; no action is required.

- **FQXSPPEM4004I: SNMP [arg1] enabled by user [arg2] .**

A user enabled SNMPv1 or SNMPv3 or Traps

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0073

User Action:

Information only; no action is required.

- **FQXSPPEM4005I: SNMP [arg1] disabled by user [arg2] .**

A user disabled SNMPv1 or SNMPv3 or Traps

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0074

User Action:

Information only; no action is required.

- **FQXSPPEM4006I: Alert Configuration Global Event Notification set by user [arg1]: RetryLimit=[arg2], RetryInterval=[arg3], EntryInterval=[arg4].**

A user changes the Global Event Notification settings.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0110

User Action:

Information only; no action is required.

- **FQXSPPEM4007I: Alert Recipient Number [arg1] updated: Name=[arg2], DeliveryMethod=[arg3], Address=[arg4], IncludeLog=[arg5], Enabled=[arg6], EnabledAlerts=[arg7], AllowedFilters=[arg8] by user [arg9] from [arg10] at IP address [arg11].**

A user adds or updates an Alert Recipient

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0111

User Action:

Information only; no action is required.

- **FQXSPPEM4008I: SNMP Traps enabled by user [arg1]: EnabledAlerts=[arg2], AllowedFilters=[arg3] .**

A user enabled the SNMP Traps configuration

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0112

User Action:

Information only; no action is required.

- **FQXSPPEM4009I: The UEFI Definitions have been changed.**

UEFI Definitions change has been detected

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0152

User Action:

Information only; no action is required.

- **FQXSPPEM4010I: UEFI Reported: [arg1].**

UEFI audit event logged.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0161

User Action:

Information only; no action is required.

- **FQXSPPEM4011I: XCC failed to log previous event [arg1].**

XCC failed to log a previous event.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0196

User Action:

Information only; no action is required.

- **FQXSPPEM4012I: User [arg1] made system [arg2] Encapsulation lite Mode.**

Encapsulation lite mode status change

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0201

User Action:

Information only; no action is required.

- **FQXSP4013I: Battery error was detected by RAID controller. The battery unit needs replacement.([arg1],[arg2],[arg3],[arg4],[arg5])**

Battery error was detected by RAID controller

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0202

User Action:

Information only; no action is required.

- **FQXSP4014I: The RAID controller has problem with the battery. Please contact technical support to resolve this issue.([arg1],[arg2],[arg3],[arg4],[arg5])**

The RAID controller has problem with the battery

Severity: Info
Serviceable: No
Automatically notify Support: Yes
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0203

User Action:

Information only; no action is required.

- **FQXSP4015I: The RAID controller detected unrecoverable error. The controller needs replacement.([arg1],[arg2],[arg3],[arg4],[arg5])**

The RAID controller detected unrecoverable error

Severity: Info
Serviceable: No
Automatically notify Support: Yes
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0204

User Action:

Information only; no action is required.

- **FQXSPeM4016I: The RAID controller detected one or more problems. Please contact technical support for additional assistance.([arg1],[arg2],[arg3],[arg4],[arg5])**

The RAID controller detected one or more problems

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0205

User Action:

Information only; no action is required.

- **FQXSPeM4017I: The RAID controller detected one or more possible configuration changes within the subsystem. Please check the drive LED status. If necessary, contact technical support for additional assistance.([arg1],[arg2],[arg3],[arg4],[arg5])**

The RAID controller detected one or more possible configuration changes within the subsystem

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0206

User Action:

Information only; no action is required.

- **FQXSPeM4018I: Enclosure/Chassis issue detected with one or more units. Please check the enclosure/chassis units to repair the problem.([arg1],[arg2],[arg3],[arg4],[arg5])**

Enclosure/Chassis issue detected with one or more units

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0207

User Action:

Information only; no action is required.

- **FQXSPeM4019I: Connectivity issue detected with the enclosure/chassis. Please check your cable configurations to repair the problem.([arg1],[arg2],[arg3],[arg4],[arg5])**

Connectivity issue detected with the enclosure/chassis

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0208

User Action:

Information only; no action is required.

- **FQXSPPEM4020I: Fan problem detected with the enclosure/chassis. Please check the enclosure/chassis unit fan for correct operation.([arg1],[arg2],[arg3],[arg4],[arg5])**

Fan problem detected with the enclosure/chassis

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0209

User Action:

Information only; no action is required.

- **FQXSPPEM4022I: Enclosure/Chassis power supply has problem. Please check the enclosure/chassis unit power supply for correct operation.([arg1],[arg2],[arg3],[arg4],[arg5])**

Enclosure/Chassis power supply has problem

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0210

User Action:

Information only; no action is required.

- **FQXSPPEM4023I: One or more virtual drive are in abnormal status that may cause unavailable virtual drive. Please check the event logs and if events are targeted to the same disk then replace the drive. If necessary, contact technical support for additional assistance.([arg1],[arg2],[arg3],[arg4],[arg5])**

One or more virtual drive are in abnormal status that may cause unavailable virtual drive

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0211

User Action:

Information only; no action is required.

- **FQXSPPEM4024I: The RAID controller detected one or more possible configuration problem within the subsystem. Please check the event logs and if events are targeted to the same disk then replace the drive. If necessary, contact technical support for additional assistance.([arg1],[arg2],[arg3],[arg4],[arg5])**

The RAID controller detected one or more possible configuration problem within the subsystem

Severity: Info
Serviceable: No
Automatically notify Support: No

Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0212

User Action:

Information only; no action is required.

- **FQXSPeM4025I: One or more virtual drive have problem. Please contact technical support to resolve this issue.**([arg1],[arg2],[arg3],[arg4],[arg5])

One or more virtual drive have problem

Severity: Info
Serviceable: No
Automatically notify Support: Yes
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0213

User Action:

Information only; no action is required.

- **FQXSPeM4026I: Drive error was detected by RAID controller. Please contact technical support to resolve this issue.**([arg1],[arg2],[arg3],[arg4],[arg5])

Drive error was detected by RAID controller

Severity: Info
Serviceable: No
Automatically notify Support: Yes
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0214

User Action:

Information only; no action is required.

- **FQXSPeM4027I: Drive error was detected by RAID controller. Please check the event logs and if events are targeted to the same disk then replace the drive. If necessary, contact technical support for additional assistance.**([arg1],[arg2],[arg3],[arg4],[arg5])

Drive error was detected by RAID controller

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0215

User Action:

Information only; no action is required.

- **FQXSPeM4028I: The port [arg1] of PCIe device [arg2] at [arg3] has link [arg4].**

PCI device link

Severity: Info
Serviceable: No

Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0220

User Action:

Information only; no action is required.

- **FQXSP4029I: All PCIe slots on [arg1] may not be functional based upon your current CPU population.**

PCIe not be functional

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0221

User Action:

Information only; no action is required.

- **FQXSP4030I: A scheduled operation on the RAID controller has encountered an issue. Refer to RAID Logs under Server Management, Local Storage, for details.([arg1],[arg2],[arg3],[arg4],[arg5])**

The RAID controller has scheduled operation issue

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0223

User Action:

Information only; no action is required.

- **FQXSP4031I: SSD wear threshold setting is changed from [arg1] to [arg2] by user [arg3] from [arg4] at IP address [arg5].**

SSD wear threshold setting is changed by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0273

User Action:

Information only; no action is required.

- **FQXSP4032I: Acoustic Mode [arg1] has been engaged. Fan speed limits are in place.**

This message is for the use case where Acoustic Mode is engaged.

Severity: Info
Serviceable: No

Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0274

User Action:

Information only; no action is required.

- **FQXSPEM4033I: Acoustic Mode [arg1] has been disengaged to allow adequate cooling.**

This message is for the use case where Acoustic Mode is disengaged.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0275

User Action:

Information only; no action is required.

- **FQXSPEM4036I: Dust filter measurement schedule is configured on server [arg1] by user [arg2] from [arg3] at IP address [arg4].**

Dust filter measurement schedule is configured

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0305

User Action:

Information only; no action is required.

- **FQXSPEM4037I: Attempting to perform scheduled dust filter measurement on server [arg1].**

Attempting to perform scheduled dust filter measurement

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0306

User Action:

Information only; no action is required.

- **FQXSPEM4038I: Dust filter measurement schedule is disabled on server [arg1] by user [arg2] from [arg3] at IP address [arg4].**

Dust filter measurement schedule is disabled

Severity: Info
Serviceable: No
Automatically notify Support: No

Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0307

User Action:

Information only; no action is required.

- **FQXSP4039I: Attempting to perform an immediate dust filter measurement on server [arg1] by user [arg2] from [arg3] at IP address [arg4].**

Attempting to perform an immediate dust filter measurement

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0308

User Action:

Information only; no action is required.

- **FQXSP4040I: Dust filter measurement is completed. The airflow pathway is obstructed, check and replace the dust filter, or remove any obstructing object.**

Alert the user when dust filter measurement fails

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0309

User Action:

Information only; no action is required.

- **FQXSP4041I: The SmartNIC in slot [arg1] encountered boot timeout.**

SmartNIC in a certain slot encountered boot timeout

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0312

User Action:

Information only; no action is required.

- **FQXSP4042I: The SmartNIC in slot [arg1] went through a crash dump.**

SmartNIC in a certain slot went through a crash dump

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other

SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0313

User Action:

Information only; no action is required.

- **FQXSPPEM4043I: A [arg1] failure has been detected and need [arg2] to recover.**

backplane failure has detected

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: IMM CIM ID: 0320

User Action:

Information only; no action is required.

- **FQXSPPEM4044I: Dust filter measurement was successfully completed, no action is needed.**

Alert the user when dust filter measurement is completed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0321

User Action:

Information only; no action is required.

- **FQXSPFC4000I: The bare metal connection process has been started.**

Bare Metal Connection process has been started

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0143

User Action:

Information only; no action is required.

- **FQXSPFC4001I: The bare metal update application reports a status of [arg1].**

Bare Metal Update Application Status

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0144

User Action:

Information only; no action is required.

- **FQXSPFC4002I: System running in setup.**

System running in setup

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0193

User Action:

Information only; no action is required.

- **FQXSPFC4003I: UEFI deployment boot mode is enabled for NextBoot.**

UEFI deployment boot mode is enabled for NextBoot

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0197

User Action:

Information only; no action is required.

- **FQXSPFC4004I: UEFI deployment boot mode is enabled for NextAc.**

UEFI deployment boot mode is enabled for NextAC

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0198

User Action:

Information only; no action is required.

- **FQXSPFC4005I: UEFI deployment boot mode has been disabled.**

UEFI deployment boot mode has been disabled

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0199

User Action:

Information only; no action is required.

- **FQXSPFW0000N: The System [ComputerSystemElementName] encountered a POST Error.**

This message is for the use case when an implementation has detected a Post Error.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0184

User Action:

Complete the following steps:

1. Original UEFI settings are still present. If customer desires to continue using the original settings, select Save Settings.
2. If User did not intentionally trigger the reboots, check logs for probable cause. For example, if there is a battery fault event, follow the steps to resolve that event.
3. Undo recent system changes (settings or devices added). Verify that the system boots. Then, re-install options one at a time to locate the problem.
4. Check Lenovo support site for an applicable service bulletin or firmware update that applies to this error. Update UEFI firmware if applicable.
5. Remove and re-install CMOS battery on system board for 30 seconds to clear CMOS contents. If it boots successfully, then restore system settings.
6. If problem persists, collect Service Data log.
7. Contact Lenovo Support.

- **FQXSPFW0002N: The System [ComputerSystemElementName] encountered a firmware hang.**

This message is for the use case when an implementation has detected a System Firmware Hang.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: System - Boot failure
SNMP Trap ID: 25
CIM Prefix: PLAT CIM ID: 0186

User Action:

Complete the following steps:

1. Original UEFI settings are still present. If customer desires to continue using the original settings, select Save Settings.
2. If User did not intentionally trigger the reboots, check logs for probable cause. For example, if there is a battery fault event, follow the steps to resolve that event.
3. Undo recent system changes (settings or devices added). Verify that the system boots. Then, re-install options one at a time to locate the problem.
4. Check Lenovo support site for an applicable service bulletin or firmware update that applies to this error. Update UEFI firmware if applicable.
5. Remove and re-install CMOS battery on system board for 30 seconds to clear CMOS contents. If it boots successfully, then restore system settings.
6. If problem persists, collect Service Data log.
7. Contact Lenovo Support.

- **FQXSPIO0000I: The connector [PhysicalConnectorElementName] has been detected as present or connected.**

This message is for the use case when an implementation has detected a Connector has been Connected.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0264

User Action:

Information only;no action is required.

- **FQXSPIO0003N: A diagnostic interrupt has occurred on system [ComputerSystemElementName].**

This message is for the use case when an implementation has detected a Front Panel NMI / Diagnostic Interrupt.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0222

User Action:

If the NMI button has not been pressed, complete the following steps:

1. Reboot the system.
2. If error still exist, then collect service log and contact Lenovo support.

- **FQXSPIO0004L: A bus timeout has occurred on bus [SensorElementName].**

This message is for the use case when an implementation has detected a Bus Timeout.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0224

User Action:

Complete the following steps:

1. Please reseal the processor and reboot the server.
2. If the problem still exist, (service technician) please replace the system board.
3. If the problem still exist, contact Lenovo support.

- **FQXSPIO0006N: A software NMI has occurred on system [ComputerSystemElementName].**

This message is for the use case when an implementation has detected a Software NMI.

Severity: Error
Serviceable: Yes
Automatically notify Support: No

Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0228

User Action:

Check the event log in system event log to resolve any issues related the NMI

- **FQXSPIO0007N: A PCI PERR has occurred on system [ComputerSystemElementName].**

This message is for the use case when an implementation has detected a PCI PERR.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0232

User Action:

Complete the following steps to solve:

1. Reseat the adapter or other slot.
2. If the problem still exist then replace the adapter.
3. If the problem still exist then contact local service.

- **FQXSPIO0008N: A PCI SERR has occurred on system [ComputerSystemElementName].**

This message is for the use case when an implementation has detected a PCI SERR.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0234

User Action:

Complete the following steps to solve:

1. Reseat the adapter or other slot.
2. If the problem still exist then replace the adapter.
3. If the problem still exist then contact local service.

- **FQXSPIO0010I: A Correctable Bus Error has occurred on bus [SensorElementName].**

This message is for the use case when an implementation has detected a Bus Correctable Error.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0238

User Action:

Information only; please correct the error recorded in system log to resolve the error

- **FQXSPIO0011N: An Uncorrectable Error has occurred on [SensorElementName].**

This message is for the use case when an implementation has detected a Bus Uncorrectable Error.

Severity: Error
Serviceable: Yes
Automatically notify Support: Yes
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0240

User Action:

Check <http://support.lenovo.com/> for TECH tips or firmware updates that might correct the error.

1. Make sure that all I/O expansion adapters have correct and matching levels of device drivers and firmware.
2. Check the event log of XClarity Controller for additional information about failing components.
3. If there are no entries related to the error in the event log, contact Lenovo support

- **FQXSPIO0013N: A Fatal Bus Error has occurred on bus [SensorElementName].**

This message is for the use case when an implementation has detected a Bus Fatal Error.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0244

User Action:

Complete the following steps:

1. Check Lenovo support site for an applicable service bulletin or firmware update for the system or adapter that applies to this error.
2. If problem persists, collect Service Data log.
3. Contact Lenovo Support.

- **FQXSPIO0014J: Bus [SensorElementName] is operating in a degraded state.**

This message is for the use case when an implementation has detected a Bus is Degraded.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0246

User Action:

Complete the following steps to solve:

1. Reseat the adapter or other slot.
2. If the problem still exist then replace the adapter.
3. If the problem still exist then contact local service.

- **FQXSPIO0015M: Fault in slot [PhysicalConnectorSystemElementName] on system [ComputerSystemElementName].**

This message is for the use case when an implementation has detected a Fault in a slot.

Severity: Error
Serviceable: Yes
Automatically notify Support: Yes
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0330

User Action:

Complete the following steps to fix the error:

1. Make sure that all I/O expansion adapters have correct and matching levels of device drivers and firmware.
2. Check the event log of XClarity Controller for additional information about failing components. Check <http://support.lenovo.com/> for TECH tips or firmware updates that might correct the error.
3. If there are no entries related to the error in the event log, contact Lenovo support
4. If the message persists more than 24 hours after GPU is replaced, contact Lenovo service

- **FQXSPIO0016I: Identifying slot [PhysicalConnectorElementName] on system [ComputerSystemElementName].**

This message is for the use case when an implementation has detected a Identify in a slot was Enabled.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0332

User Action:

Information only; no action is required.

- **FQXSPIO2003I: System [ComputerSystemElementName] has recovered from a diagnostic interrupt.**

This message is for the use case when an implementation has detected a recovery from a Front Panel NMI / Diagnostic Interrupt

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0223

User Action:

Information only; no action is required

- **FQXSPIO2004I: Bus [SensorElementName] has recovered from a bus timeout.**

This message is for the use case when an implementation has detected that a system has recovered from a Bus Timeout.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Other

SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0225

User Action:

Information only; no action is required

- **FQXSPIO2006I: System [ComputerSystemElementName] has recovered from an NMI.**

This message is for the use case when an implementation has detected a Software NMI has been Recovered from.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0230

User Action:

Information only; no action is required

- **FQXSPIO2007I: A PCI PERR recovery has occurred on system [ComputerSystemElementName].**

This message is for the use case when an implementation has detected a PCI PERR recovered.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0233

User Action:

Information only; no action is required

- **FQXSPIO2008I: A PCI SERR on system [ComputerSystemElementName] has deasserted.**

This message is for the use case when an implementation has detected a PCI SERR deassertion.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0235

User Action:

Information only; no action is required

- **FQXSPIO2010I: Bus [SensorElementName] has recovered from a Correctable Bus Error.**

This message is for the use case when an implementation has detected that a system has recovered from a Bus Correctable Error.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22

CIM Prefix: PLAT CIM ID: 0239

User Action:

Information only; no action is required.

- **FQXSPIO2013I: Bus [SensorElementName] has recovered from a Fatal Bus Error.**

This message is for the use case when an implementation has detected that a system has recovered from a Bus Fatal Error.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0245

User Action:

Please monitor fatal bus error status and collect FFDC log for Lenovo service to diagnostic the bus/device containing this error.

- **FQXSPIO4001I: GPU Board Status was changed by [arg1] of [arg1].**

This message is for the use case where GPU Board Status was changed.

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0276

User Action:

Information only; no action is required.

- **FQXSPIO4002I: GPU Board Status was recovered by [arg1] of [arg1].**

This message is for the use case where GPU Board Status was changed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0277

User Action:

Information only; no action is required.

- **FQXSPIO4003I: The PCIe switch has changed to normal mode by user [arg1] from [arg2] at IP address [arg3].**

User changed the PCIe switch to normal mode.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22

CIM Prefix: IMM CIM ID: 0349

User Action:

Information only; no action is required.

- **FQXSPIO4004I: The PCIe switch has changed to update-ready mode by user [arg1] from [arg2] at IP address [arg3].**

User changed the PCIe switch to update-ready mode.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0350

User Action:

Information only; no action is required.

- **FQXSPMA0001I: Error Detected and Corrected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].**

This message is for the use case when an implementation has detected a Memory corrected error.

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Memory
SNMP Trap ID: 43
CIM Prefix: PLAT CIM ID: 0124

User Action:

Information only; no action is required.

- **FQXSPMA0002N: Configuration Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].**

This message is for the use case when an implementation has detected a Memory DIMM configuration error has been corrected.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Memory
SNMP Trap ID: 41
CIM Prefix: PLAT CIM ID: 0126

User Action:

Complete the following steps:

1. If the DIMM configuration was changed prior to this failure verify that the DIMMs are installed in the correct population sequence.
2. RESEAT the DIMM that failed POST memory test and the DIMMs on adjacent slots if populated. Boot to F1 setup and enable the DIMM. Reboot the system.
3. If the DIMMs have been upgraded just prior to the issue than update uEFI to the latest version.
4. If the problem persists, collect Service Data logs.

5. Contact Lenovo Support.

- **FQXSPMA0006N: Parity Error for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].**

This message is for the use case when an implementation has detected a Memory parity error.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Memory
SNMP Trap ID: 41
CIM Prefix: PLAT CIM ID: 0134

User Action:

Complete the following action until the problem is solved.

1. Ensure air baffle is installed well to fix the listed error.
2. Reseat the identified DIMM and clean DIMM dust on the PIN to resolved the listed error.
3. Remove the identified DIMM and run parity check again.
4. Contact Lenovo service if the problem is not solved by the steps above.

- **FQXSPMA0007L: Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].**

This message is for the use case when an implementation has detected a Memory Scrub failure.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Memory
SNMP Trap ID: 41
CIM Prefix: PLAT CIM ID: 0136

User Action:

Complete the following steps:

1. Ensure one or more DIMMs are installed in the server.
2. Resolve existing memory errors if they are present.
3. If no memory fault is recorded in the logs, verify that all DIMM connectors are enabled using the Setup utility or the OneCLI utility.
4. Reseat all DIMMs ensuring that DIMMs are installed in the correct population sequence, according to the service information for this product.
5. Clear CMOS memory on system board. Note that all firmware settings will revert to the defaults.
6. Reflash UEFI firmware.
7. If problem persists, collect Service Data log.
8. Contact Lenovo Support.

- **FQXSPMA0008N: Uncorrectable error detected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].**

This message is for the use case when an implementation has detected a Memory uncorrectable error.

Severity: Error
Serviceable: Yes
Automatically notify Support: No

Alert Category: Critical - Memory
SNMP Trap ID: 41
CIM Prefix: PLAT CIM ID: 0138

User Action:

Complete the following steps:

1. If the server has recently been installed, moved, serviced, or upgraded, verify that the DIMM is properly seated and visually verify that there is no foreign material in any DIMM connector on that memory channel. If either of these conditions is found, correct and retry with the same DIMM. (Note: The event Log might contain a recent FQXSFMA0011I event denoting detected change in DIMM population that could be related to this problem.)
2. If no problem is observed on the DIMM connectors or the problem persists, replace the DIMM identified by LightPath and/or event log entry.
3. If problem recurs on the same DIMM connector, replace the other DIMMs on the same memory channel.
4. Check Lenovo support site for an applicable service bulletin or firmware update that applies to this memory error.
5. If problem recurs on the same DIMM connector, inspect connector for damage. If damage found or problem persists, collect Service Data log.
6. Contact Lenovo Support.

- **FQXSPMA0010J: [PhysicalMemoryElementName] on Subsystem [MemoryElementName] Throttled.**

This message is for the use case when an implementation has detected Memory has been Throttled.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0142

User Action:

Complete the following steps:

1. Check the event log of XClarity Controller for any fan or cooling related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers are in place, clean, and correctly installed.
3. Make sure that the room temperature is within operating specifications.
4. If the problem persists and there are no other DIMMs with the same indication, replace the DIMM.

- **FQXSPMA0011G: Memory Logging Limit Reached for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].**

This message is for the use case when an implementation has detected that the Memory Logging Limit has been Reached.

Severity: Warning
Serviceable: Yes
Automatically notify Support: Yes
Alert Category: Warning - Memory
SNMP Trap ID: 43
CIM Prefix: PLAT CIM ID: 0144

User Action:

Complete the following steps:

1. If the server has recently been installed, moved, serviced, or upgraded, verify that the DIMM is properly seated and visually verify that there is no foreign material in any DIMM connector on that memory channel. If either of these conditions is found, correct and retry with the same DIMM. (Note: The event Log might contain a recent FQXSFMA0011I event denoting detected change in DIMM population that could be related to this problem.)
2. If no problem is observed on the DIMM connectors or the problem persists, replace the DIMM identified by LightPath and/or event log entry.
3. If problem recurs on the same DIMM connector, replace the other DIMMs on the same memory channel.
4. Check Lenovo support site for an applicable service bulletin or firmware update that applies to this memory error.
5. If problem recurs on the same DIMM connector, inspect connector for damage. If damage found or problem persists, collect Service Data log.
6. Contact Lenovo Support.

- **FQXSPMA0012M: An Over-Temperature Condition has been detected on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].**

This message is for the use case when an implementation has detected an Over Temperature Condition for Memory that has been Detected.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0146

User Action:

Complete the following steps until the problem is solved:

1. Check the event log of XClarity Controller (XCC) for any fan- or cooling-related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers/air-baffles are in place, clean, and correctly installed.
3. Make sure that the room temperature is within operating specifications.
4. If the problem remains and no other DIMMs have the same indication, replace the DIMM.

- **FQXSPMA0022I: Post Package Repair Success for [PhysicalMemoryElementName] on Subsystem [MemoryElementName].**

This message is for the use case when an implementation has detected that Memory double chip sparing has been initiated.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0140

User Action:

Information only; no action is required.

- **FQXSPMA0024G: Sensor [SensorElementName] has asserted.**

This message is for the use case when an implementation has detected a Sensor has asserted.

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Memory
SNMP Trap ID: 43
CIM Prefix: PLAT CIM ID: 0508

User Action:

Complete the following steps:

1. If the DIMM configuration was changed prior to this failure verify that the DIMMs are installed in the correct population sequence.
2. RESEAT the DIMM that failed POST memory test and the DIMMs on adjacent slots if populated. Boot to F1 setup and enable the DIMM. Reboot the system.
3. If the DIMMs have been upgraded just prior to the issue than update uEFI to the latest version.
4. If the problem persists, collect Service Data logs.
5. Contact Lenovo Support.

- **FQXSPMA0025I: Sensor [SensorElementName] has asserted.**

This message is for the use case when an implementation has detected a Sensor has asserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0508

User Action:

Ensure the installed DIMM is supported by Lenovo.

- **FQXSPMA0034M: System had DIMM PMIC power fault, DIMM need to replace, NO virtual reset function.**

This message is for the use case when an implementation has detected System had DIMM PMIC power fault.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Memory
SNMP Trap ID: 41
CIM Prefix: PLAT CIM ID: 0522

User Action:

Complete the following steps until the problem is solved:

1. Reseat the DIMM and ensure the installation is well.
2. If the problem still exist, please replace the DIMM.

- **FQXSPMA2001I: Error Detected and Corrected for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has deasserted.**

This message is for the use case when an implementation has detected a Memory corrected error deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0125

User Action:

Information only; no action is required

- **FQXSPMA2007I: Scrub Failure for [PhysicalMemoryElementName] on Subsystem [MemoryElementName] has recovered.**

This message is for the use case when an implementation has detected a Memory Scrub failure recovery.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Memory
SNMP Trap ID: 41
CIM Prefix: PLAT CIM ID: 0137

User Action:

Information only; no action is required

- **FQXSPMA2010I: [PhysicalMemoryElementName] on Subsystem [MemoryElementName] is no longer Throttled.**

This message is for the use case when an implementation has detected Memory is no longer Throttled.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0143

User Action:

Information only; no action is required

- **FQXSPMA2012I: An Over-Temperature Condition has been removed on the [PhysicalMemoryElementName] on Subsystem [MemoryElementName].**

This message is for the use case when an implementation has detected an Over Temperature Condition for Memory that has been Removed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0147

User Action:

Information only; no action is required

- **FQXSPMA2024I: Sensor [SensorElementName] has deasserted.**

This message is for the use case when an implementation has detected a Sensor has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Memory
SNMP Trap ID: 43
CIM Prefix: PLAT CIM ID: 0509

User Action:

Information only; no action is required

- **FQXSPNM4000I: Management Controller [arg1] Network Initialization Complete.**

This message is for the use case where a Management Controller network has completed initialization.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0001

User Action:

Information only; no action is required.

- **FQXSPNM4001I: Ethernet Data Rate modified from [arg1] to [arg2] by user [arg3].**

This message is for the use case where a user modifies the Ethernet Port data rate.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0003

User Action:

Information only; no action is required.

- **FQXSPNM4002I: Ethernet Duplex setting modified from [arg1] to [arg2] by user [arg3].**

This message is for the use case where A user modifies the Ethernet Port duplex setting.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0004

User Action:

Information only; no action is required.

- **FQXSPNM4003I: Ethernet MTU setting modified from [arg1] to [arg2] by user [arg3].**

This message is for the use case where a user modifies the Ethernet Port MTU setting.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0005

User Action:

Information only; no action is required.

- **FQXSPNM4004I: Ethernet locally administered MAC address modified from [arg1] to [arg2] by user [arg3].**

This message is for the use case where a user modifies the Ethernet Port MAC address setting.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0006

User Action:

Information only; no action is required.

- **FQXSPNM4005I: Ethernet interface [arg1] by user [arg2].**

This message is for the use case where a user enables or disabled the ethernet interface.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0007

User Action:

Information only; no action is required.

- **FQXSPNM4006I: Hostname set to [arg1] by user [arg2].**

This message is for the use case where user modifies the Hostname of a Management Controller.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0008

User Action:

Information only; no action is required.

- **FQXSPNM4007I: IP address of network interface modified from [arg1] to [arg2] by user [arg3].**

This message is for the use case where user modifies the IP address of a Management Controller.

Severity: Info
Serviceable: No

Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0009

User Action:

Information only; no action is required.

- **FQXSPNM4008I: IP subnet mask of network interface modified from [arg1] to [arg2] by user [arg3].**

This message is for the use case where a user modifies the IP subnet mask of a Management Controller.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0010

User Action:

Information only; no action is required.

- **FQXSPNM4009I: IP address of default gateway modified from [arg1] to [arg2] by user [arg3].**

This message is for the use case where a user modifies the default gateway IP address of a Management Controller.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0011

User Action:

Information only; no action is required.

- **FQXSPNM4010I: DHCP[[arg1]] failure, no IP address assigned.**

This message is for the use case where a DHCP server fails to assign an IP address to a Management Controller.

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0013

User Action:

Complete the following steps until the problem is solved:

1. Make sure that the XCC/BMC management network cable is connected and the network ports is active.
2. Make sure that there is a DHCP server on the network that can assign an IP address to the XCC/BMC.
3. If problem persists, collect Service Data log.

4. Contact Lenovo Support.

- **FQXSPNM4011I: ENET[[arg1]] DHCP-HSTN=[arg2], DN=[arg3], IP@=[arg4], SN=[arg5], GW@=[arg6], DNS1@=[arg7] .**

This message is for the use case where a Management Controller IP address and configuration has been assigned by the DHCP server.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0022

User Action:

Information only; no action is required.

- **FQXSPNM4012I: ENET[[arg1]] IP-Cfg:HstName=[arg2], IP@=[arg3] ,NetMsk=[arg4], GW@=[arg5] .**

This message is for the use case where a Management Controller IP address and configuration has been assigned statically using user data.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0023

User Action:

Information only; no action is required.

- **FQXSPNM4013I: LAN: Ethernet[[arg1]] interface is no longer active.**

This message is for the use case where a Management Controller ethernet interface is no longer active.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0024

User Action:

Information only; no action is required.

- **FQXSPNM4014I: LAN: Ethernet[[arg1]] interface is now active.**

This message is for the use case where a Management Controller ethernet interface is now active.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0025

User Action:

Information only; no action is required.

- **FQXSPNM4015I: DHCP setting changed to [arg1] by user [arg2].**

This message is for the use case where a user changes the DHCP setting.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0026

User Action:

Information only; no action is required.

- **FQXSPNM4016I: Domain name set to [arg1] by user [arg2].**

Domain name set by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0043

User Action:

Information only; no action is required.

- **FQXSPNM4017I: Domain Source changed to [arg1] by user [arg2].**

Domain source changed by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0044

User Action:

Information only; no action is required.

- **FQXSPNM4018I: DDNS setting changed to [arg1] by user [arg2].**

DDNS setting changed by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0045

User Action:

Information only; no action is required.

- **FQXSPNM4019I: DDNS registration successful. The domain name is [arg1].**

DDNS registration and values

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0046

User Action:

Information only; no action is required.

- **FQXSPNM4020I: IPv6 enabled by user [arg1] .**

IPv6 protocol is enabled by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0047

User Action:

Information only; no action is required.

- **FQXSPNM4021I: IPv6 disabled by user [arg1] .**

IPv6 protocol is disabled by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0048

User Action:

Information only; no action is required.

- **FQXSPNM4022I: IPv6 static IP configuration enabled by user [arg1].**

IPv6 static address assignment method is enabled by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0049

User Action:

Information only; no action is required.

- **FQXSPNM4023I: IPv6 DHCP enabled by user [arg1].**

IPv6 DHCP assignment method is enabled by user

Severity: Info
Serviceable: No

Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0050

User Action:

Information only; no action is required.

- **FQXSPNM4024I: IPv6 stateless auto-configuration enabled by user [arg1].**

IPv6 stateless auto-assignment method is enabled by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0051

User Action:

Information only; no action is required.

- **FQXSPNM4025I: IPv6 static IP configuration disabled by user [arg1].**

IPv6 static assignment method is disabled by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0052

User Action:

Information only; no action is required.

- **FQXSPNM4026I: IPv6 DHCP disabled by user [arg1].**

IPv6 DHCP assignment method is disabled by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0053

User Action:

Information only; no action is required.

- **FQXSPNM4027I: IPv6 stateless auto-configuration disabled by user [arg1].**

IPv6 stateless auto-assignment method is disabled by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22

CIM Prefix: IMM CIM ID: 0054

User Action:

Information only; no action is required.

- **FQXSPNM4028I: ENET[[arg1]] IPv6-LinkLocal:HstName=[arg2], IP@[arg3] ,Pref=[arg4].**

IPv6 Link Local address is active

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0055

User Action:

Information only; no action is required.

- **FQXSPNM4029I: ENET[[arg1]] IPv6-Static:HstName=[arg2], IP@[arg3] ,Pref=[arg4], GW@[arg5] .**

IPv6 Static address is active

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0056

User Action:

Information only; no action is required.

- **FQXSPNM4030I: ENET[[arg1]] DHCPv6-HSTN=[arg2], DN=[arg3], IP@[arg4], Pref=[arg5], DNS1@[arg5].**

IPv6 DHCP-assigned address is active

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0057

User Action:

Information only; no action is required.

- **FQXSPNM4031I: IPv6 static address of network interface modified from [arg1] to [arg2] by user [arg3].**

A user modifies the IPv6 static address of a Management Controller

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0058

User Action:

Information only; no action is required.

- **FQXSPNM4032I: DHCPv6 failure, no IP address assigned.**

S DHCP6 server fails to assign an IP address to a Management Controller.

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0059

User Action:

Complete the following steps until the problem is solved:

1. Make sure that the XCC/BMC management network cable is connected and the network ports is active.
2. Make sure that there is a DHCPv6 server on the network that can assign an IP address to the XCC/BMC.
3. If problem persists, collect Service Data log.
4. Contact Lenovo Support.

- **FQXSPNM4033I: Telnet port number changed from [arg1] to [arg2] by user [arg3].**

A user has modified the telnet port number

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0061

User Action:

Information only; no action is required.

- **FQXSPNM4034I: SSH port number changed from [arg1] to [arg2] by user [arg3].**

A user has modified the SSH port number

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0062

User Action:

Information only; no action is required.

- **FQXSPNM4035I: Web-HTTP port number changed from [arg1] to [arg2] by user [arg3].**

A user has modified the Web HTTP port number

Severity: Info
Serviceable: No

Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0063

User Action:

Information only; no action is required.

- **FQXSPNM4036I: Web-HTTPS port number changed from [arg1] to [arg2] by user [arg3].**

A user has modified the Web HTTPS port number

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0064

User Action:

Information only; no action is required.

- **FQXSPNM4037I: CIM/XML HTTP port number changed from [arg1] to [arg2] by user [arg3].**

A user has modified the CIM HTTP port number

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0065

User Action:

Information only; no action is required.

- **FQXSPNM4038I: CIM/XML HTTPS port number changed from [arg1] to [arg2] by user [arg3].**

A user has modified the CIM HTTPS port number

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0066

User Action:

Information only; no action is required.

- **FQXSPNM4039I: SNMP Agent port number changed from [arg1] to [arg2] by user [arg3].**

A user has modified the SNMP Agent port number

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22

CIM Prefix: IMM CIM ID: 0067

User Action:

Information only; no action is required.

- **FQXSPNM4040I: SNMP Traps port number changed from [arg1] to [arg2] by user [arg3].**

A user has modified the SNMP Traps port number

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0068

User Action:

Information only; no action is required.

- **FQXSPNM4041I: Syslog port number changed from [arg1] to [arg2] by user [arg3].**

A user has modified the Syslog receiver port number

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0069

User Action:

Information only; no action is required.

- **FQXSPNM4042I: Remote Presence port number changed from [arg1] to [arg2] by user [arg3].**

A user has modified the Remote Presence port number

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0070

User Action:

Information only; no action is required.

- **FQXSPNM4043I: SMTP Server set by user [arg1] to [arg2]:[arg3].**

A user configured the SMTP server

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0086

User Action:

Information only; no action is required.

- **FQXSPNM4044I: Telnet [arg1] by user [arg2].**

A user enables or disables Telnet services

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0087

User Action:

Information only; no action is required.

- **FQXSPNM4045I: DNS servers set by user [arg1]: UseAdditionalServers=[arg2], PreferredDNStype=[arg3], IPv4Server1=[arg4], IPv4Server2=[arg5], IPv4Server3=[arg6], IPv6Server1=[arg7], IPv6Server2=[arg8], IPv6Server3=[arg9].**

A user configures the DNS servers

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0088

User Action:

Information only; no action is required.

- **FQXSPNM4046I: LAN over USB [arg1] by user [arg2].**

A user configured USB-LAN

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0089

User Action:

Information only; no action is required.

- **FQXSPNM4047I: LAN over USB Port Forwarding set by user [arg1]: ExternalPort=[arg2], USB-LAN port=[arg3].**

A user configured USB-LAN port forwarding

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0090

User Action:

Information only; no action is required.

- **FQXSPNM4048I: PXE boot requested by user [arg1].**

PXE boot requested

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0129

User Action:

Information only; no action is required.

- **FQXSPNM4049I: User [arg1] has initiated a TKLM Server Connection Test to check connectivity to server [arg2].**

User initiated a TKLM Server Connection test.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0159

User Action:

Information only; no action is required.

- **FQXSPNM4050I: User [arg1] has initiated an SMTP Server Connection Test.**

User initiated an SMTP Server Connection test.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0160

User Action:

Information only; no action is required.

- **FQXSPNM4051I: User [arg1] has set the SMTP Server reverse-path to [arg2].**

User set SMTP Server reverse-path address

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0163

User Action:

Information only; no action is required.

- **FQXSPNM4052I: DHCP specified hostname is set to [arg1] by user [arg2].**

DHCP specified hostname is set by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0216

User Action:

Information only; no action is required.

- **FQXSPNM4053I: DNS discovery of Lenovo XClarity Administrator has been [arg1] by user [arg2].**

DNS discovery of Lenovo XClarity Administrator

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0217

User Action:

Information only; no action is required.

- **FQXSPNM4054I: The hostname from DHCP is [arg1] by user [arg2].**

This message is for getting hostname from DHCP.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0244

User Action:

Information only; no action is required.

- **FQXSPNM4055I: The hostname from DHCP is invalid.**

This message is for hostname from DHCP is invalid.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0245

User Action:

Information only; no action is required.

- **FQXSPNM4056I: The NTP server address [arg1] is invalid.**

Report NTP server invalid

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0249

User Action:

Information only; no action is required.

- **FQXSPNM4057I: Security: IP address: [arg1] had [arg2] login failures, it will be blocked to access for [arg3] minutes.**

This message is for the use case where IP address blocking.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0250

User Action:

Information only; no action is required.

- **FQXSPNM4058I: IP address of network interface [arg1] is modified from [arg2] to [arg3] by user [arg4].**

This message is for the use case where user modifies the IP address of a Management Controller.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - IMM Network event
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0286

User Action:

Information only; no action is required.

- **FQXSPNM4059I: IP subnet mask of network interface [arg1] is modified from [arg2] to [arg3] by user [arg4].**

This message is for the use case where a user modifies the IP subnet mask of a Management Controller.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0287

User Action:

Information only; no action is required.

- **FQXSPNM4060I: IP address of default gateway of network interface [arg1] is modified from [arg2] to [arg3] by user [arg4].**

This message is for the use case where a user modifies the default gateway IP address of a Management Controller.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0288

User Action:

Information only; no action is required.

- **FQXSPNM4061I: WIFI interface is [arg1] by user [arg2] from [arg3] at IP address [arg4].**

This message is for the use case where a user WIFI enable/disable.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0340

User Action:

Information only; no action is required.

- **FQXSPNM4062I: IP address of WIFI interface is modified from [arg1] to [arg2] by user [arg3].**

This message is for the use case where a user WIFI IP address set.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0341

User Action:

Information only; no action is required.

- **FQXSPNM4063I: IP subnet mask of WIFI interface is modified from [arg1] to [arg2] by user [arg3].**

This message is for the use case where a user WIFI IP subnet mask set.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0342

User Action:

Information only; no action is required.

- **FQXSPNM4064I: IP address of default gateway of WIFI interface is modified from [arg1] to [arg2] by user [arg3].**

This message is for the use case where a user WIFI IP default gateway set.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0343

User Action:

Information only; no action is required.

- **FQXSPNM4065I: Country code of WIFI interface is modified to [arg1] by user [arg2] from [arg3] at IP address [arg4].**

This message is for the use case where a user WIFI Country code modified.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0344

User Action:

Information only; no action is required.

- **FQXSPOS4000I: OS Watchdog response [arg1] by [arg2] .**

This message is for the use case where an OS Watchdog has been enabled or disabled by a user.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0012

User Action:

Information only; no action is required.

- **FQXSPOS4001I: Watchdog [arg1] Screen Capture Occurred .**

This message is for the use case where an operating system error has occurred and the screen was captured.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0028

User Action:

Complete the following steps until the problem is solved:

1. If there was no operating-system error:
2. Reconfigure the watchdog timer to a higher value.
3. Make sure that the BMC Ethernet-over-USB interface is enabled.

4. Reinstall the RNDIS or cdc_ether device driver for the operating system.
5. Disable the watchdog.
6. If there was an operating-system error, check the integrity of the installed operating system.

- **FQXSPOS4002I: Watchdog [arg1] Failed to Capture Screen.**

This message is for the use case where an operating system error has occurred and the screen capture failed.

Severity: Error
 Serviceable: No
 Automatically notify Support: No
 Alert Category: System - other
 SNMP Trap ID: 22
 CIM Prefix: IMM CIM ID: 0029

User Action:

Complete the following steps until the problem is solved:

1. Reconfigure the watchdog timer to a higher value.
2. Make sure that the BMC Ethernet over USB interface is enabled.
3. Reinstall the RNDIS or cdc_ether device driver for the operating system.
4. Disable the watchdog.
5. Check the integrity of the installed operating system.
6. If problem persists, collect Service Data log.
7. Contact Lenovo Support.

- **FQXSPOS4003I: Platform Watchdog Timer expired for [arg1].**

An implementation has detected an OS Loader Watchdog Timer Expired

Severity: Error
 Serviceable: No
 Automatically notify Support: No
 Alert Category: System - Loader timeout
 SNMP Trap ID: 26
 CIM Prefix: IMM CIM ID: 0060

User Action:

Complete the following steps until the problem is solved:

1. Reconfigure the watchdog timer to a higher value.
2. Make sure that the BMC Ethernet over USB interface is enabled.
3. Reinstall the RNDIS or cdc_ether device driver for the operating system.
4. Disable the watchdog.
5. If problem persists, collect Service Data log.
6. Contact Lenovo Support. Check the integrity of the installed operating system.

- **FQXSPOS4004I: Operating System status has changed to [arg1].**

Operating System status change

Severity: Info
 Serviceable: No
 Automatically notify Support: No

Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0191

User Action:

Information only; no action is required.

- **FQXSPOS4005I: Host Power-On password changed by user [arg1] from [arg2] at IP address [arg3].**

This message is for the use case where Host Power-On password changed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0231

User Action:

Information only; no action is required.

- **FQXSPOS4006I: Host Power-On password cleared by user [arg1] from [arg2] at IP address [arg3].**

This message is for the use case where Host Power-On password cleared.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0232

User Action:

Information only; no action is required.

- **FQXSPOS4007I: Host Admin password changed by user [arg1] from [arg2] at IP address [arg3].**

This message is for the use case where Host Admin password changed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0233

User Action:

Information only; no action is required.

- **FQXSPOS4008I: Host Admin password cleared by user [arg1] from [arg2] at IP address [arg3].**

This message is for the use case where Host Admin password cleared.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0234

User Action:

Information only; no action is required.

- **FQXSPPOS4009I: OS Crash Video Captured.**

This message is for the use case where OS Crash Video Captured.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0235

User Action:

Information only; no action is required.

- **FQXSPPOS4010I: OS Crash Video Capture Failed.**

This message is for the use case where OS Crash Video Capture Failed.

Severity: Error
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0236

User Action:

Complete the following steps until the problem is solved:

1. Check if the OS watchdog is enabled
2. Check if the crash video recording is enabled
3. If problem persists, collect Service Data log.
4. Contact Lenovo Support.

- **FQXSPPOS4011I: OS failure screen capture with hardware error is [arg1] by user [arg2] from [arg3] at IP address [arg4].**

OS failure screen capture with hardware error is enabled or disabled by user.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0280

User Action:

Information only; no action is required.

- **FQXSPPOS4012I: POST watchdog Screen Capture Occurred.**

This message is for the use case where an operating system error has occurred and the screen was captured.

Severity: Info
Serviceable: No

Automatically notify Support: No
Alert Category: System - other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0302

User Action:

Information only; no action is required.

- **FQXSPPP4000I: Attempting to [arg1] server [arg2] by user [arg3].**

This message is for the use case where a user is using the Management Controller to perform a power function on the system.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 37
CIM Prefix: IMM CIM ID: 0015

User Action:

Information only; no action is required.

- **FQXSPPP4001I: Server Power Off Delay set to [arg1] by user [arg2].**

A user configured the Server Power Off Delay

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0081

User Action:

Information only; no action is required.

- **FQXSPPP4002I: Server [arg1] scheduled for [arg2] at [arg3] by user [arg4].**

A user configured a Server Power action at a specific time

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0082

User Action:

Information only; no action is required.

- **FQXSPPP4003I: Server [arg1] scheduled for every [arg2] at [arg3] by user [arg4].**

A user configured a recurring Server Power Action

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other

SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0083

User Action:

Information only; no action is required.

- **FQXSPPP4004I: Server [arg1] [arg2] cleared by user [arg3].**

A user cleared a Server Power Action.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0084

User Action:

Information only; no action is required.

- **FQXSPPP4005I: The power cap value changed from [arg1] watts to [arg2] watts by user [arg3].**

Power Cap values changed by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0113

User Action:

Information only; no action is required.

- **FQXSPPP4006I: The minimum power cap value changed from [arg1] watts to [arg2] watts.**

Minimum Power Cap value changed

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0114

User Action:

Information only; no action is required.

- **FQXSPPP4007I: The maximum power cap value changed from [arg1] watts to [arg2] watts.**

Maximum Power Cap value changed

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0115

User Action:

Information only; no action is required.

- **FQXSPPP4008I: The soft minimum power cap value changed from [arg1] watts to [arg2] watts.**

Soft Minimum Power Cap value changed

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0116

User Action:

Information only; no action is required.

- **FQXSPPP4009I: The measured power value exceeded the power cap value.**

Power exceeded cap

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Power
SNMP Trap ID: 164
CIM Prefix: IMM CIM ID: 0117

User Action:

Information only; no action is required.

- **FQXSPPP4010I: The new minimum power cap value exceeded the power cap value.**

Minimum Power Cap exceeds Power Cap

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Power
SNMP Trap ID: 164
CIM Prefix: IMM CIM ID: 0118

User Action:

Information only; no action is required.

- **FQXSPPP4011I: Power capping was activated by user [arg1].**

Power capping activated by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0119

User Action:

Information only; no action is required.

- **FQXSPPP4012I: Power capping was deactivated by user [arg1].**

Power capping deactivated by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0120

User Action:

Information only; no action is required.

- **FQXSPPP4013I: Static Power Savings mode has been turned on by user [arg1].**

Static Power Savings mode turned on by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0121

User Action:

Information only; no action is required.

- **FQXSPPP4014I: Static Power Savings mode has been turned off by user [arg1].**

Static Power Savings mode turned off by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0122

User Action:

Information only; no action is required.

- **FQXSPPP4015I: Dynamic Power Savings mode has been turned on by user [arg1].**

Dynamic Power Savings mode turned on by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0123

User Action:

Information only; no action is required.

- **FQXSPPP4016I: Dynamic Power Savings mode has been turned off by user [arg1].**

Dynamic Power Savings mode turned off by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0124

User Action:

Information only; no action is required.

- **FQXSPPP4017I: Power cap and external throttling occurred.**

Power cap and external throttling occurred

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0125

User Action:

Information only; no action is required.

- **FQXSPPP4018I: External throttling occurred .**

External throttling occurred

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0126

User Action:

Information only; no action is required.

- **FQXSPPP4019I: Power cap throttling occurred.**

Power cap throttling occurred

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0127

User Action:

Information only; no action is required.

- **FQXSPPP4020I: The measured power value has returned below the power cap value.**

Power exceeded cap recovered

Severity: Info
Serviceable: No
Automatically notify Support: No

Alert Category: Warning - Power
SNMP Trap ID: 164
CIM Prefix: IMM CIM ID: 0130

User Action:

Information only; no action is required.

- **FQXSPPP4021I: The new minimum power cap value has returned below the power cap value.**

Minimum Power Cap exceeds Power Cap recovered

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Power
SNMP Trap ID: 164
CIM Prefix: IMM CIM ID: 0131

User Action:

Information only; no action is required.

- **FQXSPPP4022I: The server was restarted for an unknown reason.**

The server was restarted for an unknown reason

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0166

User Action:

Information only; no action is required.

- **FQXSPPP4023I: The server is restarted by chassis control command.**

Server is restarted by chassis control command

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0167

User Action:

Information only; no action is required.

- **FQXSPPP4024I: The server was reset via push button.**

Server was reset via push button

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0168

User Action:

Information only; no action is required.

- **FQXSPPP4025I: The server was powered-up via power push button.**

Server was power-up via power push button

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0169

User Action:

Information only; no action is required.

- **FQXSPPP4026I: The server was restarted when the watchdog expired..**

Server was restarted when the watchdog expired.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0170

User Action:

Information only; no action is required.

- **FQXSPPP4027I: The server was restarted for OEM reason.**

Server was restarted for OEM reason

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0171

User Action:

Information only; no action is required.

- **FQXSPPP4028I: The server was automatically powered on because the power restore policy is set to always on.**

Server was automatically powered on because the power restore policy is set to always on.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0172

User Action:

Information only; no action is required.

- **FQXSPPP4029I: The server was automatically powered on because the power restore policy is set to restore previous power state..**

Server was automatically powered on because the power restore policy is set to restore previous power state.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0173

User Action:

Information only; no action is required.

- **FQXSPPP4030I: The server was reset via Platform Event Filter.**

Server was reset via Platform Event Filter

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0174

User Action:

Information only; no action is required.

- **FQXSPPP4031I: The server was power-cycled via Platform Event Filter.**

Server was power-cycled via Platform Event Filter

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0175

User Action:

Information only; no action is required.

- **FQXSPPP4032I: The server was soft reset.**

Server was soft reset

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0176

User Action:

Information only; no action is required.

- **FQXSPPP4033I: The server was powered up via Real Time Clock (scheduled power on).**

Server was powered up via Real Time Clock (scheduled power on)

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0177

User Action:

Information only; no action is required.

- **FQXSPPP4034I: The server was powered off for an unknown reason.**

Server was powered off for an unknown reason

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0178

User Action:

Information only; no action is required.

- **FQXSPPP4035I: The server was powered off by chassis control command.**

Server was powered off by chassis control command

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0179

User Action:

Information only; no action is required.

- **FQXSPPP4036I: The server was powered off via push button.**

Server was powered off via push button

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0180

User Action:

Information only; no action is required.

- **FQXSPPP4037I: The server was powered off when the watchdog expired.**

Server was powered off when the watchdog expired.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0181

User Action:

Information only; no action is required.

- **FQXSPPP4038I: The server stayed powered off because the power restore policy is set to always off.**

Server stayed powered off because the power restore policy is set to always off.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0182

User Action:

Information only; no action is required.

- **FQXSPPP4039I: The server stayed powered off because the power restore policy is set to restore previous power state..**

Server stayed powered off because the power restore policy is set to restore previous power state.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0183

User Action:

Information only; no action is required.

- **FQXSPPP4040I: The server was powered off via Platform Event Filter.**

Server was power off via Platform Event Filter

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0184

User Action:

Information only; no action is required.

- **FQXSPPP4041I: The server was powered off via Real Time Clock (scheduled power off).**

Server was powered up via Real Time Clock (scheduled power off)

Severity: Info

Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0185

User Action:

Information only; no action is required.

- **FQXSPPP4042I: Management Controller [arg1] reset was initiated due to Power-On-Reset.**

Management Controller reset was initiated due to Power-On-Reset

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0186

User Action:

Information only; no action is required.

- **FQXSPPP4043I: Management Controller [arg1] reset was initiated by PRESET.**

Management Controller reset was initiated by PRESET

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0187

User Action:

Information only; no action is required.

- **FQXSPPP4044I: Management Controller [arg1] reset was initiated by CMM.**

Management Controller reset was initiated by CMM

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0188

User Action:

Information only; no action is required.

- **FQXSPPP4045I: Management Controller [arg1] reset was initiated by XCC firmware.**

Management Controller reset was initiated by XCC firmware

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other

SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0189

User Action:

Information only; no action is required.

- **FQXSPPP4047I: Management Controller [arg1] reset was initiated by user [arg2].**

This message is for the use case where a Management Controller reset is initiated by a user.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0021

User Action:

Information only; no action is required.

- **FQXSPPP4048I: Attempting to AC power cycle server [arg1] by user [arg2].**

AC power cycle server

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0227

User Action:

Information only; no action is required.

- **FQXSPPP4049I: Management Controller [arg1] reset was initiated by Front Panel.**

Management Controller reset was initiated by Front Panel

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0252

User Action:

Information only; no action is required.

- **FQXSPPP4050I: Management Controller [arg1] reset was initiated to activate PFR Firmware.**

Management Controller reset was initiated to activate PFR Firmware.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0253

User Action:

Information only; no action is required.

- **FQXSPPP4051: The programmable GPU total power capping value in slot [arg1] is changed to [arg2] watts by user [arg3] from [arg4] at IP address [arg5].**

Programmable GPU total power capping changed by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0296

User Action:

Information only; no action is required.

- **FQXSPPP4052: The programmable GPU peak power capping value in slot [arg1] is changed to [arg2] watts by user [arg3] from [arg4] at IP address [arg5].**

Programmable GPU peak power capping changed by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0297

User Action:

Information only; no action is required.

- **FQXSPPP4053: This message is reserved.**

This message is reserved.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0301

User Action:

Information only; no action is required.

- **FQXSPPP4054: Unbalanced PSU config is detected, system is using less node PSU capacity.**

This message is for the use case where user installed unbalanced PSU.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0316

User Action:

Information only; no action is required.

- **FQXSPPR2001I: [ManagedElementName] detected as absent.**

This message is for the use case when an implementation has detected a Managed Element is Absent.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0392

User Action:

Information only; no action is required

- **FQXSPPU0001N: An Over-Temperature Condition has been detected on [ProcessorElementName].**

This message is for the use case when an implementation has detected an Over-Temperature Condition Detected for Processor.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0036

User Action:

Complete the following steps until the problem is solved:

1. Check the event log of XClarity Controller (XCC) for any fan- or cooling-related issues.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers/air-baffles are in place, clean, and correctly installed.
3. Make sure that the room temperature and inlet water temperature/flow rate to the rack is within operating specifications.
4. Make sure that the CPU/GPU cold plate is securely installed.
5. (Trained technician only) Replace the system board.

- **FQXSPPU0003N: [ProcessorElementName] has Failed with IERR.**

This message is for the use case when an implementation has detected a Processor Failed - IERR Condition.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - CPU
SNMP Trap ID: 40
CIM Prefix: PLAT CIM ID: 0042

User Action:

Complete the following steps:

1. Check Lenovo support site for an applicable service bulletin or UEFI firmware update that applies to this Processor error.
2. Reboot system.

3. If problem persists, collect Service Data log.
4. Contact Lenovo Support.

- **FQXSPPU0004M: [ProcessorElementName] has Failed with FRB1/BIST condition.**

This message is for the use case when an implementation has detected a Processor Failed - FRB1/BIST condition.

Severity: Error
Serviceable: Yes
Automatically notify Support: Yes
Alert Category: Critical - CPU
SNMP Trap ID: 40
CIM Prefix: PLAT CIM ID: 0044

User Action:

Complete the following steps:

1. If the system board or firmware was just updated, check the Lenovo support site for an applicable service bulletin or firmware update that applies to this processor error.
2. If problem persists, collect Service Data log.
3. Contact Lenovo Support.

- **FQXSPPU0009N: [ProcessorElementName] has a Configuration Mismatch.**

This message is for the use case when an implementation has detected a Processor Configuration Mismatch has occurred.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - CPU
SNMP Trap ID: 40
CIM Prefix: PLAT CIM ID: 0062

User Action:

Complete the following steps:

1. Check Lenovo support site for an applicable service bulletin or firmware update that applies to this processor error.
2. If problem persists, collect Service Data log.
3. Contact Lenovo Support.

- **FQXSPPU0010G: The Processor [ProcessorElementName] is operating in a Degraded State due to [ProcessorElementName].**

This message is for the use case when an implementation has detected a Processor is running in the Degraded state.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - CPU
SNMP Trap ID: 42
CIM Prefix: PLAT CIM ID: 0038

User Action:

Complete the following steps until the problem is solved:

1. Check the XCC event log for any fan or cooling related issues and address them first.
2. Make sure that the airflow at the front and rear of the chassis is not obstructed and that fillers/air-baffles are correctly installed and are in place.
3. Make sure that the room temperature and inlet water temperature/flow rate to the rack is within operating specifications.
4. Upgrade all system and chassis (if applicable) firmware to the latest level.
5. If problem persists, collect Service Data log.
6. Contact Lenovo Support."

- **FQXSPPU0011N: An SM BIOS Uncorrectable CPU complex error for [ProcessorElementName] has asserted.**

This message is for the use case when an SM BIOS Uncorrectable CPU complex error has asserted.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - CPU
SNMP Trap ID: 40
CIM Prefix: PLAT CIM ID: 0816

User Action:

Complete the following steps:

1. Check Lenovo support site for an applicable service bulletin or UEFI firmware update that applies to this error.
2. Reboot system.
3. If problem persists, collect Service Data log.
4. Contact Lenovo Support.

- **FQXSPPU0014I: CPU protective power limitation is asserted.**

This message is for the use case when an implementation has detected a CPU protective power limitation is asserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0508

User Action:

Please ensure processor in healthy status.

- **FQXSPPU0015G: Sensor [SensorElementName] has asserted.**

This message is for the use case when an implementation has detected a Sensor has asserted.

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - CPU
SNMP Trap ID: 42
CIM Prefix: PLAT CIM ID: 0508

User Action:

Complete the following steps to solve:

1. Check if all CPUs have the same on demand capabilities enabled. If XCC reports the status of the feature in "Pending" state, then reboot A/C cycle the server.
2. Retrieve the SDSi activation code from Lenovo LKMS portal and reload using XCC GUI.
3. Collect Service Data log and contact Lenovo Support.

- **FQXSPPU2001I: An Over-Temperature Condition has been removed on [ProcessorElementName].**

This message is for the use case when an implementation has detected a Over-Temperature Condition has been Removed for Processor.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Temperature
SNMP Trap ID: 0
CIM Prefix: PLAT CIM ID: 0037

User Action:

Information only; no action is required

- **FQXSPPU2002I: The Processor [ProcessorElementName] is no longer operating in a Degraded State.**

This message is for the use case when an implementation has detected a Processor is no longer running in the Degraded state.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - CPU
SNMP Trap ID: 42
CIM Prefix: PLAT CIM ID: 0039

User Action:

Information only; no action is required

- **FQXSPPU2014I: CPU protective power limitation is deasserted.**

This message is for the use case when an implementation has detected a CPU protective power limitation is deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0509

User Action:

Information only; no action is required.

- **FQXSPPU2015I: Sensor [SensorElementName] has deasserted.**

This message is for the use case when an implementation has detected a Sensor has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0509

User Action:

Information only; no action is required.

- **FQXSPPW0001I: [PowerSupplyElementName] has been added to container [PhysicalPackageElementName].**

This message is for the use case when an implementation has detected a Power Supply has been added.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0084

User Action:

Information only; no action is required

- **FQXSPPW0002L: [PowerSupplyElementName] has Failed.**

This message is for the use case when an implementation has detected a Power Supply has failed.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Power
SNMP Trap ID: 4
CIM Prefix: PLAT CIM ID: 0086

User Action:

Please check event log in xClarity Controller (XCC) Web GUI to identify the power supply unit failure. Check system spec and replace the power supply unit to the same specification.

- **FQXSPPW0003G: Failure predicted on [PowerSupplyElementName].**

This message is for the use case when an implementation has detected a Power Supply failure is predicted.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Power
SNMP Trap ID: 164
CIM Prefix: PLAT CIM ID: 0088

User Action:

Please check event log in xClarity Controller (XCC) Web GUI to identify the power supply unit failure

- **FQXSPPW0005I: [PowerSupplyElementName] is operating in an Input State that is out of range.**

This message is for the use case when an implementation has detected a Power Supply that has input out of range.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0098

User Action:

Information only; no action is required

- **FQXSPW0006I: [PowerSupplyElementName] has lost input.**

This message is for the use case when an implementation has detected a Power Supply that has input that has been lost.

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Power
SNMP Trap ID: 164
CIM Prefix: PLAT CIM ID: 0100

User Action:

Make sure power cables are connected correctly.

- **FQXSPW0007L: [PowerSupplyElementName] has a Configuration Mismatch.**

This message is for the use case when an implementation has detected a Power Supply with a Configuration Error.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Power
SNMP Trap ID: 4
CIM Prefix: PLAT CIM ID: 0104

User Action:

Please check the consistency of PSU models on xClarity Controller (XCC) Web GUI.

- **FQXSPW0008I: [SensorElementName] has been turned off.**

This message is for the use case when an implementation has detected a Power Unit that has been Disabled.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Power Off
SNMP Trap ID: 23
CIM Prefix: PLAT CIM ID: 0106

User Action:

Information only; no action is required.

- **FQXSPW0009I: [PowerSupplyElementName] has been Power Cycled.**

This message is for the use case when an implementation has detected a Power Unit that has been power cycled.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0108

User Action:

Information only; no action is required

- **FQXSPW0031J: Numeric sensor [NumericSensorElementName] going low (lower non-critical) has asserted.**

This message is for the use case when an implementation has detected a Lower Non-critical sensor going low has asserted.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Voltage
SNMP Trap ID: 13
CIM Prefix: PLAT CIM ID: 0476

User Action:

CMOS battery is recommended to replace with new one.

- **FQXSPW0035M: Numeric sensor [NumericSensorElementName] going low (lower critical) has asserted.**

This message is for the use case when an implementation has detected a Lower Critical sensor going low has asserted.

Severity: Error
Serviceable: Yes
Automatically notify Support: Yes
Alert Category: Critical - Voltage
SNMP Trap ID: 1
CIM Prefix: PLAT CIM ID: 0480

User Action:

Complete the following steps:

1. If the specified sensor is Planar 3.3V or Planar 5V, (trained technician only)replace the system board.
2. If the specified sensor is Planar 12V, ensure PDB board is installed correctly and check the XClarity Controller event log for power-supply-related issues, and resolve those issues.
3. If the problem remains, replace (trained technician only)the PDB board or system board.

- **FQXSPW0057J: Sensor [SensorElementName] has transitioned from normal to non-critical state.**

This message is for the use case when an implementation has detected a Sensor transitioned to non-critical from normal.

Severity: Warning
Serviceable: Yes

Automatically notify Support: No
Alert Category: Warning - Power
SNMP Trap ID: 164
CIM Prefix: PLAT CIM ID: 0520

User Action:

Please check event log in xClarity Controller web interface.

- **FQXSPPW0061M: Sensor [SensorElementName] has transitioned to critical from a less severe state.**

This message is for the use case when an implementation has detected a Sensor transitioned to critical from less severe.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Power
SNMP Trap ID: 4
CIM Prefix: PLAT CIM ID: 0522

User Action:

Complete the following steps:

1. Ensure power supply unit to meet the system spec in wattage, efficiency level and supported list.
2. Check the event log in xClarity Controller (XCC) Web GUI to the detail information to reseal/reinstall/upgrade power supply unit.
3. If the problem still exist, please contact Lenovo support

- **FQXSPPW0062M: Sensor [SensorElementName] has transitioned to critical from a less severe state.**

This message is for the use case when an implementation has detected a Sensor transitioned to critical from less severe.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Power
SNMP Trap ID: 4
CIM Prefix: PLAT CIM ID: 0522

User Action:

Complete the following steps until the problem is solved.

1. Check the specification on Lenovo Docs (<http://pubs.lenovo.com>) to the server.
2. Ensure all PSU specification is the same in the system.
3. If there is mismatched PSU installed, please replace PSU with the same specification.

- **FQXSPPW0063M: Sensor [SensorElementName] has transitioned to critical from a less severe state.**

This message is for the use case when an implementation has detected a Sensor transitioned to critical from less severe.

Severity: Error
Serviceable: Yes
Automatically notify Support: Yes

Alert Category: Critical - Voltage
SNMP Trap ID: 1
CIM Prefix: PLAT CIM ID: 0522

User Action:

Complete the following steps until the problem is solved:

1. If the specified sensor is Planar 3.3V or Planar 5V, replace the system board (trained technician only).
2. If the specified sensor is Planar 12V, check XClarity Controller (XCC)event log for power-supply-related issues and resolve those issues. If the problem remains, replace the system board (trained technician only).
3. Contact local service provider. To locate a reseller authorized by Lenovo to provide warranty service, go to <http://www.ibm.com/partnerworld> and click Business Partner Locator.

- **FQXSPW0101J: Redundancy Degraded for [RedundancySetElementName] has asserted.**

This message is for the use case when Redundancy Degraded has asserted.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Redundant Power Supply
SNMP Trap ID: 10
CIM Prefix: PLAT CIM ID: 0804

User Action:

Please ensure the PSU wattage, PSU efficiency level and the power supply unit is supported for the system.

- **FQXSPW0104J: Non-redundant:Sufficient Resources from Redundancy Degraded or Fully Redundant for [RedundancySetElementName] has asserted.**

This message is for the use case when a Redundancy Set has transitioned from Redundancy Degraded or Fully Redundant to Non-redundant:Sufficient.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Redundant Power Supply
SNMP Trap ID: 10
CIM Prefix: PLAT CIM ID: 0806

User Action:

Please ensure the PSU wattage, PSU efficiency level and the power supply unit is supported for the system.

- **FQXSPW0110M: Non-redundant:Insufficient Resources for [RedundancySetElementName] has asserted.**

This message is for the use case when a Redundancy Set has transitioned to Non-redundant:Insufficient Resources.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Redundant Power Supply
SNMP Trap ID: 9
CIM Prefix: PLAT CIM ID: 0810

User Action:

Complete the following steps until the problem is solved:

1. Check if any power adapter is missing, failing or not installed properly. If so, re-install or replace it.
2. Check the power adapter max rate and power capping policy. If the required power resource is not met, change the power adapter or modify power capping mechanism.

- **FQXSPW2001I: [PowerSupplyElementName] has been removed from container [PhysicalPackageElementName].**

This message is for the use case when an implementation has detected a Power Supply has been removed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0085

User Action:

Information only; no action is required

- **FQXSPW2002I: [PowerSupplyElementName] has returned to OK status.**

This message is for the use case when an implementation has detected a Power Supply return to normal operational status.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Power
SNMP Trap ID: 4
CIM Prefix: PLAT CIM ID: 0087

User Action:

Information only; no action is required

- **FQXSPW2003I: Failure no longer predicted on [PowerSupplyElementName].**

This message is for the use case when an implementation has detected a Power Supply failure is no longer predicted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Power
SNMP Trap ID: 164
CIM Prefix: PLAT CIM ID: 0089

User Action:

Information only; no action is required

- **FQXSPW2006I: [PowerSupplyElementName] has returned to a Normal Input State.**

This message is for the use case when an implementation has detected a Power Supply that has input that has returned to normal.

Severity: Info

Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0099

User Action:

Information only; no action is required

- **FQXSPPW2007I: [PowerSupplyElementName] Configuration is OK.**

This message is for the use case when an implementation when a Power Supply configuration is OK.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Power
SNMP Trap ID: 4
CIM Prefix: PLAT CIM ID: 0105

User Action:

Information only; no action is required

- **FQXSPPW2008I: [PowerSupplyElementName] has been turned on.**

This message is for the use case when an implementation has detected a Power Unit that has been Enabled.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Power On
SNMP Trap ID: 24
CIM Prefix: PLAT CIM ID: 0107

User Action:

Information only; no action is required

- **FQXSPPW2018I: [PowerSupplyElementName] out-of-range has returned to a Normal Input State.**

This message is for the use case when an implementation has detected a Power Supply that has input that has returned to normal.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0099

User Action:

Information only; no action is required.

- **FQXSPPW2031I: Numeric sensor [NumericSensorElementName] going low (lower non-critical) has deasserted.**

This message is for the use case when an implementation has detected a Lower Non-critical sensor going low has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Voltage
SNMP Trap ID: 13
CIM Prefix: PLAT CIM ID: 0477

User Action:

Information only; no action is required

- **FQXSPPW2035I: Numeric sensor [NumericSensorElementName] going low (lower critical) has deasserted.**

This message is for the use case when an implementation has detected a Lower Critical sensor going low has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Voltage
SNMP Trap ID: 1
CIM Prefix: PLAT CIM ID: 0481

User Action:

Information only; no action is required

- **FQXSPPW2057I: Sensor [SensorElementName] has deasserted the transition from normal to non-critical state.**

This message is for the use case when an implementation has detected that a Sensor has deasserted a transition to non-critical from normal.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Power
SNMP Trap ID: 164
CIM Prefix: PLAT CIM ID: 0521

User Action:

Information only; no action is required

- **FQXSPPW2061I: Sensor [SensorElementName] has transitioned to a less severe state from critical.**

This message is for the use case when an implementation has detected a Sensor transition to less severe from critical.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Power
SNMP Trap ID: 4
CIM Prefix: PLAT CIM ID: 0523

User Action:

Information only; no action is required.

- **FQXSPPW2062I: Sensor [SensorElementName] has transitioned to a less severe state from critical.**

This message is for the use case when an implementation has detected a Sensor transition to less severe from critical.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Power
SNMP Trap ID: 4
CIM Prefix: PLAT CIM ID: 0523

User Action:

Information only; no action is required.

- **FQXSPW2063I: Sensor [SensorElementName] has transitioned to a less severe state from critical.**

This message is for the use case when an implementation has detected a Sensor transition to less severe from critical.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Voltage
SNMP Trap ID: 1
CIM Prefix: PLAT CIM ID: 0523

User Action:

Information only; no action is required

- **FQXSPW2101I: Redundancy Degraded for [RedundancySetElementName] has deasserted.**

This message is for the use case when Redundancy Degraded has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Redundant Power Supply
SNMP Trap ID: 10
CIM Prefix: PLAT CIM ID: 0805

User Action:

Please check the correlated message with PDU/Power logs to understand if a phase of power is dropping out or the PSUs are failing.

- **FQXSPW2104I: Non-redundant:Sufficient Resources from Redundancy Degraded or Fully Redundant for [RedundancySetElementName] has deasserted.**

This message is for the use case when a Redundancy Set has transitioned from Non-redundant:Sufficient Resources.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Redundant Power Supply
SNMP Trap ID: 10
CIM Prefix: PLAT CIM ID: 0807

User Action:

Information only; no action is required.

- **FQXSPW2110I: Non-redundant:Insufficient Resources for [RedundancySetElementName] has deasserted.**

This message is for the use case when a Redundancy Set has transitioned from Non-redundant: Insufficient Resources.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Redundant Power Supply
SNMP Trap ID: 9
CIM Prefix: PLAT CIM ID: 0811

User Action:

Information only; no action is required.

- **FQXSPW4001I: PCIe Power Brake for [arg1] has been [arg2].**

This message is for the use case where PCIe Power Brake.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0243

User Action:

Check if system have fan fail error, Raidlink CEM fail occurring or Ambient temperature over 35C, implement the "error" service action to recovery the system and reduce ambient temperature under 35C.

- **FQXSPW4002I: Total graphics power value has exceeded the pre-configured limit.**

This message is for the use case where total graphics power value value has exceeded the pre-configured limit.

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: IMM CIM ID: 0328

User Action:

Information only; no action is required.

- **FQXSPW4003I: The customized total graphics power is within the pre-configured limit.**

This message is for the use case where the customized total graphics power is within the pre-configured limit.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0329

User Action:

Information only; no action is required.

- **FQXSPSD0000I: The [StorageVolumeElementName] has been added.**

This message is for the use case when an implementation has detected a Drive has been Added.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0162

User Action:

Information only; no action is required

- **FQXSPSD0001I: The [StorageVolumeElementName] Drive [arg1] in the enclosure/chassis(MTM-SN: [arg2]) has been added.**

This message is for the use case when an implementation has detected a Drive has been Added.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0162

User Action:

Information only; no action is required

- **FQXSPSD0001L: The [StorageVolumeElementName] has a fault.**

This message is for the use case when an implementation has detected a Drive was Disabled due to fault.

Severity: Error
Serviceable: Yes
Automatically notify Support: Yes
Alert Category: Critical - Hard Disk drive
SNMP Trap ID: 5
CIM Prefix: PLAT CIM ID: 0164

User Action:

Complete the following steps:

1. Make sure that the reported device is compatible by checking <https://static.lenovo.com/us/en/serverproven/index.shtml>.
2. Collect the service data log from the management controller interface and contact Lenovo Support.

- **FQXSPSD0002G: Failure Predicted on [StorageVolumeElementName] for array [ComputerSystemElementName].**

This message is for the use case when an implementation has detected an Array Failure is Predicted.

Severity: Warning
Serviceable: Yes
Automatically notify Support: Yes
Alert Category: System - Predicted Failure
SNMP Trap ID: 27
CIM Prefix: PLAT CIM ID: 0168

User Action:

Complete the following steps:

1. Replace the identified drive at the next maintenance period.
2. If the problem persists after replacement, collect the service data log from the XCC WebGUI and contact Lenovo Support.

- **FQXSPSD0002L: Drive [arg1] in the enclosure/chassis(MTM-SN: [arg2]) has a fault.**

This message is for the use case when an implementation has detected a Drive was Disabled due to fault.

Severity: Error
Serviceable: Yes
Automatically notify Support: Yes
Alert Category: Critical - Hard Disk drive
SNMP Trap ID: 5
CIM Prefix: PLAT CIM ID: 0164

User Action:

Complete the following steps:

1. Check the Support Portal(<http://support.lenovo.com/>)for service bulletins and TECH tips and firmware update related to your drive.
2. Check for any other RAID-related error.
3. Replace the drive.

- **FQXSPSD0003G: Failure Predicted on drive [arg1] in the enclosure/chassis (MTM-SN: [arg2]).**

This message is for the use case when an implementation has detected an Array Failure is Predicted.

Severity: Warning
Serviceable: Yes
Automatically notify Support: Yes
Alert Category: System - Predicted Failure
SNMP Trap ID: 27
CIM Prefix: PLAT CIM ID: 0168

User Action:

Replace hard disk drive 0 at the next maintenance period.

- **FQXSPSD0003I: Hot Spare enabled for [ComputerSystemElementName].**

This message is for the use case when an implementation has detected a Hot Spare has been Enabled.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0170

User Action:

Information only; no action is required.

- **FQXSPSD0005I: Hot Spare enabled for drive [arg1] in the enclosure/chassis (MTM-SN: [arg2]).**

This message is for the use case when an implementation has detected a Hot Spare has been Enabled.

Severity: Info

Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0170

User Action:

Information only; no action is required

- **FQXSPSD0005L: Array [ComputerSystemElementName] is in critical condition.**

This message is for the use case when an implementation has detected that an Array is Critical.

Severity: Error
Serviceable: Yes
Automatically notify Support: Yes
Alert Category: Critical - Hard Disk drive
SNMP Trap ID: 5
CIM Prefix: PLAT CIM ID: 0174

User Action:

Replace the hard disk drive that is indicated by a lit status LED.

- **FQXSPSD0007I: Rebuild in progress for Array in system [ComputerSystemElementName].**

This message is for the use case when an implementation has detected that an Array Rebuild is in Progress.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0178

User Action:

Information only; no action is required

- **FQXSPSD0007L: Array critical asserted on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]).**

This message is for the use case when an implementation has detected that an Array is Critical.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Hard Disk drive
SNMP Trap ID: 5
CIM Prefix: PLAT CIM ID: 0174

User Action:

Replace the hard disk drive that is indicated by a lit status LED.

- **FQXSPSD0008I: Array rebuild in progress on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]).**

This message is for the use case when an implementation has detected that an Array Rebuild is in Progress.

Severity: Info

Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0178

User Action:

Information only; no action is required

- **FQXSPSD0008L: Array failed on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]).**

This message is for the use case when an implementation has detected that an Array Failed.

Severity: Error
Serviceable: Yes
Automatically notify Support: Yes
Alert Category: Critical - Hard Disk drive
SNMP Trap ID: 5
CIM Prefix: PLAT CIM ID: 0176

User Action:

Complete the following steps:

1. Replace any hard disk drive that is indicated by a lit status LED.
2. Re-create the array.
3. Restore the data from a backup.

- **FQXSPSD2000I: The [StorageVolumeElementName] has been removed from unit [PhysicalPackageElementName].**

This message is for the use case when an implementation has detected a Drive has been Removed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0163

User Action:

Complete the following steps until the problem is solved:

1. If drive was intentionally removed, make sure that there is a filler in the drive bay.
2. Make sure that the drive is correctly seated.
3. If drive is correctly seated, replace the drive.

- **FQXSPSD2001I: The [StorageVolumeElementName] has recovered from a fault.**

This message is for the use case when an implementation has detected a Drive was Enabled.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Hard Disk drive
SNMP Trap ID: 5
CIM Prefix: PLAT CIM ID: 0167

User Action:

Information only; no action is required

- **FQXSPSD2002I: Failure no longer Predicted on [StorageVolumeElementName] for array [ComputerSystemElementName].**

This message is for the use case when an implementation has detected an Array Failure is no longer Predicted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Predicted Failure
SNMP Trap ID: 27
CIM Prefix: PLAT CIM ID: 0169

User Action:

Information only; no action is required

- **FQXSPSD2005I: Critical Array [ComputerSystemElementName] has deasserted.**

This message is for the use case when an implementation has detected that a Critical Array has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Hard Disk drive
SNMP Trap ID: 5
CIM Prefix: PLAT CIM ID: 0175

User Action:

Information only; no action is required

- **FQXSPSD2006I: Array in system [ComputerSystemElementName] has been restored.**

This message is for the use case when an implementation has detected that a Failed Array has been Restored.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Hard Disk drive
SNMP Trap ID: 5
CIM Prefix: PLAT CIM ID: 0177

User Action:

Information only; no action is required.

- **FQXSPSD2007I: Rebuild completed for Array in system [ComputerSystemElementName].**

This message is for the use case when an implementation has detected that an Array Rebuild has Completed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0179

User Action:

Information only; no action is required

- **FQXSPSD2008I: Drive [arg1] in the enclosure/chassis(MTM-SN: [arg2]) has recovered from a fault.**

This message is for the use case when an implementation has detected a Drive was Enabled.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Hard Disk drive
SNMP Trap ID: 5
CIM Prefix: PLAT CIM ID: 0167

User Action:

Information only; no action is required

- **FQXSPSD2010I: Drive [arg1] in the enclosure/chassis(MTM-SN: [arg2]) has been removed.**

This message is for the use case when an implementation has detected a Drive has been Removed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0163

User Action:

Complete the following steps until the problem is solved:

1. If drive was intentionally removed, make sure that there is a filler in the drive bay.
2. Make sure that the drive is correctly seated.
3. If drive is correctly seated, replace the drive.

- **FQXSPSD2011I: Failure no longer Predicted on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]).**

This message is for the use case when an implementation has detected an Array Failure is no longer Predicted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Predicted Failure
SNMP Trap ID: 27
CIM Prefix: PLAT CIM ID: 0169

User Action:

Information only; no action is required

- **FQXSPSD2012I: Hot Spare disabled for drive [arg1] in the enclosure/chassis (MTM-SN: [arg2]).**

This message is for the use case when an implementation has detected a Hot Spare has been Disabled.

Severity: Info
Serviceable: No
Automatically notify Support: No

Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0171

User Action:

Information only; no action is required

- **FQXSPSD2013I: Array critical deasserted on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]).**

This message is for the use case when an implementation has detected that a Critical Array has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Hard Disk drive
SNMP Trap ID: 5
CIM Prefix: PLAT CIM ID: 0175

User Action:

Information only; no action is required

- **FQXSPSD2014I: Array restored on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]).**

This message is for the use case when an implementation has detected that a Failed Array has been Restored.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Hard Disk drive
SNMP Trap ID: 5
CIM Prefix: PLAT CIM ID: 0177

User Action:

Information only; no action is required

- **FQXSPSD2015I: Array rebuild completed on drive [arg1] in the enclosure/chassis (MTM-S/N: [arg2]).**

This message is for the use case when an implementation has detected that an Array Rebuild has Completed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0179

User Action:

Information only; no action is required

- **FQXSPSE0000F: The Chassis [PhysicalPackageElementName] was opened.**

This message is for the use case when the Chassis has been opened.

Severity: Warning

Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0004

User Action:

The chassis is either opened or is not properly sealed, please ensure the chassis is installed well.

- **FQXSPSE0010J: System guard detected inventory mismatch with trusted snapshot.**

This message is for the use case when an implementation has detected a system guard detected inventory mismatch with trusted snapshot.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0520

User Action:

Complete the following steps to solve:

1. If the user sets up the server for the first time after receiving the order, check with the seller whether there was a hardware change made since the system left Lenovo manufacturing. If the hardware change is expected, ignore this message or deassert the event as described in step 4. If the hardware change is not expected, report the issue to the seller.
2. If the user enables the System Guard feature after initial setup of hardware, check whether there are any hardware changes or hardware errors. If yes, resolve them first.
3. If the user enables the feature with the policy "Prevent OS booting (only on CPU and DIMM event)", UEFI boot would stop during POST and promote user input with warning on the POST screen. See System Guard in XCC 2 User Guide for details.(https://pubs.lenovo.com/xcc2/NN1ia_c_systemguard?_highlight=system)
4. To acknowledge the inventory change of hardware components, the user can disable System Guard, or manually capture a snapshot (after POST has completed) from XCC GUI. See System Guard in XCC 2 User Guide for details.
5. If the problem persists, collect service data logs and contact Lenovo Support.

- **FQXSPSE2000I: The Chassis [PhysicalPackageName] was closed.**

This message is for the use case when a Chassis has been closed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0005

User Action:

Information only; no action is required.

- **FQXSPSE2010I: System guard changed to compliant status.**

This message is for the use case when an implementation has detected that system Guard changed to compliant status.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0521

User Action:

Information only; no action is required

- **FQXSPSE4000I: Certificate Authority [arg1] has detected a [arg2] Certificate Error.**

This message is for the use case when there is an error with an SSL Server, SSL Client, or SSL Trusted CA Certificate.

Severity: Error
Serviceable: No
Automatically notify Support: No
Alert Category: System - other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0002

User Action:

Complete the following steps until the problem is solved:

1. Make sure that the certificate that you are importing is correct and properly generated.
2. If problem persists, collect Service Data log.
3. Contact Lenovo Support.

- **FQXSPSE4001I: Remote Login Successful. Login ID: [arg1] using [arg2] from [arg3] at IP address [arg4].**

This message is for the use case where a user successfully logs in to a Management Controller.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0014

User Action:

Information only; no action is required.

- **FQXSPSE4002I: Security: Userid: [arg1] using [arg2] had [arg3] login failures from WEB client at IP address [arg4].**

This message is for the use case where a user has failed to log in to a Management Controller from a web browser.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0016

User Action:

Complete the following steps until the problem is solved:

1. Make sure that the correct login ID and password are being used.
2. Have the system administrator reset the login ID or password.

- **FQXSPSE4003I: Security: Login ID: [arg1] had [arg2] login failures from CLI at [arg3].**

This message is for the use case where a user has failed to log in to a Management Controller from the Legacy CLI.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0017

User Action:

Complete the following steps until the problem is solved:

1. Make sure that the correct login ID and password are being used.
2. Have the system administrator reset the login ID or password.

- **FQXSPSE4004I: Remote access attempt failed. Invalid userid or password received. Userid is [arg1] from WEB browser at IP address [arg2].**

This message is for the use case where a remote user has failed to establish a remote control session from a Web browser session.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0018

User Action:

Make sure that the correct login ID and password are being used.

- **FQXSPSE4005I: Remote access attempt failed. Invalid userid or password received. Userid is [arg1] from TELNET client at IP address [arg2].**

This message is for the use case where a user has failed to log in to a Management Controller from a telnet session.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0019

User Action:

Make sure that the correct login ID and password are being used.

- **FQXSPSE4006I: XCC detected an invalid SSL certificate in the Management Controller [arg1] .**

This message is for the use case where a Management Controller has detected invalid SSL data in the configuration data and is clearing the configuration data region and disabling the SSL.

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0034

User Action:

Complete the following steps until the problem is solved:

1. Make sure that the certificate that you are importing is correct and properly generated / certificate CSR is correct
2. If problem persists, collect Service Data log.
3. Contact Lenovo Support.

- **FQXSPSE4007I: Security: Userid: [arg1] using [arg2] had [arg3] login failures from an SSH client at IP address [arg4].**

This message is for the use case where a user has failed to log in to a Management Controller from SSH.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0041

User Action:

Complete the following steps until the problem is solved:

1. Make sure that the correct login ID and password are being used.
2. Have the system administrator reset the login ID or password.

- **FQXSPSE4008I: SNMPv1 [arg1] set by user [arg2]: Name=[arg3], AccessType=[arg4], Address=[arg5], .**

A user changed the SNMP community string

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0075

User Action:

Information only; no action is required.

- **FQXSPSE4009I: LDAP Server configuration set by user [arg1]: SelectionMethod=[arg2], DomainName=[arg3], Server1=[arg4], Server2=[arg5], Server3=[arg6], Server4=[arg7].**

A user changed the LDAP server configuration

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22

CIM Prefix: IMM CIM ID: 0076

User Action:

Information only; no action is required.

- **FQXSPSE4010I: LDAP set by user [arg1]: RootDN=[arg2], UIDSearchAttribute=[arg3], BindingMethod=[arg4], EnhancedRBS=[arg5], TargetName=[arg6], GroupFilter=[arg7], GroupAttribute=[arg8], LoginAttribute=[arg9].**

A user configured an LDAP Miscellaneous setting

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0077

User Action:

Information only; no action is required.

- **FQXSPSE4011I: Secure Web services (HTTPS) [arg1] by user [arg2].**

A user enables or disables Secure web services

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0091

User Action:

Information only; no action is required.

- **FQXSPSE4012I: Secure CIM/XML(HTTPS) [arg1] by user [arg2].**

A user enables or disables Secure CIM/XML services

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0092

User Action:

Information only; no action is required.

- **FQXSPSE4013I: Secure LDAP [arg1] by user [arg2].**

A user enables or disables Secure LDAP services

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0093

User Action:

Information only; no action is required.

- **FQXSPSE4014I: SSH [arg1] by user [arg2].**

A user enables or disables SSH services

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0094

User Action:

Information only; no action is required.

- **FQXSPSE4015I: Global Login General Settings set by user [arg1]: AuthenticationMethod=[arg2], LockoutPeriod=[arg3], SessionTimeout=[arg4].**

A user changes the Global Login General Settings

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0098

User Action:

Information only; no action is required.

- **FQXSPSE4016I: Global Login Account Security set by user [arg1]: PasswordRequired=[arg2], PasswordExpirationPeriod=[arg3], MinimumPasswordReuseCycle=[arg4], MinimumPasswordLength=[arg5], MinimumPasswordChangeInterval=[arg6], MaxmumLoginFailures=[arg7], LockoutAfterMaxFailures=[arg8].**

A user changes the Global Login Account Security Settings to Legacy

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0099

User Action:

Information only; no action is required.

- **FQXSPSE4017I: User [arg1] created.**

A user account was created

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0100

User Action:

Information only; no action is required.

- **FQXSPSE4018I: User [arg1] removed.**

A user account was deleted

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0101

User Action:

Information only; no action is required.

- **FQXSPSE4019I: User [arg1] password modified.**

A user account was changed

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0102

User Action:

Information only; no action is required.

- **FQXSPSE4020I: User [arg1] role set to [arg2].**

A user account role assigned

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0103

User Action:

Information only; no action is required.

- **FQXSPSE4021I: User [arg1] custom privileges set: [arg2][arg3][arg4][arg5][arg6][arg7][arg8][arg9].**

User account privileges assigned

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0104

User Action:

Information only; no action is required.

- **FQXSPSE4022I: User [arg1] for SNMPv3 set: AuthenticationProtocol=[arg2], PrivacyProtocol=[arg3], AccessType=[arg4], HostforTraps=[arg5] by user [arg6] from [arg7] at IP address [arg8].**

User account SNMPv3 settings changed

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0105

User Action:

Information only; no action is required.

- **FQXSPSE4023I: SSH Client key added for user [arg1] by user [arg2] from [arg3] at IP address [arg4].**

User locally defined an SSH Client key

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0106

User Action:

Information only; no action is required.

- **FQXSPSE4024I: SSH Client key imported for user [arg1] from [arg2] by user [arg3] from [arg4] at IP address [arg5].**

User imported an SSH Client key

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0107

User Action:

Information only; no action is required.

- **FQXSPSE4025I: SSH Client key removed from user [arg1] by user [arg2] from [arg3] at IP address [arg4].**

User removed an SSH Client key

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0108

User Action:

Information only; no action is required.

- **FQXSPSE4026I: Security: Userid: [arg1] had [arg2] login failures from a CIM client at IP address [arg3].**

This message is for the use case where a user has failed to log in to a Management Controller from CIM.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0140

User Action:

Information only; no action is required.

- **FQXSPSE4027I: Remote access attempt failed. Invalid userid or password received. Userid is [arg1] from a CIM client at IP address [arg2].**

This message is for the use case where a remote user has failed to establish a remote control session from CIM.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0141

User Action:

Information only; no action is required.

- **FQXSPSE4028I: Security: Userid: [arg1] had [arg2] login failures from IPMI client at IP address [arg3].**

This message is for the use case where a user has failed to log in to a Management Controller from IPMI.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0153

User Action:

Information only; no action is required.

- **FQXSPSE4029I: Security: Userid: [arg1] had [arg2] login failures from SNMP client at IP address [arg3].**

This message is for the use case where a user has failed to access a Management Controller from SNMP.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0154

User Action:

Information only; no action is required.

- **FQXSPSE4030I: Security: Userid: [arg1] had [arg2] login failures from IPMI serial client.**

This message is for the use case where a user has failed to log in to a Management Controller from IPMI serial client

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0155

User Action:

Information only; no action is required.

- **FQXSPSE4031I: Remote Login Successful. Login ID: [arg1] from [arg2] serial interface.**

This message is for the use case where a user successfully logs in to a Management Controller.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0156

User Action:

Information only; no action is required.

- **FQXSPSE4032I: Login ID: [arg1] from [arg2] at IP address [arg3] has logged off.**

This message is for the use case where a user has logged off of a Management Controller.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0157

User Action:

Information only; no action is required.

- **FQXSPSE4033I: Login ID: [arg1] from [arg2] at IP address [arg3] has been logged off.**

This message is for the use case where a user has been logged off of a Management Controller.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0158

User Action:

Information only; no action is required.

- **FQXSPSE4034I: User [arg1] has removed a certificate.**

User removed certificate

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0164

User Action:

Information only; no action is required.

- **FQXSPSE4035I: A certificate has been revoked .**

A certificate has been revoked

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0165

User Action:

Information only; no action is required.

- **FQXSPSE4036I: The [arg1] certificate is expired and has been removed.**

Expired certificate has been removed

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0190

User Action:

Information only; no action is required.

- **FQXSPSE4037I: Crypto mode modified from [arg1] to [arg2] by user [arg3].**

Crypto mode modified

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0218

User Action:

Information only; no action is required.

- **FQXSPSE4038I: Minimum TLS level modified from [arg1] to [arg2] by user [arg3].**

Minimum TLS level modified

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0219

User Action:

Information only; no action is required.

- **FQXSPSE4039I: Temporary user account [arg1] is created by inband tool.**

Temporary user account create

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0228

User Action:

Information only; no action is required.

- **FQXSPSE4040I: Temporary user account [arg1] expires.**

Temporary user account expire

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0229

User Action:

The user account you input has expired.

- **FQXSPSE4041I: Security: Userid: [arg1] had [arg2] login failures from a SFTP client at IP address [arg3].**

This message is for the use case where a user has failed to log in to a Management Controller from SFTP.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0230

User Action:

Information only; no action is required.

- **FQXSPSE4042I: The third-party password function [arg1] by user [arg2] from [arg3] at IP address [arg4].**

This message is for the use case where a user successfully switch the third-party password function.

Severity: Info

Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0238

User Action:

Information only; no action is required.

- **FQXSPSE4043I: Retrieving the third-party password [arg1] by user [arg2] from [arg3] at IP address [arg4].**

This message is for the use case where a user successfully switch the retrieving the third-party password.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0239

User Action:

Information only; no action is required.

- **FQXSPSE4044I: User [arg1] third-party hashed password has been [arg2] by user [arg3] from [arg4] at IP address [arg5].**

This message is for the use case where a user successfully manage the third-party hashed password.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0240

User Action:

Information only; no action is required.

- **FQXSPSE4045I: The Salt of user [arg1] third-party password has been [arg2] by user [arg3] from [arg4] at IP address [arg5].**

This message is for the use case where a user successfully manage the third-party password salt.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0241

User Action:

Information only; no action is required.

- **FQXSPSE4046I: The third-party password of the user [arg1] has been retrieved by user [arg2] from [arg3] at IP address [arg4].**

This message is for the use case where a user successfully retrieving the third-party password.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0242

User Action:

Information only; no action is required.

- **FQXSPSE4047I: Role [arg1] is [arg2] and assigned with custom privileges [arg3][arg4][arg5][arg6][arg7][arg8][arg9][arg10][arg11] by user [arg12] .**

Role create modify and assign

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0246

User Action:

Information only; no action is required.

- **FQXSPSE4048I: Role [arg1] is removed by user [arg2].**

Role is removed

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0247

User Action:

Information only; no action is required.

- **FQXSPSE4049I: Role [arg1] is assigned to user [arg2] by user [arg3].**

Role is assigned

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0248

User Action:

Information only; no action is required.

- **FQXSPSE4050I: [arg1] sent IPMI command from [arg2], raw data: [arg3][arg4][arg5].**

This message is for the use case where IPMI command to be sent.

Severity: Info
Serviceable: No

Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0251

User Action:

Information only; no action is required.

- **FQXSPSE4051I: Management Controller [arg1] joined the neighbor group [arg2] by user [arg3] at IP address [arg4].**

This message is for the use case where MC joins a group.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0261

User Action:

Information only; no action is required.

- **FQXSPSE4052I: The password of neighbor group [arg1] is modified by [arg2] [arg3] at IP address [arg4].**

This message is for the use case where the group user password is modified.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0262

User Action:

Information only; no action is required.

- **FQXSPSE4053I: Management Controller [arg1] left the neighbor group [arg2] by user [arg3] at IP address [arg4].**

This message is for the use case where MC leaves a group.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0263

User Action:

Information only; no action is required.

- **FQXSPSE4054I: IPMI SEL wrapping mode is [arg1] by user [arg2] at IP address [arg3].**

IPMI SEL wrapping mode is changed.

Severity: Info
Serviceable: No

Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0264

User Action:

Information only; no action is required.

- **FQXSPSE4055I: SED encryption is enabled by user [arg1] at IP address [arg2].**

SED encryption is enabled.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0265

User Action:

Information only; no action is required.

- **FQXSPSE4056I: SED AK is [arg1] by user [arg2] at IP address [arg3].**

SED AK is regenerated or recovered.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0266

User Action:

Information only; no action is required.

- **FQXSPSE4057I: User [arg1] created by user [arg2] from [arg3] at IP address [arg4].**

A user account was created by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0267

User Action:

Information only; no action is required.

- **FQXSPSE4058I: User [arg1] removed by user [arg2] from [arg3] at IP address [arg4].**

A user account was deleted by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22

CIM Prefix: IMM CIM ID: 0268

User Action:

Information only; no action is required.

- **FQXSPSE4059I: User [arg1] password modified by user [arg2] from [arg3] at IP address [arg4].**

A user account was changed by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0269

User Action:

Information only; no action is required.

- **FQXSPSE4060I: User [arg1] role set to [arg2] by user [arg3] from [arg4] at IP address [arg5].**

A user account role assigned by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0270

User Action:

Information only; no action is required.

- **FQXSPSE4061I: User [arg1] custom privileges set: [arg2][arg3][arg4][arg5][arg6][arg7][arg8][arg9] by user [arg10] from [arg11] at IP address [arg12].**

User account privileges assigned by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0271

User Action:

Information only; no action is required.

- **FQXSPSE4062I: The system guard snapshot is captured by user [arg1] from [arg2] at IP address [arg3].**

The system guard snapshot is captured by user.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0278

User Action:

Information only; no action is required.

- **FQXSPSE4063I: The system guard configuration is updated: status=[arg1], hardware inventory=[arg2] and action=[arg3] by user [arg4] from [arg5] at IP address [arg6].**

The system guard configuration is updated by user.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0279

User Action:

Information only; no action is required.

- **FQXSPSE4064I: SNMPv3 engine ID is changed from [arg1] to [arg2] by user [arg3] from [arg4] at IP address [arg5].**

SNMPv3 engine ID changed

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0282

User Action:

Information only; no action is required.

- **FQXSPSE4065I: SFTP [arg1] by user [arg2] from [arg3] at IP address [arg4].**

A user enables and disables SFTP service

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0283

User Action:

Information only; no action is required.

- **FQXSPSE4066I: Security mode is modified from [arg1] to [arg2] by user [arg3] from [arg4] at IP address [arg5].**

Security mode modified by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0284

User Action:

Information only; no action is required.

- **FQXSPSE4067I: User [arg1] accessible interfaces is set to [arg2][arg3][arg4][arg5][arg6] by user [arg7] from [arg8] at IP address [arg9].**

User account accessible interfaces assigned by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0285

User Action:

Information only; no action is required.

- **FQXSPSE4068I: Security: Userid: [arg1] using [arg2] had [arg3] login failures from Redfish client at IP address [arg4].**

This message is for the use case where a user has failed to log in to a Management Controller from Redfish.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Remote Login
SNMP Trap ID: 30
CIM Prefix: IMM CIM ID: 0289

User Action:

Information only; no action is required.

- **FQXSPSE4069I: LDAP set by user [arg1]: RootDN=[arg2], UIDSearchAttribute=[arg3], BindingMethod=[arg4], TargetName=[arg5], GroupFilter=[arg6], GroupAttribute=[arg7], LoginAttribute=[arg8].**

A user configured an LDAP Miscellaneous setting

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0290

User Action:

Information only; no action is required.

- **FQXSPSE4070I: Lockdown mode is [arg1] by user [arg2] from [arg3] at IP address [arg4].**

A user enables or disables Lockdown mode

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other

SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0291

User Action:

Information only; no action is required.

- **FQXSPSE4071I: Chassis Intrusion detection is [arg1] by user [arg2] from [arg3] at IP address [arg4].**

A user enables or disables Chassis Intrusion detection

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0292

User Action:

Information only; no action is required.

- **FQXSPSE4072I: Random SED AK is regenerated by user [arg1] from [arg2] at IP address [arg3].**

A user regenerates a random SED AK

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0294

User Action:

Information only; no action is required.

- **FQXSPSE4073I: Motion detection is [arg1] by user [arg2] from [arg3] at IP address [arg4].**

Motion detection is enabled or disabled by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0295

User Action:

Information only; no action is required.

- **FQXSPSE4074I: Security mode downgrades because the XCC2 Platinum Upgrade key is expired or deleted.**

This message is for the use case where security mode downgrades because XCC2 Platinum Upgrade key is expired or deleted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other

SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0300

User Action:

Information only; no action is required.

- **FQXSPSE4075I: [arg1] by KCS to allow secure boot to be enabled by user [arg2] from [arg3] at IP address [arg4].**

Allow Secure boot to be enabled over KCS

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0310

User Action:

Information only; no action is required.

- **FQXSPSE4076I: [arg1] by KCS to allow secure boot to be disabled by user [arg2] from [arg3] at IP address [arg4].**

Allow Secure boot to be disabled over KCS

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0311

User Action:

Information only; no action is required.

- **FQXSPSE4077I: Bluetooth button on front panel is [arg1] on server [arg2] by user [arg3] from [arg4] at IP address [arg5].**

Bluetooth button on front panel is enabled/disabled by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0314

User Action:

Information only; no action is required.

- **FQXSPSE4078I: Bluetooth is [arg1] by pressing bluetooth button on front panel.**

Bluetooth is enabled/disabled by pressing bluetooth button on front panel

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other

SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0315

User Action:

Information only; no action is required.

- **FQXSPSE4079I: The Operator role is [arg1] to contain Remote Console Access permission by user [arg2] from [arg3] at IP address [arg4].**

Update privilege to enable/disable Operator to access Remote Console

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0322

User Action:

Information only; no action is required.

- **FQXSPSE4080I: The user [arg1] attempts to clear CMOS from [arg2] at IP address [arg4].**

User attempts to clear CMOS

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0323

User Action:

Information only; no action is required.

- **FQXSPSE4081I: BMC returns the valid local cached key to UEFI for SED drives.**

This message is for the use case where BMC returns the local cached key to UEFI for SED drives.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0327

User Action:

Information only; no action is required.

- **FQXSPSE4082I: Remote key management server is unaccessible.**

This message is for the use case where remote key management server is unaccessible.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0330

User Action:

Information only; no action is required.

- **FQXSPSE4083I: The local cached key has expired and destroyed it.**

This message is for the use case where the local cached key has expired and destroyed it.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0331

User Action:

Information only; no action is required.

- **FQXSPSE4084I: Periodic connection to remote key management server succeeded.**

This message is for the use case where the remote key management server poll function has succeeded.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0332

User Action:

Information only; no action is required.

- **FQXSPSE4085I: Periodic connection to remote key management server failed.**

This message is for the use case where the remote key management server poll function has failed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0333

User Action:

Information only; no action is required.

- **FQXSPSE4088I: The chassis care-taker node ID is changed from [arg1] to [arg2].**

This message is for the use case where chassis caretaker node is changed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0336

User Action:

Information only; no action is required.

- **FQXSPSE4089I: The chassis node with node ID [arg1] is inserted.**

This message is for the use case where node is inserted into the chassis.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0337

User Action:

Information only; no action is required.

- **FQXSPSE4090I: The chassis node with node ID [arg1] is removed.**

This message is for the use case where node is removed from the chassis.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0338

User Action:

Information only; no action is required.

- **FQXSPSE4091I: SNMPv2 [arg1] set by user [arg2]: Name=[arg3], AccessType=[arg4], Address=[arg5].**

A user changed the SNMP community string

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0339

User Action:

Information only; no action is required.

- **FQXSPSE4092I: SNMPv1 [arg1] set by user [arg2]: Name=[arg3], AccessType=[arg4].**

A user changed the SNMPv1 community name

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0345

User Action:

Information only; no action is required.

- **FQXSPSE4093I: SNMPv1 [arg1] set by user [arg2]: address=[arg3].**

A user changed the SNMPv1 community address

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0346

User Action:

Information only; no action is required.

- **FQXSPSE4094I: SNMPv2 [arg1] set by user [arg2]: Name=[arg3], AccessType=[arg4].**

A user changed the SNMPv2 community name

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0347

User Action:

Information only; no action is required.

- **FQXSPSE4095I: SNMPv2 [arg1] set by user [arg2]: address=[arg3].**

A user changed the SNMPv1 community address

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0348

User Action:

Information only; no action is required.

- **FQXSPSR0001N: Sensor [SensorElementName] has transitioned to non-recoverable from a less severe state.**

This message is for the use case when an implementation has detected a Sensor transitioned to non-recoverable from less severe.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Hard Disk drive
SNMP Trap ID: 5
CIM Prefix: PLAT CIM ID: 0524

User Action:

Using XCC web or LSA or Storcli to check the status of every virtual disk on your system, resolve the problem on the problematic virtual disk(s).

- **FQXSPSR2001I: Sensor [SensorElementName] has deasserted the transition to non-recoverable from a less severe state.**

This message is for the use case when an implementation has detected that the Sensor transition to non-recoverable from less severe has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Hard Disk drive
SNMP Trap ID: 5
CIM Prefix: PLAT CIM ID: 0525

User Action:

Information only; no action is required

- **FQXSPSS4000I: Management Controller Test Alert Generated by [arg1].**

This message is for the use case where a user has generated a Test Alert.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0040

User Action:

Information only; no action is required.

- **FQXSPSS4001I: Server General Settings set by user [arg1]: Name=[arg2], Contact=[arg3], Location=[arg4], Room=[arg5], RackID=[arg6], Rack U-position=[arg7], Address=[arg8].**

A user configured the Location setting

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0080

User Action:

Information only; no action is required.

- **FQXSPSS4002I: License key for [arg1] added by user [arg2].**

A user installs License Key

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0096

User Action:

Information only; no action is required.

- **FQXSPSS4003I: License key for [arg1] removed by user [arg2].**

A user removes a License Key

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0097

User Action:

Information only; no action is required.

- **FQXSPSS4004I: Test Call Home Generated by user [arg1].**

Test Call Home generated by user.

Severity: Info
Serviceable: No
Automatically notify Support: Yes
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0134

User Action:

Information only; no action is required.

- **FQXSPSS4005I: Manual Call Home by user [arg1]: [arg2].**

Manual Call Home by user.

Severity: Info
Serviceable: No
Automatically notify Support: Yes
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0135

User Action:

Information only; no action is required.

- **FQXSPSS4006I: Call Home to [arg1] failed to complete: [arg2].**

Call Home failed to complete.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0195

User Action:

Information only; no action is required.

- **FQXSPSS4007I: The BMC functionality tier is changed from [arg1] to [arg2].**

Tier Change

Severity: Info
Serviceable: No
Automatically notify Support: No

Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0222

User Action:

Information only; no action is required.

- **FQXSPSS4008I: The [arg1] setting has been changed to [arg2] by user [arg3].**

The setting has been changed by user

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0225

User Action:

Information only; no action is required.

- **FQXSPSS4009I: System enters LXPM maintenance mode.**

The system enters maintenance mode

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0226

User Action:

Information only; no action is required.

- **FQXSPSS4010I: Test Audit Log generated by user [arg1].**

This message is for the use case where OS Crash Video Capture Failed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0237

User Action:

Information only; no action is required.

- **FQXSPSS4011I: Fan speed boost setting is changed from [arg1] to [arg2].**

The setting of fan speed boost is changed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0254

User Action:

Information only; no action is required.

- **FQXSPTR4000I: Management Controller [arg1] clock has been set from NTP server [arg2].**

This message is for the use case where a Management Controller clock has been set from the Network Time Protocol server.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0033

User Action:

Complete the following steps until the problem is solved:

1. Make sure that the certificate that you are importing is correct.
2. Try to import the certificate again.

- **FQXSPTR4001I: Date and Time set by user [arg1]: Date=[arg2], Time=[arg3], DST Auto-adjust=[arg4], Timezone=[arg5].**

A user configured the Date and Time settings

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0079

User Action:

Information only; no action is required.

- **FQXSPTR4002I: Synchronize time setting by user [arg1]: Mode=Sync with NTP Server, NTPServerHost1=[arg2]:[arg3],NTPServerHost2=[arg4]:[arg5],NTPServerHost3=[arg6]:[arg7], NTPServerHost4=[arg8]:[arg9],NTPUpdateFrequency=[arg10].**

A user configured the Date and Time synchronize settings

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0085

User Action:

Information only; no action is required.

- **FQXSPTR4003I: Synchronize time setting by user [arg1]: Mode=Sync with server clock.**

A user configured the Date and Time synchronize settings

Severity: Info
Serviceable: No
Automatically notify Support: No

Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0224

User Action:

Information only; no action is required.

- **FQXSPUN0009G: Sensor [SensorElementName] has asserted.**

This message is for the use case when an implementation has detected a Sensor has asserted.

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0508

User Action:

Reboot the system. If the problem still exist, press F1 or use LXPM to do XCC FW update.

- **FQXSPUN0017I: Sensor [SensorElementName] has transitioned to normal state.**

This message is for the use case when an implementation has detected a Sensor transition to the normal state.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0518

User Action:

Information only; no action is required

- **FQXSPUN0018J: Sensor [SensorElementName] has transitioned from normal to non-critical state.**

This message is for the use case when an implementation has detected a Sensor transitioned to non-critical from normal.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0520

User Action:

Please check event log of XClarity Controller to investigate the identified device for enhancement.

- **FQXSPUN0019M: Sensor [SensorElementName] has transitioned to critical from a less severe state.**

This message is for the use case when an implementation has detected a Sensor transitioned to critical from less severe.

Severity: Error
Serviceable: Yes

Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0522

User Action:

Complete the following steps:

1. Please check XCC web GUI to see the identified error.
2. Check system event log to fix the error.
3. If the problem still exist, please contact local service.

- **FQXSPUN0023N: Sensor [SensorElementName] has transitioned to non-recoverable.**

This message is for the use case when an implementation has detected a Sensor transitioned to non-recoverable.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0530

User Action:

Complete the following steps:

1. Check the Lenovo support site for an applicable service bulletin or firmware update that applies to this error.
2. Reboot the system.
3. If the error continues, replace the system-board assembly (see hardware maintenance manual).

- **FQXSPUN0026I: Device [LogicalDeviceElementName] has been added.**

This message is for the use case when an implementation has detected a Device was inserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0536

User Action:

Information only; no action is required

- **FQXSPUN0048I: The RAID controller in PCI slot [arg1] in optimal status.**

This message is for the use case when an implementation has detected a Sensor transition to the normal state.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0518

User Action:

Information only; no action is required

- **FQXSPUN0056I: Sensor [SensorElementName] has deasserted.**

This message is for the use case when an implementation has detected a Sensor has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0509

User Action:

Information only; no action is required

- **FQXSPUN0058J: The remaining life for [arg1] is lower than the threshold [arg2].**

This message is for the use case when an implementation has detected the remaining life of any one of the SSDs in the system is lower than the defined threshold.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0520

User Action:

Please notice the identified component life might be end.

- **FQXSPUN0059J: Sensor [SensorElementName] has transitioned from normal to warning state.**

This message is for the use case when an implementation has detected a Sensor transitioned to non-critical from normal.

Severity: Warning
Serviceable: Yes
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0520

User Action:

Do an AC cycle and check whether the problem persists. If yes, collect service data logs and contact Lenovo Support.

- **FQXSPUN0060G: Sensor [SensorElementName] has asserted.**

This message is for the use case when an implementation has detected a Sensor has asserted.

Severity: Warning
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0508

User Action:

Collect service data logs and contact Lenovo Support.

- **FQXSPUN2009I: Sensor [SensorElementName] has deasserted.**

This message is for the use case when an implementation has detected a Sensor has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0509

User Action:

Information only; no action is required

- **FQXSPUN2012I: Sensor [SensorElementName] has deasserted.**

This message is for the use case when an implementation has detected a Sensor has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0509

User Action:

Information only; no action is required

- **FQXSPUN2018I: Sensor [SensorElementName] has deasserted the transition from normal to non-critical state.**

This message is for the use case when an implementation has detected that a Sensor has deasserted a transition to non-critical from normal.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0521

User Action:

Information only; no action is required

- **FQXSPUN2019I: Sensor [SensorElementName] has transitioned to a less severe state from critical.**

This message is for the use case when an implementation has detected a Sensor transition to less severe from critical.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0523

User Action:

Information only; no action is required

- **FQXSPUN2023I: Sensor [SensorElementName] has deasserted the transition to non-recoverable.**

This message is for the use case when an implementation has detected that the Sensor transition to non-recoverable has deasserted.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0531

User Action:

Information only; no action is required

- **FQXSPUN2049I: The RAID controller in PCI slot [arg1] is no longer in warning status.**

This message is for the use case when an implementation has detected that a Sensor has deasserted a transition to non-critical from normal.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0521

User Action:

Information only; no action is required.

- **FQXSPUN2050I: The RAID controller in PCI slot [arg1] is no longer in critical status.**

This message is for the use case when an implementation has detected a Sensor transition to less severe from critical.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0523

User Action:

Information only; no action is required

- **FQXSPUN2058I: The remaining life for all SSDs is above threshold [arg1].**

This message is for the use case when an implementation has detected that the remaining life for all SSDs is above threshold.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: Warning - Other
SNMP Trap ID: 60
CIM Prefix: PLAT CIM ID: 0521

User Action:

Please monitor SSD life in normal status.

- **FQXSPUP0002I: A firmware or software change occurred on system [ComputerSystemElementName].**

This message is for the use case when an implementation has detected that the Firmware or Software Changed.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0438

User Action:

Information only; no action is required

- **FQXSPUP0007L: Invalid or Unsupported firmware or software was detected on system [ComputerSystemElementName].**

This message is for the use case when an implementation has detected an Invalid/Unsupported Firmware/Software Version.

Severity: Error
Serviceable: Yes
Automatically notify Support: No
Alert Category: Critical - Other
SNMP Trap ID: 50
CIM Prefix: PLAT CIM ID: 0446

User Action:

Reflash or update XCC firmware

- **FQXSPUP4000I: Please ensure that the Management Controller [arg1] is flashed with the correct firmware. The Management Controller is unable to match its firmware to the server.**

This message is for the use case where a Management Controller firmware version does not match the server.

Severity: Error
Serviceable: No
Automatically notify Support: No
Alert Category: System - other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0031

User Action:

Complete the following steps until the problem is solved:

1. Update the BMC firmware.
2. NOTE: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
3. If problem persists, collect Service Data log.
4. Contact Lenovo Support.

- **FQXSPUP4001: Flash of [arg1] from [arg2] succeeded for user [arg3] .**

This message is for the use case where a user has successfully flashed the firmware component (MC Main Application, MC Boot ROM, BIOS, Diagnostics, System Power Backplane, Remote Expansion Enclosure Power Backplane, Integrated System Management).

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0035

User Action:

Information only; no action is required.

- **FQXSPUP4002: Flash of [arg1] from [arg2] failed for user [arg3].**

This message is for the use case where a user has not flashed the firmware component from the interface and IP address due to a failure.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0036

User Action:

Information only; no action is required.

- **FQXSPUP4003: [arg1] firmware mismatch internal to system [arg2]. Please attempt to flash the [arg3] firmware.**

This message is for the use case where a specific type of firmware mismatch has been detected.

Severity: Error
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0042

User Action:

Complete the following steps until the problem is solved:

1. AC cycle the system.
2. Reflash XCC/BMC firmware to the latest version.
3. NOTE: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
4. If problem persists, collect Service Data log.
5. Contact Lenovo Support.

- **FQXSPUP4004: XCC firmware mismatch between nodes/servers [arg1] and [arg2]. Please attempt to flash the XCC firmware to the same level on all nodes/servers.**

A mismatch of XCC firmware has been detected between nodes/servers

Severity: Error
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0132

User Action:

Complete the following steps until the problem is solved:

1. Reflash XCC/BMC firmware to the latest version on all servers.
 2. NOTE: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
 3. If problem persists, collect Service Data log.
 4. Contact Lenovo Support.
- **FQXSPUP4005I: FPGA firmware mismatch between nodes/servers [arg1] and [arg2]. Please attempt to flash the FPGA firmware to the same level on all nodes/servers.**

A mismatch of FPGA firmware has been detected between nodes/servers

Severity: Error
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0133

User Action:

Complete the following steps until the problem is solved:

1. Reflash XCC/BMC firmware to the latest version on all servers.
 2. NOTE: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
 3. If problem persists, collect Service Data log.
 4. Contact Lenovo Support.
- **FQXSPUP4006I: Auto promote primary XCC to backup is [arg1] by user [arg2] from [arg3] at IP address [arg4].**

Auto promote primary XCC to backup is enabled or disabled.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0281

User Action:

Information only; no action is required.

- **FQXSPUP4007I: Violation access to XCC SPI flash is detected and isolated.**

This message is for the use case where violation access to XCC SPI flash is detected and isolated.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0298

User Action:

Information only; no action is required.

- **FQXSPUP4008I: Violation access to UEFI SPI flash is detected and isolated.**

This message is for the use case where violation access to UEFI SPI flash is detected and isolated.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0299

User Action:

Information only; no action is required.

- **FQXSPUP4009I: Please ensure that the system is flashed with the correct [arg1] firmware. The Management Controller is unable to match the firmware to the server.**

This message is for the use case where a firmware version does not match the server.

Severity: Error
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0324

User Action:

Information only; no action is required.

- **FQXSPUP4010I: Flash [arg1] of [arg2] from [arg3] succeeded for user [arg4] .**

This message is for the use case where a user has successfully flashed the firmware component (MC Main Application, MC Boot ROM, BIOS, Diagnostics, System Power Backplane, Remote Expansion Enclosure Power Backplane, Integrated System Management).

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0325

User Action:

Information only; no action is required.

- **FQXSPUP4011I: Flash [arg1] of [arg2] from [arg3] failed for user [arg4].**

This message is for the use case where a user has not flashed the firmware component from the interface and IP address due to a failure.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: IMM CIM ID: 0326

User Action:

Information only; no action is required.

- **FQXSPWD0000I: Watchdog Timer expired for [WatchdogElementName].**

This message is for the use case when an implementation has detected a Watchdog Timer Expired.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0368

User Action:

Information only; no action is required

- **FQXSPWD0001I: Reboot of system [ComputerSystemElementName] initiated by watchdog [WatchdogElementName].**

This message is for the use case when an implementation has detected a Reboot by a Watchdog occurred.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0370

User Action:

Information only; no action is required

- **FQXSPWD0002I: Powering off system [ComputerSystemElementName] initiated by watchdog [WatchdogElementName].**

This message is for the use case when an implementation has detected a Poweroff by Watchdog has occurred.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0372

User Action:

Information only; no action is required

- **FQXSPWD0003I: Power cycle of system [ComputerSystemElementName] initiated by watchdog [WatchdogElementName].**

This message is for the use case when an implementation has detected a Power Cycle by Watchdog occurred.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0374

User Action:

Information only; no action is required

- **FQXSPWD0004I: Watchdog Timer interrupt occurred for [WatchdogElementName].**

This message is for the use case when an implementation has detected a Watchdog Timer interrupt occurred.

Severity: Info
Serviceable: No
Automatically notify Support: No
Alert Category: System - Other
SNMP Trap ID: 22
CIM Prefix: PLAT CIM ID: 0376

User Action:

Information only; no action is required

Chapter 3. UEFI events

UEFI error messages can be generated when the server starts up (POST) or while the server is running. UEFI error messages are logged in the Lenovo XClarity Controller event log in the server.

For each event code, the following fields are displayed:

Event identifier

An identifier that uniquely identifies an event.

Event description

The logged message string that appears for an event.

Explanation

Provides additional information to explain why the event occurred.

Severity

An indication of the level of concern for the condition. The severity is abbreviated in the event log to the first character. The following severities can be displayed:

- **Informational.** The event was recorded for audit purposes, usually a user action or a change of states that is normal behavior.
- **Warning.** The event is not as severe as an error, but if possible, the condition should be corrected before it becomes an error. It might also be a condition that requires additional monitoring or maintenance.
- **Error.** The event is a failure or critical condition that impairs service or an expected function.

User Action

Indicates what actions you should perform to solve the event. Perform the steps listed in this section in the order shown until the problem is solved. If you cannot solve the problem after performing all steps, contact Lenovo Support.

UEFI events organized by severity

The following table lists all UEFI events, organized by severity (Information, Error, and Warning).

Table 3. Events organized by severity

| Event ID | Message String | Severity |
|--------------|--|---------------|
| FQXSFI00005I | An intra-board UPI has been disabled on the link between processor [arg1] port [arg2] and processor [arg3]port [arg4] because of UPI topology downgrade. | Informational |
| FQXSFI00006I | An inter-board UPI has been disabled on the link between processor [arg1] port [arg2] and processor [arg3]port [arg4] because of UPI topology downgrade. | Informational |
| FQXSFI00021I | PCIe DPC software triggering occurred in physical [arg1] number [arg2]. | Informational |
| FQXSFMA0001I | DIMM [arg1] Disable has been recovered. [arg2] | Informational |
| FQXSFMA0002I | The uncorrectable memory error state has been cleared. | Informational |

Table 3. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXSFMA0006I | [arg1] DIMM [arg2] has been detected, the DIMM serial number is [arg3]. | Informational |
| FQXSFMA0008I | DIMM [arg1] POST memory test failure has been recovered. [arg2] | Informational |
| FQXSFMA0009I | Invalid memory configuration for Mirror Mode has been recovered. | Informational |
| FQXSFMA0026I | DIMM [arg1] Self-healing, attempt post package repair (PPR) succeeded. [arg2] | Informational |
| FQXSFMA0027I | Invalid memory configuration (unsupported DIMM Population) recovered. | Informational |
| FQXSFMA0029I | The PFA of DIMM [arg1] has been deasserted after applying PPR for this DIMM. [arg2] | Informational |
| FQXSFMA0052I | DIMM [arg1] has been disabled due to the error on DIMM [arg2].[arg3] | Informational |
| FQXSFMA0053I | DIMM [arg1] re-enabled due to memory module combination updating. | Informational |
| FQXSFMA0056I | Uncorrected memory error occurred on DIMM [arg1] has been deasserted after performing post package repair. DIMM identifier is [arg2]. | Informational |
| FQXSFMA0063I | A correctable memory error handled by ADDDC on DIMM [arg1]. DIMM identifier is [arg2]. | Informational |
| FQXSFMA0065I | Multi-bit CE of DIMM [arg1] has been deasserted after performing post package repair. DIMM identifier is [arg2]. | Informational |
| FQXSFMA0067I | Errors per row counter threshold limit exceeded on DIMM [arg1] has been deasserted after performing post package repair. DIMM identifier is [arg2]. | Informational |
| FQXSFMA0079I | NVRAM [arg1] corruption detected and recovered. | Informational |
| FQXSFP4034I | TPM Firmware recovery is finished, rebooting system to take effect. | Informational |
| FQXSFP4038I | TPM Firmware recovery successful. | Informational |
| FQXSFP4041I | TPM Firmware update is in progress. Please DO NOT power off or reset system. | Informational |
| FQXSFP4042I | TPM Firmware update is finished, rebooting system to take effect. | Informational |
| FQXSFP4044I | The current TPM firmware version could not support TPM version toggling. | Informational |
| FQXSFP4059I | User requested to skip freezing lock of AHCI-attached SATA drives. System UEFI accepted the request and will execute prior to OS boot. | Informational |
| FQXSFP4060I | Skipped freezing lock of AHCI-attached SATA drives. | Informational |
| FQXSFP4061I | Restored default locking behavior of AHCI-attached SATA drives. | Informational |
| FQXSFP4062I | CPU debugging is deactivated. | Informational |
| FQXSFP4080I | Host Power-On password has been changed. | Informational |
| FQXSFP4081I | Host Power-On password has been cleared. | Informational |
| FQXSFP4082I | Host Admin password has been changed. | Informational |

Table 3. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|--|---------------|
| FQXSFP4083I | Host Admin password has been cleared. | Informational |
| FQXSFSR0002I | [arg1] GPT corruption recovered, DiskGUID: [arg2] | Informational |
| FQXSFSR0003I | Boot OS successfully. | Informational |
| FQXSFIO0008M | An intra-board UPI dynamic link width reduction has been detected on the link between processor [arg1] port [arg2] and processor [arg3] port [arg4]. | Warning |
| FQXSFIO0009M | An inter-board UPI dynamic link width reduction has been detected on the link between processor [arg1] port [arg2] and processor [arg3] port [arg4]. | Warning |
| FQXSFIO0021J | PCIe Error Recovery has occurred in physical [arg1] number [arg2]. The [arg3] may not operate correctly. | Warning |
| FQXSFIO0022J | PCIe Link Width has degraded from [arg1] to [arg2] in physical [arg3] number [arg4]. | Warning |
| FQXSFIO0023J | PCIe Link Speed has degraded from [arg1] to [arg2] in physical [arg3] number [arg4]. | Warning |
| FQXSFIO0024I | An error has been detected by the IEH on processor [arg1]. The type of IEH is [arg2]. The index of the IEH is [arg3]. The value of lehErrorStatus register is [arg4]. Please check error logs for additional downstream device error data. | Warning |
| FQXSFIO0025I | An error has been detected by the IIO on processor [arg1]. The index of the IIO stack is [arg2]. The type of IIO Internal Error is [arg3]. Please check error logs for additional downstream device error data. | Warning |
| FQXSFIO0036G | PCIe Correctable Error Threshold limit has been exceeded at Segment 0x[arg1] Bus 0x[arg2] Device 0x[arg3] Function 0x[arg4]. The Vendor ID for the device is 0x[arg5] and the Device ID is 0x[arg6]. The physical [arg7] number is [arg8]. | Warning |
| FQXSFIO0041J | PCIe Leaky Bucket Event : [arg1] occurred at Segment [arg2] Bus [arg3] Device [arg4] Function [arg5]. The physical [arg6] number is [arg7]. | Warning |
| FQXSFMA0026G | Multi-bit CE occurred on DIMM [arg1], need to restart the system for DIMM Self-healing to attempt post package repair (PPR).[arg2] | Warning |
| FQXSFMA0027G | Multi-bit CE occurred on DIMM [arg1] different rows.[arg2] | Warning |
| FQXSFMA0027M | DIMM [arg1] Self-healing, attempt post package repair (PPR) failed. [arg2] | Warning |
| FQXSFMA0028M | DIMM [arg1] Self-healing, attempt post package repair (PPR) exceeded DIMM level threshold. [arg2] | Warning |
| FQXSFMA0029G | DIMM [arg1] Self-healing, attempt post package repair (PPR) failed: Insufficient rows available for repair. [arg2] | Warning |
| FQXSFMA0047M | SPD CRC checking failed on DIMM [arg1]. [arg2] | Warning |
| FQXSFMA0048M | DIMM [arg1] disabled due to PMIC failure during POST, DIMM identifier is [arg2]. | Warning |
| FQXSFMA0049M | DIMM [arg1] disabled due to memory module power failure. DIMM [arg2] detected and good, DIMM [arg3] not detected. | Warning |

Table 3. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|--|----------|
| FQXSFMA0050G | DRAM PFA threshold limit exceeded on DIMM [arg1] sub-channel [arg2] Rank [arg3] DRAM [arg4], DIMM identifier is [arg5]. | Warning |
| FQXSFMA0053G | An uncorrected memory error has been recovered by mirror on DIMM [arg1] at address [arg2].[arg3] | Warning |
| FQXSFMA0053M | DIMM [arg1] not defective but disabled due to unsupported memory module combination on CPU [arg2]. | Warning |
| FQXSFMA0054G | Mirror failover operation was successful. DIMM [arg1] has failed over to the mirrored DIMM [arg2].[arg3] | Warning |
| FQXSFMA0055G | Mirror failover operation is skipped and page retire for uncorrectable error (at [arg1]) on DIMM [arg2] is reported to OS. [arg3] | Warning |
| FQXSFMA0057G | Page Retire PFA Threshold limit exceeded on DIMM [arg1] at address [arg2].[arg3] [arg4] | Warning |
| FQXSFMA0064M | DIMM [arg1] disabled due to memory module power failure. DIMM [arg2] detected and good. | Warning |
| FQXSFMA0067G | Errors per row counter threshold limit exceeded on DIMM [arg1] sub-channel [arg2] Rank [arg3] DRAM [arg4], need to restart the system for DIMM Self-healing to attempt post package repair (PPR), DIMM identifier is [arg5]. | Warning |
| FQXSFMA0076M | DIMM [arg1] is not supported, DIMM identifier is [arg2]. | Warning |
| FQXSFPU0023G | Secure Boot Image Verification Failure Warning. | Warning |
| FQXSFPU0039G | 3rd party option rom of PCIe physical [arg1] number [arg2] failed secure boot verification. | Warning |
| FQXSFPU0040G | Secure boot keys were reset to factory default. | Warning |
| FQXSFPU0062F | System uncorrected recoverable error happened in Processor [arg1] Core [arg2] MC bank [arg3] with MC Status [arg4], MC Address [arg5], and MC Misc [arg6]. | Warning |
| FQXSFPU4033F | TPM Firmware recovery is in progress. Please DO NOT power off or reset system. | Warning |
| FQXSFPU4035M | TPM Firmware recovery failed. TPM chip may be damaged. | Warning |
| FQXSFPU4040M | TPM selftest has failed. | Warning |
| FQXSFPU4050G | Failed to update TPM Firmware. | Warning |
| FQXSFPU4051G | Undefined TPM_POLICY found. | Warning |
| FQXSFPU4052G | TPM_POLICY is not locked. | Warning |
| FQXSFPU4053G | System TPM_POLICY does not match the planar. | Warning |
| FQXSFPU4062M | CPU debugging is activated. | Warning |
| FQXSFSR0001M | [arg1] GPT corruption detected, DiskGUID: [arg2] | Warning |
| FQXSFSR0003G | The number of boot attempts has been exceeded. No bootable device found. | Warning |
| FQXSFIO0005M | An intra-board UPI failure has been detected on the link between processor [arg1] port [arg2] and processor [arg3] port [arg4]. | Error |

Table 3. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|--|----------|
| FQXSFIO0006M | An inter-board UPI failure has been detected on the link between processor [arg1] port [arg2] and processor [arg3] port [arg4]. | Error |
| FQXSFIO0013M | New added PCI device(s) at [arg1] triggered [arg2] out of resource. | Error |
| FQXSFIO0024M | An error has been detected by the IEH on processor [arg1]. The type of IEH is [arg2]. The index of the IEH is [arg3]. The value of lehErrorStatus register is [arg4]. Please check error logs for additional downstream device error data. | Error |
| FQXSFIO0025M | An error has been detected by the IIO on processor [arg1]. The index of the IIO stack is [arg2]. The type of IIO Internal Error is [arg3]. Please check error logs for additional downstream device error data. | Error |
| FQXSFIO0035M | An Uncorrectable PCIe Error has Occurred at Segment 0x[arg1] Bus 0x[arg2] Device 0x[arg3] Function 0x[arg4]. The Vendor ID for the device is 0x[arg5] and the Device ID is 0x[arg6]. The physical [arg7] number is [arg8]. | Error |
| FQXSFMA0001M | DIMM [arg1] has been disabled due to an error detected during POST. [arg2] | Error |
| FQXSFMA0002M | An uncorrectable memory error has been detected on DIMM [arg1] at address [arg2]. [arg3] | Error |
| FQXSFMA0004N | No system memory has been detected. | Error |
| FQXSFMA0008M | DIMM [arg1] has failed the POST memory test. [arg2] | Error |
| FQXSFMA0009K | Invalid memory configuration for Mirror Mode. Please correct memory configuration. | Error |
| FQXSFMA0027K | Invalid memory configuration (Unsupported DIMM Population) detected. Please verify memory configuration is valid. | Error |
| FQXSFMA0056M | An uncorrected recoverable memory error has been detected on DIMM [arg1] at address [arg2].[arg3] [arg4] | Error |
| FQXSFMA0066M | Memory address parity error occurred on CPU [arg1] channel [arg2] with DIMM [arg3]. | Error |
| FQXSFMA0077N | SMBus failure encountered when accessing to the SPD of DIMM [arg1]. | Error |
| FQXSFMA0078N | System encountered fatal error [arg1] during memory initialization. | Error |
| FQXSFMA0082M | An uncorrected recoverable memory error has been detected on DIMM [arg1] and post package repair (PPR) recorded. | Error |
| FQXSFMA0083M | An uncorrected recoverable memory error has been detected on DIMM [arg1] and post package repair (PPR) recording failed. | Error |
| FQXSFPU0016N | A processor within the system has failed the BIST. | Error |
| FQXSFPU0018N | CATERR(IERR) has asserted on processor [arg1]. | Error |
| FQXSFPU0019N | An uncorrectable error has been detected on processor [arg1]. | Error |
| FQXSFPU0027N | System uncorrectable error has occurred on Processor [arg1] Core [arg2] MC bank [arg3] with MC Status [arg4], MC Address [arg5], and MC Misc [arg6]. | Error |
| FQXSFPU0030N | A firmware fault has been detected in the UEFI image. | Error |

Table 3. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|----------|
| FQXSFPJ0035N | A 3-strike timeout has occurred on processor [arg1]. | Error |
| FQXSFPJ4056M | TPM card is changed, need install back the original TPM card which shipped with the system. | Error |
| FQXSFSM0008M | Boot permission timeout detected. | Error |

List of UEFI events

This section lists all messages that can be sent from UEFI.

- **FQXSFI0005I: An intra-board UPI has been disabled on the link between processor [arg1] port [arg2] and processor [arg3] port [arg4] because of UPI topology downgrade.**

This message is used to report UPI failure.

Severity: Info

Parameters:

[arg1] Socket number, 1-based

[arg2] Port Number

[arg3] Socket number, 1-based

[arg4] Port Number

User Action:

Complete the following steps:

1. This event should be followed by a recent FQXSFI0005M / FQXSFI0006M event denoting some UPI links failure which caused UPI topology downgrade.
2. Solve the event FQXSFI0005M / FQXSFI0006M at first, then this event should be solved automatically.
3. If no recent or after fixing FQXSFI0005M / FQXSFI0006M event, this event still persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFI0005M: An intra-board UPI failure has been detected on the link between processor [arg1] port [arg2] and processor [arg3] port [arg4].**

This message is used to report UPI failure.

Severity: Error

Parameters:

[arg1] Socket number, 1-based

[arg2] Port Number

[arg3] Socket number, 1-based

[arg4] Port Number

User Action:

Complete the following steps:

1. Power off the system and remove A/C power.

2. Restore A/C power and power on the system.
3. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFI0006I: An inter-board UPI has been disabled on the link between processor [arg1] port [arg2] and processor [arg3] port [arg4] because of UPI topology downgrade.**

This message is used to report UPI failure.

Severity: Info

Parameters:

[arg1] Socket number, 1-based

[arg2] Port Number

[arg3] Socket number, 1-based

[arg4] Port Number

User Action:

Complete the following steps:

1. This event should be followed by a recent FQXSFI0005M / FQXSFI0006M event denoting some UPI links failure which caused UPI topology downgrade.
2. Solve the event FQXSFI0005M / FQXSFI0006M at first, then this event should be solved automatically.
3. If no recent or after fixing FQXSFI0005M / FQXSFI0006M event, this event still persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFI0006M: An inter-board UPI failure has been detected on the link between processor [arg1] port [arg2] and processor [arg3] port [arg4].**

This message is used to report UPI failure.

Severity: Error

Parameters:

[arg1] Socket number, 1-based

[arg2] Port Number

[arg3] Socket number, 1-based

[arg4] Port Number

User Action:

Complete the following steps:

1. Power off the system and remove A/C power.
2. Restore A/C power and power on the system.
3. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFI0008M: An intra-board UPI dynamic link width reduction has been detected on the link between processor [arg1] port [arg2] and processor [arg3] port [arg4].**

This message is used to report UPI dynamic link width reduction.

Severity: Warning

Parameters:

[arg1] Socket number, 1-based

[arg2] Port Number

[arg3] Socket number, 1-based

[arg4] Port Number

User Action:

Complete the following steps:

1. Power off the system and remove A/C power.
2. Restore A/C power and power on the system.
3. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFIO0009M: An inter-board UPI dynamic link width reduction has been detected on the link between processor *[arg1]* port *[arg2]* and processor *[arg3]* port *[arg4]*.**

This message is used to report UPI dynamic link width reduction.

Severity: Warning

Parameters:

[arg1] Socket number, 1-based

[arg2] Port Number

[arg3] Socket number, 1-based

[arg4] Port Number

User Action:

Complete the following steps:

1. Power off the system and remove A/C power.
2. Restore A/C power and power on the system.
3. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFIO0013M: New added PCI device(s) at *[arg1]* triggered *[arg2]* out of resource.**

This message is reported when PCI resources are insufficient.

Severity: Error

Parameters:

[arg1] String, dynamic string to mention potential PCIe slot(s) or NVMe drive bay(s). i.e. Slot(Bay) 1/2/4/5... etc.

[arg2] Bus /Legacy IO / 32-bit MMIO / 64-bit MMIO

User Action:

Complete the following steps:

1. If resource insufficient is 32-bit MMIO, change System Settings->Devices and I/O Ports->MM Config Base to a lower value such as from 3GB to 2GB or 2GB to 1GB.
2. If resource insufficient is 64-bit MMIO, change the following settings to disable these two features if not needed. System Settings->Devices and I/O Ports-> SRIOV (or Resizable BAR) to disabled.
3. Check Lenovo Support site for any applicable service bulletin or UEFI or adapter firmware update that applies to this error.
4. If the problem persists, remove new added devices from system slots or disable them.
5. if do need to enable all new added devices, collect Service Data logs, and contact Lenovo Support.

- **FQXSFIO0021I: PCIe DPC software triggering occurred in physical [arg1] number [arg2].**

This message is reported when PCIE DPC software was triggered.

Severity: Info

Parameters:

[arg1] Slot/bay

[arg2] Slot number /bay number

User Action:

Information only; no action is required.

- **FQXSFIO0021J: PCIe Error Recovery has occurred in physical [arg1] number [arg2]. The [arg3] may not operate correctly.**

This message is reported when PCIe error was recovered.

Severity: Warning

Parameters:

[arg1] Slot/bay

[arg2] Instance number

[arg3] Adapter/disk

User Action:

Complete the following steps:

1. Check the log for a separate error related to an associated PCIe device or NVME disk and resolve that error.
2. Check the Lenovo Support site for an applicable service bulletin or firmware update for the system or adapter that applies to this error.
3. Check the system spec to make sure that the PCIe device or NVME disk is installed in the compatible PCIe slot or bay and a compatible cable is used. If not, performance of this device might be impacted.
4. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFIO0022J: PCIe Link Width has degraded from [arg1] to [arg2] in physical [arg3] number [arg4].**

This message is reported when PCIe Link Width was degraded.

Severity: Warning

Parameters:

[arg1] x16/x8/x4/x2/x1

[arg2] x16/x8/x4/x2/x1

[arg3] Slot/bay

[arg4] Instance number

User Action:

Complete the following steps:

1. Check the log for a separate error related to an associated PCIe device or NVME disk and resolve that error.
2. Check the Lenovo Support site for an applicable service bulletin or firmware update for the system or adapter that applies to this error.
3. Check the system spec to make sure that the PCIe device or NVME disk is installed in the compatible PCIe slot or bay and a compatible cable is used. If not, performance of this device might be impacted.
4. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFI0023J: PCIe Link Speed has degraded from [arg1] to [arg2] in physical [arg3] number [arg4].**

This message is reported when PCIe Link Speed was degraded.

Severity: Warning

Parameters:

[arg1] 32 GT/s / 16 GT/s / 8.0 GT/s / 5.0 GT/s / 2.5 GT/s

[arg2] 32 GT/s / 16 GT/s / 8.0 GT/s / 5.0 GT/s / 2.5 GT/s

[arg3] Slot/bay

[arg4] Instance number

User Action:

Complete the following steps:

1. Check the log for a separate error related to an associated PCIe device or NVME disk and resolve that error.
2. Check the Lenovo Support site for an applicable service bulletin or firmware update for the system or adapter that applies to this error.
3. Check the system spec to make sure that the PCIe device or NVME disk is installed in the compatible PCIe slot or bay and a compatible cable is used. If not, performance of this device might be impacted.
4. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFI0024I: An error has been detected by the IEH on processor [arg1]. The type of IEH is [arg2]. The index of the IEH is [arg3]. The value of lehErrorStatus register is [arg4]. Please check error logs for additional downstream device error data.**

This message is reported when an error has been detected by the IEH.

Severity: Warning

Parameters:

[arg1] Processor number, 1 - based

[arg2] IEH type

[arg3] IEH index

[arg4] lehErrorStatus register value

User Action:

Complete the following steps:

1. Check Lenovo Support site for an applicable service bulletin or firmware update for the system or adapter that applies to this error.
2. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFI0024M: An error has been detected by the IEH on processor [arg1]. The type of IEH is [arg2]. The index of the IEH is [arg3]. The value of lehErrorStatus register is [arg4]. Please check error logs for additional downstream device error data.**

This message is reported when an error has been detected by the IEH.

Severity: Error

Parameters:

[arg1] Processor number, 1 - based

[arg2] IEH type

[arg3] IEH index

[arg4] lehErrorStatus register value

User Action:

Complete the following steps:

1. Check Lenovo Support site for an applicable service bulletin or firmware update for the system or adapter that applies to this error.
2. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFI0025I: An error has been detected by the IIO on processor [arg1]. The index of the IIO stack is [arg2]. The type of IIO Internal Error is [arg3]. Please check error logs for additional downstream device error data.**

This message is reported when an error has been detected by the IIO.

Severity: Warning

Parameters:

[arg1] Processor number, 1 - based

[arg2] IIO stack index

[arg3] VTD error / CBDMA error / M2PCIE error / IRP error / Ring error / ITC error /OTC error

User Action:

Complete the following steps:

1. Check Lenovo Support site for an applicable service bulletin or firmware update for the system or adapter that applies to this error.
 2. If the problem persists, collect Service Data logs and contact Lenovo Support.
- **FQXSFI0025M: An error has been detected by the IIO on processor [arg1]. The index of the IIO stack is [arg2]. The type of IIO Internal Error is [arg3]. Please check error logs for additional downstream device error data.**

This message is reported when an error has been detected by the IIO.

Severity: Error

Parameters:

[arg1] Processor number, 1 - based

[arg2] IIO stack index

[arg3] VTD error / CBDMA error / M2PCIE error / IRP error / Ring error / ITC error /OTC error

User Action:

Complete the following steps:

1. Check Lenovo Support site for an applicable service bulletin or firmware update for the system or adapter that applies to this error.
 2. If the problem persists, collect Service Data logs and contact Lenovo Support.
- **FQXSFI0035M: An Uncorrectable PCIe Error has Occurred at Segment 0x[arg1] Bus 0x[arg2] Device 0x[arg3] Function 0x[arg4]. The Vendor ID for the device is 0x[arg5] and the Device ID is 0x[arg6]. The physical [arg7] number is [arg8].**

This message is reported when an uncorrectable PCIe Error has occurred at PCIE device.

Severity: Error

Parameters:

[arg1] Segment

[arg2] Bus

[arg3] Device

[arg4] Function

[arg5] VID

[arg6] DID

[arg7] Slot/Bay

[arg8] Instance number

User Action:

Complete the following steps:

1. Check Lenovo Support site for an applicable device driver, firmware update, version of service information for this product or other information that applies to this error. Load new device driver and any required firmware updates.
2. If this device and/or any attached cables were recently installed, moved, serviced or upgraded.

- a. Reseat adapter or disk and any attached cables.
 - b. Reload Device Driver.
 - c. If device is not recognized, reconfiguring slot to Gen1 or Gen2 may be required. Gen1/Gen2 settings can be configured via F1 Setup -> System Settings -> Devices and I/O Ports ->PCIe Gen1/Gen2/Gen3 Speed Selection, or the OneCLI utility.
 - d. If a PCIe error has also been reported on a second slot within the same node, ensure steps a, b, and c above are also performed for that adapter or disk before proceeding.
3. If the problem persists, collect Service Data logs and contact Lenovo Support.
- **FQXSFIO0036G: PCIe Correctable Error Threshold limit has been exceeded at Segment 0x[arg1] Bus 0x[arg2] Device 0x[arg3] Function 0x[arg4]. The Vendor ID for the device is 0x[arg5] and the Device ID is 0x[arg6]. The physical [arg7] number is [arg8].**

This message is reported when PCIe Correctable Error Threshold limit has been exceeded at PCIE device.

Severity: Warning

Parameters:

[arg1] Segment

[arg2] Bus

[arg3] Device

[arg4] Function

[arg5] VID

[arg6] DID

[arg7] Slot/Bay

[arg8] Instance number

User Action:

Complete the following steps:

1. Check Lenovo Support site for an applicable device driver, firmware update, version of service information for this product or other information that applies to this error. Load new device driver and any required firmware updates.
 2. If this device and/or any attached cables were recently installed, moved, serviced or upgraded.
 - a. Reseat adapter or disk and any attached cables.
 - b. Reload Device Driver.
 - c. If device is not recognized, reconfiguring slot to lower speed may be required. Gen1/Gen2/Gen3 settings can be configured via F1 Setup -> System Settings -> Devices and I/O Ports ->PCIe Gen1/Gen2/Gen3/Gen4 Speed Selection, or the OneCLI utility.
 - d. If a PCIe error has also been reported on a second slot within the same node, please ensure steps a, b, and c above are also performed for that adapter or disk before proceeding.
 3. If the problem persists, collect Service Data logs and contact Lenovo Support.
- **FQXSFIO0041J: PCIe Leaky Bucket Event : [arg1] occurred at Segment [arg2] Bus [arg3] Device [arg4] Function [arg5]. The physical [arg6] number is [arg7].**

This message is reported when PCIe Leaky Bucket Event has occurred at PCIE device.

Severity: Warning

Parameters:

[arg1] PCIe Leaky Bucket Event

[arg2] Segment

[arg3] Bus

[arg4] Device

[arg5] Function

[arg6] Slot/Bay

[arg7] Instance number

User Action:

Complete the following steps:

1. Check the log for a separate error related to an associated PCIe device or NVME disk and resolve that error.
2. Check the Lenovo Support site for an applicable service bulletin or firmware update for the system or adapter that applies to this error.
3. Check the system spec to make sure that the PCIe device or NVME disk is installed in the compatible PCIe slot or bay and a compatible cable is used. If not, performance of this device might be impacted.
4. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFMA0001I: DIMM [arg1] Disable has been recovered. [arg2]**

This message is reported when a DIMM has been re-enabled.

Severity: Info

Parameters:

[arg1] DIMM slot silk label

[arg2] DIMM identifier consists of S/N, FRU and UDI, e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Information only; no action is required.

- **FQXSFMA0001M: DIMM [arg1] has been disabled due to an error detected during POST. [arg2]**

This message is reported when a DIMM has been disabled.

Severity: Error

Parameters:

[arg1] DIMM slot silk label

[arg2] DIMM identifier consists of S/N, FRU and UDI, e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Reseat the affected DIMM (Note: The event Log might contain a recent FQXSFMA0011I event denoting detected change in DIMM population that could be related to this problem.)
2. Boot to F1 setup and enable the DIMM (For AMD, do not need to enable DIMM in Setup). Reboot the system.
3. Update UEFI firmware to the latest version.

4. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFMA0002I: The uncorrectable memory error state has been cleared.**

This message is reported when uncorrectable memory error state has been cleared.

Severity: Info

User Action:

Information only; no action is required.

- **FQXSFMA0002M: An uncorrectable memory error has been detected on DIMM [arg1] at address [arg2]. [arg3]**

This message is reported when an uncorrectable memory error state has been cleared.

Severity: Error

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] Address of the system where the error occurred

[arg3] DIMM identifier consists of S/N, FRU and UDI, e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Check Lenovo Support site for an applicable service bulletin or firmware update that applies to this memory error.
2. Reseat the affected DIMM (Note: The event Log might contain a recent FQXSFMA0011I event denoting detected change in DIMM population that could be related to this problem.)
3. Swap the affected DIMM to another known good slot and verify whether the issue still be observed or not.
4. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFMA0004N: No system memory has been detected.**

This message is reported when no memory detected.

Severity: Error

User Action:

Complete the following steps:

1. Ensure one or more supported DIMMs are installed in the correct population sequence.
2. If the system has light-path then check for any lit DIMM-connector LEDs, and if found, reseat those DIMMs. Alternatively (i.e. if light path is not available) the same can be accomplished using XCC GUI.
3. Swap DIMMs between slots when more than one DIMM is available in the system.
4. If the DIMMs have been upgraded just prior to the issue than update uEFI using alternate or minimal configuration.
5. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFMA0006I: [arg1] DIMM [arg2] has been detected, the DIMM serial number is [arg3].**

This message is reported when DIMM has invalid UDI.

Severity: Info

Parameters:

[arg1] Unqualified/Non Lenovo

[arg2] DIMM Silk Label, 1-based

[arg3] DIMM serial number.

User Action:

Complete the following steps:

1. If this information event is logged in the XCC event log, the server does have unqualified memory installed.
2. The memory installed may not be covered under warranty.
3. Without qualified memory, speeds supported above industry standards will not be enabled.
4. Contact your Local Sales Representative or Authorized Business Partner to order qualified memory to replace the unqualified DIMM(s).
5. After you install qualified memory and power up the server, check to ensure this informational event is not logged again.
6. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFMA0008I: DIMM [arg1] POST memory test failure has been recovered. [arg2]**

This message is reported when DIMM has been recovered from training error.

Severity: Info

Parameters:

[arg1] DIMM slot silk label

[arg2] DIMM identifier consists of S/N, FRU and UDI, e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Information only; no action is required.

- **FQXSFMA0008M: DIMM [arg1] has failed the POST memory test. [arg2]**

This message is reported when DIMM has been disabled by training error.

Severity: Error

Parameters:

[arg1] DIMM slot silk label

[arg2] DIMM identifier consists of S/N, FRU and UDI, e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. If the DIMM configuration was changed prior to this failure verify that the DIMMs are installed in the correct population sequence.

2. RESEAT the DIMM that failed POST memory test and the DIMMs on adjacent slots if populated. Boot to F1 setup and enable the DIMM. Reboot the system.
3. Swap the DIMM from failure location to another known good location to see if the failure follow the DIMM or DIMM slot.
4. If this problem was encountered during an XCC / UEFI update process:
 - a. Power cycle the system by removing power for a few seconds.
 - b. Clear CMOS settings by removing battery for a few seconds.
5. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFMA0009I: Invalid memory configuration for Mirror Mode has been recovered.**

This message is reported when Mirror mode is applied successfully.

Severity: Info

User Action:

Information only; no action is required.

- **FQXSFMA0009K: Invalid memory configuration for Mirror Mode. Please correct memory configuration.**

This message is reported when Mirror mode failed to be applied with current configuration.

Severity: Error

User Action:

Complete the following steps:

1. Ensure that all the DIMMs are enabled and functional by booting to F1 Setup or in XCC web .If any DIMMs are non-functional address that first.
2. Make sure that the DIMM connectors are correctly populated for mirroring mode, according to the service information for this product.
3. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFMA0026G: Multi-bit CE occurred on DIMM [arg1], need to restart the system for DIMM Self-healing to attempt post package repair (PPR).[arg2]**

This message is reported when the error of the same row has already occurred a number of times up to the row threshold.

Severity: Warning

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Restart the system to allow for DIMM Self-healing to attempt hard post package repair (PPR) and confirm that event ID FQXSFMA0026I was recorded.
2. If the problem persists or if PPR attempt failed due to event ID FQXSFMA0027M or FQXSFMA0028M, collect Service Data logs and contact Lenovo Support.

- **FQXSFMA0026I: DIMM [arg1] Self-healing, attempt post package repair (PPR) succeeded. [arg2]**

This message is reported when DIMM attempt post package repair (PPR) succeeded.

Severity: Info

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Information only; no action is required.
 2. Note: Post Package Repair (PPR) – is the memory Self-Healing process of substituting the access to a bad cell or address row with a spare row within the DRAM device.
 - a. Soft Post Package Repair (sPPR) - repairs a row for the current boot cycle. If system power is removed or the system is rebooted (reset), the DIMM reverts to its original state.
 - b. Hard Post Package Repair (hPPR) – permanently repairs a row.
- **FQXSFMA0027G: Multi-bit CE occurred on DIMM [arg1] different rows.[arg2]**

This message is reported when the error of the same bank has already occurred a number of times up to the bank threshold.

Severity: Warning

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Run advance memory test using the XClarity Provisioning Manager. Click Diagnostics > Run Diagnostics > Memory Test > Advanced Memory Test to repair the DIMM.
 2. Reseat the failing DIMM identified by LightPath and/or event log entry.
 3. If the problem persists, collect Service Data logs, and contact Lenovo Support.
- **FQXSFMA0027I: Invalid memory configuration (unsupported DIMM Population) recovered.**

The SEL is reported when all DIMM recovered form POR errors.

Severity: Info

User Action:

Information only; no action is required.

- **FQXSFMA0027K: Invalid memory configuration (Unsupported DIMM Population) detected. Please verify memory configuration is valid.**

This message is reported when unsupported DIMM population is detected.

Severity: Error

User Action:

Complete the following steps:

1. This event could follow an uncorrectable memory error or failed memory test. Check the log and resolve that event first. DIMMs disabled by other errors or actions could cause this event.

2. Ensure that the DIMMs are populated in the correct sequence, according to the service information for this product.
3. If the DIMMs are present and properly installed, check for any lit DIMM connector error LEDs and reseat those DIMMs. Check logs for memory diagnostic codes.
4. Reset UEFI to the default settings.
5. If the problem persists, update the UEFI firmware.
6. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFMA0027M: DIMM [arg1] Self-healing, attempt post package repair (PPR) failed. [arg2]**

This message is reported when DIMM attempt post package repair (PPR) failed.

Severity: Warning

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] DIMM identifier consists of S/N, FRU and UDI, e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Reseat the affected DIMM (Note: The event Log might contain a recent FQXSFMA0011I event denoting detected change in DIMM population that could be related to this problem.)
2. Boot to F1 setup and enable the DIMM. Reboot the system.
3. Update UEFI firmware to the latest version.
4. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFMA0028M: DIMM [arg1] Self-healing, attempt post package repair (PPR) exceeded DIMM level threshold. [arg2]**

This message is reported when DIMM attempt post package repair (PPR) exceeded DIMM level threshold.

Severity: Warning

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] DIMM identifier consists of S/N, FRU and UDI, e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Reseat the affected DIMM (Note: The event Log might contain a recent FQXSFMA0011I event denoting detected change in DIMM population that could be related to this problem.)
2. Boot to F1 setup and re-enable the DIMM. Reboot the system.
3. Update UEFI firmware to the latest version.
4. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFMA0029G: DIMM [arg1] Self-healing, attempt post package repair (PPR) failed: Insufficient rows available for repair. [arg2]**

This message is reported when DIMM attempt post package repair (PPR) failed due to Insufficient rows.

Severity: Warning

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Collect Service Data logs and contact Lenovo Support.

- **FQXSFMA0029I: The PFA of DIMM [arg1] has been deasserted after applying PPR for this DIMM. [arg2]**

This message is reported to deassert the PFA sensor of the DIMM repaired by PPR.

Severity: Info

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Information only; no action is required.

- **FQXSFMA0047M: SPD CRC checking failed on DIMM [arg1]. [arg2]**

This message is reported when DIMM SPD CRC check failed.

Severity: Warning

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Perform a virtual reseal or AC cycle the server.
2. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFMA0048M: DIMM [arg1] disabled due to PMIC failure during POST, DIMM identifier is [arg2].**

This message is reported when Error logged in PMIC registers.

Severity: Warning

Parameters:

[arg1] Disabled DIMM

[arg2] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Power off the system and remove A/C power.
2. Reseat the DIMM in the slot specified by the event message.
3. Restore A/C power and power on the system.
4. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFMA0049M: DIMM *[arg1]* disabled due to memory module power failure. DIMM *[arg2]* detected and good, DIMM *[arg3]* not detected.**

This message is reported when DDRIO power failure detected.

Severity: Warning

Parameters:

[arg1] Disabled slot

[arg2] Disabled but detected DIMMs

[arg3] Disabled but not detected DIMMs e.g. "DIMM 1,2 disabled due to memory module power failure. DIMM 2 detected and good, DIMM 1 not detected."

User Action:

Complete the following steps:

1. Power off the system and remove A/C power.
2. Check DIMM slots specified in the message. If DIMM installed but undetected, remove it and then restore the A/C power and power on the system.
3. If all DIMMs detected or error persists after removing undetected DIMMs, reseat all the DIMMs in the slots specified by the message and then restore the A/C power and power on the system.
4. If the problem persists or undetected DIMM needs to be replaced, collect Service Data logs and contact Lenovo Support.

- **FQXSFMA0050G: DRAM PFA threshold limit exceeded on DIMM *[arg1]* sub-channel *[arg2]* Rank *[arg3]* DRAM *[arg4]*, DIMM identifier is *[arg5]*.**

This message is reported when DIMM has a lot of single bit ECC error.

Severity: Warning

Parameters:

[arg1] DIMM Silk Label

[arg2] Sub Channel

[arg3] Rank number

[arg4] Device number (0&1&2)

[arg5] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Power off the system and remove the A/C power.
2. Reseat the affected DIMM.

3. Restore the A/C power and power on the system.
 4. Check Lenovo support site for an applicable service bulletin or firmware update that applies to this memory error.
 5. Run advance memory test using the XClarity Provisioning Manager. Click Diagnostics > Run Diagnostics > Memory Test > Advanced Memory Test to repair the DIMM.
 6. If the problem persists, collect Service Data logs and contact Lenovo Support.
- **FQXSFMA0052I: DIMM [arg1] has been disabled due to the error on DIMM [arg2].[arg3]**

This message is reported when DDRIO power failure detected.

Severity: Info

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] DIMM Silk Label, 1-based

[arg3] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Power off the system and remove A/C power.
2. Reseat the DIMM in the slot specified by the event message.
3. Restore A/C power and power on the system.
4. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFMA0053G: An uncorrected memory error has been recovered by mirror on DIMM [arg1] at address [arg2].[arg3]**

This message is reported when an uncorrected memory error has been recovered by mirror.

Severity: Warning

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] Address of the system where the error occurred

[arg3] DIMM identifier consists of S/N, FRU and UDI, e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Keep the system running until next planned maintenance window.
2. During planned maintenance, power off the system and remove A/C power.
3. Reseat the failing DIMM identified by LightPath and/or event log entry.
4. Restore A/C power and power on the system.
5. Check Lenovo Support site for an applicable service bulletin or firmware update that applies to this memory error.
6. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFMA0053I: DIMM [arg1] re-enabled due to memory module combination updating.**

This message is reported when DIMM recovered from population downgrade error.

Severity: Info

Parameters:

[arg1] DIMM Silk Label list. (eg1. 1 2. 1 & 2 & 3).

User Action:

Information only; no action is required.

- **FQXSFMA0053M: DIMM [arg1] not defective but disabled due to unsupported memory module combination on CPU [arg2].**

This message is reported when DIMM disabled due to population downgrade.

Severity: Warning

Parameters:

[arg1] DIMM Silk Label list. (eg1. 1 2. 1 & 2 & 3).

[arg2] CPU label

User Action:

Complete the following steps:

1. This event could follow an uncorrectable memory error or failed memory test. Check the log and resolve that event first. DIMMs disabled by other errors or actions could cause this event.
 2. Ensure that the DIMM are populated in the correct sequence, according to the service information for this product.
 3. If DIMMs are present and properly installed, check for any lit DIMM connector error LEDs, and if found, reseal those DIMMs, then check logs for memory diagnostic codes.
 4. Reset UEFI to default settings.
 5. If problem persists, update UEFI firmware.
 6. If the problem persists, collect Service Data logs and contact Lenovo Support.
- **FQXSFMA0054G: Mirror failover operation was successful. DIMM [arg1] has failed over to the mirrored DIMM [arg2].[arg3]**

This message is reported when the persistent UE occurred in the DIMM that triggered Mirror failover.

Severity: Warning

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] DIMM Silk Label, 1-based

[arg3] DIMM identifier consists of S/N, FRU and UDI, e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Keep the system running until next planned maintenance window.
2. During planned maintenance, power off the system and remove A/C power.
3. Reseat the failing DIMM identified by LightPath and/or event log entry.
4. Restore A/C power and power on the system.

5. Check Lenovo Support site for an applicable service bulletin or firmware update that applies to this memory error.
 6. If the problem persists, collect Service Data logs and contact Lenovo Support.
- **FQXSFMA0055G: Mirror failover operation is skipped and page retire for uncorrectable error (at [arg1]) on DIMM [arg2] is reported to OS. [arg3]**

This message is reported when the persistent UE occurred in the DIMM that triggered Mirror failover.

Severity: Warning

Parameters:

[arg1] Physical address

[arg2] DIMM Silk Label, 1-based

[arg3] DIMM identifier consists of S/N, FRU and UDI, e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Power off the system and remove A/C power.
 2. Reseat the failing DIMM identified by LightPath and/or event log entry.
 3. Restore A/C power and power on the system.
 4. Check Lenovo Support site for an applicable service bulletin or firmware update that applies to this memory error.
 5. If the problem persists, collect Service Data logs and contact Lenovo Support.
- **FQXSFMA0056I: Uncorrected memory error occurred on DIMM [arg1] has been deasserted after performing post package repair. DIMM identifier is [arg2].**

This message is reported when an uncorrected recoverable memory error has been recovered.

Severity: Info

Parameters:

[arg1] DIMM Silk Label

[arg2] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Information only; no action is required.

- **FQXSFMA0056M: An uncorrected recoverable memory error has been detected on DIMM [arg1] at address [arg2].[arg3] [arg4]**

This message is reported when an uncorrected recoverable memory error has been detected.

Severity: Error

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] Address of the system where the error occurred

[arg3] DIMM identifier consists of S/N, FRU and UDI, e.g. "739E68ED-VC10 FRU 0123456"

[arg4] Indicate the error is UCNA or SRAR, "-T0" for UCNA, "-T1" for SRAR

User Action:

1. Power off the system and remove A/C power.
 2. Reseat the failing DIMM identified by LightPath and/or event log entry
 3. Restore A/C power and power on the system.
 4. Check Lenovo Support site for an applicable service bulletin or firmware update that applies to this memory error.
 5. Run advance memory test using the XClarity Provisioning Manager. Click Diagnostics > Run Diagnostics > Memory Test > Advanced Memory Test to repair the DIMM.
 6. If the problem persists, collect Service Data logs and contact Lenovo Support.
- **FQXSFMA0057G: Page Retire PFA Threshold limit exceeded on DIMM [arg1] at address [arg2]. [arg3] [arg4]**

This message is reported when PFA threshold limit exceeded.

Severity: Warning

Parameters:

[arg1] DIMM Silk Label, 1-based

[arg2] Address of the system where error occurred

[arg3] Page retire PFA policy reached, "-T0";"-T1";"-T2";"-T3";"-T4".

[arg4] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Power off the system and remove the A/C power.
 2. Reseat the affected DIMM.
 3. Restore the A/C power and power on the system.
 4. Check Lenovo support site for an applicable service bulletin or firmware update that applies to this memory error.
 5. Run advance memory test using the XClarity Provisioning Manager. Click Diagnostics > Run Diagnostics > Memory Test > Advanced Memory Test to repair the DIMM.
 6. If the problem persists, collect Service Data logs and contact Lenovo Support.
- **FQXSFMA0063I: A correctable memory error handled by ADDDC on DIMM [arg1]. DIMM identifier is [arg2].**

This message is reported when a correctable memory error was handled by ADDDC.

Severity: Info

Parameters:

[arg1] DIMM Silk Label

[arg2] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Information only; no action is required.

- **FQXSFMA0064M: DIMM [arg1] disabled due to memory module power failure. DIMM [arg2] detected and good.**

This message is reported when DDRIO power failure detected.

Severity: Warning

Parameters:

[arg1] Disabled slot

[arg2] Disabled but detected DIMMs e.g. “DIMM 3,4 disabled due to memory module power failure. DIMM 3,4 detected and good.”

User Action:

Complete the following steps:

1. Power off the system and remove A/C power.
 2. Check DIMM slots specified in the message. If DIMM installed but undetected, remove it and then restore the A/C power and power on the system.
 3. If all DIMMs detected or error persists after removing undetected DIMMs, reseal all the DIMMs in the slots specified by the message and then restore the A/C power and power on the system.
 4. If the problem persists or undetected DIMM needs to be replaced, collect Service Data logs and contact Lenovo Support.
- **FQXSFMA0065I: Multi-bit CE of DIMM [arg1] has been deasserted after performing post package repair. DIMM identifier is [arg2].**

This message is reported when PPR is applied successfully.

Severity: Info

Parameters:

[arg1] DIMM Silk Label

[arg2] DIMM info (S/N, FRU and UDI)

User Action:

Information only; no action is required.

- **FQXSFMA0066M: Memory address parity error occurred on CPU [arg1] channel [arg2] with DIMM [arg3].**

This message is reported when DDR parity link error occurred.

Severity: Error

Parameters:

[arg1] Socket number, 1-based

[arg2] Channel on socket

[arg3] DIMM silk label 1, silk label 2 (All DIMMs on the failed channel)

User Action:

Complete the following steps:

1. Power off the system and remove A/C power.
2. Reseat the DIMMs specified by the event message.
3. Restore A/C power and power on the system.
4. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFMA0067G: Errors per row counter threshold limit exceeded on DIMM [arg1] sub-channel [arg2] Rank [arg3] DRAM [arg4], need to restart the system for DIMM Self-healing to attempt post package repair (PPR), DIMM identifier is [arg5].**

This message is reported when a row has a lot of single bit error on DIMM.

Severity: Warning

Parameters:

[arg1] DIMM Silk Label

[arg2] Sub Channel

[arg3] Rank number

[arg5] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Restart the system to allow for DIMM Self-healing to attempt hard post package repair (PPR) and confirm that event ID FQXSFMA0026I was recorded.
 2. Run advance memory test using the XClarity Provisioning Manager. Click Diagnostics > Run Diagnostics > Memory Test > Advanced Memory Test to repair the DIMM.
 3. If the problem persists or if PPR attempt failed due to event ID FQXSFMA0027M or FQXSFMA0028M, collect Service Data logs and contact Lenovo Support.
- **FQXSFMA0067I: Errors per row counter threshold limit exceeded on DIMM [arg1] has been deasserted after performing post package repair. DIMM identifier is [arg2].**

This message is reported when Errors per row counter threshold limit exceeded on DIMM.

Severity: Info

Parameters:

[arg1] DIMM Silk Label

[arg2] DIMM info (S/N, FRU and UDI.), e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Information only; no action is required.

- **FQXSFMA0076M: DIMM [arg1] is not supported, DIMM identifier is [arg2].**

This message is reported when unsupported DIMM has been detected.

Severity: Warning

Parameters:

[arg1] DIMM slot silk label

[arg2] DIMM identifier consists of S/N, FRU and UDI, e.g. "739E68ED-VC10 FRU 0123456"

User Action:

Complete the following steps:

1. Power off the system and remove A/C power.
2. Check user manual for supported DIMM types and replace the DIMM specified by the message with a supported one.
3. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFMA0077N: SMBus failure encountered when accessing to the SPD of DIMM [arg1].**

This message is reported when access DIMM SPD failed cause of SMBUS failure.

Severity: Error

Parameters:

[arg1] DIMM slot silk label

User Action:

Complete the following steps:

1. Power off the system and remove A/C power.
2. Reseat the DIMM in the slot specified by the event message.
3. Restore A/C power and power on the system.
4. If the problem persists, collect support log and contact Lenovo Support.

- **FQXSFMA0078N: System encountered fatal error [arg1] during memory initialization.**

This message is reported when system encountered fatal error during memory initialization.

Severity: Error

Parameters:

[arg1] Fatal error code, e.g. 0xD802.

User Action:

If you have enabled XCC or LXCA call home, a Lenovo Service personnel will contact you. Otherwise, please collect Debug Log and contact Lenovo Support.

- **FQXSFMA0079I: NVRAM [arg1] corruption detected and recovered.**

The message is reported when variable/FV header corruption happens.

Severity: Info

Parameters:

[arg1] "header" or "variable"

User Action:

Information only; no action is required.

- **FQXSFMA0082M: An uncorrected recoverable memory error has been detected on DIMM [arg1] and post package repair (PPR) recorded.**

This message is reported when UE PPR is recorded.

Severity: Error

Parameters:

[arg1] DIMM Silk Label, 1-based

User Action:

Complete the following steps:

1. Restart the system to attempt PPR.
2. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFMA0083M: An uncorrected recoverable memory error has been detected on DIMM [arg1] and post package repair (PPR) recording failed.**

This message is reported when the recording of UE PRR failed.

Severity: Error

Parameters:

[arg1] DIMM Silk Label, 1-based

User Action:

Complete the following steps:

1. Restart the system to run AMT.
2. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFPU0016N: A processor within the system has failed the BIST.**

This message is reported when a processor within the system has failed the BIST.

Severity: Error

User Action:

Complete the following steps:

1. If the processor or firmware was just updated, check the Lenovo Support site for an applicable service bulletin or firmware update that applies to this processor error.
2. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFPU0018N: CATERR(IERR) has asserted on processor [arg1].**

This is reported when FEH detects CPU IERR.

Severity: Error

Parameters:

[arg1] Socket number, 1-based

User Action:

Complete the following steps:

1. Check Lenovo Support site for an applicable service bulletin or UEFI firmware update that applies to this processor error.
2. Power off the system and remove A/C power.
3. Restore A/C power and power on the system.
4. Determine if there have been recent changes to the hardware, firmware or operating system. Reverse them if possible
5. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFPU0019N: An uncorrectable error has been detected on processor [arg1].**

This is reported when FEH detects CPU MCERR.

Severity: Error

Parameters:

[arg1] Socket number, 1-based.

User Action:

Complete the following steps:

1. Check Lenovo Support site for an applicable service bulletin or UEFI firmware update that applies to this error.
2. Power off the system and remove A/C power.
3. Restore A/C power and power on the system.
4. Determine if there have been recent changes to the hardware, firmware or operating system. Reverse them if possible.
5. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFP0023G: Secure Boot Image Verification Failure Warning.**

Reporting un-trusted boot image when Security Boot is enabled.

Severity: Warning

User Action:

Complete the following steps:

1. It's a security warning message when user want to boot from an unauthorized UEFI image or OS while Secure Boot is enabled and Secure Boot Mode is in User Mode. If customer does not want to boot any unauthorized UEFI image or OS, remove that bootable device.
2. If customer does want to boot this unauthorized UEFI image or OS, there're two ways to allow system boot from this unauthorized image, the first is to disable Secure Boot, the second is to enroll the unauthorized image into DB(Authorized Signature Database).
 - a. Disable Secure Boot: assert Physical Presence and then change Secure Boot Setting to Disable (in F1 Setup -> System Settings -> Security -> Security Boot Configuration -> Security Boot Setting).
 - b. Enroll the unauthorized UEFI Image. assert the Physical Presence and then change Secure Boot Policy to Custom Policy (in Setup -> System Settings -> Security -> Security Boot Configuration -> Security Boot Policy), then enter into "Security Boot Custom Policy" Menu, press the "Enroll Efi Image" button, select the unauthorized UEFI Image in the popup box.
 - c. NOTE: There're two ways to assert Physical Presence:
 - 1) Switch Physical Presence Jumper to ON;
 - 2) If the Physical Presence Policy has been set to enabled (F1 Setup -> System Settings -> Security -> Physical Presence Policy Configuration), user is allowed to assert remote Physical Presence via IPMI tool.)
3. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFP0027N: System uncorrectable error has occurred on Processor [arg1] Core [arg2] MC bank [arg3] with MC Status [arg4], MC Address [arg5], and MC Misc [arg6].**

This message is reported when system uncorrectable error has occurred.

Severity: Error

Parameters:

[arg1] Socket number, 1-based.

[arg2] CoreNumber

[arg3] McBankNumber

[arg4] McaStatus

[arg5] McaAddress

[arg6] McaMisc

User Action:

Complete the following steps:

1. Perform a virtual reseal or AC cycle the server.
2. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFP0030N: A firmware fault has been detected in the UEFI image.**

This message is reported when a firmware fault has been detected in the UEFI image.

Severity: Error

User Action:

Complete the following steps:

1. Check Lenovo Support site for an applicable service bulletin or firmware update that applies to this error.
2. Reflash UEFI image.
3. Undo recent system changes (settings or devices added). Verify that the system boots. Then, re-install options one at a time to locate the problem.
4. If problem persists, save customer's UEFI configurations, then remove and re-install CMOS battery for 30 seconds to clear CMOS contents. If it boots successfully, then restore system settings.
5. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFP0035N: A 3-strike timeout has occurred on processor [arg1].**

This message is reported when FEH detects CPU 3strike error.

Severity: Error

Parameters:

[arg1] Socket number, 1-based

User Action:

Complete the following steps:

1. Check Lenovo Support site for an applicable service bulletin or UEFI firmware update that applies to this error.
2. Power off the system and remove A/C power.
3. Restore A/C power and power on the system.
4. Determine if there have been recent changes to the hardware, firmware or operating system. Reverse them if possible.
5. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFP0039G: 3rd party option rom of PCIe physical [arg1] number [arg2] failed secure boot verification.**

This message is used to report un-trusted image from slot/NVMe when Security Boot is enabled.

Severity: Warning

Parameters:

[arg1] slot/bay

[arg2] slot number/bay number

User Action:

Complete the following steps:

1. It is a security warning message reported when the customer wants to load an unauthorized UEFI option ROM from slot/NVMe bay while Secure Boot is enabled. If the customer does not want to load any unauthorized UEFI option ROM from slot/NVMe bay, there are two ways to disable it:
 - a. Remove the device from slot or bay.
 - b. Disable the UEFI option ROM policy for the failed slot (in F1 Setup -> System Settings -> Devices and I/O Ports -> Enable / Disable UEFI Option ROM(s))
2. If the customer does want to load this unauthorized UEFI option ROM from slot/NVMe bay, disable Secure Boot(in F1 Setup -> System Settings -> Secure Boot).
3. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFPU0040G: Secure boot keys were reset to factory default.**

This message is reported when secure boot keys were reset to factory default.

Severity: Warning

User Action:

Complete the following steps:

1. It is a warning message reported when NVRAM corruption occurs while Secure Boot is enabled.
2. Users need to re-enroll their certification keys.
3. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFPU0062F: System uncorrected recoverable error happened in Processor *[arg1]* Core *[arg2]* MC bank *[arg3]* with MC Status *[arg4]*, MC Address *[arg5]*, and MC Misc *[arg6]*.**

This message is reported when system uncorrected recoverable error happened.

Severity: Warning

Parameters:

[arg1] Socket number, 1-based

[arg2] CoreNumber

[arg3] McBankNumber

[arg4] McaStatus

[arg5] McaAddress

[arg6] McaMisc

User Action:

Complete the following steps:

1. Perform a virtual reseal or AC cycle the server.
2. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFPU4033F: TPM Firmware recovery is in progress. Please DO NOT power off or reset system.**

The Audit log will be reported when TPM firmware is under recovery progress.

Severity: Warning

User Action:

Information only; no action is required.

Note: The system will not respond to power off signal (FQXSFP4034I) while TPM firmware recovery in progress.

- **FQXSFP4034I: TPM Firmware recovery is finished, rebooting system to take effect.**

The Audit log will be reported after TPM Firmware recovery is finished.

Severity: Info

User Action:

Information only; no action is required."

- **FQXSFP4035M: TPM Firmware recovery failed. TPM chip may be damaged.**

The Audit log will be reported when TPM Firmware recovery failed.

Severity: Warning

User Action:

1. Reboot the system.
2. If the error recurs TPM related features will not work.
3. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key."

- **FQXSFP4038I: TPM Firmware recovery successful.**

The Audit log will be reported when TPM Firmware recovery is successful.

Severity: Info

User Action:

Information only; no action is required."

- **FQXSFP4040M: TPM selftest has failed.**

The Audit log will be reported when the TPM selftest fails.

Severity: Warning

User Action:

1. Reboot the system.
2. If the error recurs TPM related features will not work.
3. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key."

- **FQXSFP4041I: TPM Firmware update is in progress. Please DO NOT power off or reset system.**

The Audit log will be reported when TPM Firmware update is in progress.

Severity: Info

User Action:

Information only; no action is required."

- **FQXSFPU4042I: TPM Firmware update is finished, rebooting system to take effect.**

The Audit log will be reported when TPM Firmware update is finished.

Severity: Info

User Action:

Information only; no action is required."

- **FQXSFPU4044I: The current TPM firmware version could not support TPM version toggling.**

The Audit log will be reported when the current TPM firmware version is not valid for toggling.

Severity: Info

User Action:

Information only; no action is required."

- **FQXSFPU4050G: Failed to update TPM Firmware.**

The Audit log will be reported when TPM firmware upgrade is failed.

Severity: Warning

User Action:

1. Clear TPM via TPM operation and retry TPM firmware update by following the instructions in your product user guides. Go to <https://thinksystem.lenovofiles.com/help/topic/com.lenovo.thinksystem.common.nav.doc/portfolio.html> and click your product link. Usually, the TPM update information is located in "System board replacement" section in "Hardware replacement procedures".
2. If the problem persists, collect Service Data logs and contact Lenovo Support. "

- **FQXSFPU4051G: Undefined TPM_POLICY found.**

The Audit log will be reported when the TPM policy is not defined yet.

Severity: Warning

User Action:

Complete the following steps:

1. Reboot the system.
2. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFPU4052G: TPM_POLICY is not locked.**

The Audit log will be reported when TPM policy is not lock yet.

Severity: Warning

User Action:

Complete the following steps:

1. Reboot the system.
2. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFPU4053G: System TPM_POLICY does not match the planar.**

The Audit log will be reported if TPM policy setting is set to disable but TPM device is found on system.

Severity: Warning

User Action:

Complete the following steps:

1. Remove any newly added TPM/TCM card from the planar or re-install the original TPM/TCM card that shipped with the system.
2. Reboot the system.
3. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFP4056M: TPM card is changed, need install back the original TPM card which shipped with the system.**

The Audit log will be reported if NationZ device is removed from system after TPM is bound to system.

Severity: Error

User Action:

Complete the following steps:

1. Re-install the original TCM/TPM card that shipped with the system.
2. Reboot the system.
3. If the problem persists, collect Service Data logs and contact Lenovo Support.

Note: The solution for this error may involve a system board replacement. If TPM encryption has been enabled, back up TPM Encryption Recovery Key.

- **FQXSFP4059I: User requested to skip freezing lock of AHCI-attached SATA drives. System UEFI accepted the request and will execute prior to OS boot.**

This message is reported when system UEFI accepted the request and will execute prior to OS boot.

Severity: Info

User Action:

Complete the following steps:

1. Change SystemOobCustom.SkipAhciFreezeLock from Disable to Enable using OneCLI tool.(use OneCLI command "OneCli config set SystemOobCustom.SkipAhciFreezeLock "Enabled" --imm IMM_USERID:IMM_PASSWORD@IMM_IP --override").
2. Reboot the system into OS.

- **FQXSFP4060I: Skipped freezing lock of AHCI-attached SATA drives.**

This message is reported when freezing lock of AHCI-attached SATA drives have been skipped.

Severity: Info

User Action:

Information only; no action is required.

- **FQXSFP4061I: Restored default locking behavior of AHCI-attached SATA drives.**

This message is reported when default locking behavior of AHCI-attached SATA drives have been restored.

Severity: Info

User Action:

Information only; no action is required.

- **FQXSFP4062I: CPU debugging is deactivated.**

This message is reported when user disabled CPU debugging.

Severity: Info

User Action:

Information only; no action is required.

- **FQXSFPU4062M: CPU debugging is activated.**

This message is reported when user enabled CPU debugging.

Severity: Warning

User Action:

Contact Lenovo Support.

- **FQXSFPU4080I: Host Power-On password has been changed.**

This message is reported when Host Power-On password has been changed.

Severity: Info

User Action:

Information only; no action is required.

- **FQXSFPU4081I: Host Power-On password has been cleared.**

This message is reported when Host Power-On password has been cleared.

Severity: Info

User Action:

Information only; no action is required.

- **FQXSFPU4082I: Host Admin password has been changed.**

This message is reported when Host Admin password has been changed.

Severity: Info

User Action:

Information only; no action is required.

- **FQXSFPU4083I: Host Admin password has been cleared.**

This message is reported when Host Admin password has been cleared.

Severity: Info

User Action:

Information only; no action is required.

- **FQXSFSM0008M: Boot permission timeout detected.**

This message is reported when Boot permission timeout detected.

Severity: Error

User Action:

Complete the following steps:

1. Review XCC logs for communication errors and resolve.
2. AC cycle the system.

3. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFSR0001M: [arg1] GPT corruption detected, DiskGUID: [arg2]**

This message is reported when GPT corruption detected.

Severity: Warning

Parameters:

[arg1] GPT corruption location. "Primary" Only primary GPT partition table corruption. "Backup" Only backup GPT partition table corruption. "Both Primary and Backup" Both GPT partition tables corruption.

[arg2] Disk GUID.

User Action:

Complete the following steps:

1. Remove all the external drive during POST to avoid that this event is triggered by mistake.
2. Check the XCC event log. If this event has a follow up recovery event log, it means that GTP corruption has been recovered successfully. Ignore this event message and do not perform the remaining steps.
3. Back up the data disk.
4. Press F1 Setup->System Settings->Recovery and RAS->Disk GPT Recovery and set the value to "Automatic".
5. Save the settings and restart the system.
6. Boot to F1 setup. The system will automatically try to recover the GPT during the POST.
7. Restart the system.
8. Re-format the LUN or disk and re-install the OS.
9. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFSR0002I: [arg1] GPT corruption recovered, DiskGUID: [arg2]**

This message is reported when GPT corruption repaired.

Severity: Info

Parameters:

[arg1] GPT corruption location. "Primary" Only primary GPT partition table corruption. "Backup" Only backup GPT partition table corruption. "Both Primary and Backup" Both GPT partition tables corruption.

[arg2] Disk GUID

User Action:

Information only; no action is required.

- **FQXSFSR0003G: The number of boot attempts has been exceeded. No bootable device found.**

This message is reported when Boot OS failed more than 50 times.

Severity: Warning

User Action:

Complete the following steps:

1. Remove AC power from the system.
2. Connect at least one bootable device to the system.
3. Connect AC power to the system.

4. Power on system and retry.

5. If the problem persists, collect Service Data logs and contact Lenovo Support.

- **FQXSFSR0003I: Boot OS successfully.**

This message is reported when clear sensor status which previous boot failed more than 50 times when boot OS successfully.

Severity: Info

User Action:

User boot OS successfully.

Chapter 4. XClarity Provisioning Manager events

The following events can be generated by the Lenovo XClarity Provisioning Manager.

For each event code, the following fields are displayed:

Event identifier

An identifier that uniquely identifies an event.

Event description

The logged message string that appears for an event.

Explanation

Provides additional information to explain why the event occurred.

Severity

An indication of the level of concern for the condition. The severity is abbreviated in the event log to the first character. The following severities can be displayed:

- **Informational.** The event was recorded for audit purposes, usually a user action or a change of states that is normal behavior.
- **Warning.** The event is not as severe as an error, but if possible, the condition should be corrected before it becomes an error. It might also be a condition that requires additional monitoring or maintenance.
- **Error.** The event is a failure or critical condition that impairs service or an expected function.

User Action

Indicates what actions you should perform to solve the event. Perform the steps listed in this section in the order shown until the problem is solved. If you cannot solve the problem after performing all steps, contact Lenovo Support.

LXPM events organized by severity

The following table lists all LXPM events, organized by severity (Information, Error, and Warning).

Table 4. Events organized by severity

| Event ID | Message String | Severity |
|--------------|--|---------------|
| FQXPMCL0005I | Start to install OS: [arg1]. | Informational |
| FQXPMCL0006I | Export RAID configuration successfully. | Informational |
| FQXPMCL0007I | Import RAID configuration successfully. | Informational |
| FQXPMCL0008I | Export UEFI settings successfully. | Informational |
| FQXPMCL0009I | Import UEFI settings successfully. | Informational |
| FQXPMCL0010I | Export BMC settings successfully. | Informational |
| FQXPMCL0011I | Import BMC settings successfully. | Informational |
| FQXPMEM0002I | LXPM firmware image found. Starting LXPM. | Informational |
| FQXPMEM0003I | LXPM has exited. Control returned to UEFI. | Informational |

Table 4. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|---|---------------|
| FQXPMEM0004I | Launching diagnostic program. | Informational |
| FQXPMEM0005I | Boot diagnostic program successfully. | Informational |
| FQXPMER0002I | Clearing RAID configuration and internal storage data | Informational |
| FQXPMER0003I | RAID configuration cleared successfully | Informational |
| FQXPMER0004I | Internal storage drives erased successfully | Informational |
| FQXPMER0005I | All system logs cleared successfully | Informational |
| FQXPMER0006I | UEFI factory default settings loaded successfully | Informational |
| FQXPMER0007I | BMC factory default settings loaded successfully | Informational |
| FQXPMNM0002I | Set BMC network parameters to new values. | Informational |
| FQXPMOS0028I | Start to install OS: [arg1]. | Informational |
| FQXPMSR0012I | Change disk drives' state successfully. | Informational |
| FQXPMSR0022I | Create new virtual disk(s) successfully. | Informational |
| FQXPMSR0032I | Removed existing virtual disk(s) successfully. | Informational |
| FQXPMUP0101I | Start to update LXPM. | Informational |
| FQXPMUP0102I | Start to update Window driver. | Informational |
| FQXPMUP0103I | Start to update Linux driver. | Informational |
| FQXPMUP0104I | Start to update UEFI. | Informational |
| FQXPMUP0105I | Start to update BMC. | Informational |
| FQXPMUP0106I | Successfully updated the firmware. | Informational |
| FQXPMVD0003I | Update VPD data successfully. | Informational |
| FQXPMCL0001K | Bootx64.efi is not found. Failed to Boot OS. | Warning |
| FQXPMCL0003K | BMC communication failed: DRIVER Mount Failure. | Warning |
| FQXPMCL0004K | BMC communication succeeded. Volume Name Mismatched. | Warning |
| FQXPMCL0006K | Failed to export RAID configuration. | Warning |
| FQXPMCL0007K | Failed to import RAID configuration. | Warning |
| FQXPMCL0008K | Failed to export UEFI settings. | Warning |
| FQXPMCL0009K | Failed to import UEFI settings. | Warning |
| FQXPMCL0010K | Failed to export BMC settings. | Warning |
| FQXPMCL0011K | Failed import BMC settings. | Warning |
| FQXPMNM0001G | Failed to set new BMC network parameters. | Warning |
| FQXPMOS0001K | Bootx64.efi is not found. Failed to Boot OS. | Warning |
| FQXPMOS0004K | BMC Communication Failed: EMMC2USB Mount Failure. | Warning |
| FQXPMOS0005K | BMC communication failed: DRIVER Mount Failure. | Warning |
| FQXPMOS0006K | BMC communication succeeded. Volume Name Mismatched. | Warning |

Table 4. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|--|----------|
| FQXPMOS0007K | Failed to read License RTF file. | Warning |
| FQXPMOS0008K | Failed to detect any remote OS media for OS installation. | Warning |
| FQXPMSR0001K | Found unsupported RAID adapter. | Warning |
| FQXPMSR0011K | Failed to change disk drives' state. | Warning |
| FQXPMSS0001K | Failed to mount work partition while getting service data. | Warning |
| FQXPMSS0002K | Failed to mount work partition while getting debug log. | Warning |
| FQXPMSS0003K | No service data file created in the work partition | Warning |
| FQXPMSS0004K | No debug log file created in the work partition | Warning |
| FQXPMUP0003K | Unable to obtain the minimum level of UEFI. | Warning |
| FQXPMUP0004K | Unable to obtain the installed version of UEFI. | Warning |
| FQXPMUP0005K | Unable to obtain the installed version of BMC. | Warning |
| FQXPMUP0006K | Unable to obtain the installed version of LXPM. | Warning |
| FQXPMUP0007K | Unable to obtain the installed version of Linux driver. | Warning |
| FQXPMUP0008K | Unable to obtain the installed version of Windows driver. | Warning |
| FQXPMVD0001H | Failed to get VPD data. | Warning |
| FQXPMVD0002H | Failed to update the VPD data. | Warning |
| FQXPMVD0011K | Failed to get the TPM/TPM card/TCM policy status. | Warning |
| FQXPMVD0012K | Failed to set the TPM/TPM card/TCM policy. | Warning |
| FQXPMEM0001M | Unable to locate LXPM firmware image. | Error |
| FQXPMEM0006M | Unable to locate diagnostic firmware image. | Error |
| FQXPMEM0007M | Diagnostic image cannot be launched as "Console Redirection" is enabled. | Error |
| FQXPMEM0008M | Diagnostic image cannot be launched as the image may be corrupt. | Error |
| FQXPMER0002M | Failed to clear RAID configuration. | Error |
| FQXPMER0003M | Failed to erase internal storage drives. | Error |
| FQXPMER0004M | Failed to clear system logs. | Error |
| FQXPMER0005M | Failed to load UEFI factory default settings. | Error |
| FQXPMER0006M | Failed to load XCC factory default settings. | Error |
| FQXPMSD0001M | HDD Test was interrupted by the host with a hardware or software reset. | Error |
| FQXPMSD0002M | A fatal error or unknown test error occurred while the device was executing its self-test. | Error |
| FQXPMSD0003M | Self-test completed having a test element that failed and the test element that failed is not known. | Error |
| FQXPMSD0004M | Self-test completed having the electrical element of the test failed. | Error |

Table 4. Events organized by severity (continued)

| Event ID | Message String | Severity |
|--------------|--|----------|
| FQXPMSD0005M | Self-test completed having the servo (and/or seek) test element of the test failed. | Error |
| FQXPMSD0006M | Self-test completed having the read element of the test failed. | Error |
| FQXPMSD0007M | Hard Drive(s) not found | Error |
| FQXPMSD0008M | UEFI is not ready for LXPM to send command to test hard drive. | Error |
| FQXPMSD0009M | Device error detected when LXPM sent a test command to a hard drive. | Error |
| FQXPMSD0010M | UEFI timed out when LXPM sent a test command to a hard drive. | Error |
| FQXPMSD0011M | The hard drive is not supported by UEFI while LXPM sent a command to test the hard drive. | Error |
| FQXPMSR0021L | Failed to create new virtual disk(s). | Error |
| FQXPMSR0031L | Failed to remove existing virtual disk(s). | Error |
| FQXPMUP0201M | BMC communication failed: EMMC2USB mount failure. Failed to update the firmware. | Error |
| FQXPMUP0202M | Transfer the update package error. Failed to update the firmware. | Error |
| FQXPMUP0203M | BMC communication failed: EMMC2USB unmount failure. Failed to update the firmware. | Error |
| FQXPMUP0204M | BMC communication failed: Execute the update command failure. Failed to update the firmware. | Error |
| FQXPMUP0205M | BMC communication failed: Get the update status failure. Failed to update the firmware. | Error |
| FQXPMUP0206M | The level of the update package is too old. Failed to update the firmware. | Error |
| FQXPMUP0207M | The update package is invalid. Failed to update the firmware. | Error |
| FQXPMUP0208M | Failed to execute the reboot BMC command. | Error |

List of XClarity Provisioning Manager events

This section lists all messages that can be sent from the Lenovo XClarity Provisioning Manager.

- **FQXPML0001K: Bootx64.efi is not found. Failed to Boot OS.**

Severity: Warning

User Action:

1. Restart BMC via supported method and reboot the system.
2. If the problem persists, reflash BMC firmware.
3. Reboot system and retry OS booting.
4. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

5. If the problem persists, contact technical support.

- **FQXPMCL0003K: BMC communication failed: DRIVER Mount Failure.**

Severity: Warning

User Action:

1. Ensure proper operation of the virtual USB connection.
2. Restart BMC via supported method and reboot the system.
3. Reflash BMC firmware.
4. Clone the image over and retry the operation.
5. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

6. If the problem persists, contact technical support.

- **FQXPMCL0004K: BMC communication succeeded. Volume Name Mismatched.**

Severity: Warning

User Action:

1. Restart BMC via supported method and reboot the system.
2. Reflash BMC firmware.
3. Clone the image over and retry the operation.
4. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

5. If the problem persists, contact technical support.

- **FQXPMCL0005I: Start to install OS: [arg1].**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMCL0006I: Export RAID configuration successfully.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMCL0006K: Failed to export RAID configuration.**

Severity: Warning

User Action:

1. Check the following Lenovo Support site for information on supported RAID adapters. <https://serverproven.lenovo.com>
2. Ensure that RAID adapter, LXPM, and UEFI firmware are at the latest levels.
3. Ensure that the state of the RAID adapter and disk drives are normal.
4. Verify proper physical connection of the disk drive, SAS expander (if applicable) and RAID adapter.

5. Reboot the machine and retry the export of the RAID configuration.
6. If the problem persists, contact technical support.

- **FQXPMCL0007I: Import RAID configuration successfully.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMCL0007K: Failed to import RAID configuration.**

Severity: Warning

User Action:

1. Check the following Lenovo Support site for information on supported RAID adapters. <https://serverproven.lenovo.com>
2. Ensure that RAID adapter, LXPM, and UEFI firmware are at the latest levels.
3. Ensure that the state of RAID adapter and disk drives are healthy.
4. Ensure good physical connection between the disk drives and RAID adapter.
5. Ensure that the platform and RAID config is identical to original configuration.
6. Reboot the machine and retry the import of the RAID configuration.
7. If the problem persists, contact technical support.

- **FQXPMCL0008I: Export UEFI settings successfully.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMCL0008K: Failed to export UEFI settings.**

Severity: Warning

User Action:

1. Ensure proper connection to USB/network drive and retry to export UEFI setting.
2. Reboot and try the UEFI setting export again.
3. Reflash UEFI firmware.
4. If the problem persists, contact technical support.

- **FQXPMCL0009I: Import UEFI settings successfully.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMCL0009K: Failed to import UEFI settings.**

Severity: Warning

User Action:

1. Ensure proper connection to USB/network drive and retry the UEFI setting import.

2. Ensure that same system model type to import the UEFI setting and UEFI version should be the same.
3. Reboot and try to import a new clone of the UEFI settings.
4. Reflash UEFI firmware.
5. If the problem persists, contact technical support.

- **FQXPMCL0010I: Export BMC settings successfully.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMCL0010K: Failed to export BMC settings.**

Severity: Warning

User Action:

1. Restart BMC via supported method and reboot the system.
2. Perform AC reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

3. Retry the export of BMC setting.
4. If the problem persists, contact technical support.

- **FQXPMCL0011I: Import BMC settings successfully.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMCL0011K: Failed import BMC settings.**

Severity: Warning

User Action:

1. Ensure BMC version is the same between source and target.
2. Restart BMC via supported method and reboot the system.
3. Perform AC reset or virtual reseal.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

4. Retry the import of BMC setting.
5. If the problem persists, contact technical support.

- **FQXPMEM0001M: Unable to locate LXPM firmware image.**

Severity: Error

User Action:

1. Restart BMC via supported method and reboot the system.
2. Reflash the LXPM.

3. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

4. If the problem persists, contact technical support.

- **FQXPMEM0002I: LXPM firmware image found. Starting LXPM.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMEM0003I: LXPM has exited. Control returned to UEFI.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMEM0004I: Launching diagnostic program.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMEM0005I: Boot diagnostic program successfully.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMEM0006M: Unable to locate diagnostic firmware image.**

Severity: Error

User Action:

1. Restart BMC via supported method and reboot the system.
2. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

3. If the problem persists, contact technical support.

- **FQXPMEM0007M: Diagnostic image cannot be launched as "Console Redirection" is enabled.**

Severity: Error

User Action:

1. Disable "Configure Console Redirection" in UEFI Setup by following below steps: - Go to F1 Setup -> System Settings -> Devices and I/O Ports-> Console Redirection Settings -> - Select "Console Redirection" - Change the setting to "Disable" and save - Next reboot the system.
2. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

3. If the problem persists, contact technical support.

- **FQXPMEM0008M: Diagnostic image cannot be launched as the image may be corrupt.**

Severity: Error

User Action:

1. Restart BMC via supported method and reboot the system.
2. Perform AC reset or virtual reseal.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

3. Reflash the LXPM.
4. If the problem persists, contact technical support.

- **FQXPMER0002I: Clearing RAID configuration and internal storage data**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMER0002M: Failed to clear RAID configuration.**

Severity: Error

User Action:

1. Restart the system and retry the operation again.
2. If the problem persists, contact technical support.

- **FQXPMER0003I: RAID configuration cleared successfully**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMER0003M: Failed to erase internal storage drives.**

Severity: Error

User Action:

1. Ensure the proper connection of hard drives, backplane, and related cables.
2. Check if security function is enabled for the hard disk drives, if yes, disable that and retry the operation.
3. Ensure that device firmware is at the latest level.
4. Restart the system and retry the operation again.
5. If the problem persists, contact technical support.

- **FQXPMER0004I: Internal storage drives erased successfully**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMER0004M: Failed to clear system logs.**

Severity: Error

User Action:

1. Restart BMC via supported method and reboot the system.
2. Retry this operation again.
3. If the problem persists, contact technical support.

- **FQXPMER0005I: All system logs cleared successfully**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMER0005M: Failed to load UEFI factory default settings.**

Severity: Error

User Action:

1. Restart BMC via supported method and reboot the system.
2. Retry this operation again.
3. If the problem persists, contact technical support.

- **FQXPMER0006I: UEFI factory default settings loaded successfully**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMER0006M: Failed to load XCC factory default settings.**

Severity: Error

User Action:

1. Restart BMC via supported method and reboot the system.
2. Retry this operation again.
3. If the problem persists, perform AC power cycle. (wait for several seconds between AC power is off and on)
4. Retry this operation again.
5. If the problem persists, contact technical support.

- **FQXPMER0007I: BMC factory default settings loaded successfully**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMMN0001G: Failed to set new BMC network parameters.**

Severity: Warning

User Action:

1. Ensure input parameters are valid.
2. Wait for one minute and retry the setting.
3. Restart BMC via supported method and reboot the system.
4. Retry the setting change.
5. Use UEFI setup to change parameters (optional).

- **FQXPMNM0002I: Set BMC network parameters to new values.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMOS0001K: Bootx64.efi is not found. Failed to Boot OS.**

Severity: Warning

User Action:

1. Restart BMC via supported method and reboot the system.
2. Reflash BMC firmware.
3. Reboot system and retry OS booting.
4. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

5. If the problem persists, contact technical support.

- **FQXPMOS0004K: BMC Communication Failed: EMMC2USB Mount Failure.**

Severity: Warning

User Action:

1. Ensure proper operation of the virtual USB connection.
2. Restart BMC via supported method and reboot the system.
3. Reflash BMC firmware.
4. Retry OS deployment.
5. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

6. If the problem persists, contact technical support.

- **FQXPMOS0005K: BMC communication failed: DRIVER Mount Failure.**

Severity: Warning

User Action:

1. Ensure proper operation of the virtual USB connection.
2. Restart BMC via supported method and reboot the system.
3. Reflash BMC firmware.
4. Retry OS deployment.
5. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

6. If the problem persists, contact technical support.

- **FQXPMOS0006K: BMC communication succeeded. Volume Name Mismatched.**

Severity: Warning

User Action:

1. Restart BMC via supported method and reboot the system.
2. If the problem persists, reflash BMC firmware.
3. Retry OS deployment.
4. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

5. If the problem persists, contact technical support.

- **FQXPMOS0007K: Failed to read License RTF file.**

Severity: Warning

User Action:

1. Restart BMC via supported method and reboot the system.
2. If the problem persists, reflash BMC firmware.
3. Use another OS media (USB DVD or USB key).
4. Retry OS deployment.
5. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

6. If the problem persists, contact technical support.

- **FQXPMOS0008K: Failed to detect any remote OS media for OS installation.**

Severity: Warning

User Action:

1. Ensure that proper operation of SMB/CIFS and NFS communications (make sure the Ethernet cable has been plugged and network settings are correct.).
2. Make sure that the OS version and folder path are correct.
3. Retry CIFS and NFS installation.
4. If the problem persists, contact technical support.

- **FQXPMOS0028I: Start to install OS: [arg1].**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMSD0001M: HDD Test was interrupted by the host with a hardware or software reset.**

Severity: Error

User Action:

1. Remove A/C from the server and reseal all drives, backplanes, RAID adapters, expanders (if any), and cables.
2. Ensure that device firmware is at the latest level.
3. Retry the test.
4. If the problem persists, contact technical support.

- **FQXPMSD0002M: A fatal error or unknown test error occurred while the device was executing its self-test.**

Severity: Error

User Action:

1. Remove A/C from the server and reseal all drives, backplanes, RAID adapters, expanders (if any), and cables.
2. Ensure that device firmware is at the latest level.
3. Retry the test.
4. If the problem persists, contact technical support.

- **FQXPMSD0003M: Self-test completed having a test element that failed and the test element that failed is not known.**

Severity: Error

User Action:

1. Remove A/C from the server and reseal all drives, backplanes, RAID adapters, expanders (if any), and cables.
2. Ensure that device firmware is at the latest level.
3. Retry the test.
4. If the problem persists, contact technical support.

- **FQXPMSD0004M: Self-test completed having the electrical element of the test failed.**

Severity: Error

User Action:

1. Remove A/C from the server and reseal all drives, backplanes, RAID adapters, expanders (if any), and cables.
2. Ensure that device firmware is at the latest level.
3. Retry the test.
4. If the problem persists, contact technical support.

- **FQXPMSD0005M: Self-test completed having the servo (and/or seek) test element of the test failed.**

Severity: Error

User Action:

1. Remove A/C from the server and reseal all drives, backplanes, RAID adapters, expanders (if any), and cables.
2. Ensure that device firmware is at the latest level.
3. Retry the test.

4. If the problem persists, contact technical support.

- **FQXPMSD0006M: Self-test completed having the read element of the test failed.**

Severity: Error

User Action:

1. Remove A/C from the server and reseal all drives, backplanes, RAID adapters, expanders (if any), and cables.
2. Ensure that device firmware is at the latest level.
3. Retry the test.
4. If the problem persists, contact technical support.

- **FQXPMSD0007M: Hard Drive(s) not found**

Severity: Error

User Action:

1. Remove A/C from the server and reseal all drives, backplanes, RAID adapters, expanders (if any), and cables.
2. Ensure that device firmware is at the latest level.
3. Verify that the same Error is present in BMC or OneCLI inventory log.
4. Retry the test.
5. If the problem persists, contact technical support.

- **FQXPMSD0008M: UEFI is not ready for LXPM to send command to test hard drive.**

Severity: Error

User Action:

1. Reboot the system and run the test again.
2. If this message is still reported, run the latest version of SMART tool on OS which is open-source tool and could be downloaded from website to check hard drive status.
3. If the problem persists, contact technical support.

- **FQXPMSD0009M: Device error detected when LXPM sent a test command to a hard drive.**

Severity: Error

User Action:

1. Do one of the following:
 - If the affected drive(s) are detected by the system, update the disk drive firmware and reboot the server.
 - If the affected drive(s) are not detected by the system or failing to respond:
 - a. Power off the server and remove A/C power.
 - b. Reseat the associated RAID controller, SAS cables, backplane and drive(s).
 - c. Restore system power and reboot the server.
2. Re-run the disk drive test from LXPM. For details, see the LXPM documentation at: <https://pubs.lenovo.com/lxpm-overview/>. Click on the LXPM version for your server model, and choose Using LXPM -> Diagnostics -> Running diagnostics from the left navigation tree.
3. If the problem persists, save the test result to a test_hdd.txt file using a local USB storage device or a shared network folder.

4. Contact technical support for a drive replacement.

- **FQXPMSD0010M: UEFI timed out when LXPM sent a test command to a hard drive.**

Severity: Error

User Action:

1. Do one of the following:
 - If the affected drive(s) are detected by the system, update the disk drive firmware and reboot the server.
 - If the affected drive(s) are not detected by the system or failing to respond:
 - a. Power off the server and remove A/C power.
 - b. Reseat the associated RAID controller, SAS cables, backplane and drive(s).
 - c. Restore system power and reboot the server.
2. Run the disk drive test from LXPM. For details, see the LXPM documentation at: <https://pubs.lenovo.com/lxpm-overview/>. Click on the LXPM version for your server model, and choose Using LXPM -> Diagnostics -> Running diagnostics from the left navigation tree.
3. If the problem persists, save the test result to a test_hdd.txt file using a local USB storage device or a shared network folder.
4. Contact technical support for a drive replacement.

- **FQXPMSD0011M: The hard drive is not supported by UEFI while LXPM sent a command to test the hard drive.**

Severity: Error

User Action:

1. Check hard drive specification to see if the hard drive support ATA self-test feature.
2. If the problem persists, contact technical support.

- **FQXPMSR0001K: Found unsupported RAID adapter.**

Severity: Warning

User Action:

1. Check the following Lenovo Support site for information on supported RAID adapters. <https://serverproven.lenovo.com>
2. Ensure that RAID adapter, LXPM, and UEFI firmware are at the latest levels.
3. If the problem persists, contact technical support.

- **FQXPMSR0011K: Failed to change disk drives' state.**

Severity: Warning

User Action:

1. Ensure that LXPM and RAID adapter firmware are at the latest levels.
2. Ensure that the state of the RAID adapter and disk drives are both healthy.
3. Verify proper physical connection of the disk drive, SAS expander (if applicable) and RAID adapter.
4. Ensure that the operation to the special drive is legal or logical. (For example, you cannot change Unconfigured BAD to Online status)
5. Reboot the machine and retry to change disk drives' state.

6. If the problem persists, contact technical support.

- **FQXPMSR0012I: Change disk drives' state successfully.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMSR0021L: Failed to create new virtual disk(s).**

Severity: Error

User Action:

1. Ensure that LXPm and RAID adapter firmware are at the latest levels.
2. Ensure that the state of RAID adapter and disk drives are both healthy.
3. Verify proper physical connection of the disk drive, SAS expander (if applicable) and RAID adapter.
4. Ensure that the drive status is correct (Unconfigured Good).
5. Reboot the machine and retry to create new virtual disk.
6. If the problem persists, contact technical support.

- **FQXPMSR0022I: Create new virtual disk(s) successfully.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMSR0031L: Failed to remove existing virtual disk(s).**

Severity: Error

User Action:

1. Ensure that LXPm and RAID adapter firmware are at the latest levels.
2. Ensure that the state of RAID adapter and disk drives are both healthy.
3. Verify proper physical connection of the disk drive, SAS expander (if applicable) and RAID adapter.
4. Reboot the machine and retry to remove the existing virtual disk.
5. If the problem persists, contact technical support.

- **FQXPMSR0032I: Removed existing virtual disk(s) successfully.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMS0001K: Failed to mount work partition while getting service data.**

Severity: Warning

User Action:

1. Retry this operation again.
2. Try to get service data from the XCC web interface.
3. If the problem persists, try a different Lenovo tool to perform the operation (e.g., XClarity Administrator or XClarity Essential OneCLI).

4. If the problem persists, contact technical support.

- **FQXPMSS0002K: Failed to mount work partition while getting debug log.**

Severity: Warning

User Action:

1. Retry this operation again.
2. Try to get debug logs from the XCC web interface.
3. If the problem persists, try a different Lenovo tool to perform the operation (e.g., XClarity Administrator or XClarity Essential OneCLI).
4. If the problem persists, contact technical support.

- **FQXPMSS0003K: No service data file created in the work partition**

Severity: Warning

User Action:

1. Retry this operation again.
2. Try to get service data from the XCC web interface.
3. If the problem persists, try a different Lenovo tool to perform the operation (e.g., XClarity Administrator or XClarity Essential OneCLI).
4. If the problem persists, contact technical support.

- **FQXPMSS0004K: No debug log file created in the work partition**

Severity: Warning

User Action:

1. Retry this operation again.
2. Try to get debug logs from the XCC web interface.
3. If the problem persists, try a different Lenovo tool to perform the operation (e.g., XClarity Administrator or XClarity Essential OneCLI).
4. If the problem persists, contact technical support.

- **FQXPMUP0003K: Unable to obtain the minimum level of UEFI.**

Severity: Warning

User Action:

1. Restart BMC via supported method and reboot the system.
2. Reflash BMC firmware.
3. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

4. If the problem persists, contact technical support.

- **FQXPMUP0004K: Unable to obtain the installed version of UEFI.**

Severity: Warning

User Action:

1. Restart BMC via supported method and reboot the system.

2. Reflash BMC firmware.
3. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

4. If the problem persists, contact technical support.

- **FQXPMUP0005K: Unable to obtain the installed version of BMC.**

Severity: Warning

User Action:

1. Restart BMC via supported method and reboot the system.
2. Reflash BMC firmware.
3. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

4. If the problem persists, contact technical support.

- **FQXPMUP0006K: Unable to obtain the installed version of LXPM.**

Severity: Warning

User Action:

1. Restart BMC via supported method and reboot the system.
2. Reflash BMC firmware.
3. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

4. If the problem persists, contact technical support.

- **FQXPMUP0007K: Unable to obtain the installed version of Linux driver.**

Severity: Warning

User Action:

1. Restart BMC via supported method and reboot the system.
2. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

3. If the problem persists, contact technical support.

- **FQXPMUP0008K: Unable to obtain the installed version of Windows driver.**

Severity: Warning

User Action:

1. Restart BMC via supported method and reboot the system.
2. Reflash BMC firmware.
3. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

4. If the problem persists, contact technical support.

- **FQXPMUP0101I: Start to update LXPM.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMUP0102I: Start to update Window driver.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMUP0103I: Start to update Linux driver.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMUP0104I: Start to update UEFI.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMUP0105I: Start to update BMC.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMUP0106I: Successfully updated the firmware.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMUP0201M: BMC communication failed: EMMC2USB mount failure. Failed to update the firmware.**

Severity: Error

User Action:

1. Restart BMC via supported method and BMC setting via UEFI setup or "Restart Management Controller" in BMC web UI. Then, reboot the system.
2. If the problem persists, reflash the BMC firmware.
3. If the problem persists, perform AC reset or virtual reseal.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

4. If the problem persists, try a different Lenovo tool to perform the update (e.g., XClarity Administrator, XClarity Controller, or XClarity Essential OneCLI).
5. If the problem persists, contact technical support.

- **FQXPMUP0202M: Transfer the update package error. Failed to update the firmware.**

Severity: Error

User Action:

1. Ensure that the update package is not corrupt undamaged and then retry the update.
2. Ensure that proper connection to USB/network drive and retry the update.
3. Restart BMC via supported methods and BMC setting via UEFI setup or "Restart Management Controller" in BMC web UI. Then, reboot the system.
4. If the problem persists, reflash the BMC firmware.
5. If the problem persists, perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

6. If the problem persists, try a different Lenovo tool to perform the update (e.g., XClarity Administrator, XClarity Controller, or XClarity Essential OneCLI).
7. If the problem persists, contact technical support.

- **FQXPMUP0203M: BMC communication failed: EMMC2USB unmount failure. Failed to update the firmware.**

Severity: Error

User Action:

1. Restart BMC via supported method and reboot the system.
2. Reflash the BMC firmware.
3. If the problem persists, perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

4. If the problem persists, try a different Lenovo tool to perform the update (e.g., XClarity Administrator, XClarity Controller, or XClarity Essential OneCLI).
5. If the problem persists, contact technical support.

- **FQXPMUP0204M: BMC communication failed: Execute the update command failure. Failed to update the firmware.**

Severity: Error

User Action:

1. Restart BMC via supported method.
2. Reflash BMC firmware.
3. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

4. If the problem persists, try a different Lenovo tool to perform the update (e.g., XClarity Administrator, XClarity Controller, or XClarity Essential OneCLI).
5. If the problem persists, contact technical support.

- **FQXPMUP0205M: BMC communication failed: Get the update status failure. Failed to update the firmware.**

Severity: Error

User Action:

1. Restart BMC via supported method and reboot the system.
2. Reflash BMC firmware.
3. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

4. If the problem persists, try a different Lenovo tool to perform the update (e.g., XClarity Administrator, XClarity Controller, or XClarity Essential OneCLI).
5. If the problem persists, contact technical support.

- **FQXPMUP0206M: The level of the update package is too old. Failed to update the firmware.**

Severity: Error

User Action:

1. Follow prompts to select a newer version of the update package and retry the update.
2. Restart BMC via supported method and reboot the system.
3. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

4. If the problem persists, try a different Lenovo tool to perform the update (e.g., XClarity Administrator, XClarity Controller, or XClarity Essential OneCLI).
5. If the problem persists, contact technical support.

- **FQXPMUP0207M: The update package is invalid. Failed to update the firmware.**

Severity: Error

User Action:

1. Ensure that the update package is not corrupt and retry the update.
2. Ensure proper connection to USB/network drive and retry the update.
3. Restart BMC via supported method and BMC setting via UEFI setup or "Restart Management Controller" in BMC web UI. Then, reboot the system.
4. Reflash the BMC firmware.
5. Perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

6. If the problem persists, try a different Lenovo tool to perform the update (e.g., XClarity Administrator, XClarity Controller, or XClarity Essential OneCLI).
7. If the problem persists, contact technical support.

- **FQXPMUP0208M: Failed to execute the reboot BMC command.**

Severity: Error

User Action:

1. Restart BMC via supported method and reboot the system.
2. Reflash BMC firmware.
3. If the problem persists, perform AC reset or virtual reset.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

4. If the problem persists, contact technical support.

- **FQXPMVD0001H: Failed to get VPD data.**

Severity: Warning

User Action:

1. Press "Global Settings" button and press "Update VPD" button again.
2. Perform AC reset or virtual reset if step 1 failed.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

3. If the problem persists, contact technical support.

- **FQXPMVD0002H: Failed to update the VPD data.**

Severity: Warning

User Action:

1. Press "Update" button on VPD update page.
2. Perform AC reset or virtual reset if step 1 failed.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

3. If the problem persists, contact technical support.

- **FQXPMVD0003I: Update VPD data successfully.**

Severity: Info

User Action:

Information only; no action is required.

- **FQXPMVD0011K: Failed to get the TPM/TPM card/TCM policy status.**

Severity: Warning

User Action:

1. Press "Global Settings" button and press "Update VPD" button again.
2. Perform AC reset or virtual reset if step 1 failed.

Note: When performing AC reset, after powering off AC, wait for several seconds before powering on AC. After AC power is restored, power on the host system.

3. If the problem persists, contact technical support.

- **FQXPMVD0012K: Failed to set the TPM/TPM card/TCM policy.**

Severity: Warning

User Action:

1. Press "Apply" button on VPD update page.
2. Reboot the system if step 1 failed.
3. If the problem persists, contact technical support.

Appendix A. Getting help and technical assistance

If you need help, service, or technical assistance or just want more information about Lenovo products, you will find a wide variety of sources available from Lenovo to assist you.

On the World Wide Web, up-to-date information about Lenovo systems, optional devices, services, and support are available at:

<http://datacentersupport.lenovo.com>

Note: IBM is Lenovo's preferred service provider for ThinkSystem.

Before you call

Before you call, there are several steps that you can take to try and solve the problem yourself. If you decide that you do need to call for assistance, gather the information that will be needed by the service technician to more quickly resolve your problem.

Attempt to resolve the problem yourself

You can solve many problems without outside assistance by following the troubleshooting procedures that Lenovo provides in the online help or in the Lenovo product documentation. The online help also describes the diagnostic tests that you can perform. The documentation for most systems, operating systems, and programs contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the operating system or program.

You can find the product documentation for your ThinkSystem products at the following location:

<https://pubs.lenovo.com/>

You can take these steps to try to solve the problem yourself:

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Check for updated software, firmware, and operating-system device drivers for your Lenovo product. (See the following links) The Lenovo Warranty terms and conditions state that you, the owner of the Lenovo product, are responsible for maintaining and updating all software and firmware for the product (unless it is covered by an additional maintenance contract). Your service technician will request that you upgrade your software and firmware if the problem has a documented solution within a software upgrade.
 - Drivers and software downloads
 - <https://datacentersupport.lenovo.com/tw/en/products/servers/thinksystem/sr780av3/7dj5/downloads/driver-list/>
 - Operating system support center
 - <https://datacentersupport.lenovo.com/solutions/server-os>
 - Operating system installing instructions
 - <https://pubs.lenovo.com/thinksystem#os-installation>
- If you have installed new hardware or software in your environment, check <https://serverproven.lenovo.com> to make sure that the hardware and software are supported by your product.
- Refer to “Problem Determination” in *User Guide* or *Hardware Maintenance Guide* for instructions on isolating and solving issues.

- Go to <http://datacentersupport.lenovo.com> and check for information to help you solve the problem.

To find the Tech Tips available for your server:

1. Go to <http://datacentersupport.lenovo.com> and navigate to the support page for your server.
2. Click on **How To's** from the navigation pane.
3. Click **Article Type** → **Solution** from the drop-down menu.

Follow the on-screen instructions to choose the category for the problem that you are having.

- Check Lenovo Data Center Forum at https://forums.lenovo.com/t5/Datacenter-Systems/ct-p/sv_eg to see if someone else has encountered a similar problem.

Gathering information needed to call Support

If you require warranty service for your Lenovo product, the service technicians will be able to assist you more efficiently if you prepare the appropriate information before you call. You can also go to <http://datacentersupport.lenovo.com/warrantylookup> for more information about your product warranty.

Gather the following information to provide to the service technician. This data will help the service technician quickly provide a solution to your problem and ensure that you receive the level of service for which you might have contracted.

- Hardware and Software Maintenance agreement contract numbers, if applicable
- Machine type number (Lenovo 4-digit machine identifier). Machine type number can be found on the ID label, see “Identifying the server and access the Lenovo XClarity Controller” in *User Guide* or *System Configuration Guide*.
- Model number
- Serial number
- Current system UEFI and firmware levels
- Other pertinent information such as error messages and logs

As an alternative to calling Lenovo Support, you can go to <https://support.lenovo.com/servicerequest> to submit an Electronic Service Request. Submitting an Electronic Service Request will start the process of determining a solution to your problem by making the pertinent information available to the service technicians. The Lenovo service technicians can start working on your solution as soon as you have completed and submitted an Electronic Service Request.

Collecting service data

To clearly identify the root cause of a server issue or at the request of Lenovo Support, you might need collect service data that can be used for further analysis. Service data includes information such as event logs and hardware inventory.

Service data can be collected through the following tools:

- **Lenovo XClarity Provisioning Manager**

Use the Collect Service Data function of Lenovo XClarity Provisioning Manager to collect system service data. You can collect existing system log data or run a new diagnostic to collect new data.

- **Lenovo XClarity Controller**

You can use the Lenovo XClarity Controller web interface or the CLI to collect service data for the server. The file can be saved and sent to Lenovo Support.

- For more information about using the web interface to collect service data, see the “Backing up the BMC configuration” section in the XCC documentation compatible with your server at <https://pubs.lenovo.com/lxcc-overview/>.
- For more information about using the CLI to collect service data, see the “XCC `ffdc` command” section in the XCC documentation compatible with your server at <https://pubs.lenovo.com/lxcc-overview/>.

- **Lenovo XClarity Administrator**

Lenovo XClarity Administrator can be set up to collect and send diagnostic files automatically to Lenovo Support when certain serviceable events occur in Lenovo XClarity Administrator and the managed endpoints. You can choose to send diagnostic files to Lenovo Support using Call Home or to another service provider using SFTP. You can also manually collect diagnostic files, open a problem record, and send diagnostic files to the Lenovo Support.

You can find more information about setting up automatic problem notification within the Lenovo XClarity Administrator at https://pubs.lenovo.com/lxca/admin_setupcallhome.

- **Lenovo XClarity Essentials OneCLI**

Lenovo XClarity Essentials OneCLI has inventory application to collect service data. It can run both in-band and out-of-band. When running in-band within the host operating system on the server, OneCLI can collect information about the operating system, such as the operating system event log, in addition to the hardware service data.

To obtain service data, you can run the `getinfor` command. For more information about running the `getinfor`, see https://pubs.lenovo.com/lxce-onecli/onecli_r_getinfor_command.

Contacting Support

You can contact Support to obtain help for your issue.

You can receive hardware service through a Lenovo Authorized Service Provider. To locate a service provider authorized by Lenovo to provide warranty service, go to <https://datacentersupport.lenovo.com/serviceprovider> and use filter searching for different countries. For Lenovo support telephone numbers, see <https://datacentersupport.lenovo.com/supportphonenumber> for your region support details.

Lenovo