

ThinkSystem SR860 V2 Type 7Z59 and 7Z60 Quick Start


The shipping box contains the following items:

- SR860 V2
- Material box

If any item is missing or damaged, contact local service. Make sure to keep the proof of purchase and packing materials. They might be required for warranty service.

First glance


Server front view:



Î	13	

1 VGA connector (optional)	7 USB 2 (USB 3.1)
2 2.5-inch drive bays	8 Power button/LED (green)
3 Drive activity LED (green)	Network activity LED (green)
4 Drive status LED (yellow)	10 Identification button/LED (blue)
5 Pull-out information tab	11 System error LED (yellow)
USB 1 (USB 2.0 with Lenovo XClarity Controller management)	12 Rack release latches

Server rear view:



1 PCIe slot 1-4 (riser cage)	11 PCIe slot 13 (x16)
2 7mm drive bay 0	12 Serial connector
3 7mm drive bay 1	13 VGA connector
4 PCIe slot 9-12 (riser cage)	14 USB 3 and 4 (USB 3.1)
5 AC power LED (green)	15 XClarity Controller network connector
6 DC power LED (green)	16 NMI button
7 Power error LED (yellow)	PCIe slot 8 (OCP 3.0 Ethernet adapter)
8 Power supply units	18 PCIe slot 7 (PCIe riser)
9 PCIe slot 15 (x8)	19 PCIe slot 6 (PCIe riser)
10 PCIe slot 14 (x8)	20 PCIe slot 5 (PCIe riser)

Setting up the System

1. Install the required components.

- 2. Install the server into the rack.
- See *Rack Installation Guide*, which comes with the rail kit. 3. Connect the cables.
- 4. Connect the management controller to the network.
- 5. Power on the server.
- 6. Configure the system.

For detailed information about installing hardware options and configuring the system, see the following website: http://thinksystem.lenovofiles.com/help/topic/SR860V2/introduction.ht



Technical specifications

Dimensions and weight

- Height: 175 mm (6.9 inches)
- Width:
 - With rack handles: 482.0 mm (19.0 inches)
- Without rack handles: 434.4 mm (17.1 inches)
- Depth: 835.9 mm (32.9 inches)
- Weight (depending upon configuration):
 - Maximum: 62.0 kg (136.7 lb)

Note: The depth is measured with rack handles installed.

Processor

This server supports Intel Xeon Processor Scalable Family, up to four processors from

- Intel Xeon Platinum processor
- Intel Xeon Gold processor

Memory

- Minimum: 32 GB
- Maximum:
 - RDIMM: 3 TB
 - 3DS-RDIMM: 6 TB
- DIMM types:
 - TruDDR4 ECC 3200 MT/s RDIMM and 3DS-RDIMM
 - Persistent Memory Module (PMEM)
- Slots: 24/48 DIMM slots, two-way interleaved

Storage bays (depending on the model):

Six storage drive backplanes support up to forty-eight 2.5inch drives:

- Bay 0-23: SATA/SAS/NVMe drives
- Bay 24-48: SATA/SAS drives

Networking:

- One Ethernet connector as dedicated management
 port
- Two or four Ethernet connectors on OCP 3.0
 Ethernet adapter

Where to go for support

Link		QR Code
LEROVO Press	Lenovo Press (Product guides and white papers) https://lenovopress.com/	
9	Lenovo Datacenter Systems Forums https://forums.lenovo.com/t5/ Datacenter-Systems/ct- p/sv_eg	
	Lenovo Support - SR860 V2 (including drivers and software) <u>http://datacentersupport.leno vo.com/products/servers/thin</u> <u>ksystem/SR860v2</u>	
Ð	Lenovo Product Security Advisories <u>http://support.lenovo.com/us/</u> <u>en/product_security/home</u>	
8	Lenovo Server Proven (Compatibility information) <u>https://static.lenovo.com/us/e</u> n/serverproven/index.shtml	

Second Edition (August 2021)

© Copyright Lenovo 2020, 2021.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration (GSA) contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.